


AUTOMATIC TRANSMISSION SYSTEM

OPERATION

AT04A-02




Shift Lever Position	Gear Position	S1	S2	S3	S4	C ₀	C ₁	C ₂	B ₀	B ₁	B ₂	B ₃	B ₄	F ₀	F ₁	F ₂
P	Park	ON	OFF	ON	OFF	○										
R	Reverse	ON	OFF	OFF	OFF			○	○				○			
N	Neutral	ON	OFF	ON	OFF	○										
D M (5)*	1st	ON	OFF	OFF	OFF	○	○							○		○
	2nd	ON	ON	OFF	OFF	○	○					○		○		
	3rd	OFF	ON	OFF	OFF	○	○				○			○	○	
	4th	OFF	OFF	ON	OFF	○	○	○			○			○		
	5th	OFF	OFF	OFF	ON		○	○	○		○					
3	1st	ON	OFF	OFF	OFF	○	○							○		○
	2nd	ON	ON	OFF	OFF	○	○					○		○		
	3rd	OFF	ON	ON	OFF	○	○			○	○			○	○	
2	1st	ON	OFF	ON	OFF	○	○							○		○
	2nd	ON	ON	OFF	OFF	○	○					○		○		
L	1st	ON	OFF	OFF	OFF	○	○						○	○		○

○ : Operating

* : When the shift lever position is "M" and the gear position indicator shows "5".

FUNCTION OF COMPONENTS



D01427

Component		Function
C ₀	O/D Direct Clutch	Connects O/D sun gear & O/D planetary carrier.
C ₁	Forward Clutch	Connects input shaft and rear planetary sun gear.
C ₂	Direct Clutch	Connects input shaft and front & center planetary sun gear.
B ₀	O/D Brake	Prevents O/D sun gear from turning either clockwise or counterclockwise.
B ₁	3rd Coast Brake	Prevents front & center planetary sun gear from turning either clockwise or counterclockwise.
B ₂	3rd Brake	Prevents outer race of F ₁ from turning either clockwise or counterclockwise thus preventing the front & center planetary sun gear from turning counterclockwise.
B ₃	2nd Brake	Prevents front planetary carrier from turning either clockwise or counterclockwise.
B ₄	1st & Reverse Brake	Prevents rear planetary ring gear from turning either clockwise or counterclockwise.
F ₀	O/D One-way Clutch	When the transmission is being driven by the engine, this clutch connects the O/D sun gear and O/D planetary carrier.
F ₁	No.1 One-way Clutch	When B ₂ is operating, this clutch prevents the front & center planetary sun gear from turning counterclockwise.
F ₂	No.2 One-way Clutch	Prevents rear planetary ring gear from turning clockwise.