

I GROUND POINT (LHD)

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J2	A	J7	99 (LHD)	J16	100 (LHD)
J3	B	J9	99 (LHD)	J17	100 (LHD)
J4	97 (LHD)	J12	100 (LHD)		
J5	99 (LHD)	J13	100 (LHD)		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
2	80 (LHD)	Engine Room No.2 R/B (Engine Compartment Right)
3	94 (LHD)	Engine Room No.3 R/B (Engine Compartment Right)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1B	82 (LHD)	Front Door LH Wire and Driver Side J/B (Left Kick Panel)
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1F		
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1I	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1J	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1L		
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2E	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2F		
2G		
2H		
2J		
2K	84 (LHD)	Front Door RH Wire and Passenger Side J/B (Right Kick Panel)
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	112 (LHD)	Engine Wire and Engine Room Main Wire (Inside of the ECU Box)
IA3	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
IE1	116 (LHD)	Floor No.3 Wire and Floor No.2 Wire (Near the Steering Column)
IF1	116 (LHD)	Instrument Panel Wire and A/C Sub Wire (Left Side of the Blower Unit)
IH1	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
BA1	118 (LHD)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
BB1	118 (LHD)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BD1	118 (LHD)	Floor No.2 Wire and Luggage Room Wire (Right Side of the Luggage Door)
BD2		
BE1	120 (LHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)

**: GROUND POINTS**

Code	See Page	Ground Points Location
EA	112 (LHD)	Front Side of Cylinder Head
EB	112 (LHD)	Rear Side of Cylinder Head
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IE	114 (LHD)	Instrument Panel Center
IF	114 (LHD)	Instrument Panel Reinforcement RH
IG	114 (LHD)	Cowl Side Panel RH
IH	114 (LHD)	Front Floor Panel Center LH
II	114 (LHD)	Front Floor Panel Center RH
BJ	118 (LHD)	Front Floor Panel LH
BK	118 (LHD)	Left Quarter Panel LH
BL	118 (LHD)	Front Floor Panel RH
BM	118 (LHD)	Roof Panel

**: SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	112 (LHD)	Engine Wire	I3	116 (LHD)	Engine Room Main Wire
E10	112 (LHD)	Engine Room Main Wire	B1	118 (LHD)	Roof Wire
E11			B3	120 (LHD)	Front Seat LH Wire