

FOREWORD

This wiring diagram manual has been prepared to provide information on the electrical system of the IS 200.

Applicable models: GXE10 Series

For service specifications and repair procedures of the above models other than those listed in this manual, refer to the following manuals;

Manual Name	Pub. No.
• LEXUS IS 200 Repair Manual Volume 1 Volume 2	RM684E1 RM684E2
• LEXUS IS 200 New Car Features	NCF165E

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION

NOTICE

When handling supplemental restraint system components (removal, installation or inspection, etc.), always follow the direction given in the repair manuals listed above to prevent accidents and supplemental restraint system malfunction.

English

Français

Español

Deutsch