

SERVICE HINTS

N1 (A) BACK-UP LIGHT SW [NEUTRAL START SW] (A/T)

3-2 : Closed with the shift lever at R position

B1 (B) BACK-UP LIGHT SW (M/T)

2-1 : Closed with the shift lever at R position

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
B1	B	96 (LHD)	J3	B	105 (RHD)
		104 (RHD)	J17		100 (LHD)
J2	A	97 (LHD)			108 (RHD)
		105 (RHD)	N1	A	97 (LHD)
J3	B	97 (LHD)			105 (RHD)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1H	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1I	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1K	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2I	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
BK	118 (LHD)	Left Quarter Panel LH
	128 (RHD)	