

SERVICE HINTS

R18 REMOTE CONTROL MIRROR SW

- 6-10 : Continuity with the operation SW at **DOWN** or **RIGHT** position
- 9-6 : Continuity with the operation SW at **UP** or **LEFT** position
- 4-9, 3-10 : Continuity with the retractor SW at **RETRACTION** position
- 3-9, 4-10 : Continuity with the retractor SW at **RETURN** position
- 9-GROUND : Approx. **12** volts with the ignition SW at **ACC** or **ON** position
- 10-GROUND : Always continuity

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J12	108 (RHD)	R17	109 (RHD)		
R16	109 (RHD)	R18	109 (RHD)		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1K	88 (RHD)	Front Door RH Wire and Driver Side J/B (Right Kick Panel)
1L	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	124 (RHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
II1	126 (RHD)	Front Door RH Wire and Instrument Panel Wire (Left Kick Panel)

: GROUND POINTS

Code	See Page	Ground Points Location
BL	128 (RHD)	Front Floor Panel RH