

# LIGHT REMINDER (RHD)

## SYSTEM OUTLINE

This system is provided to remind the driver to turn off the taillights and headlights.

## LIGHT REMINDER OPERATION

In case the driver's side door is opened while the light control SW is at TAIL or HEAD with the ignition SW turned to off from on, through the communication control of the body ECU etc., the light reminder buzzer in the combination meter comes on.

## SERVICE HINTS

### C14 (A), (B) COMBINATION SW

(A)14, (B)16-GROUND : Continuity with light control SW at **TAIL** or **HEAD** position

### D8 DOOR COURTESY SW FRONT RH

1-GROUND : Closed with door open

### B7 (B) BODY ECU

6-GROUND : Continuity with driver door open

## ○ : PARTS LOCATION

| Code | See Page    | Code | See Page    | Code | See Page    |
|------|-------------|------|-------------|------|-------------|
| A14  | A 106 (RHD) | C14  | B 106 (RHD) | J5   | 107 (RHD)   |
| A15  | B 106 (RHD) | D2   | 106 (RHD)   | J8   | 107 (RHD)   |
| B6   | A 106 (RHD) | D4   | 106 (RHD)   | J9   | 107 (RHD)   |
| B7   | B 106 (RHD) | D8   | 108 (RHD)   | J10  | 107 (RHD)   |
| C10  | 106 (RHD)   | E2   | A 104 (RHD) | T4   | A 107 (RHD) |
| C14  | A 106 (RHD) | E3   | B 104 (RHD) | T5   | B 107 (RHD) |

## ○ : RELAY BLOCKS

| Code | See Page | Relay Blocks (Relay Block Location)            |
|------|----------|--|
| 1    | 81 (RHD) | Engine Room No.1 R/B (Engine Compartment Left) |

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

| Code | See Page | Junction Block and Wire Harness (Connector Location)           |
|------|----------|--|
| 1A   | 88 (RHD) | Engine Room Main Wire and Driver Side J/B (Right Kick Panel)   |
| 1B   |          |  |
| 1C   |          |  |
| 1E   | 88 (RHD) | Instrument Panel Wire and Driver Side J/B (Right Kick Panel)   |
| 1F   |          |  |
| 1H   |          |  |
| 1I   |          |  |
| 2E   | 90 (RHD) | Instrument Panel Wire and Passenger Side J/B (Left Kick Panel) |
| 2F   |          |  |
| 2G   | 90 (RHD) | Engine Room Main Wire and Passenger Side J/B (Left Kick Panel) |
| 2H   | 90 (RHD) | Instrument Panel Wire and Passenger Side J/B (Left Kick Panel) |
| 2I   | 90 (RHD) | Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)       |
| 2L   | 90 (RHD) | Instrument Panel Wire and Passenger Side J/B (Left Kick Panel) |

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

| Code | See Page  | Joining Wire Harness and Wire Harness (Connector Location)                    |
|------|-----------|---|
| IA3  | 124 (RHD) | Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B) |

**: GROUND POINTS**

| Code | See Page  | Ground Points Location      |
|------|-----------|-----------------------------|
| EC   | 122 (RHD) | Left Fender Apron           |
| ID   | 124 (RHD) | Cowl Side Panel LH          |
| IF   | 124 (RHD) | Cowl Side Panel RH          |
| IH   | 124 (RHD) | Front Floor Panel Center RH |
| BJ   | 128 (RHD) | Front Floor Panel LH        |