

# RADIO AND PLAYER (LHD 6 SPEAKER)

## SERVICE HINTS

### R5 (D) RADIO AND PLAYER

(D) 4-GROUND : Always approx. **12** volts

(D) 3-GROUND : Approx. **12** volts with the ignition SW at **ACC** or **ON** position

(D) 7-GROUND : Always continuity

## ○ : PARTS LOCATION

Code	See Page	Code		See Page	Code		See Page
A29	98 (LHD)	N4	B	101 (LHD)	R14		101 (LHD)
F11	100 (LHD)	N5	C	101 (LHD)	R15		101 (LHD)
F12	100 (LHD)	R2	A	99 (LHD)	T8	A	101 (LHD)
F13	100 (LHD)	R3	B	99 (LHD)	T9	B	101 (LHD)
F14	100 (LHD)	R4	C	99 (LHD)			
J6	99 (LHD)	R5	D	99 (LHD)			

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
IB2		
IC1	114 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IG1	116 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IH2	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
IH3		
II1	116 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
II	114 (LHD)	Front Floor Panel Center RH

