

SERVICE HINTS

TAIL RELAY

5-3 : Closed with light control SW at **TAIL** or **HEAD** position

C14 LIGHT CONTROL SW [COMB. SW]

14-16 : Closed with light control SW at **TAIL** or **HEAD** position

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A14	98 (LHD)	J5	99 (LHD)	R7	99 (LHD)
A19	98 (LHD)	J7	99 (LHD)	R8	99 (LHD)
A30	98 (LHD)	J8	99 (LHD)	R9	99 (LHD)
C9	98 (LHD)	J9	99 (LHD)	S6	99 (LHD)
C10	98 (LHD)	J11	99 (LHD)	S7	99 (LHD)
C14	98 (LHD)	J13	100 (LHD)	S9	A 99 (LHD)
D1	98 (LHD)	M1	99 (LHD)	S10	B 99 (LHD)
E10	99 (LHD)	N3	A 101 (LHD)	T6	A 99 (LHD)
G1	99 (LHD)	N6	D 101 (LHD)		B 99 (LHD)
H13	99 (LHD)	R4	C 99 (LHD)		
H14	99 (LHD)	R6	B 99 (LHD)		

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1E		
1F		
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1O		
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2F	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2G		
2L	84 (LHD)	Floor Wire and Passenger Side J/B (Right Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IH1	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
IH2		

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IE	114 (LHD)	Instrument Panel Center
IG	114 (LHD)	Cowl Side Panel RH
II	114 (LHD)	Front Floor Panel Center RH
BL	118 (LHD)	Front Floor Panel RH

○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I4	116 (LHD)	Instrument Panel Wire			