

SERVICE HINTS**S6, S7 SEAT HEATER SW (DRIVER'S SEAT, PASSENGER'S SEAT)**3-GROUND : Approx. 12 volts with ignition SW at **ON** or **ST** position

2-GROUND : Always continuity

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J7	99 (LHD)	S7	99 (LHD)	S12	109 (RHD)
	107 (RHD)		107 (RHD)		110 (RHD)
S6	99 (LHD)	S12	101 (LHD)	S13	101 (LHD)
	107 (RHD)		102 (LHD)		109 (RHD)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1I	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1L	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2F	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2I	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB2	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)
	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
IH3	116 (LHD)	Instrument Panel Wire and Floor Wire (Near the Passenger Side J/B)
	126 (RHD)	Instrument Panel Wire and Floor Wire (Near the Driver Side J/B)
BE1	120 (LHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)
	130 (RHD)	Floor Wire and Front Seat RH Wire (Under the Driver's Seat)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
ID	114 (LHD)	Cowl Side Panel LH
BJ	118 (LHD)	Front Floor Panel LH
	128 (RHD)	
BL	118 (LHD)	Front Floor Panel RH
	128 (RHD)	