

## REAR FOG LIGHT (LHD)

### SERVICE HINTS

#### R7 REAR FOG LIGHT SW

- 1-GROUND : Approx. **12** volts with the light control SW at **HEAD** or **TAIL** position and the rear fog light SW at **ON** position
- 2-GROUND : Approx. **12** volts with the light control SW at **HEAD** or **TAIL** position
- 7-GROUND : Always continuity
- 3, 4, 5-GROUND : Always approx. **12** volts

### ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C14	98 (LHD)	J9	99 (LHD)	J17	100 (LHD)
D1	98 (LHD)	J11	99 (LHD)	R7	99 (LHD)
J5	99 (LHD)	J14	100 (LHD)	R12	101 (LHD)
J8	99 (LHD)	J16	100 (LHD)	R13	101 (LHD)

### ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1E		
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
2B	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2F	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2G		
2M	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	114 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Driver Side J/B)

### ▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
ID	114 (LHD)	Cowl Side Panel LH
IG	114 (LHD)	Cowl Side Panel RH
BJ	118 (LHD)	Front Floor Panel LH
BK	118 (LHD)	Left Quarter Panel LH

