

SERVICE HINTS

C8 CIGARETTE LIGHTER

2-GROUND : Approx. 12 volts with ignition SW at **ACC** or **ON** position

1-GROUND : Always continuity

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C8	98 (LHD)	J5	99 (LHD)		
	106 (RHD)				

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1L	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
IG	114 (LHD)	Cowl Side Panel RH
BL	128 (RHD)	Front Floor Panel RH