

SERVICE HINTS**P15 POWER SEAT CONTROL SW**

1-GROUND : Always approx. 12 volts

4-GROUND : Always continuity

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
P15	102 (LHD)	P17	102 (LHD)	P19	102 (LHD)
	110 (RHD)		110 (RHD)		110 (RHD)
P16	102 (LHD)	P18	102 (LHD)		
	110 (RHD)		110 (RHD)		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1I	82 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1L	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
BE1	120 (LHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)
	130 (RHD)	Floor Wire and Front Seat RH Wire (Under the Driver's Seat)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
BJ	118 (LHD)	Front Floor Panel LH
BL	128 (RHD)	Front Floor Panel RH