

# SEAT BELT WARNING (RHD)

## SYSTEM OUTLINE

### SEAT BELT WARNING SYSTEM

When the ignition SW is turned to the ON position, the signal is input to the body ECU. At this time, to determine whether or not the driver fastens the seat belt, the signal from the buckle SW RH is input to TERMINAL DBKL of the body ECU. If the driver does not fasten the seat belt, the seat belt warning light in the combination meter flashes and the alarm buzzer goes on, in response to the communication control of the body ECU etc.

If the passenger does not fasten the seat belt, the signals from the buckle SW LH and seat belt warning occupant detection sensor are input to TERMINAL P-S/B of the A/C control assembly and through communication control of the body ECU etc. the passenger seat belt warning light in the A/C control assembly is flashed.

## SERVICE HINTS

### B9 BUCKLE SW RH

1-2 : Continuity with driver's seat belt in use

### B10 BUCKLE SW LH AND SEAT BELT WARNING OCCUPANT DETECTION SENSOR

1-2 : Continuity with front passenger's seat belt in use

### U1 UNLOCK WARNING SW

1-2 : Continuity with ignition key in cylinder

## ○ : PARTS LOCATION

Code		See Page	Code		See Page	Code	See Page
A14	A	106 (RHD)	C10		106 (RHD)	J9	107 (RHD)
A15	B	106 (RHD)	D2		106 (RHD)	J10	107 (RHD)
B6	A	106 (RHD)	D4		106 (RHD)	J11	107 (RHD)
B7	B	106 (RHD)	D8		108 (RHD)	T5	107 (RHD)
B9		108 (RHD)	E2	A	104 (RHD)	U1	107 (RHD)
		110 (RHD)	E3	B	104 (RHD)		
B10		108 (RHD)	J5		107 (RHD)		

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1E	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1H		
2E	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2F		
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2I	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IB1	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
BE1	130 (RHD)	Floor Wire and Front Seat RH Wire (Under the Driver's Seat)

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	122 (RHD)	Left Fender Apron
ID	124 (RHD)	Cowl Side Panel LH
IF	124 (RHD)	Cowl Side Panel RH
IH	124 (RHD)	Front Floor Panel Center RH
BJ	128 (RHD)	Front Floor Panel LH
BL	128 (RHD)	Front Floor Panel RH

