

M PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	B 9	Buckle SW RH (w/ Power Seat)	90980-10825
A 2	A/C Condenser Fan Motor	90980-10928		Buckle SW RH (w/o Power Seat)	90980-11212
A 3	A/C Magnetic Clutch	90980-11271	B10	Buckle SW LH and Seat Belt Warning Occupant Detection Sensor	
A 4	A/C Triple Pressure SW (A/C Dual and Single Pressure SW)	90980-10943	B11	Buckle SW RH and Seat Belt Warning Occupant Detection Sensor	
A 5	ABS and Traction Actuator	90980-11698	C 1	Camshaft Position Sensor	90980-10947
A 6	ABS and Traction Actuator	90980-11413	C 2	Camshaft Timing Oil Control Valve	90980-11162
A 7	ABS Speed Sensor Front LH	90980-11002	C 3	Check Connector	90980-11195
A 8	ABS Speed Sensor Front RH		C 4	Crankshaft Position Sensor	90980-10947
A 9	Accel Position Sensor	90980-10711	C 5	Center Airbag Sensor Assembly	90980-11869
A10	Airbag Sensor Front LH	90980-11856	C 6	Center Airbag Sensor Assembly	90980-11872
A11	Airbag Sensor Front RH		C 7	Center Airbag Sensor Assembly	90980-11867
A12	Alternator	90980-09213	C 8	Cigarette Lighter	90980-10760
A13	Alternator	90980-11349	C 9	Cigarette Lighter Illumination	90980-11148
A14	A/C Control Assembly	90980-11556	C10	Combination Meter	90980-11915
A15	A/C Control Assembly	90980-11469	C11	Combination Meter	90980-11911
A16	A/C Room Temp. Sensor	90980-10825	C12	Combination SW	90980-11594
A17	A/C Solar Sensor	90980-11918	C13	Combination SW	90980-11616
A18	A/C Thermistor	90980-10825	C14	Combination SW (Eurpoe)	90980-11672
A19	A/T Shift Position Illumination	90980-11493		Combination SW (Australia)	90980-11595
A20	ABS and Traction ECU	90980-11638	D 1	Daytime Running Light Relay	90980-10807
A21	ABS and Traction ECU	90980-11637	D 2	Double Locking ECU	90980-10803
A22	ABS and Traction ECU	90980-11476	D 3	Diode (A/C)	90980-11251
A23	ABS and Traction ECU	90980-11421	D 4	DLC3	90980-11665
A24	Air Inlet Control Servo Motor	90980-11909	D 5	Door Courtesy Light Front LH	90980-11148
A25	Air Mix Control Servo Motor	90980-11165	D 6	Door Courtesy Light Front RH	
A26	Air Vent Mode Control Servo Motor		D 7	Door Courtesy SW Front LH	90980-10871
A27	Airbag Squib (Front Passenger Airbag Assembly)	90980-11886	D 8	Door Courtesy SW Front RH	
A28	Airbag Squib (Steering Wheel Pad)	90980-10850	D 9	Door Courtesy SW Rear LH	
A29	Antenna Amplifier	90980-10871	D10	Door Courtesy SW Rear RH	90980-11858
A30	Ashtray Illumination	90980-10825	D11	Door Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front LH	
A31	Automatic Light Control Sensor	90980-11107	D12	Door Lock Motor and Door Lock Detection SW Front RH (w/ Dead Lock)	90980-10799
A32	ABS Speed Sensor Rear LH	90980-11060		Door Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front RH (w/o Dead Lock)	90980-11858
A33	ABS Speed Sensor Rear RH	90980-11299	D13	Door Lock Motor and Door Lock Detection SW Front LH (w/ Dead Lock)	90980-10799
B 1	Back-Up Light SW	90980-11142		Door Lock Motor and Door Lock Detection SW Front LH (w/o Dead Lock)	90980-11150
B 2	Brake Fluid Level Warning SW	90980-11207	D14	Door Lock Motor and Door Lock Detection SW Front RH	90980-11150
B 3	Blower Motor	90980-10214			
B 4	Blower Motor Controller	90980-11667			
B 5	Blower Motor Controller	90980-11579			
B 6	Body ECU	90980-11971			
B 7	Body ECU	90980-11911			
B 8	Buckle SW LH (w/ Power Seat)	90980-10825			
	Buckle SW LH (w/o Power Seat)	90980-11212			

Note : Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using "Parts Catalog News" (published by Parts Engineering Administration Dept.).

Nota : Toutes les références du connecteur ne sont pas définies pour la fourniture. Pour passer une commande d'un connecteur ou d'une borne avec fil, prière de vérifier préalablement si cette pièce est bien disponible en se reportant à "Parts Catalog News" (publié par le Département de la Gestion de l'Ingénierie).

Code	Part Name	Part Number	Code	Part Name	Part Number
D15	Door Lock Motor and Door Lock Detection SW Rear LH (w/ Dead Lock)	90980-10799	H 8	Headlight RH (Low)	90980-11660
	Door Lock Motor and Door Lock Detection SW Rear LH (w/o Dead Lock)	90980-11150	H 9	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-11028
D16	Door Lock Motor and Door Lock Detection SW Rear RH (w/ Dead Lock)	90980-10799	H10	Heated Oxygen Sensor (Bank 2 Sensor 1)	
	Door Lock Motor and Door Lock Detection SW Rear RH (w/o Dead Lock)	90980-11150	H11	Horn LH	90980-10619
E 1	ECT Solenoid	90980-10891	H12	Horn RH	
E 2	Engine ECU (M/T) or Engine and ECT ECU (A/T)	90980-11638	H13	Headlight Beam Level Control SW	90980-10797
E 3	Engine ECU (M/T) or Engine and ECT ECU (A/T)	90980-11637	H14	Headlight Cleaner SW	90980-11013
E 4	Engine and ECT ECU	90980-11586	H15	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11028
E 5	Engine ECU (M/T) or Engine and ECT ECU (A/T)	90980-11476	H16	High Mounted Stop Light	90980-11148
E 6	Engine ECU (M/T) or Engine and ECT ECU (A/T)	90980-11421	I 1	Ignition Coil and Igniter No.1	90980-11885
E 7	Engine Hood Courtesy SW	90980-11189	I 2	Ignition Coil and Igniter No.2	
E 8	Engine Oil Level Sensor	90980-10532	I 3	Ignition Coil and Igniter No.3	
E 9	Engine Oil Pressure SW	90980-11363	I 4	Ignition Coil and Igniter No.4	
E10	ECT Pattern Select SW	90980-10933	I 5	Ignition Coil and Igniter No.5	
F 1	Front Clearance Light LH	90980-11162	I 6	Ignition Coil and Igniter No.6	
F 2	Front Clearance Light RH		I 7	Injector No.1	90980-11875
F 3	Front Fog Light LH	90980-11660	I 8	Injector No.2	
F 4	Front Fog Light RH		I 9	Injector No.3	
F 5	Front Side Turn Signal Light LH	90980-11162	I10	Injector No.4	
F 6	Front Side Turn Signal Light RH		I11	Injector No.5	
F 7	Front Turn Signal Light LH	90980-11019	I12	Injector No.6	
F 8	Front Turn Signal Light RH		I13	Intake Air Temp. Sensor	90980-11163
F 9	Front Window Deicer	90980-11295	I14	Ignition Key Cylinder Light	90980-10906
F10	Front Wiper Motor	90980-11599	I15	Ignition SW	90980-11615
F11	Front Door Speaker LH	90980-10935	I16	Interior Light	90980-10935
F12	Front Door Speaker RH		I17	Interior Light and Radar Sensor	90980-11909
F13	Front Door Tweeter Speaker LH	90980-11013	J 1	Junction Connector	90980-11542
F14	Front Door Tweeter Speaker RH		J 2	Junction Connector	90980-11661
F15	Fuel Pump and Sender	90980-11077	J 3	Junction Connector	
F16	Fuel Sender (Sub)	90980-11140	J 4	Junction Connector	90980-10803
G 1	Glove Box Light	90980-11098	J 5	Junction Connector	90980-10976
H 1	Headlight Beam Level Control Actuator LH	90980-11016	J 6	Junction Connector	-
H 2	Headlight Beam Level Control Actuator RH		J 7	Junction Connector	
H 3	Headlight Cleaner Control Relay	90980-10939	J 8	Junction Connector	
H 4	Headlight Cleaner Motor	90980-11410	J 9	Junction Connector	
H 5	Headlight LH (High)	90980-11659	J10	Junction Connector	
H 6	Headlight LH (Low)	90980-11660	J11	Junction Connector	
H 7	Headlight RH (High)	90980-11659	J12	Junction Connector	90980-11542
			J13	Junction Connector	
			J14	Junction Connector	
			J15	Junction Connector	
			J16	Junction Connector	90980-10976
			J17	Junction Connector	

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro. Al pedir un conector o terminal con cable, asegúrese, de antemano, de que esté suministrado refiriéndose a "Parts Catalog News" (publicado por el Departamento Administrativo de Ingeniería de las Partes).

Anmerkung : Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert. Im Falle der Bestellung von Stecker oder Anschlußklemme mit Draht bestätigen Sie bitte unter Verwendung der "Teile-Prospekt-Nachrichten" (herausgegeben durch die Teile-Engineering-Verwaltungsabteilung) im voraus, ob es entsprechende Lieferung gibt.

M PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
K 1	Knock Sensor 1	90980-11166	P18	Power Seat Motor (Driver's Seat Reclining Control)	90980-10825
K 2	Knock Sensor 2		P19	Power Seat Motor (Driver's Seat Slide Control)	
K 3	Kick Down SW	90980-11156	R 1	Radiator Fan Motor	90980-10928
L 1	License Plate Light LH	90980-11148	R 2	Radio and Player	90980-11909
L 2	License Plate Light RH		R 3	Radio and Player	90980-10803
L 3	Light Failure Sensor	90980-10803	R 4	Radio and Player	90980-10996
L 4	Luggage Compartment Door Courtesy SW and Opener Motor	90980-10825	R 5	Radio and Player	90980-10997
L 5	Luggage Compartment Door Key Unlock SW	90980-11368	R 6	Radio and Player	90980-11913
L 6	Luggage Compartment Door Opener Relay	90980-10171	R 7	Rear Fog Light SW	90980-11533
L 7	Luggage Compartment Light	90980-11148	R 8	Remote Control Receiver	90980-11909
M 1	Multi-Display	90980-11877	R 9	Rheostat	90980-10214
M 2	Moon Roof Control ECU	90980-10801	R10	Rear Combination Light LH	90980-11587
M 3	Moon Roof Control SW and Personal Light	90980-10367	R11	Rear Combination Light RH	
N 1	Neutral Start SW	90980-11784	R12	Rear Fog Light LH	90980-10795
N 2	Noise Filter (Ignition)	90980-10843	R13	Rear Fog Light RH	
N 3	Navigation ECU	90980-11915	R14	Rear Speaker LH	90980-11060
N 4	Navigation ECU	90980-11913	R15	Rear Speaker RH	
N 5	Navigation ECU	90980-10803	R16	Remote Control Mirror LH	90980-11532
N 6	Navigation ECU	90980-11535	R17	Remote Control Mirror RH	
N 7	Noise Filter (Rear Window Defogger)	90980-11259	R18	Remote Control Mirror SW	90980-11450
N 8	Noise Filter (Stop Light)	90980-10825	S 1	Speed Sensor (Combination Meter)	90980-11143
P 1	Power Steering Oil Pressure SW	90980-11428	S 2	Speed Sensor (Transmission Input)	90980-11156
P 2	Parking Brake SW	90980-10871	S 3	Speed Sensor (Transmission Output)	
P 3	Personal Light	90980-10935	S 4	Starter	90980-11400
P 4	Power Window Control SW Front LH	90980-10797	S 5	Starter	90980-09506
P 5	Power Window Control SW Front RH		S 6	Seat Heater SW (Driver's Seat)	90980-10797
P 6	Power Window Control SW Rear LH		S 7	Seat Heater SW (Passenger's Seat)	
P 7	Power Window Control SW Rear RH		S 8	Shift Lock Control ECU	90980-11581
P 8	Power Window Master SW	90980-11469	S 9	Stereo Component Amplifier	90980-10848
P 9	Power Window Motor Front LH (LHD)	90980-11011	S10	Stereo Component Amplifier	90980-11913
	Power Window Motor Front LH (RHD)	90980-10860	S11	Stop Light SW	90980-11118
P10	Power Window Motor Front RH (LHD)		S12	Seat Heater (Driver's Seat)	90980-10905
	Power Window Motor Front RH (RHD)	90980-11011	S13	Seat Heater (Passenger's Seat)	
P11	Power Window Motor Rear LH	90980-10860	S14	Side Airbag Sensor LH	90980-11857
P12	Power Window Motor Rear RH		S15	Side Airbag Sensor RH	
P13	Pretensioner LH	90980-11862	S16	Side Airbag Squib LH	90980-11864
P14	Pretensioner RH		S17	Side Airbag Squib RH	
P15	Power Seat Control SW	90980-10997	T 1	Throttle Control Motor	90980-10942
P16	Power Seat Motor (Driver's Seat Front Vertical Control)	90980-10825	T 2	Throttle Position Sensor	90980-10711
P17	Power Seat Motor (Driver's Seat Rear Vertical Control)		T 3	Telephone Microphone	90980-11369
			T 4	Theft Deterrent ECU	90980-11392

Note : Not all of the above part numbers of the connector are established for the supply. In case of ordering a connector or terminal with wire, please confirm in advance if there is supply for it using "Parts Catalog News" (published by Parts Engineering Administration Dept.).

Nota : Toutes les références du connecteur ne sont pas définies pour la fourniture. Pour passer une commande d'un connecteur ou d'une borne avec fil, prière de vérifier préalablement si cette pièce est bien disponible en se reportant à "Parts Catalog News" (publié par le Département de la Gestion de l'Ingénierie).

Code	Part Name	Part Number	Code	Part Name	Part Number
T 5	Theft Deterrent ECU	90980-11424	V 2	VSV (ACIS)	90980-11149
T 6	Traction Cut SW (A/T)	90980-11013	V 3	VSV (EVAP)	90980-11156
	Traction Cut SW and Snow SW (M/T)	90980-10933	V 4	Vanity Light LH	90980-10621
T 7	Transponder Key Amplifier (LHD)	90980-10789	V 5	Vanity Light RH	
	Transponder Key Amplifier (RHD)	90980-10933	W 1	Washer Motor	90980-10981
T 8	Telephone Transceiver and Speaker Relay	90980-10799	W 2	Water Temp. Sensor	90980-10737
T 9	Telephone Transceiver and Speaker Relay	90980-10798	W 3	Water Temp. SW	90980-11235
T10	Theft Warning Siren	90980-10942	W 4	Wireless Door Lock ECU	90980-11909
U 1	Unlock Warning SW and Key Interlock Solenoid	90980-10795	W 5	Woofer Speaker LH	90980-11012
V 1	Vacuum Sensor	90980-10845	W 6	Woofer Speaker RH	

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro. Al pedir un conector o terminal con cable, asegúrese, de antemano, de que esté suministrado refiriéndose a "Parts Catalog News" (publicado por el Departamento Administrativo de Ingeniería de las Partes).

Anmerkung : Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert. Im Falle der Bestellung von Stecker oder Anschlußklemme mit Draht bestätigen Sie bitte unter Verwendung der "Teile-Prospekt-Nachrichten" (herausgegeben durch die Teile-Engineering-Verwaltungsabteilung) im voraus, ob es entsprechende Lieferung gibt.