

HEADLIGHT CLEANER

SERVICE HINTS

H3 HEADLIGHT CLEANER CONTROL RELAY

5-2 : Closed with ignition SW at **ON** position, light control SW at **HEAD** position and headlight cleaner SW on

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C14	A	98 (LHD)	H4	105 (RHD)	J11
		106 (RHD)	H14	99 (LHD)	99 (LHD)
	B	98 (LHD)		107 (RHD)	107 (RHD)
		106 (RHD)	J5	99 (LHD)	99 (LHD)
H3		97 (LHD)		107 (RHD)	107 (RHD)
		105 (RHD)	J9	99 (LHD)	107 (RHD)
H4		97 (LHD)		107 (RHD)	

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	80 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	82 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1B	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1F	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1G	82 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
2F	84 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	114 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Driver Side J/B)
	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	112 (LHD)	Left Fender Apron
	122 (RHD)	
ID	124 (RHD)	Cowl Side Panel LH
IF	124 (RHD)	Cowl Side Panel RH
IG	114 (LHD)	

○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E9	122 (RHD)	Engine Room Main Wire	E11	112 (LHD)	Engine Room Main Wire

