

HEADLIGHT (RHD)

SERVICE HINTS

HEAD LP RELAY

1-2 : Closed with the light control SW at **HEAD** position or the dimmer SW at **FLASH** position

C14 (A), (B) COMBINATION SW

(A) 7, (B) 2-(A)16, (B)17 : Closed with the dimmer SW at **HIGH** or **FLASH** position

(A) 8, (B) 1-(A)16, (B)17 : Closed with the light control SW at **FLASH** position

(A)13, (B)15-(A)16, (B)17 : Closed with the dimmer SW at **HEAD** position

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C10	106 (RHD)	H6	105 (RHD)	J9	107 (RHD)
C14	A	H7	105 (RHD)	R7	107 (RHD)
	B	H8	105 (RHD)	T4	107 (RHD)
H5	105 (RHD)	J5	107 (RHD)		

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)
2	81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1B		
1E	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1F		
1G		
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EC	122 (RHD)	Left Fender Apron
ID	124 (RHD)	Cowl Side Panel LH
IF	124 (RHD)	Cowl Side Panel RH

