

Note: To use USB power, Install only D1, U3 and R3-0 Ohms
 To user external power, install U1, U2 and U3 with all its components, You must cut a jumper on bottom of Teensy 4.0





