



**SCANIA**

**16:00-01**

Issue 4 **zz-ZZ**

## **Component library**

**Truck PGRT**

**S-order**

**Bus FKN**

**Omni**

**Omni-S-order**

**Engines**

**FFU**

**Component Library****Truck PGRT**

No.	Type	Description	Harness	System
A 1	Ignition coil	Ignition coil	Engine	EMS
A 2	Ignition coil	Ignition coil	Engine	EMS
A 3	Ignition coil	Ignition coil	Engine	EMS
A 4	Spark plug	Spark plug	Engine	EMS
A 5	Spark plug	Spark plug	Engine	EMS
A 6	Spark plug	Spark plug	Engine	EMS
A 7	Spark plug	Spark plug	Engine	EMS
A 8	Spark plug	Spark plug	Engine	EMS
A 9	Ignition coil	Ignition coil	Engine	EMS
A 10	Ignition coil	Ignition coil	Engine	EMS
B 2	Switch	Switch, air distribution	Instrument panel	CCS
B 4	Switch	Switch, recirc damper closed	Floor	CCS
B 5	Switch	Switch, recirc damper open	Floor	CCS
B 6	Switch	Switch, door, driver	Instrument panel	LAS/INL
B 7	Switch	Switch, door passenger	Instrument panel	LAS/INL
B 9	Switch	Switch, diff lock	Frame	AWD
B 11	Switch	Switch, diff lock, axle	Frame	RDL
B 12	Switch	Switch, diff lock, second axle	Frame	RDL
B 13	Switch	Switch, diff lock, tandem	Frame	RDL
B 14	Switch	Switch, low gear	Frame	AWD
B 16	Switch	Switch reverse light	Gearb	COO
B 19	Switch	Switch, tilt sensor safety belt, driver	Component	SCS
B 22	Switch	Switch, tilt sensor safety belt, pass	Component	SCS
B 23	Switch	Switch, outer storage box, driver	Floor	LAS/INL
B 23/B92	Switch	Switch, outer storage box, driver	Floor	INL
B 24	Switch	Switch, front grille	Front	LAS
B 28	Switch	Switch, safety belt lock	Floor	SEAT
B 33	Switch	Switch, outer storage box, passenger	Floor	LAS/INL
B 33/B93	Switch	Switch, outer storage box, passenger	Floor	INL
B 34	Switch	Switch, foot break	Instrument panel	COO
B 36	Switch	Switch, trailer brake	Instrument panel	BMS/EBS
B 37	Switch	Micro switch, INL	Roof shelf upper	INL
B 38	Switch	Switch, roof hatch	Roof	LAS
B 41	Switch	Switch, high range	Gearb	GMS
B 42	Switch	Switch, low range	Gearb	GMS
B 43	Switch	Switch, high split	Gearb	GMS
B 44	Switch	Switch, low split	Gearb	GMS
B 45	Switch	Switch, neutral	Gearb	GMS
B 46	Switch	Micro switch, INL	Roof shelf upper	INL
B 47	Switch	Micro switch, INL	Roof shelf upper	INL
B 48	Switch	Micro switch, overhead locker, INL	Roof	INL
B 49	Switch	Switch, manual exhaust brake	Frame	COO
B 58	Switch	Switch, rear door	Door_rear_left	Crew Cab
B 59	Switch	Switch, rear door	Door_rear_right	Crew Cab
B 60	Switch	Switch, folding step LH	Door_rear_left	Crew Cab
B 61	Switch	Switch, folding step RH	Door_rear_right	Crew Cab
B 62	Switch	Switch, warning folding step LH	Door_rear_left	Crew Cab
B 63	Switch	Switch, warning folding step RH	Door_rear_right	Crew Cab
B 68	Switch	Switch, diff lock, central	Frame	AWD
B 69	Switch	Switch, left front door	Floor	Crew Cab
B 70	Switch	Switch, right front door	Floor	Crew Cab
B 76	Switch	Switch, extra 1	?	LAS

B	77	Switch	Switch, extra 2	?	LAS
B	78	Switch	Switch, switch box	Frame	HEV
B	83	Switch	Switch, battery box	Battery box	LAS
B	84	Switch	Switch, storage light, LH	Floor	Crew Cab
B	85	Switch	Switch, storage light, RH	Floor	Crew Cab
B	86	Switch	Switch, storage light	Floor	Crew Cab
B	87	Switch	Switch, acknowledge PTO EK	Gearbox	COO
B	88	Switch	Switch, acknowledge PTO EG single rear	Gearbox	COO
B	89	Switch	Switch, left rear door	Door_rear_left	FST
B	90	Switch	Switch, right rear door	Door_rear_right	FST
B	91	Switch	Switch, neutral	Frame	AWD
B	92	Switch	Switch, outer storage box driver	Floor	LAS/INL
B	93	Switch	Switch, outer storage box, passenger	Floor	LAS/INL
B	94	Switch	Switch, acknowledge PTO EG double rear upper	Gearb	GMS
B	95	Switch	Switch, acknowledge PTO EG double rear common	Gearb	GMS
B	96	Switch	Switch, acknowledge PTO EG double rear lower	Gearb	GMS
B	97	Switch	Switch, acknowledge PTO EG single rear high ratio	Gearb	GMS
B	98	Switch	Switch, acknowledge PTO EG single side	Gearb	GMS
B	99	Switch	Switch, acknowledge PTO EG3	Gearb	GMS
B	100	Switch	Door open switch	Door_rear_left	DCS
B	101	Switch	Door open switch	Door_rear_right	DCS
B	102	Switch	Lock status switch	Door driver	DCS
B	103	Switch	Lock status switch	Door passenger	DCS
B	104	Switch	Lock status switch	Door_rear_left	DCS
B	105	Switch	Lock status switch	Door_rear_right	DCS
B	106	Switch	Switch, acknowledge PTO AWD / Split shaft	Gearb	GMS
B	107	Switch	Switch, Ext storage below cab, driver	Floor	ALM
B	107/B108	Switch	Switch, Ext storage below cab, driver	Floor	INL
B	108	Switch	Switch, Ext storage below cab, driver	Floor	ALM
B	109	Switch	Switch, Ext storage below cab, passenger	Floor	ALM
B	109/B110	Switch	Switch, Ext storage below cab, passenger	Floor	INL
B	110	Switch	Switch, Ext storage below cab, passenger	Floor	ALM
B	111	Switch	Switch, Roof shelf rear	Roof_rear	INL
B	112	Switch	Switch, Roof shelf rear	Roof_rear	INL
B	113	Switch	Switch, Roof shelf rear	Roof_rear	INL
C	1	Connector	Connector, 66-pole	Instrument panel	Common
C	2.A	Connector	Connector, 2-pole	Frame	HEV
C	2.B	Connector	Connector, 2-pole	Frame	HEV
C	2.C	Connector	Connector, 2-pole	Frame	HEV
C	2.D	Connector	Connector, 2-pole	Frame	HEV
C	3	Connector	Connector, 21-pole	Roof - Roofshelf	Common
C	4	Connector	Connector, 12-pole	Component	EEC
C	5	Connector	Connector, 2-pole	Bumper	VIS
C	6	Connector	Connector, 12-pole	Component	EEC
C	7	Connector	Connector, 4-pole	Frame	EEC
C	8	Connector	Connector, 2-pole	Batt	POW
C	9	Connector	Connector, 15-pole	Instrument panel	POW
C	10	Connector	Connector, 12-pole	Frame	EEC
C	11	Connector	Connector, 5-pole	Roof - Sunvisor	VIS
C	12	Connector	Connector, 21-pole	Instrument panel - Floor	Common
C	13	Connector	Connector, 12-pole	Frame	EEC
C	14	Connector	Connector, 15-pole	Instrument panel - Door driver	POW
C	15	Connector	Junction block, 1-pole	Frame	POW
C	16	Connector	Connector, 9-pole	Floor	SEAT
C	17	Connector	Connector, 9-pole	Floor	SEAT

C	18	Connector	Connector, 12-pole	Instrument panel	Common
C	19	Connector	Connector, 21-pole, Instr-Roof	Instrument panel - Roof	Common
C	20	Connector	Connector, 21-pole	Instrument panel - Floor	Common
C	21	Connector	Connector, 12-pole	Component	EEC
C	22	Connector	Connector, 2-pole	Component	EEC
C	23	Splice	Splice, bumper, VIS	Bumper	VIS
C	24	Connector	Connector, 21-pole	Instrument panel - Roof	Common
C	25	Connector	Connector, 12-pole	Instrument panel - Door passenger	Common
C	26	Connector	Connector 21-pole	Instrument panel - Front	Common
C	27	Splice	Splice, UCS, temp level sensor	Component	EEC
C	28	Socket	Socket, 2-pole, 12/24V outlet	Instrument panel	POW
C	29	Connector	Connector 21-pole, Instr-Roof	Instrument panel - Roof	Common
C	30	Connector	Connector, 1-pole	Frame	HST
C	31	Splice	Splice, door driver	Door driver	Common
C	32	Splice	Splice, door passenger	Door passenger	Common
C	33	Connector	Connector, 4-pole	Engine	EMS
C	34	Connector	Connector, 4-pole	Engine	EMS
C	35	Connector	Connector, 6-pole	Engine	EMS
C	36	Connector	Connector, 2-pole	Front	AHS
C	37	Connector	Connector, 7-pole, OPC	Frame	GMS
C	38	Connector	Connector, 6-pole	Roof shelf	TCO
C	39	Connector	Connector, 8-pole	Engine	EMS
C	40	Connector	Connector, 6-pole	Front	VIS
C	41	Junction block	Junction block	Frame	POW
C	42	Connector	Connector, 2-pole	Engine	EMS
C	43	Splice	Splice, engine	Engine	EMS
C	44	Connector	Connector, 2-pole, AC, engine	Engine	EMS
C	45	Connector	Connector, 4-pole	Frame	EEC
C	46	Connector	Connector, 4-pole	Frame	EEC
C	47	Connector	Connector, 2-pole	Frame	VIS
C	48	Connector	Connector, 9-pole, upper roof shelf	Roof - Roofshelf upper	Common
C	49	Connector	Connector, 6-pole	Floor	LAS/INL
C	50	Connector	Connector, 6-pole	Floor	LAS/INL
C	51	Connector	Connector, 3-pole, VIS	Bumper	VIS
C	52	Connector	Connector, 3-pole, VIS	Bumper	VIS
C	53	Splice	Splice, Engine	Engine	EMS
C	54	Connector	Connector, 3-pole	Frame	EEC
C	55	Connector	Supply feed through	Frame	POW
C	57	Splice	Splice, bumper, VIS	Bumper	VIS
C	58	Connector	Connector, 4-pole	Frame - Battery box	POW
C	59	Connector	Connector, 5-pole	Bumper	VIS
C	60	Connector	Connector, 5-pole	Bumper	VIS
C	61	Splice	Splice, EEC Comp	Component	EEC
C	62	Splice	Splice, EEC Comp	Component	EEC
C	63	Splice	Splice, EEC Comp	Component	EEC
C	64	Splice	Splice, EEC Comp	Component	EEC
C	65	Splice	Splice, 1-pole	Instrument panel	AUS
C	66	Splice	Splice, 1-pole	Instrument panel	AUS
C	67	Connector	Connector, 4-pole	Frame - Battery box	POW
C	68	Cut cable	Cut cable, HVF	Instrument panel	HVF
C	69	Connector	Connector, 21-pole, instr p/front	Instrument panel - Front	Common
C	70	Connector	Connector, 3-pole	Floor	COO
C	71	Connector	Connector, 8-pole	Instrument panel	RTI/General
C	72	Connector	Connector, 3-pole, water sep. filter	Frame	COO
C	73	Splice	Splice, INL, ro sh up	Roof shelf upper	INL

C	74	Connector	Connector, 2-pole, ACL	Frame	ACL
C	75	Connector	Connector, 3-pole	Instrument panel	TAL
C	76	Connector	Connector, 4-pole	Frame	TAL
C	77	Splice	Splice, 1-pole	Instrument panel	AUS
C	78	Connector	Connector 21-pole IP-Floor	Instrument panel - Floor	POW/Common
C	79	Connector	Connector 2-pole	Frame	BMS/EBS/ABS
C	80	Connector	Connector 2-pole	Frame	BMS/EBS/ABS
C	81	Connector	Connector 2-pole	Frame	BMS/ABS
C	82	Connector	Connector 2-pole	Frame	BMS/ABS
C	83	Splice	Connector, 1-pole, splice, VIS	Instrument panel	VIS
C	84	Splice	Connector, 1-pole, splice, VIS	Instrument panel	VIS
C	85	Connector	Connector, 2-pole	Front - Component	CCS
C	86	Connector	Connector, 3-pole	Frame	BMS/ABS
C	87	Connector	Connector, 4-pole	Frame - Component	EEC
C	88	Connector	Connector, 8-pole	Engine	EMS
C	89	Connector	Connector, 21-pole	Instrument panel	SMS
C	90	Connector	Connector, 4-pole	Frame	GMS
C	91	Connector	Connector, 21-pole	Instrument panel - Floor	Common
C	92	Connector	Connector, trailer	Frame	BMS/EBS/ABS
C	93	Connector	Connector, 7-pole, RET	Frame	GMS
C	94	Connector	Connector, 21-pole	Roof shelf	ICL
C	95	Connector	Connector, 2-pole	Frame	VIS
C	96	Connector	Connector, 4-pole, PTO1 EK	Frame	COO
C	97	Splice	Splice, UCS, can	Component	EEC
C	98	Splice	Splice, UCS, can	Component	EEC
C	99	Connector	Connector, 4-pole	Frame - Component	EEC
C	100	Connector	Connector, 66-pole	Instrument panel	Common
C	101	Connector	Connector, 66-pole	Instrument panel	Common
C	102	Connector	Connector, 66-pole	Instrument panel	Common
C	103	Connector	Connector, 66-pole	Instrument panel	Common
C	104	Connector	Connector, 2-pole, KIT	Roof	KIT
C	105	Connector	Connector, 2-pole, KIT	Instrument panel - Roof	KIT
C	106	Splice	Splice, 1-pole	Gearb	GMS
C	107	Connector	Connector, 7-pole, OPC	Frame	GMS
C	108	Connector	Connector, 4-pole, OPC	Frame	GMS
C	109	Splice	Splice, 1-pole	Gearb	GMS
C	110	Splice	Splice, frame, VIS	Frame	VIS
C	111	Splice	Splice, frame, VIS	Frame	VIS
C	112	Connector	Connector, 7-pole, manual gearb/OPC	Frame	GMS
C	113	Connector	Connector, 2-pole, ADR, engine	Frame	COO/EMS
C	114	Connector	Connector, 2-pole	Frame	RDL
C	115	Connector	Connector, 2-pole	Sunvisor	VIS
C	116	Connector	Connector, 2-pole	Sunvisor	VIS
C	117	Splice	Splice, sunvisor, VIS	Sunvisor	VIS
C	118	Connector	Connector, 4-pole, manual gearb/OPC	Frame	GMS
C	119	Splice	Splice, sunvisor, VIS	Sunvisor	VIS
C	120	Connector	Connector, 2-pole	Engine	EMS
C	121	Connector	Connector, 2-pole	Frame	FHS
C	122	Connector	Connector, 7-pole, gearbox	Frame - Gearb	COO
C	123	Splice	Splice, 1-pole	Gearb	GMS
C	124	Connector	Connector, 2-pole, KIT	Roof shelf upper	KIT
C	125	Connector	Connector, 2-pole, KIT	Roof shelf upper	KIT
C	126	Socket	Outlet, TV	Roof shelf upper	KIT
C	127	Connector	Connector, 4-pole	Frame	HEV
C	128	Connector	Connector, 5-pole	Floor	VIS

C	129	Connector	Connector, 5-pole	Door driver	MIH
C	130	Connector	Connector, 5-pole	Door passenger	MIH
C	131	Connector	Connector, 5-pole	Door driver	LAS
C	132	Connector	Connector, 5-pole	Door passenger	LAS
C	133	Connector	Connector, 2-pole	Door driver	WIW
C	134	Connector	Connector, 2-pole	Door passenger	WIW
C	135	Connector	Connector, 4-pole	Frame	LAS
C	136	Connector	Connector, 7-pole	Frame	LAS
C	137	Connector	Connector, 12-pole	Instrument panel	RTG
C	138	Splice	Splice, bumper, VIS	Bumper	VIS
C	139	Splice	Splice, ICL, BWS	Instrument panel	ICL
C	140.A	Splice	Splice, sunvisor, VIS	Sunvisor	VIS
C	140.B	Splice	Splice, sunvisor, VIS	Sunvisor	VIS
C	141	Splice	Splice, bumper, VIS	Bumper	VIS
C	142	Splice	Splice, bumper, VIS	Bumper	VIS
C	143	Connector	Connector, 2-pole	Frame	BMS/ABS
C	144	Connector	Connector, 2-pole	Frame	BMS/ABS
C	145	Connector	Connector, 5-pole	Frame	LAS
C	146	Connector	Connector, 6-pole	Instrument panel	BWS
C	147	Splice	Splice, acknowledge PTO	Gearbox	COO
C	148	Connector	Connector, 6-pole	Instrument panel	VIS
C	149	Connector	Connector, 2-pole	Roof shelf	Common
C	150	Connector	Connector, 5-pole	Floor	INL
C	151	Connector	Connector, 5-pole	Floor	INL
C	152	Connector	Connector, 1-pole	Frame	BWE
C	153	Connector	Connector, 2-pole	Instrument panel	CCS
C	154	Splice	Splice, INL roof	Roof	INL
C	155	Splice	Splice, INL roof	Roof	INL
C	156	Connector	Connector, 4-pole	Frame/Component	EEC
C	157	Connector	Connector, 1-pole	Frame	BWE
C	158	Connector	Connector, 7-pole	Frame	BWE
C	159	Connector	Connector, 7-pole	Frame	BWE
C	160	Splice	Splice, FCS	Frame	FCS
C	161	Splice	Splice, FCS	Frame	FCS
C	162	Socket	Socket, 15-pole	Frame	VIS
C	163	Connector	Connector, 5-pole, SMS	Floor	SMS
C	164	Connector	Connector, 2 pole, fuel level sensor	Frame	COO
C	165	Splice	Splice, engine	Engine	EMS
C	166	Connector	Connector, 3-pole	Instrument panel	LAS/INL/Common
C	167	Connector	Connector, 12-pole	Frame/Component	EEC
C	168	Splice	Splice, bumper, VIS	Bumper	VIS
C	169	Splice	Splice	Engine	EMS
C	170	Connector	Connector, 1-pole	Component	VIS
C	171	Connector	Connector, 1-pole	Component	VIS
C	172	Splice	Splice	Component	Common
C	173	Connector	Connector, 2-pole, fueltemp	Engine	EMS
C	174	Splice	Splice	Frame	BWE
C	175	Splice	Splice	Frame	BWE
C	176	Splice	Splice, POW	Frame	POW
C	177	Connector	Connector, 2-pole, RTI/SVI	Instrument panel	RTI/SVI
C	178	Connector	Connector, 1-pole, RTI/SVI	Instrument panel	RTI/SVI
C	179	Connector	Connector, 2-pole	Roof	CLP
C	180	Socket	Socket, 2-pole, 12/24V outlet	Instrument panel	POW
C	181	Connector	Connector, 2-pole	Frame	POW
C	182	Splice	Splice, engine	Engine	EMS

C	183	Connector	Connector, 2-pole	Frame - Battery box	POW
C	184	Connector	Connector, 2-pole	Floor	BWE
C	185	Connector	Connector, 2-pole	Floor	BWE
C	186	Connector	Connector, 2-pole, bench	Floor	Crew Cab
C	187	Connector	Connector, 8-pole	Frame	AHS
C	188	Connector	Fuse holder, BWS	Frame	BWS
C	189	Connector	Connector, 4-pole	Engine	EMS
C	190	Connector	Connector, 4-pole	Engine	EMS
C	191	Connector	Connector, 2-pole	Engine	EMS
C	192	Connector	Connector, 2-pole	Engine	EMS
C	193	Connector	Connector, 16-pole	Frame	GMS
C	194	Connector	Connector, 2-pole	Frame	GMS
C	195	Connector	Connector, 6-pole	Engine	EMS
C	196	Splice	Splice, CAT	Instrument panel	CAT
C	197	Splice	Splice, CAT	Instrument panel	CAT
C	198	Connector	Connector, 3-pole	Instrument panel	FAS
C	199	Connector	Connector, 2-pole	Instrument panel	FAS
C	200	Connector	Connector, 2-pole	Instrument panel	FAS
C	201	Connector	Connector, 18-pole	Instrument panel	FAS
C	202	Splice	Splice, gearbox	Gearb	COO
C	203	Splice	Splice, POW	Instrument panel	POW
C	204	Connector	Connector, 2-pole	Instrument panel	CCS
C	205	Connector	Connector, 2-pole, trail lever	Instrument panel	(COO)/EBS
C	206	Connector	Connector, 2-pole	Engine	EMS
C	207	Connector	Connector, 5-pole, VIS	Roof	VIS
C	208	Connector	Connector, 5-pole, VIS	Roof	VIS
C	209	Splice	Splice, RDL	Instrument panel	RDL
C	210	Splice	Splice, RDL	Instrument panel	RDL
C	211	Splice	Splice, RDL	Instrument panel	RDL
C	212	Connector	Connector, 5-pole	Roof	INL
C	213	Splice	Splice, RDL	Instrument panel	RDL
C	214	Cut cable	Cut cable	Floor	TIP
C	215	Cut cable	Cut cable	Floor	TIP
C	216	Splice	Splice, Instr, VIS	Instrument panel	VIS
C	217	Splice	Splice, Instr, VIS	Instrument panel	VIS
C	218	Connector	Connector, 21-pole	Instrument panel - Floor	Common
C	219	Connector	Connector, 6-pole	Engine - Engine	EMS
C	220	Connector	Connector, 12-pole	Engine - Engine	EMS
C	221	Connector	Connector, 6-pole	Engine - Engine	EMS
C	222	Splice	Splice, Engine	Engine	EMS
C	223	Splice	Splice, Engine	Engine	EMS
C	224	Splice	Splice, Engine	Engine	EMS
C	225	Splice	Splice, Engine	Engine	EMS
C	226	Splice	Splice, Engine	Engine	EMS
C	227	Connector	Connector, 16-pole	Frame	HEV
C	228	Connector	Connector, 2-pole	Engine	EMS
C	229	Splice	Splice, GA	Gearb	GMS
C	230/C334	Connector	Connector, 6-pole, POW, battery switch, ADR RH battery	Frame - Battery box	POW
C	231	Cut cable	Cut cable, BWS, PTO ack	Frame	BWS
C	232	Splice	Splice, engine	Engine - Engine	EMS
C	233	Connector	Connector, 3-pole	Engine - Engine	EMS
C	234	Connector	Connector, 12-pole	Instrument panel	ICL/BWS
C	235	Splice	Splice, rear floor left	Floor	WIW
C	236	Splice	Splice, rear floor left	Floor	WIW
C	237	Splice	Splice, rear floor right	Floor	WIW

C 238	Splice	Splice	Instrument panel	BWE
C 239	Connector	Connector, 2-pole	Frame	BMS/EBS
C 240	Connector	Connector, 2-pole	Frame	BMS/EBS
C 241	Connector	Connector, 2-pole	Frame	LAS
C 242	Connector	Connector, 2-pole	Frame	LAS
C 243	Connector	Connector, 2-pole	Roof	INL
C 244	Connector	Connector, 12-pole	Engine	EMS
C 245	Connector	Connector, 2-pole	Engine	EMS
C 246	Splice	Splice, engine	Engine	EMS
C 247	Splice	Splice, engine	Engine	EMS
C 248	Connector	Connector, 4-pole	Engine	EMS
C 249	Splice	Splice, door driver	Door driver	Common
C 250	Splice	Splice, door passenger	Door passenger	Common
C 251	Cut cable	Cut cable, VIS	Bumper	VIS
C 252	Connector	Connector, 2-pole	Roof shelf	LAS
C 253	Connector	Connector, 2-pole	Frame	LAS
C 254	Cut cable	Cut cable, VIS	Bumper	VIS
C 255	Connector	Connector, 9-pole	Floor	AHS
C 256	Cut cable	Cut cable, VIS	Bumper	VIS
C 257	Cut cable	Cut cable, VIS	Bumper	VIS
C 258/C334	Connector	Connector, 6-pole, POW, battery switch, ADR LH	Frame	POW
C 259	Connector	Connector, 21-pole	Instrument panel	BWE
C 260	Connector	Connector, 12-pole, BWS	Instrument panel	BWS
C 261	Connector	Connector, 21-pole	Instrument panel	POW/Common
C 262/C405	Connector	Connector, 2-pole POW, TCO, RH battery	Frame - Battery box	POW
C 263	Connector	Connector, 37-pole	Frame	GMS
C 264	Connector	Connector, 16-pole	Frame	GMS
C 265/C405	Connector	Connector, 2-pole POW, TCO, LH near C405	Frame	POW
C 266/L101	Connector	Connector, 7p, VIS, rear comb lamp left	Frame	VIS
C 267	Connector	Connector, 1-pole	Instrument panel	LAS
C 268	Connector	Connector, 6-pole, SMS	Instrument panel	SMS
C 269	Splice	Splice, GMS	Gearbox	GMS
C 270	Connector	Connector, 2-pole, water sep. heater	Frame	COO
C 271	Connector	Connector, 3-pole	Instrument panel	RTI/General
C 272	Connector	Connector, 21-pole	Instrument panel - Roof	Common
C 273	Connector	Connector, 21-pole	Roof - Roofshelf	Common
C 274	Joint Connector	Joint connector, instr light	Instrument panel	ICL
C 274.B	Splice	Splice, instr light	Instrument panel	ICL
C 274.C	Splice	Splice, instr light	Instrument panel	ICL
C 275	Joint Connector	Joint connector, instr light	Instrument panel	ICL
C 275.B	Splice	Splice, instr light	Instrument panel	ICL
C 275.C	Splice	Splice, instr light	Instrument panel	ICL
C 276	Joint Connector	Joint connector, instr light	Instrument panel	ICL
C 277	Connector	Connector, 2-pole	Frame	AWD
C 278	Splice	Splice, TCO Hino	Roof	TCO
C 279	Splice	Splice, TCO Hino	Roof	TCO
C 280	Splice			
C 281	Splice			
C 282	Connector	Connector, 12-pole	Component	EEC
C 283	Connector	Connector, 5-pole	Floor	AHS
C 284	Connector	Connector, 8-pole	Roof shelf	TCO
C 285	Splice	Splice, door driver	Door driver	Common
C 286	Splice	Splice, door passenger	Door passenger	Common
C 287	Connector	Connector, 2-pole	Floor	Refridgerator
C 288	Connector	Connector, 20-pole	Instrument panel	BWS



C	289	Connector	Connector, 10-pole, steering buttons	Instrument panel	
C	290	Connector	Connector, 2-pole, airbag	Instrument panel	CSS
C	291	Connector	Connector, 10-pole, steering buttons	Instrument panel	Common
C	292	Connector	Connector, 2-pole	Engine	EMS
C	293/L102	Connector	Connector, 7p, VIS, rear comb lamp right	Frame	VIS
C	294	Connector	Connector, 2-pole, 2 circuit steering	Bumper	COO
C	295	Connector	Connector, 2-pole, 2 circuit steering	Bumper	COO
C	296	Connector	Connector, 1-pole, RTI/SVI	Roof	RTI/SVI
C	297	Connector	Connector, 1-pole, RTI/SVI	Instrument panel	RTI/SVI
C	298	Connector	Connector, 1-pole, RTI/SVI	Roof	RTI/SVI
C	299	Connector	Connector, 1-pole, RTI/SVI	Instrument panel	RTI/SVI
C	300	Connector	Connector, 1-pole, RTI/SVI	Roof	RTI/SVI
C	301	Connector	Connector, 1-pole, GPS	Instrument panel	RTI/SVI
C	302	Connector	Connector, 1-pole, RTI/SVI	Roof	RTI/SVI
C	303	Connector	Connector, 2-pole, LAS	Front	LAS
C	304	Connector	Connector, 21-pole	Instrument panel - Floor	Crew cab
C	305	Splice	Splice, door rear left	Door_rear_left	Crew cab
C	306	Splice	Splice, door rear right	Door_rear_right	Crew cab
C	307	Connector	Connector, 15-pole	Floor - Roof_rear	Crew cab
C	308	Splice	Splice, door rear left	Door_rear_left	Crew cab
C	309	Connector	Connector, 12-pole	Frame - Engine	EEC
C	310	Splice	Splice, door rear right	Door_rear_right	Crew cab
C	311	Connector	Connector, 4-pole	Instrument panel	Crew cab
C	312	Connector	Connector, 1-pole, GSM	Instrument panel	RTI/SVI
C	313	Connector	Connector, 6-pole	Instrument panel	Crew cab
C	314	Connector	Connector, 6-pole	Instrument panel	Crew cab
C	315	Connector	Connector, 9-pole	Floor	Crew cab
C	316	Connector	Connector, 8-pole	Frame	EEC
C	317	Connector	Connector, 9-pole	Floor	Crew cab
C	318	Connector	Connector, 4-pole	Frame	ECA
C	319	Connector	Connector, 2-pole	Frame	ECA
C	320	Connector	Connector, 4-pole	Frame	Common
C	321	Connector	Connector, 4-pole	Frame	APC
C	322	Connector	Connector, 3-pole	Instrument panel	Crew cab
C	323	Connector	Connector, 5-pole	Roof_rear	Crew cab
C	324	Connector	Connector, 5-pole	Roof_rear	Crew cab
C	325	Connector	Connector, 5-pole	Roof_rear	Crew cab
C	326	Connector	Connector, 5-pole	Roof_rear	Crew cab
C	327	Connector	Connector, 9-pole	Roof_rear	Crew cab
C	328	Connector	Connector, 21-pole	Instrument panel	Crew cab
C	329	Connector	Connector, 21-pole	Instrument panel - Floor	Crew cab
C	330	Connector	Connector, 4-pole, left side	Frame	Crew cab
C	331	Connector	Connector, 2-pole, right side	Frame	Crew cab
C	332	Connector	Connector, 2-pole, left side	Frame	Crew cab
C	333	Connector	Connector, 2-pole	Engine	EMS
C	334	Connector	Connector, 6-pole	Frame	POW
C	335	Connector	Connector, 6-pole	Engine	EMS
C	336	Splice	Splice, Instr, AUX	Instrument panel	AUS
C	337	Splice	Splice, Instr, AUX	Instrument panel	AUS
C	338	Connector	Connector, 21-pole	Floor - Roof_rear	Crew cab
C	339	Connector	Connector, 3-pole	Frame - Battery box	POW
C	340	Connector	Connector, 2-pole	Component	CSS
C	341	Connector	Connector, 2-pole	Component	CSS
C	342	Connector	Connector, 2-pole	Floor	POW
C	343	Splice	Splice, POW	Instrument panel	POW

C	344	Splice	Splice, bumper, VIS
C	345	Connector	Connector, 5-pole, airflow sensor
C	346	Connector	Connector, 15-pole
C	347	Connector	Connector, 15-pole
C	348	Connector	Connector, 4-pole
C	349	Connector	Connector, 15-pole
C	350	Connector	Connector, 15-pole
C	351	Splice	Splice, Engine
C	352	Connector	Connector, 5-pole
C	353	Connector	Connector, 5-pole
C	354	Connector	Connector, 6-pole
C	355	Connector	Connector, 6-pole
C	356	Connector	Connector, 6-pole
C	357	Connector	Connector, 1-pole
C	358	Connector	Connector, 1-pole
C	359	Splice	Splice, Engine
C	360	Splice	Splice
C	361	Splice	Splice, POW
C	362	Splice	Splice, bumper, VIS
C	363	Connector	Connector, 4-pole, RTC
C	364	Connector	Connector, 7-pole
C	365	Connector	Connector, 7-pole
C	366	Splice	Splice, bumper, VIS
C	367	Splice	Splice, bumper, VIS
C	368	Connector	Connector, 2-pole, RTI/SVI
C	369	Connector	Connector, 2-pole, RTI/SVI
C	370	Connector	Connector, 3-pole
C	371	Splice	Splice, bumper, VIS
C	372	Connector	Connector, 2-pole, fan, engine
C	373	Splice	Splice, bumper, VIS
C	374	Connector	Connector, 2-pole
C	375	Connector	Connector, 2-pole
C	376	Splice	Splice, frame, VIS
C	377	Connector	Connector, Jump start positive
C	378	Splice	Splice, ECA
C	379	Splice	Splice, POW
C	380	Splice	Splice, POW
C	381	Connector	Connector, 2-pole
C	382	Connector	Connector, 3-pole
C	383	Connector	Connector, 3-pole
C	384	Splice	Splice, RTG
C	385	Splice	Splice, RTG
C	386	Connector	Joint connector ENV SENS CAN
C	387	Connector	Joint connector CAN
C	388	Connector	Connector, 6-pole
C	389	Connector	Connector, 7-pole
C	390	Connector	Connector, 4-pole
C	391	Connector	Connector, 3-pole, External identifier
C	392/C273	Connector	Connector, 21-pole
C	393/C273	Connector	Connector, 21-pole
C	394	Cut cable	Cut cable, RTC, External identifier
C	395	Connector	Connector, 6-pole
C	396	Connector	Connector, 3-pole
C	397	Connector	Connector, 2-pole
C	398	Connector	Connector, 2-pole

Bumper	VIS
Engine	Engine
Floor - Door_rear_left	Crew cab
Floor - Door_rear_left	Crew cab
Engine	EMS
Floor - Door_rear_right	Crew cab
Floor - Door_rear_right	Crew cab
Engine	EMS
Door_rear_left	Crew cab
Door_rear_right	Crew cab
Floor	Crew cab
Roof_rear	Crew cab
Instrument panel - Floor	Crew cab
Roof	RTC
Roof	RTC
Engine	EMS
Frame	POW
Frame	POW
Bumper	VIS
Roof shelf	RTC
Frame	VIS
Frame	VIS
Bumper	VIS
Bumper	VIS
Roof	RTI/SVI
Instrument panel	RTI/SVI
Roof	RTI
Bumper	VIS
Engine	EMS
Bumper	VIS
Frame-Component	EEC
Frame	EEC
Frame	VIS
Frame	POW
Frame	ECA
Frame	POW
Instrument panel	POW
Frame	BMS
Frame	BMS
Frame	BMS
Instrument panel	RTG
Instrument panel	RTG
Instrument panel	COO
Frame	SMS
Instrument panel	MOP
Frame	BMS/EBBS
Engine - Frame	EMS
Roof shelf	RTI
Roof	RTI
Roof shelf	RTI
Roof shelf	RTC
Instrument panel	POW
Instrument panel	RVI
Engine	EMS
Engine	EMS

C	399	Connector	Connector, 1-pole, MOP
C	400	Splice	Splice, mutebox
C	401	Splice	Splice, mutebox
C	402	Connector	Connector, 9-pole
C	403	Splice	Splice, mutebox
C	404	Splice	Splice, mutebox
C	405	Connector	Connector, 2-pole
C	406	Connector	Connector, 2-pole
C	407	Socket	Socket, 2-pole, 24V outlet
C	408	Splice	Splice, sunvisor, VIS
C	409	Splice	Splice, bumper, VIS
C	410	Splice	Splice, bumper, VIS
C	411	Connector	Connector, 2-pole
C	412	Connector	Connector, 2-pole
C	413	Cut cable	Cut cable
C	414	Cut cable	Cut cable
C	415	Cut cable	Cut cable
C	416	Cut cable	Cut cable
C	417	Cut cable	Cut cable
C	418	Cut cable	Cut cable
C	419	Connector	Connector, 3-pole
C	420	Connector	Connector, 2-pole
C	421	Connector	Connector, 2-pole
C	422	Splice	Splice, mutebox
C	423	Splice	Splice, mutebox
C	424	Cut cable	Cut cable
C	425	Connector	Connector, 2-pole
C	426	Connector	Connector, 3-pole
C	427	Connector	Connector, 21-pole
C	427.A	Connector	Connector, 15-pole
C	427.B	Connector	Connector, 2-pole
C	428	Connector	Connector, 3-pole
C	429	Connector	Connector, 7-pole, RET
C	430	Connector	Connector, 7-pole
C	431	Connector	Connector, 5-pole
C	432	Socket	Socket, 7-pole, 24N
C	433	Connector	Connector, 3-pole
C	434	Connector	Connector, 2-pole
C	435	Connector	Connector, 3-pole
C	436	Connector	Connector, 12-pole
C	437	Joint connector	Joint connector Sub-Bus CAN
C	438	Joint connector	Joint connector Batt-Bus CAN
C	439	Splice	Splice, instr, VIS
C	440	Splice	Splice, instr, VIS
C	441	Splice	Splice, KIT
C	442	Connector	Connector, 3-pole
C	443	Connector	Connector, 21-pole
C	444	Connector	Connector, 16-pole
C	445	Connector	Connector, 3-pole
C	446	Connector	Connector, 12-pole
C	447	Connector	Connector, 6-pole
C	448	Connector	Connector, 20-pole
C	449	Connector	Connector, 18-pole
C	450	Connector	Connector, 2-pole, VIS
C	450-1	Connector	Connector, 12-pole, VIS

Instrument panel	MOP
Instrument panel	RTI
Instrument panel	RTI
Floor	AHS
Instrument panel	RTI
Instrument panel	MOP
Batt	POW
Batt	POW
Floor	POW
Sunvisor	VIS
Bumper	VIS
Bumper	VIS
Component	VIS
Instrument panel	AUS
Bumper	BWE
Roof	BWE
Roof	BWE
Instrument panel	BWE
Instrument panel	BWE
Bumper	BWE
Instrument panel	AHS
Door_rear_left	Crew cab
Door_rear_right	Crew cab
Instrument panel	RTI
Instrument panel	RTI
Bumper	BWE
Frame	Crew cab
Frame	Crew cab
Frame - Engine	COO
Frame - Engine	COO
Frame - Engine	COO
Component	COO
Frame	GMS
Frame-Component	EEC
Roof	MIA/MIH
Frame	VIS
Engine	EMS
Frame	BMS
Frame	BMS
Frame-Component	HEV
Frame	HEV
Frame	HEV
Instrument panel	VIS
Instrument panel	VIS
Instrument panel	KIT
Frame	EBS
Frame	HEV
Frame	HEV
Frame	EBS
Frame	HEV
Instrument panel	BWE
Instrument panel	GMS
Instrument panel	GMS
Frame	VIS
Frame	VIS

C	450-2	Connector	Connector, 12-pole, VIS	Frame	VIS
C	451	Connector	Connector, 2-pole, manual exhaust brake	Instrument panel	COO
C	452-1	Splice	Splice, oil protection	Engine	EMS
C	452-2	Splice	Splice, oil protection	Engine	EMS
C	453-1	Splice	Splice, oil protection	Engine	EMS
C	453-2	Splice	Splice, oil protection	Engine	EMS
C	454-1	Splice	Splice, oil protection	Engine	EMS
C	454-2	Splice	Splice, oil protection	Engine	EMS
C	455-1	Splice	Splice, oil protection	Engine	EMS
C	455-2	Splice	Splice, oil protection	Engine	EMS
C	456-1	Splice	Splice, oil protection	Engine	EMS
C	456-2	Splice	Splice, oil protection	Engine	EMS
C	457-1	Splice	Splice, oil protection	Engine	EMS
C	457-2	Splice	Splice, oil protection	Engine	EMS
C	458-1	Splice	Splice, oil protection	Engine	EMS
C	458-2	Splice	Splice, oil protection	Engine	EMS
C	459-1	Splice	Splice, oil protection	Engine	EMS
C	459-2	Splice	Splice, oil protection	Engine	EMS
C	460	Connector	Connector, 2-pole	Engine	EMS
C	461	Connector	Connector, 4-pole, EGR mass flow	Engine	EMS
C	462	Connector	Connector, 3-pole	Engine - Frame	EEC
C	463	Connector	Connector, 8-pole	Roof shelf	TCO
C	464	Joint connector	Joint connector orange CAN	Instrument panel	COO
C	465	Splice	Splice, instr, POW	Instrument panel	POW
C	466	Connector	Connector, 3-pole	Frame	BMS/EBS
C	467	Connector	Connector, 3-pole	Frame	BMS/EBS
C	468	Connector	Connector, 8-pole	Instrument panel	RTI
C	469	Connector	Connector, 4-pole	Frame	GMS
C	470	Connector	Connector, 4-pole	Frame	GMS
C	471	Connector	Connector, 4-pole, FMS prep	Instrument panel	FMS
C	471X	Connector	Connector, 4-pole	Instrument panel	FMS
C	472	Connector	Connector, 3-pole	Frame	BMS/EBS
C	473	Splice	Splice, valve block	Engine	EMS
C	474	Connector	Connector, 9-pole, CCS	Floor	CCS
C	475	Connector	Connector, 6-pole	Instrument panel	FAS
C	476	Connector	Connector, 3-pole	Frame	BMS/EBS
C	477	Connector	Connector, 3-pole	Frame	BMS/EBS
C	478	Connector	Connector, 3-pole	Frame	BMS/EBS
C	479	Joint connector	Joint connector green CAN	Instrument panel	COO
C	480	Joint connector	Joint connector red CAN	Instrument panel	COO
C	481	Joint connector	Joint connector yellow CAN	Instrument panel	COO
C	482	Joint connector	Joint connector wake up	Instrument panel	COO
C	483	Joint connector	Joint connector wake up	Instrument panel	COO
C	484	Connector	Connector, 15-pole	Instrument panel	VIS
C	485	Connector	Connector, 9-pole	Roof	LAS
C	486	Connector	Connector, 7-pole	Bumper	BWE
C	487	Connector	Connector, 7-pole	Bumper	BWE
C	488	Connector	Connector, 7-pole	Bumper	BWE
C	489	Connector	Connector, 21-pole, COO	Instrument panel	COO
C	490	Connector	Connector, COAX	Instrument panel	AUS
C	491	Connector	Connector, 1-pole, MOP	Instrument panel	MOP
C	492	Connector	Connector, 6-pole	Instrument panel	FAS
C	493	Connector	Connector 15-pole	Instrument panel	BWE
C	494	Connector	Connector 21-pole	Instrument panel	BWE
C	495	Connector	Connector 4-pole	Frame	GMS

C	496	Connector	Connector 7-pole	Frame	GMS
C	497	Connector	Connector 7-pole	Frame	GMS
C	498	Connector	Connector 7-pole	Frame	GMS
C	499	Connector	Connector, 2-pole, ashtray light	Instrument panel	POW
C	8000	Connector	Connector, 4-pole, ID reader	Roof Shelf	RTC
C	8001	Joint connector	Joint connector, Switch CAN	Instrument panel	COO
C	8002	Joint connector	Joint connector, Snd wake up	Instrument panel	COO
C	8003	Joint connector	Joint connector, Wake up	Instrument panel	COO
C	8004	Joint connector	Joint connector, Orange wake up	Instrument panel	COO
C	8005	Connector	Supply feed through 12V	Frame	POW
C	8006	Joint connector	Joint connector, Third wake up	Instrument panel	COO
C	8007	Connector	Connector, 3-pole	Frame	BMS/EBS
C	8008	Splice	Splice, BMS/EBS	Frame	BMS/EBS
C	8009	Connector	Connector, 3-pole	Frame	BMS/EBS
C	8010	Splice	Splice, INL, ro sh up	Roof shelf upper	INL
C	8011	Splice	Splice, INL, ro sh rear	Roof shelf rear	INL
C	8012	Splice	Splice, INL, ro sh rear	Roof shelf rear	INL
C	8013	Connector	Connector, 21-pole	Instrument panel	COO
C	8014	Splice	Splice, HEV	Frame	HEV
C	8015	Connector	Connector, 21-pole	Instrument panel - Floor	Common
C	8016	Connector	Connector, 21-pole	Roof shelf - Roof rear	Common
C	8017	Connector	Connector, 21-pole	Roof shelf - Roof rear	Common
C	8018	Connector	Connector, 21-pole	Floor - Bed module	Common
C	8019	Splice	Splice, INL, Floor	Floor	INL
C	8020	Splice	Splice, INL, Floor	Floor	INL
C	8021	Splice	Splice, INL, Floor	Floor	INL
C	8022	Splice	Splice, INL, Floor	Floor	INL
C	8023	Splice	Splice, INL, Ro Sh	Roof Shelf	INL
C	8024	Splice	Splice, INL, Ro Sh	Roof Shelf	INL
C	8025	Splice	Splice, INL, D42Instr	Instrument panel	INL
C	8026	Splice	Splice, COO, CAN_L red	Frame	COO
C	8027	Splice	Splice, COO, CAN_H red	Frame	COO
C	8028	Splice	Splice, COO, CAN_L orange	Frame	COO
C	8029	Splice	Splice, COO, CAN_H orange	Frame	COO
C	8030	Splice	Splice, COO, CAN_shield RED	Frame	COO
C	8031	Splice	Splice, COO, CAN_shield ORANGE	Frame	COO
C	8032	Splice	Splice, COO, 2:nd wake-up	Frame	COO
C	8033	Splice	Splice, COO, wake-up red	Frame	COO
C	8034	Splice	Splice, COO, wake-up orange	Frame	COO
C	8035	Connector	Connector, 2-pole	Frame	BMS/EBS
C	8036	Connector	Connector, 2-pole	Frame	BMS/EBS
C	8037	Connector	Connector, 3-pole	Frame	BMS/EBS
C	8038	Connector	Connector, 3-pole	Frame	BMS/EBS
C	8039	Splice	Splice, INL, Instr	Instrument panel	INL
C	8040	Splice	Splice, INL, Instr	Instrument panel	INL
C	8041	Splice	Splice, INL, Instr	Instrument panel	INL
C	8042	Splice	Splice, INL, Instr	Instrument panel	INL
C	8043	Splice	Splice, INL, Instr	Instrument panel	INL
C	8044	Splice	Splice, INL, Instr	Instrument panel	INL
C	8045	Connector	Connector, 8-pole	Frame	CMS
C	8046	Connector	Connector, 15-pole, HVAC	Instrument panel	CCS
C	8047	Connector	Connector, 2-pole, Passenger side roll over airbag	Floor	CSS
C	8048	Connector	Connector, 2-pole, Driver side roll over airbag	Floor	CSS
C	8049	Splice	Splice, EMS/POW	Frame	POW
C	8050-1	Splice	Splice	Door passenger	DCS

C	8050-2	Splice	Splice	Door passenger	DCS
C	8050-3	Splice	Splice	Door passenger	DCS
C	8050-4	Splice	Splice	Door passenger	DCS
C	8050-5	Splice	Splice	Door passenger	DCS
C	8050-6	Splice	Splice	Door passenger	DCS
C	8050-7	Splice	Splice	Door passenger	DCS
C	8050-8	Splice	Splice	Door passenger	DCS
C	8050-9	Splice	Splice	Door passenger	DCS
C	8051-1	Splice	Splice	Door driver	DCS
C	8051-2	Splice	Splice	Door driver	DCS
C	8051-3	Splice	Splice	Door driver	DCS
C	8052	Splice	Splice, external gnd	Door passenger	DCS
C	8053	Splice	Splice, sub-CAN H	Instrument panel	DCS
C	8054	Splice	Splice, sub-CAN L	Instrument panel	DCS
C	8055	Connector	Connector, 21-pole	Instrument panel - Roof shelf	Common
C	8056	Splice	Splice, B	Instrument panel	Common
C	8057	Splice	Splice, B+	Instrument panel	Common
C	8058	Connector	Connector, 9-pole	Instrument panel	ALM
C	8059	Cut cable	Cut cable, VIS	Bumper	VIS
C	8060	Cut cable	Cut cable, VIS	Bumper	VIS
C	8061	Splice	Splice, LIN BUS	Instrument panel	CCS
C	8062	Splice	Splice, LIN GND	Instrument panel	CCS
C	8063	Splice	Splice, 12V supply LIN nodes	Instrument panel	CCS
C	8064	Connector	Connector, 12-pole	Bumper - Bumper	DIS
C	8065	Splice	Splice	Door driver	INL
C	8066	Splice	Splice	Door passenger	INL
C	8067	Splice	Splice	Front	VIS
C	8068	Connector	Connector, 6-pole	Door driver	INL
C	8069	Connector	Connector, 6-pole	Door passenger	INL
C	8070	Splice	Splice	Front	VIS
C	8071	Connector	Connector, 4-pole	Front	VIS
C	8072	Splice	Splice	Instrument panel	BWE
C	8073	Connector	Connector, 2-pole	Instrument panel	KIT
C	8074	Connector	Connector, 2-pole	Frame	CMS
C	8075	Connector	Connector, 2-pole	Frame	CMS
C	8076	Connector	Connector, 4-pole	Frame	CMS
C	8077	Connector	Connector, 5-pole	Floor	INL
C	8078	Connector	Connector, 5-pole	Floor	INL
C	8079-1	Splice	Splice, Floor	Floor	INL
C	8079-2	Splice	Splice, Floor	Floor	INL
C	8079-3	Splice	Splice, Floor	Floor	INL
C	8079-4	Splice	Splice, Floor	Floor	INL
C	8080	Joint connector	Joint connector, instr light	Floor	ICL
C	8080.A	Splice	Splice, instr light	Floor	ICL
C	8081	Connector	Connector, 9-pole	Floor	AUS
C	8082	Connector	Socket, 12V outlet, Driver	Instrument panel - Floor	EPS
C	8083	Connector	Socket, 12V outlet, Passenger	Instrument panel	EPS
C	8084	Connector	Socket, 12V outlet, Rear	Bed module	EPS
C	8085	Connector	Socket, 12V outlet, Rear	Bed module	EPS
C	8086	Connector	Socket, 12V outlet, Roof shelf	Roof shelf	EPS
C	8087	Connector	Socket, 24V outlet, Passenger	Instrument panel	EPS
C	8088	Connector	Socket, 24V outlet, Passenger	Roof shelf	EPS
C	8089	Connector	Socket, 24V outlet, Passenger	Bed module	EPS
C	8090	Connector	Joint connector, Sub CAN CMS	Frame	CMS
C	8091	Connector	Connector, 2-pole	Component	HEV

C	8092	Splice	Splice, RTS	Instrument panel	RTS
C	8093	Splice	Splice	Component	VIS
C	8094	Splice	Splice	Component	VIS
C	8095	Splice	Splice	Component	HEV
C	8096	Junction block	Junction block	Frame	HEV
C	8097	Cut cable	Cut cable	Floor	CSS
C	8098	Splice	Splice, INL	Roof shelf upper	INL
C	8099	Splice	Splice, sub-CAN H	Instrument panel	CCS
C	8100	Splice	Splice, sub-CAN L	Instrument panel	CCS
C	8101	Splice	Splice, sub-CAN H	Floor	INL
C	8102	Splice	Splice, sub-CAN L	Floor	INL
C	8103	Splice	Splice, POW	Instrument panel	POW
C	8104	Connector	Connector, 2-pole	Roof_rear	INL
C	8105	Connector	Connector, 2-pole	Engine	EMS
D	16	Diode	Diode, diff lock	Instrument panel	RDL
D	17	Diode	Diode, diff lock	Instrument panel	RDL
D	25	Diode	Light emitting diode roof shelf	Roof shelf	LAS
D	35	Sensor	Sensor, throttle pedal	Instrument panel	COO
D	39	Module	Foot brake module	Bumper	BMS/EBBS
D	40	Diode	Diode	Instrument panel	VIS
D	54	Resistor unit	Resistor unit, limited hand throttle	Instrument panel	COO
D	60	Sensor	Sensor, clutch pedal	Instrument panel	COO
D	61	Sensor	Sensor, brake pedal	Instrument panel	COO
D	62	Resistor unit	Resistor unit, 4,7kOhm	Instrument panel	FAS
D	63	Resistor	Resistor, 220Ohm	Frame	EEC
D	64	Resistor	Resistor, 10kOhm	Component	VIS
D	65	Diode	Diode, CAT	Instrument panel	CAT
D	66	Transistor unit	Transistor unit, DIS	Instrument panel	DIS
D	67	Resistor	Brake resistor		
D	68	Diode unit	Diode unit	Instrument panel	LAS
D	69	Diode unit	Diode unit	Instrument panel	LAS
D	70	Resistor	Resistor	Frame	EMS
D	71	Diode unit	Diode unit	Instrument panel	VIS
D	72	Resistor	Resistor, RTG	Instrument panel	RTG
D	73	Resistor	Resistor, Termination 120 Ohm	Instrument panel	CCS
D	74	Resistor	Resistor, Termination 120 Ohm	Floor	INL
E	1	Control unit	Control unit, RTI/SVI	Instrument panel	RTI/SVI
E	5	Control unit	Control unit, opticruise	Instrument panel	GMS
E	6	Sensor	Hall sensor, gearbox	Frame	GMS
E	7	Control unit	Control unit alarm	Instrument panel	LAS
E	10	Limiter	Current limiter	Frame	POW
E	11	Control unit	Control unit, airbag, belt pretensioner	Floor	CSS
E	16	Control unit	Control unit, alert signal	Roof shelf	ALERT
E	17	Control unit	Control unit, climate	Instrument panel	CCS
E	18	Control unit	Control unit , SMS	Instrument panel	SMS
E	21	Control unit	Control unit, tag axle lift	Instrument panel	TAL
E	23	Control unit	Control unit, general lighting exclusive	Instrument panel	INL
E	28	Control unit	Control Unit, automatic gearbox	Instrument panel	GMS
E	30	Control unit	Control unit coordinator	Instrument panel	COO
E	32	Control unit	Control unit CUV	Instrument panel	VIS
E	33	Control unit	Control unit FM-Radio	Instrument panel	AUS
E	34	Converter	Voltage converter	Instrument panel	POW
E	35	Radio	CB radio	Roof shelf	CB radio
E	36	Amplifier	Amplifier	Roof	AUS
E	37	Control unit	Control unit, ABS	Instrument panel	BMS/ABS

E	43	Control unit	Control unit, EBS	Instrument panel	BMS/EBS
E	44	Control unit	Control unit, EMS	Engine	EMS
E	45	Control unit	Control unit, ACL	Frame	ACL
E	49	Control unit	Control unit, immobiliser	Instrument panel	COO
E	51	Control unit	Control unit, FMS-prep	Instrument panel	FMS
E	52	Converter	Pocket PC	Instrument panel	FAS
E	53	Control unit	Signal amplifier	Instrument panel	TCO
E	54	Control unit	Control unit, HVF	Instrument panel	HVF
E	55	Control unit	Control unit, VDC	Roof shelf	FAS
E	56	Control unit	Control unit, APS	Bumper	APS
E	57	Control unit	Control unit, BWS	Instrument panel	BWS
E	58	Control unit	Mute-function	Instrument panel	FAS
E	59	Control unit	Control unit, battery master switch	Battery box	POW
E	62	Puls converter	Puls converter	Instrument panel	TCO
E	65	Control unit	Control unit, AWD	Instrument panel	AWD
E	66	Control unit	Control unit, FAS	Instrument panel	FAS
E	67	Control unit	Control unit, EEC	Component	EEC
E	68	Amplifier	Amplifier, aerial	Instrument panel	RTI
E	69	Amplifier	Amplifier	Instrument panel	FAS
E	70	Control unit	Control unit, DIS	Bumper	DIS
E	71	Control unit	Control unit, DAS	Instrument panel	DAS
E	72	Converter	Voltage converter	Instrument panel	PPC
E	73	Control unit	Control unit, RTI	Instrument panel	RTI
E	74	Control unit	Control unit	Roof shelf	TOL
E	75	DSRC module	DSRC module	Instrument panel	TOL
E	76	Screen	Screen	Instrument panel	RTI
E	77	Control unit	Control unit, CLS	xx	xx
E	78	Control unit	Control unit, TPM	Frame	TPM
E	79	Control unit	Control unit, LDW	Instrument panel	LDW
E	80	Control unit	Control unit, AID	Instrument panel	AID
E	81	Control unit	Control unit, BMU	Frame	HEV
E	82	Control unit	Control unit, MGU	Frame	HEV
E	83	Control unit	Battery pack	Frame	HEV
E	84	Control unit	Control unit, DCC1	Frame	HEV
E	85	Control module	Control module, Ignition output stage	Engine	EMS
E	86	Control module	Control module, Ignition output stage	Engine	EMS
E	87	Control module	Control module, Ignition output stage	Engine	EMS
E	88	Control unit	Control unit, GCS	Engine	EMS
E	89	Control unit	Control unit, RTC	Instrument panel	RTC
E	90	Control unit	Control unit, DCC2	Frame	HEV
E	92	Control unit	Control unit, FM radio w. Navi	Instrument panel	AUS
E	93	Control unit	Control unit, ECA	Gearb	ECA
E	94	I/O-Expander	LIN I/O-expander	Instrument panel	SMS
E	95	Control unit	Control unit, RVI	Instrument panel	RVI
E	99	Video converter	Video converter	Instrument panel	
E	100	Control unit	Control unit, FM Radio	Instrument panel	AUS
E	101	Control unit	Control unit, FLC	Instrument panel	FLC
E	102	Control unit	Control unit, ROH	Roof	ROH
E	103	Control unit	Control unit, OCS	Engine	EMS
E	104	Control unit	Control unit Ignition	Engine	EMS
E	105	Converter	Voltage converter, 24 DC-230 AC	Instrument panel	POW
E	106	Control unit		Door driver	DCS
E	107	Control unit		Door passenger	DCS
E	108	Control unit		Door_rear_left	DCS
E	109	Control unit		Door_rear_right	DCS



E	110	Module	CAN Module	Engine	EMS
E	111	Control unit	Control unit, BCI	Instrument panel	BWE
E	112	Control unit	Control unit, EST	Frame	EST
E	113	Control unit	Control unit, CMS	Frame	CMS
E	114	Control unit	Control unit, COL	Frame	COL
E	115	Expansion unit	Expansion unit A, BCI	Frame	BWE
E	116	Expansion unit	Expansion unit B, BCI	Frame	BWE
E	117	Expansion unit	Expansion unit C, BCI	Frame	BWE
E	118	Expansion unit	Expansion unit D, BCI	Frame	BWE
E	119	Expansion unit	Expansion unit E, BCI	Frame	BWE
E	120	Expansion unit	Expansion unit F, BCI	Frame	BWE
E	121	Expansion unit	Expansion unit G, BCI	Frame	BWE
E	122	Expansion unit	Expansion unit H, BCI	Frame	BWE
E	123	Expansion unit	Expansion unit I, BCI	Frame	BWE
E	124	Battery charger	Battery charger	Frame	POW
E	125	Display	Display, radio	Instrument panel	AUS/MIB
E	126	Module	Module supply	Front Grill	VIS
E	127	Module	Module supply	Front Grill	VIS
E	128	Control unit	Control unit, EPP	Frame	EPP
E	129	Battery equalize	Battery equalizer	Frame	POW
F	4	Fuse	Fuse, KIT	Instrument panel - Roof	KIT
F	5	Fuse holder	Fuse holder, 8-pole	Instrument panel	Common
F	8	Fuse	Fuse	Frame	POW
F	9	Fuse holder	Fuse holder, 4-pole	Instrument panel	COO
F	10	Fuse holder	Fuse holder, 2-pole	Component	TAL
F	11	Fuse holder	Fuse holder, 2-pole	Roof shelf	FAS
F	12	Fuse holder	Fuse holder, 2-pole	Roof shelf	FAS
F	13	Fuse holder	Fuse holder, 2-pole	Instrument panel	RTI/SVI
F	14	Fuse holder	Fuse holder, 4-pole	Instrument panel	Common
F	15	Fuse holder	Fuse holder, 4-pole	Instrument panel	Crew cab
F	16	Fuse holder	Fuse holder, 1-pole	Frame	Crew cab
F	17	Fuse holder	Fuse holder, 8-pole	Instrument panel	Common
F	18	Fuse holder	Fuse holder, 6-pole	Roof shelf	Common
F	19	Fuse holder	Fuse holder, 2-pole	Instrument panel	RTI/General
F	20	Fuse	Fuse, FCS	Battery box	FCS
F	21	Fuse holder	Fuse holder, 4-pole	Instrument panel	BWS
F	22	Fuse holder	Fuse holder, 8-pole	Instrument panel	BWS
F	23	Fuse holder	Fuse holder	Frame	BWE
F	24	Fuse	Fuse	Frame	POW
F	25	Fuse holder	Fuse holder, 1-pole, POW, TCO, RH battery	Battery box	POW
F	26	Fuse	Fuse	Frame	POW
F	27	Fuse holder	Fuse holder, 2-pole	Instrument panel	EHW
F	28	Fuse holder	Fuse holder, 8-pole	Instrument panel	RTS
G	1	Ground	Joint connector, ground	Instrument panel	POW
G	2	Ground	Joint connector, ground	Instrument panel	POW
G	3	Ground	Joint connector, ground	Instrument panel	POW
G	4	Ground	Joint connector, ground	Instrument panel	POW
G	5	Ground	Joint connector, ground	Instrument panel	POW
G	8	Ground	Ground, floor	Floor	Common
G	8.A	Ground		Floor	Common
G	8.B	Ground		Floor	Common
G	8.C	Ground		Floor	Common
G	8.D	Ground		Floor	Common
G	8.E	Ground		Floor	Common
G	8.F	Ground		Floor	Common

G	8.G	Ground		Floor	Common
G	8.H	Ground		Floor	Common
G	8.I	Ground		Floor	Common
G	8.J	Ground		Floor	Common
G	8.K	Ground		Floor	Common
G	8.L	Ground		Floor	Common
G	9	Ground	Joint connector, ground	Roof shelf	Common
G	10	Ground	Ground, roof	Roof	Common
G	10.A	Ground	Ground, roof	Roof	Common
G	10.B	Ground	Ground, roof	Roof	Common
G	10.C	Ground	Ground, roof	Roof	Common
G	10.D	Ground	Ground, roof	Roof	Common
G	10.E	Ground	Ground, roof	Roof	Common
G	10.F	Ground	Ground, roof	Roof	Common
G	10.G	Ground	Ground, roof	Roof	Common
G	10.H	Ground	Ground, roof	Roof	Common
G	10.I	Ground	Ground, roof	Roof	Common
G	10.J	Ground	Ground, roof	Roof	Common
G	10.K	Ground	Ground, roof	Roof	Common
G	10.L	Ground	Ground, roof	Roof	Common
G	12	Ground	Ground, el-central unit	Instrument panel	Common
G	13	Ground	Ground, torpedo wall	Instrument panel - Frame	Common
G	13.A	Ground		Instrument panel	Common
G	13.B	Ground		Instrument panel	Common
G	13.C	Ground		Instrument panel	Common
G	13.D	Ground		Instrument panel	Common
G	13.E	Ground		Instrument panel	Common
G	13.F	Ground		Instrument panel	Common
G	13.G	Ground		Instrument panel	Common
G	13.H	Ground		Instrument panel	Common
G	13.I	Ground		Instrument panel	Common
G	13.J	Ground		Instrument panel	Common
G	13.K	Ground		Instrument panel	Common
G	13.L	Ground		Instrument panel	Common
G	13.M	Ground		Frame	Common
G	13.N	Ground		Frame	Common
G	13.O	Ground		Frame	Common
G	13.P	Ground		Frame	Common
G	13.Q	Ground		Frame	Common
G	13.R	Ground		Frame	Common
G	13.S	Ground		Frame	Common
G	13.T	Ground		Frame	Common
G	13.U	Ground		Frame	Common
G	13.V	Ground		Frame	Common
G	13.X	Ground		Frame	Common
G	13.Y	Ground		Frame	Common
G	13.Z	Ground		Frame	COO
G	13.W	Ground		Frame	Common
G	14	Ground	Ground, torpedo wall	Instrument panel	Common
G	14.A	Ground		Instrument panel	Common
G	14.B	Ground		Instrument panel	Common
G	14.C	Ground		Instrument panel	Common
G	14.D	Ground		Instrument panel	Common
G	14.E	Ground		Instrument panel	Common
G	14.F	Ground		Instrument panel	Common

G	14.G	Ground		Instrument panel	Common
G	14.H	Ground		Instrument panel	Common
G	14.I	Ground		Instrument panel	Common
G	14.J	Ground		Instrument panel	Common
G	14.K	Ground		Instrument panel	Common
G	14.L	Ground		Instrument panel	Common
G	15	Ground	Ground, torpedo wall	Instrument panel	Common
G	15.A	Ground		Instrument panel	Common
G	15.B	Ground		Instrument panel	Common
G	15.C	Ground		Instrument panel	Common
G	15.D	Ground		Instrument panel	Common
G	15.E	Ground		Instrument panel	Common
G	15.F	Ground		Instrument panel	Common
G	15.G	Ground		Instrument panel	Common
G	15.H	Ground		Instrument panel	Common
G	15.I	Ground		Instrument panel	Common
G	15.J	Ground		Instrument panel	Common
G	15.K	Ground		Instrument panel	Common
G	15.L	Ground		Instrument panel	Common
G	16	Ground	Ground, roof	Roof	Common
G	16.A	Ground		Roof	Common
G	16.B	Ground		Roof	Common
G	16.C	Ground		Roof	Common
G	16.D	Ground		Roof	Common
G	16.E	Ground		Roof	Common
G	16.F	Ground		Roof	Common
G	16.G	Ground		Roof	Common
G	16.H	Ground		Roof	Common
G	16.I	Ground		Roof	Common
G	16.J	Ground		Roof	Common
G	16.K	Ground		Roof	Common
G	16.L	Ground		Roof	Common
G	17	Ground	Ground, floor	Floor	Common
G	17.A	Ground		Floor	Common
G	17.B	Ground		Floor	Common
G	17.C	Ground		Floor	Common
G	17.D	Ground		Floor	Common
G	17.E	Ground		Floor	Common
G	17.F	Ground		Floor	Common
G	17.G	Ground		Floor	Common
G	17.H	Ground		Floor	Common
G	17.I	Ground		Floor	Common
G	17.J	Ground		Floor	Common
G	17.K	Ground		Floor	Common
G	17.L	Ground		Floor	Common
G	20	Ground	Ground, cab front	Front	Common
G	21	Ground		Front	Common
G	21.A	Ground		Front	Common
G	21.B	Ground		Front	Common
G	21.C	Ground		Front	Common
G	21.D	Ground		Front	Common
G	22	Ground		Front	Common
G	22.A	Ground		Front	Common
G	22.B	Ground		Front	Common
G	22.C	Ground		Front	Common

G	22.D	Ground		Front	Common
G	27	Ground	Ground, frame	Frame	EMS/GMS
G	29	Ground	Ground, engine	Engine	EMS
G	30	Ground	Ground, frame	Frame	Common
G	30.A	Ground		Frame	Common
G	32	Ground	Ground, frame	Frame	Common
G	33	Ground	Ground, frame	Frame	Common
G	42	Ground	Ground, frame	Frame	Common
G	46	Ground	Ground, frame	Frame	BWS
G	47	Ground	Ground, frame	Frame	BWS
G	48	Ground	Ground, floor	Floor	Crew cab
G	48.A	Ground	Ground, floor	Floor	Crew cab
G	48.B	Ground	Ground, floor	Floor	Crew cab
G	48.C	Ground	Ground, floor	Floor	Crew cab
G	48.D	Ground	Ground, floor	Floor	Crew cab
G	49	Ground	Ground, component	Component	Common
G	50.A	Ground	Ground, engine, GCS	Engine	EMS
G	50.B	Ground	Ground, engine, GCS	Engine	EMS
G	50.C	Ground	Ground, engine, GCS	Engine	EMS
G	51	Ground	Ground, Rear frame end	Frame	POW
G	52	Ground	Ground, Jump start	Frame	POW
G	53	Ground	Ground, engine, GCS	Engine	EMS
G	54	Ground	Ground, left side member, rear	Frame	BWS
G	55	Ground	Ground, ECA, frame	Frame	ECA
G	56	Ground	Ground, engine, GCS	Engine	EMS
G	57	Ground	Ground, engine, GCS	Engine	EMS
G	58	Ground	Ground, engine, GCS	Engine	EMS
G	59	Ground	Ground, engine, GCS	Engine	EMS
G	60	Ground	Ground	Frame	HEV
G	61.A	Ground	Ground, Engine, OCS	Engine	EMS
G	61.B	Ground	Ground, Engine, OCS	Engine	EMS
G	61.C	Ground	Ground, Engine, OCS	Engine	EMS
G	62	Ground	Ground, Engine, OCS	Engine	EMS
G	63	Ground	Ground	Frame	HEV
G	64	Ground	Ground, roof shelf	Roof shelf	Pow, Common
G	65	Ground	Ground, roof shelf	Roof shelf	Pow, Common
G	66	Ground	Ground, floor passenger side	Floor	Pow, Common
G	67	Ground	Ground, Frame	Frame	Pow, Common
G	68	Ground	Ground, Frame	Frame	Pow, Common
G	69	Ground	Ground, Instrument panel	Instrument panel	POW
G	70	Ground	Ground, Body builder	Instrument panel	BWE
G	71	Ground	Ground, Body builder	Instrument panel	BWE
G	72.A	Ground	Ground, Screen	Engine	EMS
G	72.B	Ground	Ground, Screen	Engine	EMS
G	72.C	Ground	Ground, Screen	Engine	EMS
G	72.D	Ground	Ground, Screen	Engine	EMS
G	72.E	Ground	Ground, Screen	Engine	EMS
G	73.A	Ground	Ground	Engine	EMS
G	73.B	Ground	Ground	Engine	EMS
G	73.C	Ground	Ground	Engine	EMS
G	73.D	Ground	Ground	Engine	EMS
G	73.E	Ground	Ground	Engine	EMS
G	74.A	Ground	Ground	Engine	EMS
G	74.B	Ground	Ground	Engine	EMS
G	75	Ground	Ground	Roof shelf	KIT

G	76	Ground	Ground, BWE	Roof shelf	BWE
G	77	Ground	Ground, frame	Frame	EST
G	78	Ground	Ground	Component	HEV
G	79	Ground	Ground	Component	HEV
G	80	Ground	Ground	Component	HEV
G	81	Ground	Ground	Component	HEV
G	82	Ground	Ground	Component	HEV
H	1	Lighter	Cigarette lighter	Instrument panel	ASH
H	2	Heater	Electrical heated rear view mirror	Door driver	MIH
H	3	Heater	Electrical heated rear view mirror	Door passenger	MIH
H	4	Heater	Heater, air processing unit	Bumper	APS
H	5	Heater	Heating element, seat, driver	Floor	SEAT
H	6	Heater	Heating element, seat, passenger	Floor	SEAT
H	7	Heater	Heating element, backrest, driver	Floor	SEAT
H	8	Heater	Heating element, backrest, passenger	Floor	SEAT
H	9	Heater	Electrical heated wide angle mirror	Door passenger	MIH
H	12	Heater	Heater, water to air	Frame	AHS
H	12.A	Heater	Power supply	Frame	AHS
H	12.B	Heater	CAN interface and communication	Frame	AHS
H	12.C	Heater	Fuel metering	Frame	AHS
H	12.D	Heater	Water pump	Frame	AHS
H	13	Heater	Heater, air to air	Floor	AHS
H	14	Squib unit	Squib unit, airbag	Instrument panel	CSS
H	15	Heater	Heater, fuel filter	Frame	FHS
H	16	Squib unit	Squib unit, seat belt	Floor	CSS
H	17	Squib unit	Squib unit, seat belt	Floor	CSS
H	18	Heater	Heater, water sep fuel filter	Frame	FHS
H	21	Auxiliary equip	Micro oven	Roof	KIT
H	22	Auxiliary equip	Coffemaker	Roof shelf upper	KIT
H	23	Lighter	Cigarette lighter, passenger	Floor	ASH
H	24	Lighter	Cigarette lighter, driver	Floor	ASH
H	25	Heater	Heater, Hose heater	Frame	EEC
H	26	Heater	Heater, Hose heater	Frame	EEC
H	27	Heater	Heater, Hose heater	Frame	EEC
H	28	Heater	Heater, Hose heater	Frame	EEC
H	29	Heater	Heater, Hose heater	Frame	EEC
H	30	Squib unit	Squib unit, Left side rollover airbag		CSS
H	31	Squib unit	Squib unit, Right side rollover airbag		CSS
H	32	Heater	Heater, RESS	Component	HEV
H	33	Heater	Electrical heated front mirror	Roof_rear	DCS
H	34	Heater	Electrical heated side mirror	Door passenger	DCS
H	35	Heater	Heater EI heated windscreen	Instrument panel	EHW
K	1	Diagnostics	Diagnostics outlet	Instrument panel	COO
K	2	Diagnostics	Diagnostics outlet, automatic gearbox	Instrument panel	GMS
L	1	Lamp	Dipped beam, LH	Bumper	VIS
L	2	Lamp	Dipped beam, RH	Bumper	VIS
L	3	Lamp	High beam, LH	Bumper	VIS
L	4	Lamp	High beam, RH	Bumper	VIS
L	5	Lamp	Outer storage box, lamp, driver	Floor	INL
L	6	Lamp	Outer storage box, lamp, passenger	Floor	INL
L	7	Lamp	Position light, front LH	Bumper	VIS
L	8	Lamp	Position light, front RH	Bumper	VIS
L	9	Lamp	Direc ind light, front	Bumper	VIS
L	10	Lamp	Direc ind light, front	Bumper	VIS
L	11	Lamp	Distance light	Bumper	VIS

L	12	Lamp	Distance light	Bumper	VIS
L	13	Lamp	Front fog light, left	Bumper	VIS
L	14	Lamp	Front fog light, right	Bumper	VIS
L	15	Lamp	Work light	Roof	VIS
L	16	Lamp	Work light	Roof	VIS
L	17	Lamp	Rotating beacon	Roof	VIS
L	32	Lamp	Boarding step lamp, driver	Door driver	INL
L	33	Lamp	Boarding step lamp, passenger	Door passenger	INL
L	36	Lamp	Work light	Floor	VIS
L	37	Lamp	Direction indicator light, left	Frame	VIS
L	38	Lamp	Direction indicator light, right	Frame	VIS
L	39	Lamp	Tail light, l side	Frame	VIS
L	40	Lamp	Tail light, r side	Frame	VIS
L	41	Lamp	Stop light, l side	Frame	VIS
L	42	Lamp	Stop light, r side	Frame	VIS
L	43	Lamp	Reverse light, l side	Frame	VIS
L	44	Lamp	Rear fog light, l side	Frame	VIS
L	45	Lamp	End out marker light,	Sunvisor	VIS
L	46	Lamp	End out marker light,	Sunvisor	VIS
L	47	Lamp	No. plate light, left	Frame	VIS
L	48	Lamp	No. plate light, right	Frame	VIS
L	51	Lamp	Signlamp	Roof	VIS
L	54	Lamp	Headlining lamp, driver	Roof	INL
L	55	Lamp	Headlining lamp, passenger	Roof	INL
L	56	Lamp	Bed lamp, lower, driver	Floor	INL
L	58	Lamp	Bed lamp, upper, driver	Roof	INL
L	61	Lamp	Bed lamp, lower, passenger	Floor	INL
L	62	Lamp	Bed lamp, upper, passenger	Roof	INL
L	63	Lamp	Distance light	Sunvisor	VIS
L	64	Lamp	Distance light	Sunvisor	VIS
L	65	Lamp	Rotating beacon	Roof	VIS
L	67	Lamp	Side marker lamp	Frame	VIS
L	68	Lamp	Side marker lamp	Frame	VIS
L	69	Lamp	Side marker lamp	Frame	VIS
L	69X	Lamp	Side marker lamp	Frame	VIS
L	70	Lamp	Side marker lamp	Frame	VIS
L	71	Lamp	Reading lamp	Roof_rear	Crew cab
L	72	Lamp	Reading lamp	Roof_rear	Crew cab
L	73	Lamp	General lighting	Roof_rear	Crew cab
L	74	Lamp	General lighting	Roof_rear	Crew cab
L	78	Lamp	Boarding step light	Door_rear_left	Crew cab
L	79	Lamp	Boarding step light	Door_rear_right	Crew cab
L	80	Lamp	Fluorescent tube	Roof_rear	Crew cab
L	84	Lamp	ID-light,	Sunvisor	VIS
L	85	Lamp	ID-light,	Sunvisor	VIS
L	86	Lamp	ID-light,	Sunvisor	VIS
L	91	Lamp	Reverse light, r side	Frame	VIS
L	92	Lamp	Rear fog light, r side	Frame	VIS
L	93	Lamp	End out marker light, l side	Frame	VIS
L	94	Lamp	End out marker light, r side	Frame	VIS
L	95	Lamp	Number plate light	Frame	VIS
L	96	Lamp	Side marker lamp	Frame	VIS
L	97	Lamp	Side marker lamp	Frame	VIS
L	98	Lamp	Side marker lamp	Frame	VIS
L	99	Lamp	Side marker lamp	Frame	VIS

L	100	Lamp	Rotating beacon	Roof	VIS
L	101	Lamp	Rear combination lamp, left	Frame	VIS
L	102	Lamp	Rear combination lamp, right	Frame	VIS
L	101,2	Lamp	Connector, Rear combination lamp	Frame	VIS
L	101X,2X	Lamp	Connector, Rear combination lamp	Frame	VIS
L	114	Lamp	Lamp, upper roofshelf, INL	Roof shelf upper	INL
L	115	Lamp	Lamp, upper roofshelf, INL	Roof shelf upper	INL
L	116	Lamp	Lamp, upper roofshelf, INL	Roof shelf upper	INL
L	117	Lamp	Lamp, upper roofshelf, INL	Roof shelf upper	INL
L	118	Lamp	Lamp, upper roofshelf, INL	Roof shelf upper	INL
L	119	Lamp	Lamp, upper roofshelf, INL	Roof shelf upper	INL
L	120	Lamp	Lamp, overhead locker, INL	Roof	INL
L	121	Lamp	Category six lamp	Bumper	VIS
L	122	Lamp	Category six lamp	Bumper	VIS
L	123	Lamp	Bodybuilder lamp, BWS	Instrument panel	BWS
L	124	Lamp	Bodybuilder lamp, BWS	Instrument panel	BWS
L	125	Lamp	Bodybuilder lamp, BWS	Instrument panel	BWS
L	126	Lamp	Bodybuilder lamp, BWS	Instrument panel	BWS
L	127	Lamp	Gasdischarge lamp, left	Bumper	VIS
L	128	Lamp	Gasdischarge lamp, right	Bumper	VIS
L	129	Lamp	Gasdischarge lamp, dir. Ind, left	Bumper	VIS
L	130	Lamp	Gasdischarge lamp, dir. Ind, right	Bumper	VIS
L	131	Lamp	Side marker front, left	Bumper	VIS
L	132	Lamp	Side marker front, right	Bumper	VIS
L	133	Lamp	Lamp, illumination under dashboard	Instrument panel	INL
L	134	Lamp	Ashtray light	Floor	ASH
L	135	Lamp	Ashtray light	Floor	ASH
L	136	Lamp	Lamp, storage light, LH	Floor	Crew cab
L	137	Lamp	Lamp, storage light, RH	Floor	Crew cab
L	138	Lamp	Dir/Pos lamp, front LH	Bumper	VIS
L	139	Lamp	Dir/Pos lamp, front RH	Bumper	VIS
L	140	Lamp	Headlamp, LH	Bumper	VIS
L	141	Lamp	Headlamp, RH	Bumper	VIS
L	142	Lamp	Rotating beacon	Roof	VIS
L	143	Lamp	Map reading lamp	Roof shelf	INL
L	144	Lamp	Ambient light, under instrument panel	Instrument panel	INL
L	145	Lamp	Daytime runing light, left	Bumper	VIS
L	146	Lamp	Daytime runing light, right	Bumper	VIS
L	13/L145	Lamp	Front fog light, left / Daytime runing light, left	Bumper	VIS
L	14/L146	Lamp	Front fog light, right / Daytime runing light, right	Bumper	VIS
L	147	Lamp	Work lamp	Frame	BWS
L	148	Lamp	Work lamp	Frame	BWS
L	149	Lamp	Read lamp, driver	Roof	INL
L	150	Lamp	Read lamp, passenger	Roof	INL
L	160	Lamp	Headlamp unit, LH	Bumper	VIS
L	161	Lamp	Headlamp unit, RH	Bumper	VIS
L	162	Lamp	Door handle light	Door driver	DCS
L	163	Lamp	Door handle light	Door passenger	DCS
L	164	Lamp	Door handle light	Door_rear_left	DCS
L	165	Lamp	Door handle light	Door_rear_right	DCS
L	166	Lamp	Red warning light	Door driver	DCS
L	167	Lamp	Red warning light	Door passenger	DCS
L	168	Lamp	Red warning light	Door_rear_left	DCS
L	169	Lamp	Red warning light	Door_rear_right	DCS
L	170	Lamp	Door storage light	Door driver	DCS

L	171	Lamp	Door storage light	Door passenger	DCS
L	172	Lamp	Door storage light	Door_rear_left	DCS
L	173	Lamp	Door storage light	Door_rear_right	DCS
L	174	Lamp	Cornering light, left	Bumper	VIS
L	175	Lamp	Cornering light, right	Bumper	VIS
L	176	Lamp	Light below IP	Instrument panel	INL
L	177	Lamp	Light below IP	Instrument panel	INL
L	178	Lamp	Light below IP	Instrument panel	INL
L	179	Lamp	Light below IP	Instrument panel	INL
L	180	Lamp	Light IP centre	Instrument panel	INL
L	181	Lamp	Light below roof shelf centre	Roof shelf	INL
L	182	Lamp	Light open storage above door, left	Roof_rear	INL
L	183	Lamp	Light open storage above door, right	Roof_rear	INL
L	184	Lamp	Light rear side window, left	Roof_rear	INL
L	185	Lamp	Light rear side window, right	Roof_rear	INL
L	186	Lamp	Outer storage below cab, lamp, driver	Floor	INL
L	187	Lamp	Outer storage below cab, lamp, passenger	Floor	INL
L	188	Lamp	Bed lamp exclusive, lower, left	Roof_rear	INL
L	189	Lamp	Bed lamp exclusive, upper, left	Roof_rear	INL
L	190	Lamp	Bed lamp exclusive, lower, right	Roof_rear	INL
L	191	Lamp	Bed lamp exclusive, upper, right	Roof_rear	INL
L	192	Lamp	Light below roof shelf centre	Roof shelf	INL
L	193	Lamp	Lamp, roof shelf rear module	Roof shelf	INL
L	13/L174	Lamp	Front fog light, left / Cornering light, left	Bumper	VIS
L	14/L175	Lamp	Front fog light, right / Cornering light, right	Bumper	VIS
L	194	Lamp	Fog / Cornering light unit, LH	Bumper	VIS
L	195	Lamp	Fog / Cornering light unit, RH	Bumper	VIS
L	194X	Lamp	Connector, Fog / Cornering light unit, LH	Bumper	VIS
L	195X	Lamp	Connector, Fog / Cornering light unit, RH	Bumper	VIS
L	196	Lamp	EOML / Spot lamp unit, LH	Roof_rear	VIS
L	197	Lamp	EOML / Spot lamp unit, RH	Roof_rear	VIS
L	198	Lamp	Lamp, Roof shelf rear	Roof_rear	INL
L	199	Lamp	Lamp, Roof shelf rear	Roof_rear	INL
L	200	Lamp	Sign lamp	Component	VIS
L	201	Lamp	Sign lamp	Component	VIS
L	202	Lamp	Sign lamp	Component	VIS
L	203	Lamp	Sign lamp	Component	VIS
L	204	Lamp	Sign lamp	Component	VIS
L	205	Lamp	Sign lamp	Component	VIS
L	5002	Lamp	Rear combination lamp, right	Frame	VIS
L	5003	Lamp	Rear combination lamp, left	Frame	VIS
M	1	Motor	Starter motor	Engine	EMS
M	2	Motor	Motor, windscreen wiper	Front	VIS
M	3	Motor	Motor fan	Front	CCS
M	4	Motor	Shifting motor recirculation valve	Floor	CCS
M	5	Motor	Motor, head lamp wiper	Bumper	VIS
M	6	Motor	Motor, head lamp wiper, right	Bumper	VIS
M	7	Motor	Motor, windscreen washer	Bumper	VIS
M	8	Motor	Motor, headlamp washer	Bumper	VIS
M	9	Motor	Motor, electric window winder, driver	Door driver	WIW
M	10	Motor	Motor, electric window winder, pass	Door passenger	WIW
M	11	Motor	Motor, hydraulic pump	Frame	TAL
M	12	Motor	Motor roof hatch	Roof	ROH
M	13	Motor	Motor adj. rear view mirror	Door passenger	MIA
M	14	Motor	Motor adj. rear view mirror	Door driver	MIA



M	15	Motor	Motor, el cab tilt pump	Frame	Crew cab
M	16	Motor	Fan motor	Roof_rear	Crew cab
M	17	Motor	Pump motor, short-stop heater	Front	AHS
M	18	Motor	Air distribution motor	Instrument panel	CCS
M	21	Motor	Motor light level control	Bumper	VIS
M	22	Motor	Motor light level control	Bumper	VIS
M	23	Motor	Motor, electric window winder, left	Door_rear_left	Crew cab
M	24	Motor	Motor, electric window winder, right	Door_rear_right	Crew cab
M	26	Motor	Motor, Rear view mirror	Roof	MIF
M	27	Motor	Fan motor AC	Roof_rear	Crew cab
M	28	Motor	Motor, electrical actuator EGR 1	Engine	EMS
M	29	Motor	Motor, power supply VGT	Engine	EMS
M	30	Motor	Motor, electrical actuator VGT	Engine	EMS
M	31	Motor	Motor, fan auxiliary cooler	Bumper	COO
M	32	Motor	Motor, Fan FCS	Frame	FCS
M	33	Electric machine	Electric machine	Component	HEV
M	34	Motor	Motor, throttle	Engine	EMS
M	35	Motor	Motor, fan auxiliary cooler	Frame	ATC
M	36	Motor	Motor, fan auxiliary cooler	Frame	ATC
M	37	Motor	Motor, Fan FCS	Frame	FCS
M	38	Motor	Coolant pump, RES	Frame	HEV
M	39	Motor	Cooling fan	Frame	HEV
M	40	Motor	Motor, Fan	Frame	HEV
M	41	Motor	Coolant pump, MGS	Frame	HEV
M	42	Motor	Motor, air inlet throttle	Engine	EMS
M	43	Motor	Motor, seat cushion ventilation driver	Component	SCS
M	44	Motor	Motor, seat backrest ventilation driver	Component	SCS
M	45	Motor	Motor, Front mirror actuator	Roof	DCS
M	46	Motor	Motor, Side mirror actuator	Roof	DCS
M	47	Motor	Door lock actuator	Door driver	DCS
M	48	Motor	Door lock actuator	Door passenger	DCS
M	49	Motor	Door lock actuator	Door_rear_left	DCS
M	50	Motor	Door lock actuator	Door_rear_right	DCS
M	51	Motor	Motor, seat cushion ventilation passenger	Component	SCS
M	52	Motor	Motor, seat backrest ventilation passenger	Component	SCS
M	53	Motor	Motor, hydraulic pump	Frame	EST
M	54	Motor	Motor, condensor fan parking cooler	Frame	COL
M	55	Motor	Motor, dual-circuit steering	Frame	CMS
M	56	Motor	Motor, Temp control flap	Component	CCS
M	57	Motor	Motor, Panel/floor flap control	Component	CCS
M	58	Motor	Motor, Air intake control	Component	CCS
M	59	Motor	Motor, Air dist./defrost stepper	Component	CCS
M	60	Motor	Motor, Recirc./aqs control	Component	CCS
M	61	Motor	Motor, Fan	Frame	HEV
N	2	Signal horn	Signal horn, air	Bumper	VIS
N	2/C5	Signal horn	Signal horn, air / Connector, 2-pole	Bumper	VIS
N	3	Loud speaker	Loud speaker, treble driver	Roof	AUS
N	4	Loud speaker	Loud speaker, treble passenger	Roof	AUS
N	5	Loud speaker	Loud speaker, CB-radio	Roof shelf	CB radio
N	5.B	Loud speaker	Loud speaker, CB-radio	Roof shelf	RTI/SVI
N	6	Loud speaker	Loud speaker	Door_rear_right	Crew cab
N	7	Loud speaker	Loud speaker	Door_rear_left	Crew cab
N	9	Sounder	Sounder	Floor	LAS
N	10	Sounder	Reverse alarm	Frame	VIS
N	13	Loud speaker	Loud speaker, door driver	Door driver	AUS

N	14	Loud speaker	Loud speaker, door passenger	Door passenger	AUS
N	16	Subwoofer	Subwoofer	Roof	AUS
N	17	Signal horn	Signal horn, el	Bumper	VIS
N	2/N17	Signal horn	Signal horn, el/air	Bumper	VIS
N	18	Loud speaker	Left loud speaker, DAU	Instrument panel	DAU
N	19	Loud speaker	Right loud speaker, DAU	Instrument panel	DAU
N	20	Loud speaker	Loud speaker, door driver	Door driver	AUS/DAU
N	21	Loud speaker	Loud speaker, door passenger	Door passenger	AUS/DAU
O	1	Instrument	Combination instrument	Instrument panel	ICL
O	1A	Instrument	Combination instrument	Instrument panel	ICL
O	1B	Instrument	Combination instrument	Instrument panel	ICL
O	1.A	Instrument	Combination instrument	Instrument panel	ICL
O	1.B	Instrument	Combination instrument	Instrument panel	ICL
O	2	Timer	Clock timer	Floor	AHS
O	4	Tachograph	Tachograph	Roof shelf	TCO
O	4.A	Tachograph	Tachograph	Roof	RTC
O	4.C	Tachograph	Tachograph	Roof	RTC
O	17	Tachograph	Tachograph	Roof shelf	TCO
O	22	Counter	Engine time counter	Instrument panel	EMS
P	1.A	Battery	Battery	Frame	POW
P	1.B	Battery	Battery	Frame	POW
P	1.C	Battery	Battery, Dual Start	Frame	POW
P	1.D	Battery	Battery, Dual Start	Frame	POW
P	1.E	Battery	Battery, Dual Power	Frame	POW
P	1.F	Battery	Battery, Dual Power	Frame	POW
P	2	Central el. unit	Central electric unit	Instrument panel	POW
P	3	Alternator	Alternator	Engine	EMS
P	7	El unit	Electric unit	Frame	HEV
P	8	Central el. unit	Central electric unit, chassis	Frame	POW
P	9	Central el. unit	Central electric unit, body builder	Instrument panel	BWE
P	10	Electric machine	Electric machine	Component	HEV
P	11	Power distributor	Power distributor, chassis	Frame	POW
R	8	Relay	Relay, stop light	Instrument panel	VIS
R	14	Relay	Relay, 15A	Instrument panel	POW
R	19	Relay	Relay, 61	Instrument panel	POW
R	20	Relay	Relay, 15B	Instrument panel	POW
R	21	Relay	Relay, 58	Instrument panel	POW
R	24	Relay	Relay, reverse light	Instrument panel	VIS
R	39	Relay	Relay, interior lighting basic	Instrument panel	INL
R	43	Relay	Relay, heater, water sep. filter	Instrument panel	FHS
R	44	Relay	Relay, tag axle lift	Component	TAL
R	46	Relay	Relay, heater, fuel filter	Instrument panel	FHS
R	56	Relay	Relay, cab tilt	Instrument panel	CAT
R	70	Relay	Relay, ADR, batt	Battery box	POW
R	75	Relay	Relay, trailer identifier	Instrument panel	HVF
R	77	Relay	Relay, ADR, instr	Instrument panel	POW
R	78	Relay	Relay, extra AC	Instrument panel	Crew cab
R	80	Relay	Relay, 15	Instrument panel	Crew cab / S-order
R	81	Relay	*opt*		VIS
R	82	Relay	*opt*		VIS
R	83	Relay	*opt*		VIS
R	84	Relay	*opt*		VIS
R	85	Relay	Relay, UCS	Instrument panel	EEC
R	86	Relay	Relay, ATL	Instrument panel	ATL
R	87	Relay	Relay, DIS	Instrument panel	DIS

R	88	Holder	Relay holder	Instrument panel	FST
R	88A	Relay	Relay, folding step LH	Instrument panel	FST
R	88B	Relay	Relay, folding step RH	Instrument panel	FST
R	89	Holder	Relay holder	Instrument panel	VIS
R	89A	Relay	Relay, reduced reverse alarm	Instrument panel	VIS
R	89B	Relay	Relay, short-stop heater	Instrument panel	AHS
R	90	Relay			
R	91	Relay	Relay, FCS	Battery box / Instrument panel	FCS
R	92	Relay	Relay, delayed shut off	Instrument panel	RTI
R	93	Relay	Relay, headlamp washer	Instrument panel	VIS
R	94	Relay	Relay, ADR, battery switch	Battery box	POW
R	94.A	Relay	Relay, ADR, battery switch	Frame	POW
R	95	Holder	Relay holder	Instrument panel	COO
R	95A	Relay	Relay, heater, water sep. filter	Instrument panel	COO
R	95B	Relay	Relay, heater, fuel filter	Instrument panel	COO
R	96	Relay	Relay, APC	Instrument panel	APC
R	97	Relay	Relay, Auto down	Instrument panel	WIW
R	99	Relay	Relay, BAD	Instrument panel	BAD
R	100	Relay	Relay, Rear view camera	Instrument panel	
R	101	Relay	Relay, Daytime runing light	Instrument panel	VIS
R	102	Relay	Relay, Daytime runing light	Instrument panel	VIS
R	103	Relay	Relay, FCS	Instrument panel	FCS
R	104	Relay	Relay, FCS	Instrument panel	FCS
R	105	Relay	Relay, Dual battery	Battery box	POW
R	106	Relay	Mini relay, EI heated windscreen	Instrument panel	EHW
R	107	Relay	Power relay, EI heated windscreen	Instrument panel	EHW
R	109	Relay	Relay, interior lighting basic	Instrument panel	INL
R	110	Relay	Relay, ACL	Instrument panel	ACL
R	111	Relay	Relay, 12V 15	Instrument panel	COO
R	112	Relay	Relay, 12V RA	Instrument panel	AUS
R	113	Relay	Relay, DCS	Instrument panel	DCS
R	114	Relay	Relay, DCS	Instrument panel	DCS
R	115	Relay	Relay, Work lamp	Roof_rear	VIS
R	116	Relay	Relay, HEV	Instrument panel	HEV
R	400	Holder	Relay holder, FHS	Instrument panel	FHS
R	401	Holder	Relay holder	Instrument panel	BAD, ??
R	402	Holder	Relay holder	Instrument panel	VIS
R	403	Holder	Relay holder	Instrument panel	VIS
R	404	Holder	Relay holder	Instrument panel	FCS
S	1	Switch	Switch, lighting	Instrument panel	VIS
S	2	Switch	Switch, hazard warning light	Instrument panel	VIS
S	3	Switch	Switch, fan	Instrument panel	CCS
S	4	Switch	Switch, starter	Instrument panel	COO
S	5	Switch	Switch, heated rear mirror	Instrument panel	MIH
S	6	Switch	Switch, exhaust brake power	Instrument panel	COO
S	7	Switch	Switch adj. rear view mirror	Door driver	MIA
S	8	Switch	Switch, rear fog light	Instrument panel	VIS
S	9	Switch	Switch, front fog light	Instrument panel	VIS
S	10	Switch	Switch, distance light	Instrument panel	VIS
S	11	Switch	Switch, tag axle 2 lift, V114	Instrument panel	SMS
S	12	Switch	Switch, diff lock, axle	Instrument panel	RDL
S	13	Switch	Switch, diff lock, tandem	Instrument panel	RDL
S	14	Switch	Switch, tag axle lift	Instrument panel	TAL
S	16	Switch	Switch, air condition	Instrument panel	CCS
S	18	Switch	Switch, worklight, fifth wheel	Instrument panel	VIS

S	20	Switch	Switch, electric window winder, driver	Door driver	WIW
S	21	Switch	Switch, electric window winder, pass	Door driver	WIW
S	22	Switch	Switch, electric window winder, pass	Door passenger	WIW
S	23	Switch	Switch, light level control	Instrument panel	VIS
S	24	Switch	Switch, windscreen wiper, washer	Instrument panel	VIS
S	25	Switch	Switch, dir ind, full/dip beam	Instrument panel	VIS
S	26	Switch	Switch, signal horn	Instrument panel	VIS
S	27	Switch	Switch, distance light	Instrument panel	VIS
S	28	Switch	Switch, pressure horn	Roof shelf	VIS
S	29	Switch	Switch, white smoke limiter	Instrument panel	COO
S	30	Switch	Switch, PTO EG1	Instrument panel	COO
S	31	Switch	Switch, PTO EK	Instrument panel	COO
S	32	Switch	Switch, el roof hatch wall	Floor	ROH
S	33	Switch	Switch, central lock	Floor	LAS
S	34	Switch	Switch, reading light, driver	Roof shelf	INL
S	35	Switch	Switch, general/read light, passenger	Door passenger	INL
S	36	Switch	Switch, interior background light	Roof shelf	INL
S	37	Switch	Switch, alert	Roof shelf	ALERT
S	40	Switch	Switch, battery master switch safety	Frame	POW
S	41	Switch	Switch, central lock	Door driver	LAS
S	42	Switch	Switch, central lock	Door passenger	LAS
S	43	Switch	Switch, retarder	Instrument panel	COO
S	44	Switch	Switch, low/high gear split	Floor	COO
S	48	Switch	Switch, central lock	Instrument panel	LAS
S	49	Switch	Switch, el roof hatch instr p	Instrument panel	ROH
S	51	Switch	Switch, cruise control/display	Component	ICL
S	55	Switch	Switch, battery master switch	Frame	POW
S	56	Switch	Switch, level adjustment	Instrument panel	SMS
S	57	Switch	Switch, general lighting basic	Roof shelf	INL
S	58	Switch	Switch, work light	Instrument panel	VIS
S	59	Switch	Switch, rotating beacon	Roof	VIS
S	60	Switch	Switch, roof sign lighting	Roof	VIS
S	62	Switch	Switch, fuel heater	Instrument panel	FHS
S	63	Switch	Switch, low/high gear range	Floor	COO
S	64	Switch	Switch, converter lockup	Instrument panel	GMS
S	65	Switch	Switch, high placed lights	Instrument panel	VIS
S	66	Switch	Switch, power take off P4	Instrument panel	
S	68	Switch	Switch, recirculation	Instrument panel	CCS
S	70	Switch	Switch, trip reset/clock reset	Instrument panel	ICL
S	71	Switch	Switch, heater, driver	Component	SEAT
S	73	Switch	Switch, ADR, POW	Instrument panel	POW
S	74	Switch	Switch, reverse Alarm	Instrument panel	VIS
S	75	Switch	Switch, alternative levels	Instrument panel	SMS
S	77	Switch	Switch, heater, passenger	Component	SEAT
S	79	Switch	Switch, general light exclusive bed	Floor	INL
S	81	Switch	Switch, gear shift automatic gearbox	Floor	GMS
S	82	Switch	Switch, differential lock, front	Instrument panel	AWD
S	83	Switch	Switch, low gear	Instrument panel	AWD
S	84	Switch	Switch, neutral position	Instrument panel	AWD
S	85	Switch	Switch, differential lock, gear case	Instrument panel	AWD
S	86	Switch	Switch, mobile telephone on/off	Instrument panel	FAS
S	87	Switch	Switch, folding rear mirror	Roof shelf	MIA
S	89	Switch	Switch, radio LH	Instrument panel	
S	90	Switch	Switch, TC off	Instrument panel	BMS/ABS/EBS
S	93	Switch	Switch, radio RH	Instrument panel	

S	101	Switch	Switch, driving mode	Instrument panel	COO
S	102	Switch	Switch, trailer brake	Instrument panel	BMS/EBS
S	105	Switch	Switch, tag axle 1 lift, V55	Instrument panel	SMS
S	106	Switch	Switch, load transfer	Instrument panel	SMS
S	107	Switch	Switch, remote control	Floor	SMS
S	112	Switch	Switch, flourecent tube	Roof_rear	Crew cab
S	113	Switch	Switch, fan	Roof_rear	Crew cab
S	114	Switch	Switch, fan	Roof_rear	Crew cab
S	116	Switch	Switch, cab tilt	Instrument panel	Crew cab
S	117	Switch	Switch, cab tilt	Frame	Crew cab
S	119	Switch	Switch, electric window winder, left	Door_rear_left	Crew cab
S	120	Switch	Switch, electric window winder, right	Door_rear_right	Crew cab
S	121	Switch	Switch, central lock, left	Door_rear_left	Crew cab
S	122	Switch	Switch, central lock, right	Door_rear_right	Crew cab
S	123	Switch	Switch, auxilliary heater	Instrument panel	AHS
S	127	Switch	Switch, central lock	Instrument panel	LAS
S	129	Switch	Switch, panic alarm	Instrument panel	LAS
S	130	Switch	Switch, External equipment	Instrument panel	BWE
S	131	Switch	Switch, on spot/slir ej	Instrument panel	BWS
S	132	Switch	Switch, BWE prep	Instrument panel	BWE
S	133	Switch	Switch, robson drive	Instrument panel	BWS
S	134	Switch	Switch, limited hand throttle	Instrument panel	COO
S	135	Switch	Switch, limited hand throttle	Instrument panel	COO
S	138	Switch	Switch, ID-lamps	Roof shelf	VIS
S	139	Switch	Switch, lighting	Instrument panel	VIS
S	140	Switch	Switch, auxiliary light	Instrument panel	VIS
S	141	Switch	Switch, multi function	Instrument panel	VIS
S	142	Switch	Switch, cruise Control	Instrument panel	COO
S	143	Switch	Switch, general light exclusive instr p	Roof shelf	INL
S	144	Switch	Switch, general/read light, passenger rear left	Door_rear_left	Crew cab
S	145	Switch	Switch, general/read light, passenger rear right	Door_rear_right	Crew cab
S	146	Switch	Switch, read light, passenger rear left	Roof_rear	Crew cab
S	147	Switch	Switch, read light, passenger rear right	Roof_rear	Crew cab
S	148	Switch	Switch, fan extra AC	Roof_rear	Crew cab
S	149	Switch	Switch, illumination under dashboard	Instrument panel	INL
S	150	Switch	Switch, reversible fan	Roof_rear	Crew cab
S	151	Switch	Switch, beacon	Instrument panel	BWS
S	152	Switch	Switch, BWE prep	Instrument panel	BWE
S	153	Switch	Switch, BWE prep	Instrument panel	BWE
S	154	Switch	Switch, BWE prep	Instrument panel	BWE
S	155	Switch	Switch, DIS	Instrument panel	DIS
S	156	Switch	Switch, AC	Instrument panel	Crew cab
S	157	Switch	Switch, AC	Roof_rear	Crew cab
S	158	Switch	Switch, Fan, AC	Roof_rear	Crew cab
S	159	Switch	Switch, Time gap	Instrument panel	COO
S	160	Switch	Switch, AICC enable	Instrument panel	DIS
S	161	Switch	Switch, CC enable	Instrument panel	DIS
S	162	Switch	Switch, remote control 2	Frame	SMS
S	163	Switch	Switch, Axle lock trailer	Instrument panel	ATL
S	164	Switch	Switch, PTO EG2	Instrument panel	BWS
S	165	Switch	Switch, Hill hold	Instrument panel	BMS/EBS
S	166	Switch	Switch, reduced reverse alarm	Instrument panel	VIS
S	167	Switch	Switch, Mode	Instrument panel	GMS
S	168	Switch	Switch, PTO ED	Instrument panel	BWS/COO
S	169	Switch	Switch, PTO ED2	Instrument panel	BWS

S	170	Switch	Switch, PTO AWD	Instrument panel	BWS
S	171	Switch	Switch, PTO Split shaft	Instrument panel	BWS
S	170/S171	Switch	Switch, PTO AWD / Split shaft	Instrument panel	BWS
S	172	Switch	Switch, LDW	Instrument panel	LDW
S	173	Switch	Switch, Info	Instrument panel	ICL
S	174	Switch	Switch, Booster pump Ethanol		
S	175	Switch	Switch, PTO EG3	Instrument panel	BWS
S	176	Switch	Switch, RTC DTCO remote download		RTC
S	177	Switch	Switch, Collision warning	Instrument panel	DIS
S	178	Switch	Switch, Regen. part. filter	Instrument panel	??
S	179	Switch	Switch, Level adjustment front	Instrument panel	SMS
S	180	Switch	Switch, Exhausted bellows	Instrument panel	SMS
S	181	Switch	Switch, Trailer tag axle lift	Instrument panel	SMS
S	182	Switch	Switch, Daytime runing light	Instrument panel	VIS
S	190	Switch	Switch, Storage box light	Roof shelf upper	
S	191	Switch	Switch, Speed module	Instrument panel	
S	192	Switch	Switch, Info module	Instrument panel	
S	193	Switch	Switch, AUS module	Instrument panel	
S	195	Switch	Switch, Reading light passenger	Instrument panel	INL
S	196	Switch	Switch, differential lock rotary switch	Instrument panel	RDL,AWD,BMS
S	197	Switch	Switch, battery master switch service	Batt	POW
S	198	Switch			
S	199	Switch			
S	201	Switch	Switch, Predefined vehicle/driving levels	Instrument panel	SMS
S	202	Switch	Switch, Storing vehicle levels	Instrument panel	SMS
S	203	Switch	Switch, Downhill speed limiter	Instrument panel	XXX
S	204	Switch	Switch, Rear view camera	Instrument panel	
S	205	Switch	Sliding fifth wheel	Instrument panel	UFS
S	206	Switch	Switch, seat ventilation driver	Component	SCS
S	207	Switch	Switch, Hill hold	Instrument panel	BMS/ABS
S	208	Switch	Switch, Door control panel	Door driver	DCS
S	209	Switch	Switch, Door control panel	Door passenger	DCS
S	210	Switch	Switch, Door control panel	Door_rear_left	DCS
S	211	Switch	Switch, Door control panel	Door_rear_right	DCS
S	212	Switch	Switch, EI heated windscreen	Instrument panel	EHW
S	213	Switch module	Switch module 1	Instrument panel	COO
S	214	Switch module	Switch module 2	Instrument panel	COO
S	215	Switch module	Switch module 4	Instrument panel	COO
S	216	Switch module	Switch module 5	Instrument panel	COO
S	217	Switch	Switch, Idle stop/start	Instrument panel	HEV
S	218	Switch	Switch, System shut down		HEV
S	219	Switch	Switch, seat ventilation passenger	Component	SCS
S	220	Switch	Switch, automatic auxiliary brake	Instrument panel	COO
S	221	Switch module	Switch module, Steering wheel	Instrument panel	COO
S	222	Switch	Switch, hazard	Instrument panel	VIS/ICL
S	223	Switch module	Switch module 6	Instrument panel	COO
S	224	Switch module	Switch module 7	Instrument panel	COO
S	225	Switch module	Switch module 9	Instrument panel	COO
S	226	Switch module	Switch module 10	Instrument panel	COO
S	227	Switch	Switch, panic alarm	Floor	ALM
S	228	Switch module	Switch module, lighting	Floor	DCS/INL
S	229	Switch	Switch, Interlock loop control	Component	HEV
S	230	Switch	Switch, EPP	Instrument panel	EPP
S	231	Switch	Switch, Foot controlled retarder	Instrument panel	COO
T	3	Monitor	Monitor, applied parking brake	Instrument panel	COO

T	5	Sensor	Sensor, oil press, oil temp engine	Engine	EMS
T	6	Monitor	Monitor, low coolant pressure	Front	CCS
T	7	Monitor	Monitor, low temperature	Floor	CCS
T	8	Monitor	Monitor, coolant level	Front	COO
T	11	Sensor	Sensor speed, front LH	Frame	BMS/EBS/ABS
T	12	Sensor	Sensor speed, front RH	Frame	BMS/EBS/ABS
T	13	Sensor	Sensor speed, rear LH	Frame	BMS/EBS/ABS
T	14	Sensor	Sensor speed, rear RH	Frame	BMS/EBS/ABS
T	15	Sensor	Sensor, pressure, lift bellow	Frame	SMS
T	16	Sensor	Sensor, fuel level	Frame	COO
T	17	Sensor	Sensor, speed	Gearb	GMS
T	18	Monitor	Monitor, low pressure	Frame	COO
T	20	Sensor	Sensor, tachograph	Frame	TCO
T	27	Sensor	Sensor, outdoor temperature	Bumper	ICL2
T	28	Sensor	Sensor speed, add 1/6ch LH	Frame	BMS/EBS/ABS
T	29	Sensor	Mass flow sensor	Engine	EMS
T	30	Sensor	Sensor speed, add 1/6ch RH	Frame	BMS/EBS/ABS
T	33	Sensor	Sensor, coolant temperature	Engine	EMS
T	34	Sensor	Sensor, load limiter	Frame	TAL
T	37	Sensor	Sensor, air temperature	Instrument panel	CCS
T	39	Sensor	Sensor lining wear, front LH	Frame	BMS/EBS
T	40	Sensor	Sensor lining wear, front RH	Frame	BMS/EBS
T	41	Sensor	Sensor lining wear, rear LH	Frame	BMS/EBS
T	42	Sensor	Sensor lining wear, rear RH	Frame	BMS/EBS
T	45	Monitor	Monitor, high oil pressure	Component	TAL
T	47	Sensor	Sensor, charger pressure/temp	Engine	EMS
T	51	Sensor	Sensor lining wear, add 1 LH	Frame	BMS/EBS
T	52	Sensor	Sensor lining wear, add 1 RH	Frame	BMS/EBS
T	55	Monitor	Monitor, flow, circuit 1	Bumper	COO
T	56	Monitor	Monitor, flow, circuit 2	Bumper	COO
T	63	Sensor	Sensor, water temp, retarder	Frame	GMS
T	70	Sensor	Sensor, pressure, rear left	Frame	SMS
T	71	Sensor	Sensor, pressure, tag/drive axle	Frame	SMS
T	72	Sensor	Sensor, distance, front	Frame	SMS
T	73	Sensor	Sensor, distance, rear left	Frame	SMS
T	74	Sensor	Sensor, engine speed 1	Engine	EMS
T	75	Sensor	Sensor, engine speed 2	Engine	EMS
T	76	Sensor	Sensor, position	Gearb	HEV
T	78	Sensor	Mass movement sensor cab	Roof shelf	LAS

T	79	Sensor	Sensor, coolant temp retarder	Frame	GMS
T	80	Sensor	Sensor, oil pressure, retarder	Gearb	GMS
T	81	Sensor	Sensor, evaporator temperature	Floor	CCS
T	82	Sensor	Sensor, solar	Instrument panel	CCS
T	83	Sensor	Sensor, speed	Gearb	GMS
T	86	Sensor	Sensor, oil temp, retarder	Frame	GMS
T	87	Sensor	Sensor, speed, LH	Frame	BMS/EBS
T	88	Sensor	Sensor, speed, RH	Frame	BMS/EBS
T	89	Sensor	Sensor, lining wear, LH	Frame	BMS/EBS
T	90	Sensor	Sensor, lining wear, RH	Frame	BMS/EBS
T	91	Sensor	Sensor, fuel pressure	Engine	EMS
T	94	Sensor	Mass movement sensor, bodybuilder	Frame	LAS
T	96	Sensor	Sensor, pressure EBL	Frame	BMS/ABS
T	97	Sensor	Sensor, distance, rear right	Frame	SMS
T	98	Sensor	Sensor, pressure, rear right	Frame	SMS
T	99	Sensor	Sensor, pressure, front axle	Frame	SMS
T	100	Sensor	Sensor, steering angle	Instrument panel	BMS/EBS
T	101	Sensor	Sensor, yaw rate	Frame	BMS/EBS
T	102	Sensor	Sensor, water separating filter	Frame	COO
T	103	Monitor	Pressure monitor, parking brake	Instrument panel	BWS
T	104	Sensor	Pressure sensor, air processing unit basic	Bumper	APS
T	105	Monitor	Monitor, air temp	Roof_rear	Crew cab
T	106	Sensor	Sensor, split	Gearb	GMS
T	107	Sensor	Sensor, lengthstroke	Gearb	GMS
T	108	Sensor	Sensor, sidestroke	Gearb	GMS
T	109	Sensor	Sensor, range	Gearb	GMS
T	110	Sensor	Sensor, oil level	Engine	EMS
T	111	Sensor	Sensor, pressure, rail	Engine	EMS
T	112	Sensor	Sensor, temperature, rail	Engine	EMS
T	113	Sensor	Sensor, temp, upstream	Component	EEC
T	114	Sensor	Sensor, temp, downstream	Component	EEC
T	115	Sensor	Sensor, nox	Frame	EEC
T	116	Sensor unit	Sensor unit, temperature/level	Component	EEC
T	117	Sensor	Sensor, parking brake	Frame	Crew cab
T	118	Sensor	Sensor, fuel temperature	Frame	EMS
T	119	Sensor	Sensor, fifth wheel indication	Frame	COO
T	120	Sensor	Sensor, turbine speed 1	Engine	EMS
T	121	Sensor	Sensor, charger temp	Engine	EMS
T	122	Sensor	Sensor, charger pressure	Engine	EMS
T	123	Sensor	Sensor, fan control, fan speed	Engine	EMS
T	124	Sensor	Sensor, position EGR 1	Engine	EMS
T	125	Sensor	Sensor, exhaust manifold pressure	Engine	EMS
T	126	Sensor	Sensor, massflow, temp	Engine	EMS
T	127	Sensor	Sensor, Clutch position	xx	xx
T	128	Sensor	Sensor, Clutch cylinder pressure	xx	xx
T	129	Sensor	Sensor, Lay shaft speed	xx	xx
T	130	Sensor	Sensor, oil temp	Gearb	GMS
T	131	Sensor	Sensor, nox	Component	EEC
T	132	Sensor	Sensor, knock 1	Engine	EMS
T	133	Sensor	Sensor, knock 2	Engine	EMS
T	134	Sensor	Sensor, press, temp CNG	Engine	EMS
T	135	Sensor	Sensor, phase	Engine	EMS
T	136	Sensor	Sensor, engine speed 2	Engine	EMS
T	137	Sensor	Sensor, lambda	Engine	EMS
T	138	Sensor	Sensor, massflow	Engine	EMS



T	139	Monitor	Monitor, Temp FCS	Frame	FCS
T	140	Sensor	Sensor, high pressure gas	Frame	EMS
T	141	Sensor	Sensor, pressure	Frame	EMS
T	142	Sensor	Sensor, TX	Roof	LAS
T	143	Sensor	Sensor, RX	Roof	LAS
T	144	Sensor	Sensor, Pressure, Axle One Left	Frame	TPM
T	145	Sensor	Sensor, Pressure, Axle One Right	Frame	TPM
T	146	Sensor	Sensor, Pressure, Axle Two Left Outer/Single	Frame	TPM
T	147	Sensor	Sensor, Pressure, Axle Two Left Inner	Frame	TPM
T	148	Sensor	Sensor, Pressure, Axle Two Right Outer/Single	Frame	TPM
T	149	Sensor	Sensor, Pressure, Axle Two Right Inner	Frame	TPM
T	150	Sensor	Sensor, Pressure, Axle Three Left Outer/Single	Frame	TPM
T	151	Sensor	Sensor, Pressure, Axle Three Left Inner	Frame	TPM
T	152	Sensor	Sensor, Pressure, Axle Three Right Outer/Single	Frame	TPM
T	153	Sensor	Sensor, Pressure, Axle Three Right Inner	Frame	TPM
T	154	Sensor	Sensor, lambda	Engine	EMS
T	155	Sensor	Sensor, Water in fuel	Frame	COO
T	156	Sensor	Sensor, oil level	Gearb	ECA
T	157	Sensor	Sensor, air filter	Front	AFI
T	158	Sensor	Sensor, temperature	Frame	EEC/APF
T	159	Sensor	Sensor, temperature	Frame	EEC/APF
T	160	Sensor	Sensor, temperature	Frame	EEC/APF
T	161	Sensor	Sensor, temperature	Gearb	HEV
T	162	Sensor	Sensor, throttle position	Engine	EMS
T	163	Sensor	Sensor, outdoor temperature	Bumper	ICL2
T	164	Monitor	Monitor, Pressure, HST	Frame	HST
T	165	Sensor	Sensor, coolant temperature	Engine	EMS
T	166	Sensor	Sensor, charger pressure	Engine	EMS
T	167	Sensor	Sensor, fuel level	Frame	COO
T	168	Sensor	Sensor, exhaust temp	Engine	EMS
T	169	Sensor	Sensor, exhaust temp	Engine	EMS
T	170	Sensor	Sensor, exhaust temp	Engine	EMS
T	171	Sensor	Sensor, exhaust temp	Engine	EMS
T	172	Sensor	Sensor, manoeuvring position	Gearb	GMS
T	173	Sensor	Sensor, pressure tag axle 2	Frame	SMS
T	174	Sensor	Sensor, knock 3	Engine	EMS
T	175	Sensor	Window sensor	Door driver	DCS
T	176	Sensor	Window sensor	Door passenger	DCS
T	177	Sensor	Window sensor	Door_rear_left	DCS
T	178	Sensor	Window sensor	Door_rear_right	DCS
T	179	Sensor	Sensor, temperature, RESS	Frame	HEV
T	180	Sensor	Sensor, Steering fluid level	Frame	COO
T	181	Sensor	Sensor, level	Component	HEV
T	182	Sensor	Sensor, level	Component	HEV
T	183	Monitor	Monitor, hydraulic fluid level	Frame	EST
T	184	Sensor	Sensor, cylinder position	Frame	EST
T	185	Monitor	Monitor, valve position sensor	Frame	EST
T	186	Sensor	Sensor, humidity	Instrument panel	CCS
T	187	Sensor	Sensor, rain/light	Instrument panel	VIS
T	188	Sensor	Mass movement sensor cab 2	Floor	ALM
T	189	Sensor	Sensor, Pressure, Axle Four Left Outer/Single	Frame	TPM
T	190	Sensor	Sensor, Pressure, Axle Four Left Inner	Frame	TPM
T	191	Sensor	Sensor, Pressure, Axle Four Right Outer/Single	Frame	TPM
T	192	Sensor	Sensor, Pressure, Axle Four Right Inner	Frame	TPM
T	193	Sensor	Sensor, Floor mix air temp	Component	CCS

T	194	Sensor	Sensor, Ventilation mix temp	Component	CCS
T	195	Sensor	Sensor, Air quality	Component	CCS
T	196	Sensor	Sensor, Washer fluid level		VIS
T	197	Sensor	Sensor, temperature	Engine	EMS
T	198	Sensor	Sensor, oil level/temp	Gearb	GMS
T	199	Sensor	Sensor, pressure/temperature, rail	Engine	EMS
T	200	Sensor	Sensor air temperature	Floor	CCS
T	201	Monitor	Monitor, Temp	Frame	HEV
U	1	Aerial	Aerial, radio	Roof	AUS
U	2	Aerial	Aerial, communication radio	Roof	CB radio
U	3	Aerial	Aerial, remote control	Instrument panel	LAS
U	4	Refridgerator	Refridgerator	Floor	REF
U	4.A	Refrigerator	Refrigerator	Floor	REF
U	4.B	Refrigerator	Refrigerator	Floor	REF
U	6	Spring coil	Spring coil	Instrument panel	Common
U	7	Condenser	Condenser, squib connector	Component	CSS
U	8	Condenser	Condenser, squib connector	Component	CSS
U	9	Microphone	Microphone	Instrument panel	RTI/SVI
U	10	Aerial	Aerial, RTI/SVI, TV	Roof	RTI/SVI
U	11	Aerial	Aerial, RTI/SVI, GSM/GPS/Radio	Roof	RTI/SVI
U	12	Aerial	Aerial, MOP	Roof	MOP
U	13	Microphone	Microphone	Instrument panel	RTI
U	14	Microphone	Microphone	Instrument panel	FAS
U	15	Aerial	Aerial, TOL	Roof	TOL
U	16	Additional AC	Additional AC	Instrument panel	CCS
U	17	Aux in	Aux in	Instrument panel	
U	18	Radio input	Aux radio input	Instrument panel	AUS
U	19	Splitter	Aerial splitter	Roof	
U	20	Aerial	Aerial, RTC, GSM/GPS/Radio	Roof	RTC
U	21	USB	USB, Radio	Instrument panel	AUS
U	22	ID reader	ID button reader	Roof Shelf	RTC
U	23	Aerial	Aerial, DAB radio	Roof	AUS/MIB
V	2	Solenoid valve	Solenoid valve, AC compressor	Engine	EMS
V	3	Solenoid valve	Pressure control valve, front LH	Frame	BMS/EBS/ABS
V	4	Solenoid valve	Pressure control valve, front RH	Frame	BMS/EBS/ABS
V	5	Solenoid valve	Pressure control valve, rear LH	Frame	BMS/ABS
V	6	Solenoid valve	Pressure control valve, rear RH	Frame	BMS/ABS
V	9	Solenoid valve	Solenoid, safety belt lock	Component	SEAT
V	10	Solenoid valve	Solenoid valve, diff lock, axle	Frame	RDL
V	11	Solenoid valve	Solenoid valve, diff lock, tandem	Frame	RDL
V	13	Solenoid valve	Solenoid valve, PTO EG1	Gearb	GMS
V	14	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	15	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	16	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	17	Solenoid valve	Solenoid valve, exhaust brake	Engine	EMS
V	20	Solenoid valve	Solenoid valve, side stroke right	Gearb	GMS
V	21	Solenoid valve	Solenoid valve, side stroke left	Gearb	GMS
V	22	Solenoid valve	Solenoid valve, neutral	Gearb	GMS
V	23	Solenoid valve	Solenoid valve, length stroke, backwards	Gearb	GMS
V	24	Solenoid valve	Solenoid valve length stroke, forwards	Gearb	GMS
V	26	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	27	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	28	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	29	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	30	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS

V	31	Solenoid valve	Solenoid valve, fan	Engine	EMS
V	32	Solenoid valve	Solenoid valve, disengage fr spring brake	Frame	SMS
V	41	Pump	Fuel metering pump	Frame	AHS
V	43	Solenoid valve	Solenoid valve, PTO EK	Gearb	COO
V	44	Solenoid valve	Solenoid valve, air horn	Floor	VIS
V	46	Solenoid valve	Pressure control valve, 6ch LH	Frame	BMS/ABS
V	47	Solenoid valve	Pressure control valve, 6ch RH	Frame	BMS/ABS
V	48	Control module	Trailer control module	Frame	BMS/EBS
V	49	Solenoid valve	Solenoid valve , tag axle down	Frame	TAL
V	50	Solenoid valve	Solenoid valve, tag axle up	Frame	TAL

V	51	Solenoid valve	Solenoid valve, rear axle	Frame	SMS
V	52	Solenoid valve	Solenoid valve, rear axle	Frame	SMS
V	53	Solenoid valve	Solenoid valve, front axle	Frame	SMS
V	54	Solenoid valve	Solenoid valve, up/down	Frame	SMS
V	55	Solenoid valve	Solenoid valve, up/down tag axle	Frame	SMS
V	59	Solenoid valve	Electronic water valve	Front	CCS
V	60	Solenoid valve	Solenoid valve, folding step LH	Frame	Crew cab
V	61	Solenoid valve	Solenoid valve, folding step RH	Frame	Crew cab
V	62	Solenoid valve	Solenoid valve, low split	Gearb	GMS
V	63	Solenoid valve	Solenoid valve, low range	Gearb	GMS
V	65	Solenoid valve	Solenoid valve, diff lock, front	Frame	AWD
V	66	Solenoid valve	Solenoid valve, low gear	Frame	AWD
V	67	Solenoid valve	Solenoid valve, neutral position	Frame	AWD
V	68	Solenoid valve	Solenoid valve, diff lock, central	Frame	AWD
V	75	Solenoid valve	Solenoid valve, accumulator	Frame	GMS
V	76	Solenoid valve	Solenoid valve, proportional	Frame	GMS
V	77	Solenoid valve	Solenoid valve, high split	Gearb	GMS
V	78	Solenoid valve	Solenoid valve, high range	Gearb	GMS
V	81	Solenoid valve	Solenoid valve, TC	Frame	BMS/ABS
V	82	Control module	Pressure control module, front	Frame	BMS/EBS
V	83	Control module	Pressure control module, add2	Frame	BMS/EBS
V	86	Control module	Pressure control module, add 1	Frame	BMS/EBS
V	95	Control module	Pressure control module, rear	Frame	BMS/EBS
V	97	Solenoid valve	Solenoid valve unit, retarder	Gearb	GMS
V	98	Solenoid valve	Solenoid valve, fuel act time	Engine	EMS
V	99	Solenoid valve	Solenoid valve, fuel act time	Engine	EMS
V	100	Solenoid valve	Solenoid valve, fuel act rail	Engine	EMS
V	101	Solenoid valve	Solenoid valve, fuel act rail	Engine	EMS
V	102	Solenoid valve	Solenoid valve, fuel shut off	Engine	EMS
V	107	Solenoid valve	Solenoid valves, Block	Engine	EMS
V	109	Solenoid valve	Solenoid valve, waste gate	Engine	EMS
V	110	Solenoid valve	Solenoid, safety belt lock, pass	Component	SEAT
V	111	Solenoid valve	Solenoid valve unit, range/split	Gearb	GMS
V	112	Solenoid valve	Solenoid valve unit, OPC	Gearb	GMS
V	113	Solenoid valve	Solenoid valve, reverse switch	Frame	GMS
V	114	Solenoid valve	Solenoid valve, up/down tag axle 2	Frame	SMS
V	115	Solenoid valve	Solenoid valve, EGR prop	Engine	EMS
V	116	Solenoid valve	Solenoid valve, EGR on/off	Engine	EMS
V	117	Dosing unit	Dosing unit	Component	EEC
V	118	Solenoid valve	Water valve, EEC	Component	EEC
V	119	Pump	Hydraulic pump	Engine	EMS
V	120	Solenoid valve	Solenoid valve, inlet metering	Engine	EMS
V	121	Solenoid valve	Solenoid valve, VGT	Engine	EMS
V	122	Solenoid valve	Solenoid valve, PTO ED	Frame	BWS
V	123	Solenoid valve	Solenoid valve, PTO EG2	Frame/Gearb	GMS
V	124	Solenoid valve	Solenoid valve, coolant water pump	Engine	EMS
V	133	Solenoid valve	Solenoid valve, PTO EG2	Gearb	BWS
V	141	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	142	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	143	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	144	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	145	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	146	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	147	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS
V	148	Solenoid valve	Solenoid valve, fuel actuator	Engine	EMS

V	149	Solenoid valve	Valve box	Gearb	ECA
V	150	Solenoid valve	Solenoid valve, PTO ED2	Frame	BWS
V	151	Solenoid valve	Solenoid valve, PTO AWD	Frame	BWS
V	152	Solenoid valve	Solenoid valve, Split shaft	Frame	BWS
V	151/V152	Solenoid valve	Solenoid valve, PTO AWD / Split shaft	Frame	BWS
V	153	Solenoid valve	Solenoid valve, Retarder accumulator	Frame	GMS
V	154	Solenoid valve	Solenoid valve, Load transfer	Frame	TAL
V	155	Solenoid valve	Solenoid valve, Low gear	Frame	AWD
V	156	Solenoid valve	Solenoid valve, High gear	Frame	AWD
V	157	Solenoid valve	Solenoid valve, EI-dump	Engine	EMS
V	164	Solenoid valve	Solenoid valve, Injector	Engine	EMS
V	165	Solenoid valve	Solenoid valve, Injector	Engine	EMS
V	166	Solenoid valve	Solenoid valve, Injector	Engine	EMS
V	167	Solenoid valve	Solenoid valve, Injector	Engine	EMS
V	168	Solenoid valve	Solenoid valve, Injector	Engine	EMS
V	169	Solenoid valve	Solenoid valve, Injector	Engine	EMS
V	170	Solenoid valve	Solenoid valve, Injector	Engine	EMS
V	171	Solenoid valve	Solenoid valve, Injector	Engine	EMS
V	172	Solenoid valve	Solenoid valve, Injector	Engine	EMS
V	173	Solenoid valve	Solenoid valve, Injector	Engine	EMS
V	174	Solenoid valve	Solenoid valve, high pressure gas	Frame	EMS
V	175	Solenoid valve	Solenoid valve, low pressure gas	Frame	EMS
V	180	Solenoid valve	Solenoid valve, auxiliary cooler	Frame	ATC
V	181	Solenoid valve	Solenoid valve, PTO EG3	Frame	BWS
V	183	Pump unit	Pump unit	Frame	EEC
V	184	Solenoid valve	Solenoid valve, Shut off	Engine	
V	185	Injection valve	injection valve	Engine	
V	186	Solenoid valve	Solenoid valve, Shut off	Frame	EEC
V	189	Solenoid valve	Solenoid valve, dump valve	Engine	EMS
V	190	Solenoid valve	Solenoid valve, dump valve	Engine	EMS
V	191	Solenoid valve	Solenoid valve, Pressure elimination	Frame	HST
V	192	Solenoid valve	Solenoid valve, Hill hold	Frame	BMS/ABS
V	193	Solenoid valve	Pressure control valve, Hill hold	Frame	BMS/ABS
V	194	Solenoid valve	Solenoid valve, water valve control	Frame	HEV
V	195	Solenoid valve	Solenoid valve, PTO double EG	Frame	GMS
V	196	Solenoid valve	Solenoid valve, APS	Frame	APS
V	197	Solenoid valve	Solenoid valve, normal mode	Frame	EST
V	198	Solenoid valve	Solenoid valve, fixed degradation	Frame	EST
V	199	Solenoid valve	Solenoid valve, caster degradation	Frame	EST
V	200	Solenoid valve	Solenoid valve, High gear	Frame	AWD
W	20	Control lamp	Control lamp, retaractable step	Instrument panel	Crew cab
W	34	Warning lamp	Warning lamp, doors	Instrument panel	Crew cab

**Component Library****S-order PGRT-series**

No	Type	Description	Harness	System
B 1005	Switch	Switch, difflock second front axle	Frame	AWD
B 1006	Switch	Switch, difflock tandem front	Frame	AWD
B 1010	Switch	Micro switch, selected first gear for GA	Floor	BWS
B 1011	Switch	Micro switch, selected revers gear for GA	Floor	BWS
B 1012	Switch	Switch, central lock	Door driver	LAS
B 1013	Switch	Switch, UFS, slider locking detection	Frame	UFS
B 1014	Switch	Switch, UFS, slider locking detection	Frame	UFS
B 1015	Switch	Switch, crash	Floor	EMS OCS
C 1035	Connector	Connector, 2-pole, Lamp socket, front pass side	Bumper	POW
C 1037	Connector	Connector, 2-pole, Aux power supply	Frame	POW
C 1160	Connector	Connector, 3-pole, P-brake pressure monitor, PTO	Instrument panel	BWS
C 1169	Connector	Connector, 7-pole, for 12-pole trailer connector front	Frame	BOL
C 1170	Connector	Connector, 7-pole, for 12-pole trailer connector rear	Frame	BOL
C 1171	Connector	Connector, 7-pole, for 12-pole trailer connector front	Frame	BOL
C 1172	Connector	Connector, 7-pole, for 12-pole trailer connector rear	Frame	BOL
C 1173	Connector	Connector, 12-pole trailer connector front, NATO	Frame	BOL
C 1174	Connector	Connector, 12-pole trailer connector rear, NATO	Frame	BOL
C 1210	Connector	Connector, 12-pole trailer connector rear, NATO	Test instrument	BOL
C 1211	Connector	Connector, 12-pole trailer connector rear, FMV	Test instrument	BOL
C 1233	Connector	Connector, 2-pole, Lamp socket, front drv side	Bumper	POW
C 1245	Connector	Connector, 4-pole, gearbox	Frame - Gearb	GMS
C 1247	Connector	Connector, 19-pole, gearbox	Frame - Gearb	GMS
C 1363	Connector	Connector, 2-pole, el heated windscreen	Instrument panel	EHW
C 1364	Connector	Connector, 2-pole, el heated windscreen	Instrument panel	EHW
C 1372	Connector	Connector, 21-pole, behind left front seat	Floor - Component	Body work
C 1373	Connector	Connector, 9-pole, BWS	Floor - Component	Body work
C 1374	Connector	Connector, 37-pole, behind left front seat	Component	Body work
C 1375	Connector	Connector, 21-pole, beside BWS plate	Instrument panel	Body work
C 1378	Splice	Splice, 1-pole, instr p, plus	Instrument panel	Body work
C 1379	Splice	Splice, 1-pole, instr p, minus	Instrument panel	Body work
C 1380	Connector	Connector, 3-pole, behind S82	Instrument panel	AWD
C 1381	Connector	Connector, 3-pole, beside E65	Instrument panel	AWD
C 1382	Connector	Connector, 3-pol, beside C276:10	Instrument panel	EHW
C 1383	Joint connector	Joint connector, 8-pole, BOL, behind P2	Instrument panel	BOL
C 1384	Joint connector	Joint connector, 12-pole, BOL, near E32	Instrument panel	BOL
C 1385	Joint connector	Joint connector, 3-pole, BOL, near G5	Instrument panel	BOL
C 1386	Joint connector	Joint connector, 3-pole, BOL, near S140	Instrument panel	BOL
C 1387	Joint connector	Joint connector, 3-pole, BOL, behind S64	Instrument panel	BOL
C 1388	Joint connector	Joint connector, 3-pole, BOL, behind S68	Instrument panel	BOL
C 1389	Joint connector	Joint connector, 3-pole, BOL, near G1	Instrument panel	BOL
C 1390	Joint connector	Joint connector, 3-pole, BOL, near G1	Instrument panel	BOL
C 1391	Joint connector	Joint connector, 3-pole, BOL, near G2/G3	Instrument panel	BOL
C 1392	Joint connector	Joint connector, 3-pole, BOL, near G2/G3	Instrument panel	BOL
C 1393	Joint connector	Joint connector, 3-pole, BOL, near G4	Instrument panel	BOL
C 1394	Joint connector	Joint connector, 21-pole, BOL, beside S1010 behind pan	Instrument panel	BOL
C 1395	Joint connector	Joint connector, 21-pole, BOL, beside S1010 behind pan	Instrument panel	BOL
C 1396	Joint connector	Joint connector, 1-pole, BOL, beside R8	Instrument panel	BOL
C 1397	Splice	Splice, BOL, in front of left tail light in frame	Frame	BOL
C 1398	Splice	Splice, BOL, in front of right tail light in frame	Frame	BOL
C 1399	Splice	Splice, BOL, in front of right tail light in frame	Frame	BOL
C 1400	Splice	Splice, BOL, in front of left tail light in frame	Frame	BOL
C 1401	Splice	Splice, BOL, beside C103	Frame	BOL

C	1402	Splice	Splice, BOL, beside C103	Frame	BOL
C	1403	Splice	Splice, BOL, beside C103	Frame	BOL
C	1404	Splice	Splice, BOL, beside G13	Frame	BOL
C	1405	Splice	Splice, BOL, in front of left tail light in frame	Frame	BOL
C	1406	Splice	Splice, BOL, in front of left tail light in frame	Frame	BOL
C	1407	Splice	Splice, BOL, in front of left tail light in frame	Frame	BOL
C	1408	Splice	Splice, BOL, in front of left tail light in frame	Frame	BOL
C	1409	Splice	Splice, BOL, in front of left tail light in frame	Frame	BOL
C	1410	Splice	Splice, BOL, in front of right tail light in frame	Frame	BOL
C	1411	Splice	Splice, BOL, in front of right tail light in frame	Frame	BOL
C	1412	Splice	Splice, BOL, in front of right tail light in frame	Frame	BOL
C	1413	Splice	Splice, BOL, in front of right tail light in frame	Frame	BOL
C	1414	Splice	Splice, BOL, in front of right tail light in frame	Frame	BOL
C	1415	Joint connector	Joint connector, 3-pole, BOL, beside C29	Instrument panel	BOL
C	1416	Joint connector	Joint connector, 6-pole, BOL, beside C100	Frame	BOL
C	1417	Splice	Splice, BOL, beside C100	Frame	BOL
C	1418	Splice	Splice, BOL, beside C100	Frame	BOL
C	1419	Splice	Splice, BOL, beside C100	Frame	BOL
C	1420	Splice	Splice, BOL, beside C100	Frame	BOL
C	1421	Splice	Splice, BOL, beside C100	Frame	BOL
C	1422	Splice	Splice, BOL, beside C100	Frame	BOL
C	1423	Connector	Connector, 7-pole, BOL, adapter to FMV, beside C1170	Frame	BOL
C	1424	Connector	Connector, 7-pole, BOL, adapter to FMV, beside C1172	Frame	BOL
C	1425	Connector	Connector, 7-pole, BOL, adapter to FMV, beside C1170	Frame	BOL
C	1426	Connector	Connector, 7-pole, BOL, adapter to FMV, beside C1172	Frame	BOL
C	1427	Connector	Connector, 6-pole, BOL, beside ELC E18	Instrument panel	BOL
C	1428	Splice	Splice, BOL, beside D1052	Instrument panel	BOL
C	1429	Splice	Splice, BOL, beside D1053	Instrument panel	BOL
C	1430	Splice	Splice, BOL, beside D1053	Instrument panel	BOL
C	1431	Splice	Splice, BOL, beside D1050	Instrument panel	BOL
C	1432	Splice	Splice, BOL, beside D1049	Instrument panel	BOL
C	1433	Splice	Splice, BOL, beside D1050	Instrument panel	BOL
C	1434	Splice	Splice, BOL, beside S1030	Instrument panel	BOL
C	1435	Splice	Splice, BOL, beside D1048	Instrument panel	BOL
C	1436	Splice	Splice, BOL, beside D1048	Instrument panel	BOL
C	1437	Splice	Splice, BOL, beside D1051	Instrument panel	BOL
C	1438	Splice	Splice, BOL, beside D1051	Instrument panel	BOL
C	1439	Splice	Splice, BOL, beside D1052	Instrument panel	BOL
C	1440	Joint connector	Joint connector, 8-pole, BOL, behind P2	Instrument panel	BOL
C	1441	Connector	Connector, 12-pole, BOL, behind panel K	Instrument panel	BOL
C	1442	Splice	Splice, BOL, beside C1425	Frame	BOL
C	1443	Splice	Splice, BOL, ICL, beside D1054	Instrument panel	BOL
C	1444	Splice	Splice, BOL, ICL, beside D1054	Instrument panel	BOL
C	1445	Splice	Splice, BOL, CCS, beside D1055	Instrument panel	BOL
C	1446	Splice	Splice, BOL, CCS, beside D1055	Instrument panel	BOL
C	1447	Splice	Splice, BOL, VIS, beside D1056	Instrument panel	BOL
C	1448	Splice	Splice, BOL, VIS, beside D1056	Instrument panel	BOL
C	1449	Splice	Splice, BOL, BWS, beside D1057	Instrument panel	BOL
C	1450	Splice	Splice, BOL, BWS, beside D1057	Instrument panel	BOL
C	1451	Splice	Splice, BOL, VIS, beside D1058	Instrument panel	BOL
C	1452	Splice	Splice, BOL, VIS, beside D1058	Instrument panel	BOL
C	1453	Splice	Splice, BOL, BMS, beside D1059	Instrument panel	BOL
C	1454	Splice	Splice, BOL, BMS, beside D1059	Instrument panel	BOL
C	1455	Connector	Connector, 3-pole, AHS, beside C218	Instrument panel	AHS
C	1456	Connector	Connector, 3-pole, AHS, beside C419	Instrument panel	AHS

C	1457	Connector	Connector, 6-pole, AHS, beside C101	Instrument panel	AHS
C	1458	Connector	Connector, 3-pole, AHS, fan, beside E17	Instrument panel	AHS
C	1459	Connector	Connector, 2-pole, BOL, behind L141	Bumper	BOL
C	1460	Splice	Splice, AHS, ATA, beside D1062	Instrument panel	AHS
C	1461	Splice	Splice, AHS, ATA, beside D1062	Instrument panel	AHS
C	1462	Splice	Splice, AHS, ATA, beside D1061	Instrument panel	AHS
C	1463	Splice	Splice, AHS, ATA, beside D1060	Instrument panel	AHS
C	1464	Splice	Splice, AHS, ATA, beside D1060	Instrument panel	AHS
C	1465	Splice	Splice, AHS, ATA, beside D1063	Instrument panel	AHS
C	1466	Splice	Splice, AHS, ATA, beside D1064	Instrument panel	AHS
C	1467	Splice	Splice, AHS, ATA, beside D1064	Instrument panel	Ahs
C	1468	Connector	Connector, 4-pole, POW, behind L141	Bumper	POW
C	1469	Splice	Splice, BOL, revers alarm, beside N10	Frame	BOL
C	1470	Splice	Splice, BOL, revers alarm, beside N10	Frame	BOL
C	1471/C33	Connector	Connector, 6-pole, POW, battery switch, ADR, RH batter	Frame	POW
C	1472/C33	Connector	Connector, 6-pole, POW, battery switch, ADR, LH	Frame	POW
C	1473/S40	Connector	Connector, 4-pole, POW, battry switch, RH battery	Frame	POW
C	1474/C40	Connector	Connector, 2-pole, POW, TCO, RH battery	Frame	POW
C	1475/C40	Connector	Connector, 2-pole, POW, TCO, LH beside C405	Frame	POW
C	1476	Splice	Splice VIS, SML adapter	Frame	VIS
C	1477	Splice	Splice VIS, SML adapter	Frame	VIS
C	1478	Connector	Connector, 2-pole, VIS, SML adapter	Frame	VIS
C	1479/C28	Connector	Connector, 2-pole, POW, hand lamp front, at C28	Instrument panel	POW
C	1480/C28	Connector	Connector, 2-pole, POW, hand lamp front, at C28	Instrument panel	POW
C	1481/L101	Connector	Connector, 7p, VIS, rear comb lamp left	Frame	VIS
C	1482/L102	Connector	Connector, 7p, VIS, rear comb lamp right	Frame	VIS
C	1483	Splice	Splice, BOL, beside C100	Frame	BOL
C	1484	Joint connector	Joint connector, 6-pole, BOL, beside C100	Frame	BOL/VIS
C	1485	Connector	Connector, 6-pole, BOL, beside SMS E18	Instrument panel	BOL
C	1486	Connector	Connector, 6-pole, BOL, beside BWS C447	Instrument panel	BOL
C	1487	Splice	Splice, BOL, beside D1065	Instrument panel	BOL
C	1488	Connector	Connector, 15-pole, RTS/iris, behindTCO	Roofshelf	RTS
C	1489	Connector	Connector, 6-pole, RTS/iris, behindTCO	Roofshelf	RTS
C	1490	Splice	RTS/Iris, inside Iris unit.	Roofshelf	RTS
C	1491	Connector	RTS/Iris, RHS roof, roofshelf.	Roofshelf	RTS
C	1492	Connector	RTS/Iris, RHS roof, instrument panel	Instrument panel	RTS
C	1493	Connector	RTS/Iris, near C 1	Instrument panel	RTS
C	1494	Connector	RTS/Iris, near C 69	Instrument panel	RTS
C	1495	Connector	RTS/Iris, as C 92	Frame	RTS
C	1496	Connector	RTS/Iris, under fifth wheel.	Frame	RTS
C	1497	Connector	Connector, BWS, warning lamp prep RHS frame	Frame	BWS
C	1498	Connector	Connector, BOL, beside C1441	Instrument panel	BOL
C	1499	Connector	Connector, 2-pole, POW, hand lamp rear	Frame	POW
C	1500	Splice	Splice, POW, hand lamp, near C102	Frame	POW
C	1501	Connector	Connector, 4-pole, VIS, Profile sign lamps	Frame	VIS
C	1502	Connector	Connector, 2-pole, VIS, Profile sign lamp front LH	Bumper	VIS
C	1503	Connector	Connector, 2-pole, VIS, Profile sign lamp front RH	Bumper	VIS
C	1504	Connector	Connector, 2-pole, VIS, Profile sign lamp rear LH	Frame	VIS
C	1505	Connector	Connector, 2-pole, VIS, Profile sign lamp rear RH	Frame	VIS
C	1506	Splice	Splice, VIS, Profile sign lamps, near C102	Frame	VIS
C	1507	Splice	Splice, VIS, Profile sign lamps, near C102	Frame	VIS
C	1508	Connector	Connector, 6-pole, BOL at C100.	Frame	BOL
C	1509	Connector	Connector, 6-pole, BOL at C100.	Frame	BOL
C	1510	Splice	Splice, RTS/Iris	Instrument panel	RTS
C	1511	Splice	Splice, RTS/Iris	Instrument panel	RTS



C	1512	Connector	Connector, 3-pole, LAS, switch central lock, near C18	Door driver	LAS
C	1513	Connector	Connector, 6-pole, VIS, lightbar, near C1	Instrument panel	VIS
C	1514	Splice	Splice, VIS, lightbar, near C1516	Component	VIS
C	1515	Connector	Connector, VIS, 15-pole, near C273	Roof - Roof shelf	VIS
C	1516	Connector	Connector, VIS, 12-pole	Roof - Component	VIS
C	1517	Connector	Connector, VIS, 8-pole, near C24	Roof - Instrument panel	VIS
C	1518	Connector	Connector, VIS, 3-pole	Frame - Component	VIS
C	1519	Connector	Connector, VIS, 3-pole	Frame - Component	VIS
C	1520	Connector	Connector, BWS, 1-pole	Frame	BWS
C	1521	Connector	Connector, BWS, 1-pole	Frame	BWS
C	1522	Connector	Connector, BWS, 7-pole	Frame	BWS
C	1523	Connector	Connector, BWS, 2-pole	Frame	BWS
C	1524	Connector	Connector, BWS, 2-pole	Frame	BWS
C	1525	Connector	Connector, BWS, 7-pole	Frame	BWS
C	1526	Splice	Splice, BWS, Nordic box, near C1524	Frame	BWS
C	1527	Splice	Splice, BWS, Nordic box, near C1525	Frame	BWS
C	1528	Connector	Connector, VIS, 3-pole	Frame - Component	VIS
C	1529	Connector	Connector, VIS, 3-pole	Frame - Component	VIS
C	1530	Splice	Splice, VIS, blue flashing lights	Frame	VIS
C	1531	Splice	Splice, VIS, blue flashing lights	Frame	VIS
C	1532	Splice	Splice, VIS, blue flashing lights	Frame	VIS
C	1533	Connector	Connector, VIS, 6-pole, near C259	Instrument panel	VIS
C	1534	Connector	Connector, VIS, 2-pole	Frame	VIS
C	1535	Connector	Connector, VIS, 5-pole	Roof	VIS
C	1536	Splice	Splice, VIS, lightbar, near C1516	Component	VIS
C	1537	Splice	Splice, SMS, variable tag axle weight	Frame	SMS
C	1538	Splice	Splice, SMS, variable tag axle weight	Frame	SMS
C	1539	Splice	Splice, BWS, working lamps	Frame	BWS
C	1540	Splice	Splice, BWS, working lamps	Frame	BWS
C	1541/C48	Connector	Connector, 7-pole, BWS, working lamps	Frame	BWS
C	1542	Connector	Connector, 7-pole, BWS	Frame	BWS
C	1543	Connector	Connector, BMS ABS AWD, 3-pole	Instrument panel	BMS
C	1544/C48	Connector	Connector, 7-pole, BWS, working lamps	Frame	BWS
C	1545	Connector	Connector, 3-pole, VIS, working lamp	Instrument panel	VIS
C	1546	Connector	Connector, 3-pole, Auxiliary compressor	Floor	BWS
C	1547	Connector	Connector, 3-pole, Auxiliary compressor	Frame/Floor	BWS
C	1548	Connector	Connector, 3-pole, Auxiliary compressor	Frame	BWS
C	1549	Splice	Splice, BWS, box body	Frame	BWS
C	1550	Splice	Splice, BWS, box body	Frame	BWS
C	1551	Splice	Splice, BWS, box body	Frame	BWS
C	1552	Splice	Splice, BWS, box body	Frame	BWS
C	1553	Splice	Splice, BOL, Stop lamp adapter	Frame	BOL
C	1554	Splice	Splice, BOL, Stop lamp adapter	Frame	BOL
C	1555	Splice	Splice, BWS Swap body	Frame	BWS
C	1556	Splice	Splice, BWS Swap body	Frame	BWS
C	1557	Connector	Connector, BWS, 7-pole	Frame - Component	BWS
C	1558	Splice	Splice, GMS, VIAB, pressure sensors	Frame	GMS
C	1559	Splice	Splice, GMS, VIAB, temperature sensors	Frame	GMS
C	1560	Splice	Splice, GMS, VIAB, solenoid valves	Frame	GMS
C	1561	Connector	Connector, 7-pole, GMS, CLR	Frame	GMS
C	1562	Connector	Connector, 7-pole, GMS, CLR	Frame	GMS
C	1563	Connector	Connector, 7-pole, GMS, CLR	Frame	GMS
C	1566/H10	Connector	Heater AHS Aux ATA adaptor	Floor - Component	ATA
C	1567	Splice	Splice, GMS ZF Transmatic	Instrument panel	GMS
C	1568	Splice	Splice, GMS ZF Transmatic	Instrument panel	GMS

C	1569	Splice	Splice, GMS ZF Transmatic	Instrument panel	GMS
C	1571	Connector	Connector, 6-pole, Body builder signal, EMS Gas	Instrument panel	CNG
C	1572	Splice	Splice VIS REGISTRATION PLATE LAMP LED	Frame	VIS
C	1573	Splice	Splice VIS REGISTRATION PLATE LAMP LED	Frame	VIS
C	1574/L101	Connector	Connector LED TAIL LAMP LH	Frame	VIS
C	1575/L102	Connector	Connector LED TAIL LAMP RH	Frame	VIS
C	1576	Splice	Splice warning buzzer	Frame	VIS
C	1577	Splice	Splice warning buzzer	Frame	VIS
C	1578	Connector	Connector, 6-pole, EMS GCS	Instrument panel/Frame	EMS
C	1579	Connector	Connector, 6-pole, EMS GCS	Instrument panel/Frame	EMS
C	1580	Connector	Connector, 6-pole, EMS GCS	Instrument panel/Frame	EMS
C	1581	Splice	Splice, resistor EMS GCS	Frame	EMS
C	1582	Splice	Splice, resistor EMS GCS	Frame	EMS
C	1583	Splice	Splice, diode BOL adapter	Instrument panel	BOL
C	1584	Splice	Splice, diode BOL adapter	Instrument panel	BOL
C	1585	Splice	Splice, diode BOL adapter	Instrument panel	BOL
C	1586	Splice	Splice, diode BOL adapter	Instrument panel	BOL
C	1587	Connector	Connector, 6-pole, BOL adapter	Instrumentpanel	BOL
C	1588	Connector	Connector, 6-pole, BOL adapter	Instrument panel	BOL
C	1589	Connector	Connector, 3-pole, BOL adapter	Instrument panel	BOL
C	1590	Connector	Connector, 9-pole, BOL adapter	Instrument panel	BOL
C	1591	Splice	Splice, diode BOL DRL	Instrument panel	BOL
C	1592	Splice	Splice, diode BOL DRL	Instrument panel	BOL
C	1593	Connector	Connector, 3-pole, BOL S1	Instrumentpanel	BOL
C	1594	Connector	Connector, 4-pole, BOL DRL	Instrumentpanel	BOL
C	1595	Connector	Connector, 6-pole, BOL DRL	Instrumentpanel	BOL
C	1596	Connector	Connector, 2-pole	Frame	EMS
C	1597	Connector	Connector, 2-pole	Frame	EMS
C	1598	Splice	Splice, EMS GCS OCS	Frame	EMS
C	1599	Splice	Splice, EMS GCS OCS	Frame	EMS
C	1600	Splice	Splice, EMS GCS OCS	Frame	EMS
C	1601	Splice	Splice, EMS GCS OCS	Frame	EMS
C	1602	Splice	Splice, EMS GCS OCS	Frame	EMS
C	1603	Splice	Splice, EMS GCS OCS	Frame	EMS
C	1604	Splice	Splice, EMS GCS OCS	Frame	EMS
C	1605	Splice	Splice, EMS GCS OCS	Frame	EMS
C	1606	Splice	Splice, EMS GCS OCS	Frame	EMS
C	1607	Splice	Splice, EMS GCS OCS	Frame	EMS
C	1608	Splice	Splice, EMS GCS OCS	Frame	EMS
C	1609	Splice	Splice, EMS GCS OCS	Frame	EMS
C	1610	Splice	Splice VIS registration plate lamp LED	Frame	VIS
C	1611	Splice	Splice VIS registration plate lamp LED	Frame	VIS
C	1612	Connector	Connector 6-pole, next to C100-103	Frame	AWD
C	1613/T8	Connector	Connector, coolant level	Front	COO
C	1614	Connector	Connector, 3-pole	Instrument panel	AWD
C	1615	Connector	Connector, 5-pole next to C100-103	Instrument panel	VIS
C	1616	Connector	Connector, 3-pole next to C1441	Instrument panel	VIS
C	1617	Connector	Connector, 4-pole MOP, Iridium	Instrument panel	MOP
C	1620	Splice	Splice, AUS military	instrument panel	AUS
C	1621	Splice	Splice, AUS military	instrument panel	AUS
C	1622	Connector	Connector, 5-pole next to C100-103	instrument panel	UFS
C	1623	Connector	Connector, 5-pole next to C100-103	instrument panel	UFS
C	1624	Connector	Connector, 4-pole	Frame	UFS
C	1625	Connector	Connector, 3-pole beside C261	Instrument panel	UFS
C	1626	Connector	Connector, 5-pole, Red, yellow tape	Instrument panel	EMS GCS

C	1627	Connector	Connector, 5-pole, Blue	Instrument panel	EMS GCS
C	1628	Connector	Connector, 5-pole, Red	Instrument panel	EMS GCS
C	1629	Splice	Splice	Frame	EMS
C	1630	Splice	Splice	Frame	EMS
C	1631	Connector	Connector, 2-pole	Instrument panel	BOL
C	1632	Connector	Connector, 3-pole next to C1394	Instrument panel	VIS
C	1633/C7	Connector	Connector, 7-pole	Frame	EEC
C	1634/C7	Connector	Connector, 7-pole	Frame	EEC
C	1635	Connector	Connector, 3-pole next to C1394	Instrument panel	BOL
C	1636	Connector	Connector, 2-pole AUS DAGER	Instrument panel	AUS
C	1637	Connector	Connector, 2-pole EHW	Door driver	EHW
C	1638	Connector	Connector, 2-pole EHW	Door passenger	EHW
C	1639	Connector	Connector, 2-pole EHW	Instrument panel	EHW
C	1640	Connector	Connector, 3-pole SMS VRB, beside C261	Instrument panel	SMS
C	1641	Connector	Connector, 6-pole, BOL, BWS connection near P2	Instrument panel	BOL
C	1642	Connector	Connector, 5pole, BOL, outside 66-pole	Instrument panel	BOL
C	1643	Connector	Connector, 5pole, BOL, outside 66-pole	Instrument panel	BOL
C	1644	Connector	Connector, 5pole, BOL, trailer, outside 66-pole	Instrument panel	BOL
C	1645	Connector	Splice, BOL, Trailer, beside G13	Instrument panel	BOL
C	1646	Connector	Connector, 6-pole, VIS, SML beside C100	Instrument panel	VIS
C	1647	Connector	Connector, 5-pole, Blue	Instrument panel	EMS OCS
C	1648	Connector	Connector, 5-pole, Red	Instrument panel	EMS OCS
C	1649	Splice	Ground gastanks, EMS OCS Eu6	Frame	EMS OCS
C	1650	Splice	Splice, 30-supply, EMS OCS Eu6	Frame	EMS OCS
C	1651	Connector	Connector, 3-pole, EMS OCS, BWS WTA	Instrument panel	BWS
C	1652/C5	Connector	Connector, 2-pole, VIS, Signal horn	Bumper	VIS
C	1653	Connector	Connector, 5-pole, red	Instrument panel	SMS
C	1654/L106	Connector	BOL, 7 Poligt	Frame	VIS
C	1655	Connector	BOL, 3 Polig	Frame	VIS
C	1656/V118	Connector	Extension, 4 polig	Frame	EEC
C	1657	Connector	Connector, 2-pole, POW, AUX 24V	Instrument panel	POW
C	1658	Connector	Connector, 2-pole, POW, AUX 24V	Instrument panel	POW
C	1659	Connector	Connector, 2-pole, POW, AUX 24V	Instrument panel	POW
C	1660	Connector	Connector, 2-pole, POW, AUX 24V	Instrument panel	POW
C	1661	Connector	Connector, 2-pole, POW, AUX 12V	Instrument panel	POW
C	1662	Connector	Connector, 2-pole, POW, AUX 12V	Instrument panel	POW
C	1663	Connector	Connector, 3-pole, POW, socket	Instrument panel	POW
C	1664	Connector	Connector, 3-pole, POW, socket	Instrument panel	POW
C	1665	Connector	Connector, 5-pole, BWE, Trailer lock ind	Instrument panel	BWE
C	1666	Connector	Connector, 3-pole, VIS	Instrument panel	VIS
C	1667	Connector	Connector, 3-pole, VIS	Instrument panel	VIS
C	1668	Connector	Connector, 3-pole, VIS	Instrument panel	VIS
C	1669	Connector	Connector, 5-pole, SMS, Tagaxel press warn	Frame	SMS
C	1670	Connector	Connector, 3-pole, BOL	Instrument panel	BOL
D	1045	Diode	Diode, ESC1 + disabled pedals, beside C259-18 & 5	Instrument panel	BWS
D	1046	Diode	Diode, ESC2 + disabled pedals, beside C259-18 & 8	Instrument panel	BWS
D	1047	Diode	Diode, ISSW3 Aux generator, beside C259-3 & C489-14	Instrument panel	BWS
D	1048	Diode	Diode, BOL, ELC, behind S1030	Instrument panel	BOL
D	1049	Diode	Diode, BOL, ELC, beside E18	Instrument panel	BOL
D	1050	Diode	Diode, BOL, ELC, beside E18	Instrument panel	BOL
D	1051	Diode	Diode, BOL, ELC, behind S1030	Instrument panel	BOL
D	1052	Diode	Diode, BOL, ELC, behind S1031	Instrument panel	BOL
D	1053	Diode	Diode, BOL, ELC, beside S1010	Instrument panel	BOL
D	1054	Diode	Diode, BOL, ICL, beside S1010	Instrument panel	BOL
D	1055	Diode	Diode, BOL, CCS, beside S1010	Instrument panel	BOL

D	1056	Diode	Diode, BOL, VIS, beside S1010	Instrument panel	BOL
D	1057	Diode	Diode, BOL, BWS, beside S1010	Instrument panel	BOL
D	1058	Diode	Diode, BOL, VIS, beside S1010	Instrument panel	BOL
D	1059	Resistor	Resistor, BOL, EBS, 10kOhm, beside S1010	Instrument panel	BOL
D	1060	Resistor	Resistor, AHS, Fan, beside S3	Instrument panel	AHS
D	1061	Diode	Diode, AHS, heater upkeep, beside R1038, ADR	Instrument panel	AHS
D	1062	Diode	Diode, AHS, 15-supply, beside R1038, ADR	Instrument panel	AHS
D	1063	Diode	Diode, AHS, fan ATA, beside E17	Instrument panel	AHS
D	1064	Diode	Diode, AHS, fan E17, beside E17	Instrument panel	AHS
D	1065	Diode	Diode, BOL, ELC, behind S1031	Instrument panel	BOL
D	1066	Diode	RTS/Iris, inside Iris unit.	Roof shelf.	RTS
D	1067	Diode	RTS/Iris, under center electric unit.	Instrument panel	RTS
D	1068	Diode	Diode, BOL adapter	Instrument panel	BOL
D	1069	Resistor	Resistor, GMS ZF Transmatic, 680 Ohm	Instrument panel	GMS
D	1070	Resistor	Resistor, GMS ZF Transmatic, 680 Ohm	Instrument panel	GMS
D	1071	Diode	Diode, BOL adapter	Instrument panel	BOL
D	1072	Diode	Diode, BOL DRL	Instrument panel	BOL
D	1073	Diode	Diode, BOL, BWS, in P2	Instrument panel	BOL
D	1074	Diode	Diode, BOL,Basic, in P2	Instrument panel	BOL
D	1075	Diode	Diode, SMS, adjusted level	instrument panel	SMS
E	18X	Control unit	Control unit , ELC, moved to pos. behind the radio	Instrument panel	SMS
E	1002	Control unit	Control unit, ZF Transmatic	Instrument panel	GMS
E	1004	Control unit	Control unit, overspeed prot. gate interlock, ZF Transmatic	Instrument panel	GMS
E	1012	Control unit	Control unit RTS/Iris, Inside roof shelf next to TCO.	Instrument panel	RTS
E	1013	Control unit	Control unit, VIS, siren amplifier	Roof shelf.	VIS
E	1013.A	Control unit	Control unit, VIS, siren amplifier	Roof shelf.	VIS
E	1013.B	Control unit	Control unit, VIS, siren amplifier	Roof shelf.	VIS
E	1013.C	Control unit	Control unit, VIS, siren amplifier	Roof shelf.	VIS
E	1014	Control unit	Control unit, GMS, CLR	Instrument panel	GMS
E	1015	Radio	Military radio	Instrument panel	AUS
F	1016	Fuse	Fuse, el heated windscreen	Instrument panel	EHW
F	1020	Fuse	Fuse holder, 4-pole, light for BOL-system, in P2	Instrument panel	BOL
F	1021	Fuse	Fuse, aux power supply, in P2	Instrument panel	BOL
F	1022	Fuse	Fuse holder, 4-pole , AHS, Aux ATA-heater, in P2	Instrument panel	AHS
F	1023	Fuse	Fuse holder, 1-pole, POW, TCO, RH battery	Frame	POW
F	1024	Fuseholder	Fuseholder, RTS/Iris.	Instrument panel	RTS
F	1026	Fuse	Fuse holder, 4-pole, BWS	Instrument panel	BWS
F	1027	Fuseholder	Fuse holder, 8-pole, VIS, lightbar fire rescue	Instrument panel	VIS
F	1028	Fuseholder	Fuse holder, 8-pole, EMS GCS	Instrument panel	EMS
F	1029	Fuseholder	Fuse holder, 8-pole, EMS GCS	Instrument panel	EMS
F	1030	Fuseholder	Fuse holder, 4-pole , 12V	Instrument panel	MOP
F	1031	Fuseholder	Fuse holder, 4-pole EHW	Instrument panel	EHW
F	1032	Fuseholder	Fuse holder, 4-pole UFS	Instrument panel	UFS
F	1033	Fuseholder	Fuse holder, 8-pole VIS, Working lamp	Instrument panel	VIS
F	1034	Fuseholder	8-pole, EMS OCS Eu6	Instrument panel	EMS
F	1035	Fuseholder	Fuse holder, 8-pole, POW, AUX 24V	Instrument panel	POW
F	1036	Fuseholder	Fuse holder, 8-pole, POW, AUX 12V	Instrument panel	POW
F	1037	Fuseholder	Fuse holder, 8-pole, BWE, Trailer lock ind	Instrument panel	BWE
F	1038	Fuseholder	Fuseholder, 8-pole, VIS	Instrument panel	VIS
G	1015	Ground	Ground, 21-pole, BOL, beside S1010 behind panel K	Instrument panel	BOL
G	1016	Ground	Ground, 21-pole, BOL, roof shelf near G9	Roof	BOL
G	1017	Ground	Ground, M6, BOL, near G14	Instrument panel	BOL
G	1018	Ground	Ground, 21-pole, BOL, beside S1010 behind panel K	Instrument panel	BOL
H	1003	Lighter	Cigarette lighter 12V	Instrument panel	POW
H	1004	Heater	Heater, el heated windscreen	Instrument panel	EHW

H	1005	Heater	Heater, AHS, Aux ATA-heater, at position H13	Floor	AHS
H	1007	Heater	Heater, AHS, Aux ATA-heater, at position H13	Floor	AHS
H	1005/C15	Connector	Heater AHS Aux ATA adaptor	Floor - Component	ATA
H	1008	Heater	Heater el heated windscreen, driver	Instrument panel	EHW
H	1009	Heater	Heater el heated windscreen, passenger	Instrument panel	EHW
K	1001	Diagnostics	Diagnostics outlet, ZF Transmatic, beside P2	Instrument panel	GMS
K	1004	Diagnostics	Diagnostics outlet, ATA, behind P2	Instrument panel	ATA
L	147/148	Lamp	Work lamp	Frame	BWS
L	147/148/C	Connector	Connector, 2-pole, BWS, working lamps	Frame	BWS
L	1011	Lamp	Lamp, BOL, left front	Frame	BOL
L	1012	Lamp	Lamp, BOL, right front	Frame	BOL
L	1013	Lamp	Lamp, BOL, stop rear, LH	Frame	BOL
L	1013.A	Connector	Connector, Stop lamp adapter	Frame	BOL
L	1014	Lamp	Lamp, BOL, stop rear, RH	Frame	BOL
L	1015	Lamp	Lamp, BOL, rear LH, inside L1041	Frame	BOL
L	1016	Lamp	Lamp, BOL, rear RH, inside L1042	Frame	BOL
L	1017	Lamp	Lamp, BOL, cross rear	Frame	BOL
L	1031	Lamp	Lamp, BOL, end out marker left rear	Frame	BOL
L	1032	Lamp	Lamp, BOL, end out marker right rear	Frame	BOL
L	1041	Lamp	Lamp, rear combination, left	Frame	BOL
L	1042	Lamp	Lamp, rear combination, right	Frame	BOL
L	1043	Lamp	Lamp, side marker	Frame	VIS
L	1044	Lamp	Lamp, side marker	Frame	VIS
L	1045	Lamp unit	Lamp unit, lightbar and siren	Roof	VIS
L	1046	Lamp	Lamp, blue rotating beacon left, lightbar	Component	VIS
L	1047	Lamp	Lamp, blue rotating beacon right, lightbar	Component	VIS
L	1048	Lamp	Lamp, blue flashing light, left, lightbar	Component	VIS
L	1049	Lamp	Lamp, blue flashing light, right, lightbar	Component	VIS
L	1050	Lamp unit	Lamp unit, blue flashing light, left	Component	VIS
L	1051	Lamp unit	Lamp unit, blue flashing light, right	Component	VIS
L	1052	Lamp unit	Lamp unit, blue flashing light, second left	Component	VIS
L	1053	Lamp unit	Lamp unit, blue flashing light, second right	Component	VIS
L	1054	Lamp	Distance light	Sunvisor	VIS
L	1055	Lamp	Distance light	Sunvisor	VIS
L	1056	Lamp	Work lamp	Frame	BWS
L	1057	Lamp	Work lamp	Frame	BWS
L	1058	Lamp	Work lamp	Frame	BWS
L	1059	Lamp	Work lamp	Frame	BWS
L	1060	Lamp	REGISTRATION PLATE LAMP LED	Frame	VIS
L	1061	Lamp	REGISTRATION PLATE LAMP LED	Frame	VIS
L	1062	Lamp	LED TAIL LAMP LH	Frame	VIS
L	1063	Lamp	LED TAIL LAMP RH	Frame	VIS
L	1064	Lamp	Infrared light	Frame	VIS
L	1065.C	Lamp	Lamp, rear combination civil, left	Frame	VIS
L	1065.M	Lamp	Lamp, rear combination military, left	Frame	VIS
L	1066.C	Lamp	Lamp, rear combination civil, right	Frame	VIS
L	1066.M	Lamp	Lamp, rear combination military, right	Frame	VIS
L	1065	Lamp	Lamp, rear combination, left	Frame	VIS
L	1065/1066	Lamp	Lamp rear combination, left right	Component	VIS
L	1066	Lamp	Lamp, rear combination, right	Frame	VIS
L	1067	Lamp	Side marker lamp, CP19E, Driver side	Frame	VIS
L	1068	Lamp	Side marker lamp, CP19E, Passenger side	Frame	VIS
L	1069	Lamp	Frame work lights	Frame	VIS
L	1070	Lamp	Frame work lights	Frame	VIS
L	1071	Lamp	Frame work lights	Frame	VIS

L	1072	Lamp	Frame work lights	Frame	VIS
N	1003	Siren	Siren, VIS, lightbar	Component	VIS
N	1004	Sounder	Summer, INL, open door warning	Instrument panel	INL
O	1006	Control	Control mini, ATA-heater, benith O2	Floor	AHS
O	1006x1	Control	Control mini, ATA-heater, beneath O2	Floor	AHS
O	1007	Control	Control mini, BOL, ATA-heater, benith O2	Floor	AHS
O	1008	Counter	Engine time counter, EMS	Instrument panel	EMS
R	1003	Relay	Relay, power supply gas	Electric panel	GCS
R	1024	Relay	Relay, el heated windscreen	Instrument panel	EHW
R	1025	Relay	Relay, el heated windscreen	Instrument panel	EHW
R	1036	Relay	Relay, BOL 15-relay, in P2	Instrument panel	BOL
R	1037	Relay	Relay, AHS, Circle pump WTA-heater, in P2	Instrument panel	AHS
R	1038	Relay	Relay, AHS, heater upkeep, in P2, ADR	Instrument panel	AHS
R	1039	Relay	Relay, AHS, fan, in P2	Instrument panel	AHS
R	1040	Relay	RTS/Iris	Instrument panel	RTS
R	1041	Relay	RTS/Iris	Instrument panel	RTS
R	1042	Relay	RTS/Iris	Instrument panel	RTS
R	1043	Relay	Relay, SMS, reset	Instrument panel	SMS
R	1044	Relay	Relay, SMS Dump	Instrument panel	SMS
R	1045	Relay	Relay, delay, tag axle	Instrument panel	SMS
R	1046	Relay	Relay, lightbar	Instrument panel	VIS
R	1047	Relay	Relay, AWD	Instrument panel	AWD
R	1048	Relay	Relay, Power supply, Common, EMS GCS	Instrument panel	EMS
R	1049	Relay	Relay, Power supply, High pressure valve, EMS GCS	Instrument panel	EMS
R	1050	Relay	Relay, Power supply, Injectors, EMS GCS	Instrument panel	EMS
R	1051	Relay	Relay, Power supply, Injectors, EMS GCS	Instrument panel	EMS
R	1052	Relay	Relay, Warning lamp, Solenoid valves LHS	Instrument panel	EMS
R	1053	Relay	Relay, Warning lamp, Solenoid valves RHS	Instrument panel	EMS
R	1054	Relay	Relay holder, Warning lamp, UFS	Instrument panel	UFS
R	1055	Relay	Relay holder, Warning lamp, UFS	Instrument panel	UFS
R	1056	Relay	Relay, BWS, UFS	Instrument panel	UFS
R	1057	Relay	Relay, Warning lamp, UFS	Instrument panel	UFS
R	1058	Relay	Relay, B1014 pos 1&4, UFS	Instrument panel	UFS
R	1059	Relay	Relay, B1014 pos 2&3, UFS	Instrument panel	UFS
R	1060	Relay	Relay, 15-supply, EMS OCS Eu6	Instrument panel	EMS
R	1061	Relay	Relay, Auxiliary heater, EMS OCS Eu6	Instrument panel	EMS
R	1062	Relay	Relay, Gas tanks Right, EMS OCS Eu6	Instrument panel	EMS
R	1063	Relay	Relay, Gas tanks Left, EMS OCS Eu6	Instrument panel	EMS
R	1064	Relay	Relay holder, Gas tanks, EMS OCS Eu6	Instrument panel	EMS
R	1065	Relay	Relay holder, 15 supply,AHS, EMS OCS Eu6	Instrument panel	EMS
R	1066	Relay	Relay holder, BOL	Instrument panel	BOL
R	1067	Relay	Relay holder, load transfer	Instrument panel	SMS
R	1068	Relay	Relay, load transfer, input BWS	Instrument panel	SMS
R	1069	Relay	Relay, load transfer, solenoid valve	Instrument panel	SMS
R	1070	Relay	Relay holder, load transfer	Instrument panel	SMS
R	1071	Relay	Relay, load transfer, split shaft	Instrument panel	SMS
R	1072	Relay	Relay, load transfer, parking brake	Instrument panel	SMS
R	1073	Relay	Relay, SMS, adjusted level	Instrument panel	SMS
R	1074	Relay	Relay holder, BWE, Trailer lock ind	Instrument panel	BWE
R	1075	Relay	Relay, VIS	Instrument panel	VIS
R	1076	Relay	Relay, VIS	Instrument panel	VIS
R	1077	Relay	Relay, VIS	Instrument panel	VIS
R	1078	Relay	Relay, VIS	Instrument panel	VIS
R	1079	Relay	Relay, holder, working lamp, VIS	Instrument panel	VIS
R	1080	Relay	Relay, holder, working lamp, VIS	Instrument panel	VIS

R	1081	Relay	Relay, holder, BWE, Trailer lock ind	Instrument panel	BWE
R	1082	Relay	Relay, holder, tagaxel press warn	instrument panel	SMS
R	1083	Relay	Relay, tagaxel press warn	instrument panel	SMS
S	1010	Switch	Switch, BOL system, behind panel K	Instrument panel	BOL
S	1018	Switch	Switch, BMS, ABS off road	Instrument panel	BMS
S	1025	Switch	Switch, front central differential lock	Instrument panel	AWD
S	1028	Switch	Switch, front wheel drive	Instrument panel	AWD
S	1029	Switch	Switch, el heated windscreen	Instrument panel	EHW
S	1030	Switch	Switch, BOL, manual controll ELC	Instrument panel	BOL
S	1031	Switch	Switch, BOL, manual controll ELC	Instrument panel	BOL
S	1032	Switch	RTS/Iris, Instrument panel F.	Instrument panel	RTS
S	1033	Switch	Switch, BWS Speed limit	Instrument panel	BWS
S	1034	Switch	Switch, VIS, lightbar	Roof shelf	VIS
S	1035	Switch	Switch, VIS, radio transmit lightbar	Roof shelf	VIS
S	1036	Switch	Switch, aut/man, tag axle	Instrument panel	SMS
S	1037	Switch	Switch, pressure, tag axle	Instrument panel	SMS
S	1038	Switch	Switch, VIS, working lamp	Instrument panel	VIS
S	41/C1564	Switch	Switch, central lock	Door	Las
S	1039/S30	Switch	Switch, IR light	Instrument panel	VIS
S	1039	Switch	Switch, IR light	Instrument panel	VIS
S	1040	Switch	Switch, load transfer	Instrument panel	SMS
S	1041	Switch	Switch, SMS, adjusted level	Instrument panel	SMS
S	1042/S20	Switch	Switch, SMS, normal level	Instrument panel	SMS
S	1043	Switch	Switch, BWE, Trailer lock ind	Instrument panel	BWE
S	1044	Switch	Switch, VIS, Work L Roof	Instrument panel	VIS
S	1045	Switch	Switch, VIS, Work L Cab	Instrument panel	VIS
S	1046	Switch	Switch, VIS, Work L Frame	Instrument panel	VIS
T	1009	Monitor	Pressure monitor, parking brake, PTO	Instrument panel	BWS
T	1010	Sensor	Sensor, level, tag axle	Frame	SMS
T	1011	Sensor	Sensor, level, tag axle	Frame	SMS
T	1012	Sensor	Sensor, turbine speed	Gearb	GMS
T	1013	Sensor	Sensor, air pressure	Gearb	GMS
T	1014	Sensor	Sensor, air pressure, filling	Gearb	GMS
T	1015	Sensor	Sensor, oil temperature	Gearb	GMS
T	1016	Sensor	Sensor, coolant temperature	Gearb	GMS
T	1017	Sensor	Sensor, BWE, Trailer lock ind	Frame	BWE
T	1018	Sensor	Sensor, SMS, Tagaxel press warn 0,2b	Frame	SMS
T	1019	Sensor	Sensor, SMS, Tagaxel press warn 3,0	Frame	SMS
U	1002	Satelit antenna	RTS/Iris, on the roof.	Roof	RTS
V	1017	Solenoid valve	Solenoid valve, gate interlock	Frame	EMS
V	1030	Solenoid valve	Solenoid valve, unlocking of fifth wheel slider	Frame	UFS
V	1031	Solenoid valve	Solenoid valve, AWS, difflock tandem front, beside V10	Frame	AWD
V	1032	Pump	Pump, AHS, ATA, Fuel metering pump, LH beam	Frame	AHS
V	1033	Solenoid valve	Solenoid valve, tag axle	Frame	SMS
V	1034	Solenoid valve	Solenoid valve, tag axle	Frame	SMS
V	1035	Solenoid valve	Solenoid valve, tag axle	Frame	SMS
V	1036	Solenoid valve	Solenoid valve, air pressure	Gearb	GMS
V	1037	Solenoid valve	Solenoid valve, fast out	Gearb	GMS
V	1038	Solenoid valve	Solenoid valve, turbine brake	Gearb	GMS
V	1039	Solenoid valve	Solenoid valve assembly, EMS GCS	Frame	EMS
V	1040	Solenoid valve	Solenoid valve assembly, EMS GCS	Frame	EMS
V	1041	Solenoid valve	Solenoid valve , EMS GCS OCS	Frame	EMS
V	1042	Solenoid valve	Solenoid valve , EMS GCS OCS	Frame	EMS
V	1043	Solenoid valve	Solenoid valve , EMS GCS OCS	Frame	EMS
V	1044	Solenoid valve	Solenoid valve , EMS GCS OCS	Frame	EMS

V	1045	Solenoid valve	Solenoid valve , EMS GCS OCS	Frame	EMS
V	1046	Solenoid valve	Solenoid valve , EMS GCS OCS	Frame	EMS
V	1047	Solenoid valve	Solenoid valve , EMS GCS OCS	Frame	EMS
V	1048	Solenoid valve	Solenoid valve , EMS GCS OCS	Frame	EMS
V	1049	Solenoid valve	Solenoid valve, diff lock, front	Frame	AWD
V	1050	Solenoid valve	Solenoid valve, load transfer	Frame	SMS



**Component Library****Bus FKN**

No.	Type	Description	Harness	System
C 500	Joint connector	Joint connector, Instrument lights	Instrument panel	ICL
C 501	Joint connector	Joint connector, Instrument lights	Instrument panel	ICL
C 502	Joint connector	Joint connector, Power supply switches	Instrument panel	BCS
C 505	Joint connector	Joint connector Red CAN	Instrument panel	
C 506	Joint connector	Joint connector Yellow CAN	Instrument panel	COO
C 507	Joint connector	Joint connector Green CAN	Instrument panel	COO
C 508	Joint connector	Joint connector Brown CAN	Instrument panel	
C 509	Connector	Connector, 6 Pole	Instrument panel	AUS
C 520	Socket	Socket, 7 pole Towing device	Instrument panel	VIS
C 535	Charging socket	Charging socket		POW
C 540	Connector	Connector, 3 pole	Instrument panel	GMS
C 590	Connector	Connector, 9 pole	Instrument panel	LDW
C 600	Connector	Connector, 21 pole	Instrument panel	POW
C 600Trans	Connector	Connector, 21 pole	Instrument panel	POW
C 601	Connector	Connector, 21 pole	Instrument panel	ICL
C 602	Connector	Connector, 21 pole	Instrument panel	VIS
C 603	Connector	Connector, 21 pole	Instrument panel	COO
C 604	Connector	Connector, 9 pole	Instrument Panel	TCO
C 605	Connector	Connector, 12 pole	Instrument panel	ICL
C 606	Connector	Connector, 36 pole	Instrument Panel	Common
C 607	Connector	Connector, 36 pole	Instrument panel	Common
C 608	Connector	Connector, 36 pole	Instrument Panel	Common
C 609	Connector	Connector, 6 pole	Instrument Panel	AICC + LDW
C 610	Connector	Connector, 3 pole	Battery Box	POW
C 620	Splice	Splice, Diode D555	Electric panel	POW
C 621	Splice	Splice, Diode D555	Electric panel	POW
C 622	Connector	Connector, Combi Join	Electric panel	HEV
C 623	Connector	Connector,	Electric panel	
C 624	Connector	Connector,	Electric panel	
C 625	Connector	Connector,	Electric panel	
C 626	Connector	Connector,	Electric panel	
C 627	Connector	Connector, 21 pole	Electric panel	BCI
C 628	Connector	Connector, 21 pole	Electric panel	BCI
C 629	Connector	Connector, 6 pole	Electric panel	BCI
C 630	Connector	Connector, 18 pole	Rear Module	EMS
C 631	Connector	Connector, 9 pole	Rear Module	APS
C 632	Connector	Connector, 15 pole	Rear Module	APS, FHS
C 633	Connector	Connector, 25 pole	Rear Module	EMS , EEC
C 634	Connector	Connector, 21 pole	Rear Module	EMS Gas
C 635	Connector	Connector, 6 pole	Rear Module	EMS Gas
C 636	Connector	Connector, 3 pole Gas Tank Supply	Body Builder connection	EMS Gas
C 637	Connector	Connector, 12 pole	Rear Module	EMS Gas
C 638	Connector	Connector, 6 pole Fuel heater	Rear Module	Fuel heater
C 639	Connector	Connector, 21 pole LCS	Rear Module	LCS
C 640	Connector	Connector, 21 pole	Rear Module	GMS
C 641	Connector	Connector, 9 pole HEV	Electric Panel	HEV
C 642	Connector	Connector, 6 pole Diagnose Cummins	Electric Panel	EMS D7
C 643	Connector	Connector, 3 pole EMS ETH	Rear Module	EMS ETH
C 650	Connector	Connector, 21 pole	Front Axle	Common
C 651	Connector	Connector, 3 pole	Front Axle	BCS
C 652	Connector	Connector, 6 pole	Front Axle -BMS ESP	BMS
C 653	Connector	Connector, 6 pole	Front axle	COO, BCS

C	655	Connector	Connector, 36 pole	Front Axle	Common
C	656	Connector	Connector, 12 pole	Front Axle	EEC
C	660	Connector	Connector, 21 pole	Rear Module	Common
C	661	Connector	Connector, 3 pole	Rear Module / Frame	BMS
C	663	Connector	Connector, 36 pole	Driven Axle	Common
C	670	Connector	Connector, 21 pole	Rear Module	Common
C	674	Connector	Connector, 3 pole	Rear Module	EMS, ETH
C	675	Connector	Connector, 6 pole	Rear Module	COO, BCS
C	680	Connector	Connector, 21 pole	Articulated	ACS
C	690	Connector	Connector, 21 pole	Body Builder connection	BCS
C	691	Connector	Connector, 18 pole	Body Builder connection	BCS
C	692	Connector	Connector, 9 pole	Body Builder connection	BCS
C	693	Connector	Connector, 12 pole	Body Builder connection	VIS
C	693A	Connector	Connector, 12 pole	Body Builder connection	VIS
C	694	Connector	Connector, 6 pole	Body Builder connection	VIS
C	695	Connector	Connector, 15 pole	Body Builder connection	VIS
C	696	Connector	Connector, 6 pole	Body Builder connection	EMS Gas
C	697	Connector	Connector, 15 pole	Body Builder connection	ICL
C	698	Connector	Connector, 12 pole	Body Builder connection	RTC
C	699	Connector	Connector, 3 pole	Body Builder connection	BB
C	710	Junction box	Connector, 5pole	Rear Module	POW
C	711	Charging socket	Connector, 2 pole	Battery Box	POW
C	712	Junction box	Connector, 5 pole HEV +24V	Rear Module	HEV
C	713	Junction box	Connector 2 pole HEV Ground	Rear Module	HEV
C	720	Junction box	Junction box, 1-pole, before articulation	Battery Box	POW
C	721	Junction box	Junction box, 1-pole, behind articulation	Battery Box	POW
C	728	Connector	Connector, 16 Pole Component Cummins.	Rear Module	EMS LCS
C	729	Splice	Splice, Air filter indicator	Rear Module	COO
C	730	Splice	Splice, 1 pole	Rear Module	BCS
C	731	Splice	Splice, 1 pole	Rear Module	BCS
C	732	Splice	Splice, Fire alarm	Rear Module	BCS
C	733	Splice	Splice, Fire alarm	Rear Module	BCS
C	734	Splice	Splice, Fire alarm	Rear Module	BCS
C	735	Splice	Splice, Fire alarm	Rear Module	BCS
C	736	Splice	Splice, Fire alarm	Rear Module	BCS
C	737	Splice	Splice, Fire alarm	Rear Module	BCS
C	738	Connector	Connector, 4 pole	Engine	EMS
C	739	Connector	Connector, 23 pole EEC	Engine	EEC 3
C	740	Connector	Connector, 7 pole	Rear Module	GMS
C	741	Connector	Connector., 4 pole	Rear Module	GMS
C	742	Splice	Splice, GMS/CLS 4 to 16 power	Rear Module	GMS
C	743	Splice	Splice, GMS/CLS 4 to 16 ground	Rear Module	GMS
C	744	Splice	Splice, GMS/CLS 16 to 4 power	Rear Module	GMS
C	745	Splice	Splice, GMS/CLS 16 to 4 ground	Rear Module	GMS
C	746	Connector	Connector, 31 pole ZF gearbox	Rear Module	GMS
C	747	Splice	Splice, Fire alarm	Rear Module	BCS
C	748	Splice	Splice, Fire alarm	Rear Module	BCS
C	749	Connector	Connector, 24 pole	Rear Module	GMS
C	750	Connector	Joint connector GMS/EMS CAN	Rear Module	GMS
C	760	Connector	Joint connector Yellow CAN	Rear Module	APS
C	761	Connector	Joint connector LCS/EEC CAN	Rear Module	LCS
C	762	Connector	Joint connector LCS/EEC CAN	Rear Module	LCS
C	763	Connector	Joint connector LCS/EMS CAN	Rear Module	LCS
C	764	Connector	Joint connector Ground LCS	Rear Module	LCS
C	765	Connector	Joint connector Ground LCS	Rear Module	LCS

C	766	Connector	Joint connector Ground LCS	Rear Module	LCS
C	767	Connector	Joint connector Power supplyLCS	Rear Module	LCS
C	768	Connector	Joint connector Power supplyLCS	Rear Module	LCS
C	769	Splice	Splice, Heating LCS/SCR Hoses	Rear Module	LCS
C	770	Splice	Splice, LCS/SCR	Rear Module	LCS
C	771	Connector	Connector, 14 pole LCS Cross over	Rear Module	LCS
C	772	Connector	Connector, 12 pole Lambda sensor Gas	Rear Module	OCS
C	773	Connector	Joint connector GMS SUB-CAN	Rear Module	HEV
C	776	Connector	Connector, 2 pole R676 Heater	Rear Module	LCS
C	795	Connector	Connector , 7 pole	Rear Module	VIS
C	796	Connector	Connector, 3 pole	Rear Module	BCS
C	797	Connector	Connector, 2 pole	Rear Module	BCS
C	798	Connector	Connector, 3 pole HEV	Rear Module	HEV
C	810	Junction box	Connector 1 pole	Before Articulation	POW
C	811	Junction box	Connector 1 pole	After Articulation	POW
C	820	Connector	Connector, 21 pole	EMS to Artic	EMS
C	821	Connector	Connector, 21 pole	APS to Artic	APS
C	822	Connector	Connector, 21 pole	EBS to Artic	BMS
C	830	Connector	Connector ,18 pole	Rear module	EMS
C	831	Connector	Connector, 9 pole	Rear module	APS
C	832	Connector	Connector, 15 pole	Rear Module	APS, FHS
C	833	Connector	Connector,3 pole	Rear Module	EMS, ETH
C	834	Connector	Connector, 21 pole	Rear Module	EMS, GAS
C	835	Connector	Connector, 9 pole	Rear Module	EMS, GAS
C	837	Connector	Connector 12 pole	Rear Module	EMS, GAS
C	838	Connector	Connector, 6 pole Fuel heater	Rear Module	Fuel heater
C	840	Connector	Connector.21 pole	Rear module	GMS
C	843	Connector	Connector.3 pole EMS ETH	Rear module	EMS ETH
C	853	Connector	Connector, 6-pole, Fuel sensors	Rear module	COO
C	860	Connector	Connector, 21	Rear module	Common
C	880	Connector	Connector, 18 pole	ACS	ACS
C	885	Connector	Joint connector Red CAN	Electric Panel Artic	EMS
C	886	Connector	Joint connector Red CAN	Electric Panel Artic	EMS
C	895	Connector	Connector, 9 pole	Rear Module	VIS
C	900	Connector	Connector, 3 pole	Body Builder connection	C200
C	901	Connector	Connector, 2 pole	Gas installation Roof	GCS
C	902	Splice	Splice, GCS High pressure tank	Gas installation Roof	GCS
C	903	Splice	Splice, GCS High pressure tank	Gas installation Roof	GCS
C	904	Connector	Connector, 18 pole HEV	Electric Panel/Roof	HEV
C	2083	Connector	Connector, 12-pole, Comfort shift	Instrument panel / Component	GMS
C	2500	Connector	Connector 21 pole , Hybrid	Electrical Panel	HMS
C	2501	Connector	Connector 21 pole , Hybrid	Electrical Panel	HMS
C	2502	Connector	Connector 21 pole , Hybrid	Electrical Panel	HMS
C	2508	Splice	Splice, DC link (Hybrid	Rear Module (Cable deck)	HMS
C	2509	Splice	Splice, DC link (Hybrid	Rear Module	HMS
C	2510	Connector	Connector, 9 pole HMS	Electric panel rear Hybrid	HMS
C	2511	Connector	Connector, 9 pole RWS	Electric panel rear Hybrid	RWS
C	2512	Connector	Connector, 9 pole RWS (Diagnose)	Electric panel rear Hybrid	RWS
C	2513	Connector	Connector, 2 pole RWS	Electric panel rear Hybrid	RWS
C	2514	Connector	Connector, 3 pole RWS	Electric panel rear Hybrid	RWS
C	2515	Connector	Connector, 3 pole RWS	Electric panel rear Hybrid	RWS
C	2516	Connector	Connector, 12 pole Hybrid	Electric Panel Body	HMS
D	500	Diode	Diode unit	Electric Panel	BSB
D	519	Sensor	Artic Angle sensor	ACS	ACS
D	555	Diode	Diode in electric panel	Electric Panel	POW

D	560	Diode	Diode, Windscreen wiper and washer	Instrument Panel / AIP	VIS
D	561	Resistor	Resistor, Power 1,5 Ohm 100W		EMS Gas
D	562	Diode	Diode, Bus stop brake hold	Electric panel	BSB
D	563	Diode	Diode, Bus stop brake 5 Km/h	Electric panel	BSB
D	564	Diode	Diode, Bus stop brake Parking Br	Electric panel	BSB
D	565	Diode	Diode unit	Electric Panel	BSB
D	566	Resistor	Resistor, Termination 120 Ohm (Cummins EEC)		LCS
D	567	Resistor	Resistor, Termination 120 Ohm (Cummins-S8)		LCS
D	568	Resistor	Resistor, Termination 120 Ohm (S8-Cummins)		LCS
D	569	Resistor	Resistor, Termination 120 Ohm (BCI)	Electric Panel outer	BCI
D	750	Diode	Diode Unit, BNS2 main Node DD		
D	2500	Resistor	Resistor, Pull-Up (HMS)	Rear Module	HMS
D	2501	Resistor	Resistor, Pull-Up (HMS)	Rear Module	HMS
D	2502	Resistor	Resistor, Pull-Up (RWS)	Electric panel rear Hybrid	RWS
D	2503	Capacitor	Capacitor HMS	Electric Panel	HMS
D	2504	Capacitor	Capacitor HMS	Electric Panel	HMS
E	500	Control unit	Signal amplifier	Electric Panel	TCO
E	502	Control unit	Control unit, GMS ZF automatic gearbox	Electric Panel	GMS
E	504	Control unit	Control unit, ELC Articulated bus Rear	Electric panel Artic	SMS
E	506	Control unit	Control unit, ZF automatic gearbox	Rear Module	GMS
E	510	Control unit	Tilt switch	Instrument panel	SMS
E	750	Control unit	Control unit, BCS	Common	BCS
E	751	Control unit	Control unit, ACS 1	Electric Panel Artic	ACS
E	752	Control unit	Control unit, ACS 2	Electric Panel Artic	ACS
E	753	Control unit	Control unit, GMS ZF automatic gearbox	Gearbox	GMS
E	754	Control unit	Control unit, GMS Voith automatic gearbox	Electric Panel	GMS
E	755	Control unit	Control unit, Voith automatic gearbox	Rear module	GMS
E	756	Control unit	Control unit, BCI (Slave)	Electric Panel	BCI
E	757	Control unit	Control unit, BCI (Slave)	Electric Panel	BCI
E	758	Control unit	Control unit, LCS /EMS	Engine	LCS
E	2500	Control unit	Control unit, Speed puls generator	Electric panel Hybrid Roof	
E	2501	Control unit	Control unit, Gateway CAN	Electric panel Hybrid Roof	
E	2502	Control unit	Control unit, Hybrid Interactor	Electric panel Hybrid Roof	
E	2503	Control unit	Control unit, RWS	Electric panel Rear Hybrid	RWS
E	2504	Control unit	Control unit WCS	Instrument panel	WCS
F	500	Fuse 1 pole	Main Fuse, 30	Battery box	POW
F	501	Fuse 1 pole	Main Fuse, B+	Battery box	POW
F	502	Fuse 2 pole	Main fuses, B+ and 30	Battery box	POW
F	550	Fuse	A.P.S. B+	Electric Panel	APS
F	551	Fuse 4 pole	Fuel Heater, APS	Electric Panel	FHS
F	552	Fuse 4 pole	Fuse Holder 4 pole, EMS Gas	Electric Panel	EMS Gas
F	553	Fuse 4 pole	Fuse Holder 4 pole, EMS Gas	Electric Panel	EMS Gas
F	554	Fuse 4 pole	Fuse Holder 4 pole, GMS/CLS	Electric Panel	GMS/CLS
F	555	Fuse 1 pole	Fuse Holder 1 Pole, Body Builder AC	Frame	POW
F	556	Fuse 4 pole	Fuse holder 4 pole, DIS (12V)	Instrument Panel	DIS
F	557	Fuse 4 pole	Fuse holder 4 pole EEC	Electric Panel	EEC
F	558	Fuse 4 pole	Fuse holder 4 pole BCI	Electric Panel	BCI
F	559	Fuse 4 pole	Fuse holder 4 pole LCS	Electric Panel	LCS
F	560	Fuse 4 pole	Fuse holder 4 pole LCS	Electric Panel	LCS
F	561	Fuse 1 pole	Main Fuse CUV (100A)	Battery box	POW
F	562	Fuse 4 pole	Fuse holder 4 pole Ethanol valve	Electric panel Artic	
F	563	Fuse 4 pole	Fuse holder 4 pole HEV	Electric Panel	HEV
F	564	Fuse 4 pole	Fuse holder 4 pole HEV	Component	HEV
F	565	Fuse 1 Pole	Main Fuse VIS (B+)	Battery box	POW
F	566	Fuse 4 pole	Fuse holder 4 pole LCS	Electric Panel	LCS

[illegible]

F	755	Fuse	Fuse, reserved for Omni		
F	756	Fuse	Fuse, reserved for Omni		
F	757	Fuse	Fuse, reserved for Omni		
F	758	Fuse	Fuse, reserved for Omni		
F	759	Fuse	Fuse, reserved for Omni		
F	760	Fuse	Fuse, reserved for Omni		
F	761	Fuse	Fuse, reserved for Omni		
F	762	Fuse	Fuse, reserved for Omni		
F	763	Fuse	Fuse, reserved for Omni		
F	764	Fuse	Fuse, reserved for Omni		
F	765	Fuse	Fuse, reserved for Omni		
F	766	Fuse	Fuse, reserved for Omni		
F	767	Fuse	Fuse, reserved for Omni		
F	768	Fuse	Fuse, reserved for Omni		
F	769	Fuse	Fuse, reserved for Omni		
F	770	Fuse	Fuse, reserved for Omni		
F	771	Fuse	Fuse, reserved for Omni		
F	772	Fuse	Fuse, reserved for Omni		
F	773	Fuse	Fuse, reserved for Omni		
F	774	Fuse	Fuse, reserved for Omni		
F	775	Fuse	Fuse, reserved for Omni		
F	776	Fuse	Fuse, reserved for Omni		
F	777	Fuse	Fuse, reserved for Omni		
F	778	Fuse	Fuse, reserved for Omni		
F	779	Fuse	Fuse, reserved for Omni		
F	780	Fuse	Fuse, reserved for Omni		
F	781	Fuse	Fuse, reserved for Omni		
F	782	Fuse	Fuse, reserved for Omni		
F	783	Fuse	Fuse, reserved for Omni		
F	784	Fuse	Fuse, reserved for Omni		
F	785	Fuse	Fuse, reserved for Omni		
F	786	Fuse	Fuse, reserved for Omni		
F	787	Fuse	Fuse, reserved for Omni		
F	788	Fuse	Fuse, reserved for Omni		
F	789	Fuse	Fuse, reserved for Omni		
F	790	Fuse	Fuse, reserved for Omni		
F	791	Fuse	Fuse, reserved for Omni		
F	792	Fuse	Fuse, reserved for Omni		
F	793	Fuse	Fuse, reserved for Omni		
F	794	Fuse	Fuse, reserved for Omni		
F	795	Fuse	Fuse, reserved for Omni		
F	796	Fuse	Fuse, reserved for Omni		
F	797	Fuse	Fuse, reserved for Omni		
F	798	Fuse	Fuse, reserved for Omni		
F	799	Fuse	Fuse, reserved for Omni		
F	800	Fuse	Main fuse B+ Body Builder	Battery bbox	POW
F	2500	Fuse 4 pole	Fuse holder 4 pole, Hybrid cooling system	Raer Module	HMS
G	500	Ground	Joint Connector Ground	Instrument Panel	POW
G	501	Ground	Joint Connector Ground	Instrument Panel	POW
G	502	Ground	Ground Bateriaes to Frame	Battery box	POW
G	503	Ground	Ground Engine to Frame	Rear Module	POW
G	504	Ground	Joint Connector Ground	Electric Panel	POW
G	505	Ground	Joint Connector Ground	Electric Panel	POW
G	556	Ground	Ground before Articulation		POW
G	557	Ground	Ground after Articulation		POW

G	568	Ground	Join Connector Ground	Electric Panel Artic	ACS
G	990	Ground	Ground Body		POW
G	2500	Ground	Ground HMS	Rear Module	HMS
G	2501	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2502	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2503	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2504	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2505	Ground	Ground HMS	Rear Module (bus Frame)	HMS
G	2506	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2507	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2508	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2509	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2510	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2511	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2512	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2513	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2514	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2515	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2516	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2517	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2518	Ground	Ground HMS	Rear Module (Cable deck)	HMS
G	2519	Ground			
G	2520	Ground	Ground ECC	Rear Module	ECC
G	2521	Ground			
H	500	Heater	Heater, hose heater	Rear Module	LCS
H	501	Heater	Heater, hose heater	Rear Module	LCS
H	502	Heater	Heater, hose heater	Rear Module	LCS
H	503	Heater	Heater, Air intake	Engine LCS	LCS
H	504	Heater	Heater, Fuel heater LCS	Engine LCS	LCS
K	500	Connector	Diagnose for ZF gearboxes	Rear Module	GMS
K	501	Connector	Diagnose for Voith gearboxes	Rear Module	GMS
K	502	Connector	Diagnose for Cummins D7	Instrument Panel	LCS
M	540	Motor	Motor, Bosster pump Ethanol	Rear Module	EMS
M	541	Motor	Motor, Vibrator in drivers chair	Component	LDW
M	579	Motor	Motor, Heater fan rear sofa DD	Climate	
M	2500	Motor	Motor, Hybrid Cooling system fan 1	Rear module	HMS
M	2501	Motor	Motor, Hybrid Cooling system fan 2	Rear module	HMS
M	2502	Motor	Motor, Hybrid Cooling system Coolland pump	Rear module	HMS
O	506	Recorder	Vehicle Data Recorder	Instrument Panel	TCO
O	507	Gauge	Gauge, Air pressure parking brake circuit	Instrument Panel	
O	508	Gauge	Gauge, Air pressure remaining circuit	Instrument Panel	
P	500	Alternator	Alternator	Engine	POW
P	501	Power distributo	Power distributor, battery compartment	Battery compartment	POW
R	500	Relay	Relay, Battery main switch	Battery box	POW
R	500X	Relay	Relay, Battery main switch	Battery compartment	Battery master switch
R	501	Relay	Relay, Steering Battery main switch	Electric Panel (P2)	POW
R	511	Relay	Relay, Emergency switch (ECE36)	Electric Panel (P2)	POW
R	512	Relay	Relay, Coollant level	Electric Panel	COO
R	650	Relay	Relay, Supply High pressure valve, Gas		
R	651	Relay	Relay, Supply Injectors, Gas		
R	652	Relay	Relay, Supply Injectors, Gas		
R	653	Relay	Relay, Supply high pressure valve aux heater	Electric panel	OCS
R	654	Relay	Relay, Master for OCS	Electric panel	OCS
R	655	Relay	Relay, Invert Coollant level	Electric panel	COO
R	660	Relay	Relay, Power supply S6/S7 + EEC	Electric panel	POW

R	661	Relay	Relay, Timer for R660	Electric panel	POW
R	662	Relay	Relay, Hose Heater/ Tank	Electric Panel	EEC
R	663	Relay	Relay, Hose heater/ Pump	Electric Panel	EEC
R	664	Relay	Relay, Parking brake applied	Electric panel	BSB
R	665	Relay	Relay, Bus Stop Brake request	Electric panel	BSB
R	666	Relay	Relay, Accelerator pedal	Electric panel	BSB
R	667	Relay	Relay, Idling Command request.	Electric panel	BSB
R	668	Relay	Relay, Timer for BSB	Electric panel	BSB
R	669	Relay	Relay, Fan and Fuel Cut off	Electric panel	???
R	670	Relay	Relay, Engine stop with Fire Alarm	Electric panel	???
R	671	Relay	Relay, Heating SCR Hose	Electric panel	LCS
R	672	Relay	Relay, Heating SCR Hose	Electric panel	LCS
R	673	Relay	Relay, Heating SCR Hose	Electric panel	LCS
R	674	Relay	Relay, LCS / SCR Sensors	Electric panel	LCS
R	675	Relay	Relay, LCS / SCR Heating Pump module	Electric panel	LCS
R	676	Relay	Relay, LCS Heater Air intake	Engine LCS	LCS
R	677	Relay	Relay, Timer	Electric panel	LCS/OCS
R	678	Relay	Relay, Power supply LCS	Electric panel	LCS
R	679	Relay	Relay, Supply Ignition, Gas	Electric panel	OCS
R	680	Relay	Relay, Ethanol valve	Electric Panel Artic	
R	681	Relay	Relay, Ground SCR hose D7	Electric panel	LCS
R	682	Relay	Relay, Ground SCR hose D7	Electric panel	LCS
R	683	Relay	Relay, Allison RELS	Electric Panel	Allison
R	700	Relay Socket	Relay Socket, 2 X Micro relay	Electric panel	
R	701	Relay Socket	Relay Socket, 2 X Micro relay	Electric panel	
R	702	Relay Socket	Relay Socket, 2 X Micro relay	Electric panel	
R	2500	Relay	Relay Hybrid cooling system fan Relay 1	Rear Module	HMS
R	2501	Relay	Relay Hybrid cooling system fan Relay 2	Rear Module	HMS
R	2502	Relay	Relay Hybrid cooling system fan Relay 3	Rear Module	HMS
R	2503	Relay	Relay WCS control lamp	Electric panel	WCS
S	500	Switch	Switch, Battery master switch	Instrument Panel	POW
S	504	Switch	Switch, Kneelin/normal level	Instrument panel	BCS
S	504X	Connector	Connector, Kneelin/normal level	Instrument panel	BCS
S	505	Switch	Switch, Fog light Rear	Instrument Panel	VIS
S	508	Switch	Switch,Engine compartment light	Rear Module	BCS
S	509	Switch	Switch,Start front/0/Start rear	Rear Module	BCS
S	510	Switch	Switch, Engine stop rear	Rear Module	BCS
S	513	Switch	Switch, Fog light Front	Instrument Panel	VIS
S	517	Switch	Switch, Gear lever for comfort shift	Component	GMS
S	520	Switch	Switch, Gear selector for automatic gearbox	Instrument panel	GMS / COO
S	522	Switch	Switch,Total raising / lowering	Instrument Panel	BCS
S	523	Switch	Switch, Alternative level	Instrument Panel	BCS
S	524	Switch	Switch, Fixed raised Idling speed	Instrument Panel	COO
S	525	Switch	Switch, Foot controlled retarder	Instrument Panel	BCS
S	527	Switch	Switch,exterior opening	door after rear axle	BNS II,Node 2.3
S	528	Switch	Switch,4-pole,exterior opening	side-middle	BNS II,Node 1.1
S	529	Switch	Switch, Exterior opening	front, right	BNS II,Node 1.3
S	529A	Connector	Connector,4 pole	drivers place	BNS II,Node 1.3
S	556	Switch	Switch, Forced closing doors	drivers place	Doors manoeuvre
S	556X	Connector	Connector, Forced closing doors	drivers place	Doors manoeuvre
S	557	Switch	Switch, Automatic opening doors	drivers place	Doors manoeuvre
S	557X	Connector	Connector, Automatic opening doors	drivers place	Doors manoeuvre
S	565	Switch	Switch, Distance lights	Instrument Panel	VIS
S	568	Switch	Switch, Emergency Switch (ECE36)	Instrument Panel	POW
S	579	Switch	Switch,3-pole ext. Pram signal	side-middle	BNS II,Node 1.1



S	580	Switch	Switch, External open request		
S	587	Switch	Switch, Manoeuvre front door	drivers place	Doors manoeuvre
S	587X	Connector	Connector, Manoeuvre front door	drivers place	Doors manoeuvre
S	584	Switch	Switch, Reset reverse interlock	Instrument Panel	ACS
S	591	Switch	Switch, Manoeuvre middle door	drivers place	Doors manoeuvre
S	591X	Connector	Connector, Manoeuvre middle door	drivers place	Doors manoeuvre
S	592	Switch	Switch, Manoeuvre rear door	drivers place	Doors manoeuvre
S	592X	Connector	Connector, Manoeuvre rear door	drivers place	Doors manoeuvre
S	593	Switch	Switch, Manoeuvre doors	drivers place	Doors manoeuvre
S	594	Switch	Switch, Ext. Opening disengagemant	Drivers place	BNS II,Node 1.3
S	595	Switch	Switch adj. rear view mirror	drivers place	rear view mirror
S	608	Switch	Switch,exterior pram signal	roof-rear-left	BNS II,Node 2.4
S	609	Switch	Switch,exterior opening	roof-rear-left	BNS II,Node 2.4
S	619	Switch	Switch, Manoeuvre door behind artic	drivers place	Doors manoeuvre
S	619X	Connector	Connector, Manoeuvre door behind artic	drivers place	Doors manoeuvre
S	622	Switch	Switch,drivers micro switch-floor	drivers place	CD radio
S	637	Switch	Switch, Locking device drivers gate	drivers place	
S	640	Switch	Switch, Manoeuvre all doors	drivers place	Doors manoeuvre
S	640X	Connector	Connector, Manoeuvre all doors	drivers place	Doors manoeuvre
S	599	Switch	Switch, El. battery master switch	Drivers place	BNS II,Node 1.3
S	656	Switch	Switch,interior opening	interior-middle	BNS II,Node 1.1
S	658	Switch	Switch,interior opening	roof-rear-left	BNS II,Node 2.4
S	692	Switch	Switch, Wheelchair place red	Wheelchair place	customer equipment
S	693	Switch	Switch, Wheelchair place green	Wheelchair place	customer equipment
S	694	Switch	Switch, Wheelchair place yellow	Wheelchair place	customer equipment
S	670	Switch	Switch,interior opening	door after rear axle	BNS II,Node 2.3
S	728	Switch	Switch, External opening	drivers place	BNS II,Node 1.3
S	729	Switch	Switch,Battery master switch ground	Battery compartment	
S	735	Switch	Switch, Booster pump Ethanol	Instrument Panel	EMS
S	740	Switch	Switch, Emergency stop	drivers place	
S	781	Switch	Switch, Diseng.stop/supervised	drivers place	BNS II,Node 1.3
S	784	Switch	Switch, Wheelchair place reset	drivers place	customer equipment
S	785	Switch	Switch,Sigal horn Fa-La	drivers place	horn fa-la
S	786	Switch	Switch, Vent.fan drivers place	drivers place	fan
S	793	Switch	Switch, Manual bus stop brake	drivers place	Doors manoeuvre
S	794	Switch	Switch, Alarm reset	drivers place	customer equipment
S	863	Switch	Switch, Switchbox Engine compartment	Rear Module	BCS
S	864	Switch	Switch, External light check	Instrument Panel	BCS
S	865	Switch	Switch, Pre selection load transfer	Instrument Panel	BCS
S	866	Switch	Switch, Pre Selection Kneeling	Instrument Panel	BCS
S	866A	Switch	Switch, Pre Selection Kneeling	Instrument Panel	BCS
S	867	Switch	Switch, Emergency stop kneeling	Instrument Panel	BCS
S	868	Switch	Switch, reserved for Omni		
S	869	Switch	Switch, reserved for Omni		
S	870	Switch	Switch, reserved for Omni		
S	871	Switch	Switch, reserved for Omni		
S	872	Switch	Switch,Main switch exit doors	Drivers place	BNS II,Node 1.2
S	873	Switch	Switch,Reset gate alarm	Drivers place	BNS II,Node 1.2
S	874	Switch	Switch,Manoe. Secur. exit doors	Drivers place	BNS II,Node 1.2
S	875	Switch	Switch, Diseng. stop request	Drivers place	BNS II,Node 1.3
S	876	Switch	Switch, Diseng. exit doors	Drivers place	BNS II,Node 1.3
S	877	Switch	Switch, Diseng. Rear door	Drivers place	BNS II,Node 1.3
S	878	Switch	Switch, wheel chair ramp	Drivers place	BNS II,Node 1.4
S	879	Switch	Switch, El. heated rear view mirrors	Drivers place	BNS II,Node 1.3
S	880	Switch	Switch, El. heated drivers seat	Drivers place	BNS II,Node 1.3

S	881	Switch	Switch, reserved for Omni		
S	882	Switch	Switch, drivers place light	drivers place	BNS II,Node 1.4
S	883	Switch	Switch,pay table light	drivers place	BNS II,Node 1.4
S	884	Switch	Switch,interior light 1st circuit	drivers place	BNS II,Node 1.4
S	885	Switch	Switch,interior light 2st circuit	drivers place	BNS II,Node 1.4
S	886	Switch	Switch,pause heating on/off	drivers place	BNS II,Node 1.4
S	887	Switch	Switch,el. heater floor	drivers place	BNS II,Node 1.4
S	888	Switch	Switch,reheated air cindition	drivers place	BNS II,Node 1.4
S	889	Switch	Switch,school sign light	drivers place	BNS II,Node 1.4
S	890	Switch	Switch,signbox light	drivers place	BNS II,Node 1.4
S	891	Switch	Switch, reserved for Omni		
S	892	Switch	Switch,reading lamps	drivers place	BNS II,Node 1.4
S	893	Switch	Switch, Dideng. supervise. stop request	drivers place	BNS II,Node 1.3
S	894	Switch	Switch,night light	drivers place	BNS II,Node 1.4
S	895	Switch	Switch,door fans	drivers place	BNS II,Node 1.4
S	896	Switch	Switch, reserved for Omni		
S	897	Switch	Switch, Reset emergency opening	drivers place	BNS II,Node 1.3
S	898	Switch	Switch, reserved for Omni		
S	899	Switch	Switch, reserved for Omni		
S	900	Switch	Switch, Manoeuvre rear door	drivers place	Doors manoeuvring
S	901	Switch	Switch, Manoeuvre middle door	drivers place	Doors manoeuvring
S	902	Switch	Switch, reserved for Omni		
S	903	Switch	Switch, wheelchair ramp/door	drivers place	BNS II,Node 1.4
S	904	Switch	Switch, wheelchair ramp disengagement	drivers place	BNS II,Node 1.4
S	905	Switch	Switch,external loud speaker	drivers place	CD radio
S	906	Switch	Switch, reserved for Omni		
S	907	Switch	Switch, Ticket machine	drivers place	Customer equipment
S	908	Switch	Switch, Manoeuvre front door	drivers place	Doors manoeuvring
S	909	Switch	Switch, Manoeuvre rear door	drivers place	Doors manoeuvring
S	910	Switch	Switch, reserved for Omni		
S	911	Switch	Switch, assault alarm stop	drivers place	speaking assault alarm
S	912	Switch	Switch, assault alarm activated	drivers place	speaking assault alarm
S	913	Switch	Switch, reserved for Omni		
S	914	Switch	Switch, reserved for Omni		
S	915	Switch	Switch, reserved for Omni		
S	916	Switch	Switch, reserved for Omni		
S	917	Switch	Switch, reserved for Omni		
S	918	Switch	Switch, reserved for Omni		
S	919	Switch	Switch, reserved for Omni		
S	920	Switch	Switch,school sign+hazard lights	drivers place	BNS II,Node 1.4
S	921	Switch	Switch, reserved for Omni		
S	922	Switch	Switch, reserved for Omni		
S	923	Switch	Switch,door system check	drivers place	BNS II,Node 1.4
S	925	Switch	Switch,diseng. reverse buzzer/timer	drivers place	BNS II,Node 1.4
S	926	Switch	Switch, reserved for Omni		
S	927	Switch	Switch, reserved for Omni		
S	928	Switch	Switch, reserved for Omni		
S	929	Switch	Switch, reserved for Omni		
S	930	Switch	Switch, Electrical sun blind	drivers place	Customer equipment
S	931	Switch	Switch, sidewalk light	drivers place	BNS II,Node 1.4
S	932	Switch	Switch, reserved for Omni		
S	933	Switch	Switch, second speed limit	drivers place	Customer equipment
S	934	Switch	Switch, third speed limit	drivers place	Customer equipment
S	935	Switch	Switch, reserved for Omni		
S	936	Switch	Switch, reserved for Omni		

S	937	Switch	Switch,Auto open. exit doors	drivers place (AIP)	Doors manoeuvre
S	938	Switch	Switch, Dis.1st/2nd leaf door in f of f axle	drivers place (AIP-FIP)	Doors manoeuvre
S	939	Switch	Switch,Testing/control lamp	drivers place	Customer equipment
S	940	Switch	Switch, Step light	drivers place (AIP)	Customer equipment
S	941	Switch	Switch, reserved for Omni		
S	942	Switch	Switch, driver fridge	drivers place	Customer equipment
S	943	Switch	Switch, Reset alcolock	drivers place	Customer equipment
S	944	Switch	Switch, Reset proddata	drivers place	Customer equipment
S	945	Switch	Switch, Manoeuvre all doors	drivers place	Doors manoeuvre
S	946	Switch	Switch, Reset stop request signal	drivers place	Doors manoeuvre
S	947	Switch	Switch, Driver area light	drivers place	Interior light
S	948	Switch	Switch, Cashier desk light	drivers place	Interior light
S	949	Switch	Switch, air conditioning disengagement	drivers place	BNS II,Node 1.3
S	950	Switch	Switch, reserved for Omni		
S	951	Switch	Switch, reserved for Omni		
S	952	Switch	Switch, reserved for Omni		
S	953	Switch	Switch, reserved for Omni		
S	954	Switch	Switch, reserved for Omni		
S	955	Switch	Switch, reserved for Omni		
S	956	Switch	Switch, reserved for Omni		
S	957	Switch	Switch, reserved for Omni		
S	958	Switch	Switch, reserved for Omni		
S	959	Switch	Switch, reserved for Omni		
S	960	Switch	Switch, reserved for Omni		
S	961	Switch	Switch, reserved for Omni		
S	962	Switch	Switch, reserved for Omni		
S	963	Switch	Switch, reserved for Omni		
S	964	Switch	Switch, reserved for Omni		
S	965	Switch	Switch, reserved for Omni		
S	968	Switch	Switch, Start and Stop engine	Instrument Panel	COO
S	969	Switch	Switch, Instrument Cluster	Instrument Panel	ICL
S	970	Switch	Switch, Windscreen wiper and washer	Instrument Panel	VIS
S	971	Switch	Switch, Release steering column	Instrument Panel	BCS
S	972	Switch	Switch, Flasher, wiper and horn lever	Instrument Panel	VIS
S	973	Switch	Switch, Diff lock	Instrument Panel	BMS
S	974	Switch	Switch, reverse gear release	Instrument Panel	GMS
S	975	Switch	Switch, Locked steered tag axel	Instrument Panel	
S	976	Switch	Switch, Speaker volume	Instrument Panel	
T	501	Sensor	Sensor, Parking brake applied	Instrument Panel	COO
T	502	Sensor	Sensor, Bus Stop Brake Applied		BSB
T	505	Sensor	Sensor, Temperature Gearbox Oil (ZF)	Rear Module	GMS
T	507	Sensor	Sensor Pressure ELC totale system	Instrument Panel	SMS
T	537	Sensor	Sensor Fuel	Front Axle	BCS
T	541	Sensor	Sensor, Artic end position switch	Artic	ACS
T	543	Sensor	Sensor, distance middle axle left	Middle axle	SMS
T	544	Sensor	Sensor, distance middle axle right	Middle axle	SMS
T	548	Sensor	Sensor, Parking brake applied	Instrument Panel	Body Builder
T	563	Sensor	Sensor/Monitor Low brake pressure tag axle	Rear Module	BCS
T	588	Monitor	Monitor, low pressure steered tag axle	Rear Module	BCS
T	589	Monitor	Monitor, flow steered tag axle	Rear Module	BCS
T	611	Sensor	Sensor, auxiliary outdoor temperature	Instrument panel	BCS
T	750	Monitor	Monitor, Fire alarm	Rear Module	BCS
T	751	Monitor	Monitor, Fire alarm	Rear Module	BCS
T	752	Monitor	Monitor, Fire alarm	Rear Module	BCS
T	753	Sensor	Sensor Pressure ACS left	Artic	ACS

T	754	Sensor	Sensor pressure ACS right	Artic	ACS
T	755	Sensor	Sensor Pressure ELC totale system rear	Rear module	SMS
T	756	Sensor	Sensor, Diff pressure	Engine	EMS
T	757	Sensor	Sensor, Air pressure parking brake circuit	Rear Module	BMS
T	758	Sensor	Sensor, Air pressure remaining circuit	Front Axle	BMS
T	759	Sensor	Sensor, pressure TAG axle left	Rear Module	SMS
T	760	Sensor	Sensor, pressure TAG axle right	Rear Module	SMS
T	761	Sensor	Sensor, pressure Middle axle left	Middle axle	SMS
T	762	Sensor	Sensor, pressure Middle Axle right	Middle axle	SMS
T	763	Sensor	Monitor, Fire alarm	Rear Module	BCS
T	764	Sensor	Sensor, temperature	Rear Module	LCS
T	765	Sensor	Sensor, soot	Rear Module	LCS
T	766	Sensor	Sensor, interior temperature	Body builder	
T	772	Sensor	Sensor, Lambda Gas	Engine	OCS
T	773	Sensor	Sensor, Presssure first trailer axle	Frist trailer	BMS/EBS
T	774	Sensor	Sensor, Presssure second trailer axle	Second trailer	BMS/EBS
T	2500	Sensor	Sensor,Hybrid coolland temperatur	Rear Module	HMS
T	2501	Sensor	Sensor, Temperature choke	Rear Module	HMS
T	2502	Sensor	Sensor, Safety angle Transducer Rear	Rear module Hybrid	RWS
T	2503	Sensor	Sensor, Safety angle Transducer Front	Rear module Hybrid	RWS
T	2504	Sensor	Sensor, Steering Pressure	Rear module Hybrid	RWS
T	2505	Sensor	Sensor, Centering Pressure	Rear module Hybrid	RWS
T	2506	Sensor	Sensor, Oil Level	Rear module Hybrid	RWS
U	20X	Aerial	Aerial, RTC, GSM/GPS/Radio	Component	RTC
V	500	Solenoid valve	Solenoid valve, Bus Stop Brake Driven Axle		BSB
V	502	Solenoid valve	Solenoid valve, activation of retarder memory	Rear Module	GMS / ZF
V	503	Solenoid valve	Solenoid valve, Retarder	Rear Module	GMS / ZF
V	523	Solenoid valve	Solenoid valve, Front axle up/down	Front axle	SMS
V	524	Solenoid valve	Solenoid valve, Driven axle	Rear Module	SMS
V	525	Solenoid valve	Solenoid valve, Tag axle up/down	Rear Module	SMS
V	526	Solenoid valve	Solenoid valve, front axle Kneeling	Front axle	SMS
V	541	Solenoid valve	Propotional valve Artic left	Artic	ACS
V	542	Solenoid valve	Propotional valve Artic right	Artic	ACS
V	543	Solenoid valve	Solenoid valve, Middle axle	Middle axle	SMS
V	553	Solenoid Valve	Solenoid valve, Emergency damping Artic	Artic	ACS
V	561	Solenoid valve	Solenoid valve, Steered tag axle	Front axle	BCS
V	566	Solenoid valve	Solenoid valve, Water seperator	Rear Module	APS
V	567	Solenoid valve	Solenoid valve, Booster pump Ethanol	Rear Module	EMS
V	585	Solenoid valve	Solenoid valve, Release steering kolom AIP	Instrument Panel	BCS
V	586	Solenoid valve	Solenoid valve, Driven /Tag axle left side	Rear Module	SMS
V	587	Solenoid valve	Solenoid valve, Driven /Tag axle right side	Rear Module	SMS
V	588	Solenoid valve	Solenoid valve, high pressure gas, tank 1	Body roof	GCS
V	589	Solenoid valve	Solenoid valve, high pressure gas, tank 2	Body roof	GCS
V	590	Solenoid valve	Solenoid valve, high pressure gas, tank 3	Body roof	GCS
V	591	Solenoid valve	Solenoid valve, high pressure gas, tank 4	Body roof	GCS
V	592	Solenoid valve	Solenoid valve, high pressure gas, tank 5	Body roof	GCS
V	593	Solenoid valve	Solenoid valve, high pressure gas, tank 6	Body roof	GCS
V	594	Solenoid valve	Solenoid valve, high pressure gas, tank 7	Body roof	GCS
V	595	Solenoid valve	Solenoid valve, high pressure gas, tank 8	Body roof	GCS
V	596	Solenoid valve	Solenoid valve, high pressure gas, tank 9	Body roof	GCS
V	597	Solenoid valve	Solenoid valve, high pressure gas, tank 10	Body roof	GCS
V	600	Solenoid valve	Solenoid valve, Bus Stop Brake Front Axle		BSB
V	601	Solenoid valve	Solenoid valve,Fuel cut off	Rear Module	???
V	602	Solenoid valve	Solenoid valve,Hydraulic fan shut off	Rear Module	???
V	603	Dosing Unit	Dosing unit/pump	Rear Module	LCS

V	604	Dosing Unit	Dosing unit/injector
V	2500	Solenoid valve	Solenoid valve, By pass valve
V	2501	Solenoid valve	Solenoid valve, Centering valve
V	2502	Solenoid valve	Solenoid valve, Charging valve
V	2503	Solenoid valve	Solenoid valve, Release valve
V	2504	Solenoid valve	Solenoid valve, Proportional valve

Rear Module
Rear module Hybrid
Rear module Hybrid
Rear module Hybrid
Rear module Hybrid
Rear module Hybrid

LCS
RWS
RWS
RWS
RWS
RWS

**Component Library****Scania-Omni**

No.	Type	Description	Harness	System
B 6000	Switch	Connector (Canon), 3 pole,Front hatch right	Front right	BNS II, Node 1.4
B 6001	Switch	Connector, 2 pole,Drivers gate alarm	Drivers place	BNS II, Node 1.4
B 6002	Switch	Switch,engine compartment hatch rear	Engine compartment	BNS II, Node 2.2
B 6003	Switch	Switch,engine compartment hatch left	Engine compartment	BNS II, Node 2.2
B 6004	Switch	Switch,engine compartment hatch right	Engine compartment	BNS II, Node 2.2
B 6005	Switch	Switch,gas fuel filling hatch	Engine compartment	BNS II, Node 2.2
B 6006	Switch	Drivers gate	dasboard	warning handbrake off
B 6007	Switch	Switch, Battery compartment	floor	BNS II, Node 1.3
B 6008	Switch	Switch, Front hatch left	floor	BNS II, Node 1.3
B 6009	Switch	Switch,engine compartment hatch rear/upper	Engine compartment	BNS II, Node 2.2
B 6010	Switch	Switch,AdBlue filling hatch	roof,rear right	BNS II, Node 2.3
B 6011	Switch	Switch,luggage compartment hatch	Luggage compartment hatch	BNS II, Node 1.1
B 6012	Switch	Switch,luggage compartment hatch	Luggage compartment hatch	BNS II, Node 2.3
B 6013	Switch	Switch,luggage compartment hatch	Luggage compartment hatch	BNS II, Node 2.2
C 6000	Connector	Connector, 6 pole,Power supply Node	Roof right	BNS II, Node 1.1
C 6001	Connector	Connector, 3 pole,Heating valve right	Roof right	BNS II, Node 1.1
C 6002	Connector	Connector, 6 pole,Climate unit right	Roof right	BNS II, Node 1.1
C 6003	Connector	Connector, 6 pole,Climate unit left	Roof right	BNS II, Node 1.1
C 6004	Connector	Connector, 3 pole	Roof right	BNS II, Node 1.1
C 6005	Connector	Connector, 6 pole,exterior opening/pram signal-middle dc	Roof right	BNS II, Node 1.1
C 6006	Connector	Connector, 9 pole	Roof right	BNS II, Node 1.1
C 6007	Connector	Connector, 3 pole	Roof right	BNS II, Node 1.1
C 6008	Connector	Connector, 6 pole	Roof right	BNS II, Node 1.1
C 6009	Connector	Connector, 3 pole	Roof right	BNS II, Node 1.1
C 6010	Connector	Connector, 3 pole	Roof right	BNS II, Node 1.1
C 6011	Connector	Connector, 4 pole	Roof right	BNS II, Node 1.1
C 6012	Connector	Connector, 2 pole	Roof right	BNS II, Node 1.1
C 6013	Connector	Connector, 2 pole	Roof right	BNS II, Node 1.1
C 6014	Connector	Connector, 2 pole	Roof exterior	BNS II, Node 1.1
C 6015	Splice	Splice,1 pole	Roof right	BNS II, Node 1.1
C 6016	Splice	Splice,1 pole	Roof right	BNS II, Node 1.1
C 6017	Splice	Splice,1 pole	Roof right	BNS II, Node 1.1
C 6018	Splice	Splice,1 pole	Roof right	BNS II, Node 1.1
C 6019	Connector	Connector,3 pole	Roof right	BNS II, Node 1.2
C 6020	Connector	Connector,3 pole	Roof right	BNS II, Node 1.2
C 6021	Connector	Connector,6 pole,power supply Nodes	Roof right	BNS II, Node 1.2
C 6022	Connector	Connector,3 pole,night light	roof front-middle	BNS II, Node 1.2
C 6023	Connector	Connector,3 pole,night light	roof front-middle	BNS II, Node 1.2
C 6024	Connector	Connector,3 pole	roof front-middle	BNS II, Node 1.2
C 6025	Connector	Connector,3 pole,	roof front-middle	BNS II, Node 1.2
C 6026	Connector	Connector,3 pole,fasten seatbelt	roof right	BNS II, Node 1.2
C 6027	Connector	Connector,3 pole,step light	Door shelf-front door	BNS II, Node 1.2
C 6028	Connector	Connector,3 pole,active lock	Door shelf-front door	BNS II, Node 1.2
C 6029	Connector	Connector,4 pole, exit open request (see notes)	roof right-front	BNS II, Node 1.2
C 6030	Connector	Connector,3 pole,	roof right	BNS II, Node 1.2
C 6031	Connector	Connector,3 pole,reading light	roof front-middle	BNS II, Node 1.2
C 6032	Connector	Connector,3 pole,stop request	roof front	BNS II, Node 1.2
C 6033	Connector	Connector,3 pole,suprvises/stop request	roof right-middle	BNS II, Node 1.2
C 6034	Connector	Connector,2 pole,emergency hammer	roof right	BNS II, Node 1.2
C 6035	Connector	Connector,3 pole,supervised request	roof right	BNS II, Node 1.2
C 6036	Connector	Connector,3 pole,suprvises/stop request	roof right-rear	BNS II, Node 1.2
C 6037	Connector	Connector,3 pole,stop request	roof right-rear	BNS II, Node 1.2

C	6038	Connector	Connector,3 pole,stop request	roof right-rear	BNS II, Node 1.2
C	6039	Splice	Splice,1 pole	roof right	BNS II, Node 1.2
C	6040	Splice	Splice,1 pole	roof right	BNS II, Node 1.2
C	6041	Splice	Splice,1 pole	roof right	BNS II, Node 1.2
C	6042	Splice	Splice,1 pole	roof right	BNS II, Node 1.2
C	6043	Splice	Splice,1 pole	roof front-middle	BNS II, Node 1.2
C	6044	Splice	Splice,1 pole	Roof right-middle	BNS II, Node 1.1
C	6045	Splice	Splice,1 pole	Roof right-middle	BNS II, Node 1.1
C	6046	Connector	Connector,3 pole	Body side-interior	BNS II, Node 1.2
C	6047	Connector	Connector,3 pole	Body side-interior	BNS II, Node 1.2
C	6048	Connector	Connector,3 pole	Body side-interior	BNS II, Node 1.2
C	6049	Connector	Connector,3 pole	Body side-interior	BNS II, Node 1.2
C	6050	Splice	Splice,1 pole	drivers place	BNS II, Node 1.4
C	6051	Splice	Splice,1 pole	drivers place	BNS II, Node 1.4
C	6052	Connector	Connector,6-pole,WCR door	drivers place	BNS II, Node 1.4
C	6053	Connector	Connector,2 pole,drivers gate lamp	drivers place	BNS II, Node 1.4
C	6054	Connector	Connector,2 pole,drivers gate alarm	drivers place	BNS II, Node 1.4
C	6055	Connector	Connector,6 pole,door manoeuvre	drivers place	BNS II, Node 1.4
C	6055X	Connector	Connector,6 pole,door manoeuvre	drivers place	BNS II, Node 1.4
C	6056	Connector	Connector,6 pole,main node	electric centre	BNS II, Node 1.4
C	6057	Connector	Connector,6 pole,power supply	drivers place	BNS II, Node 1.4
C	6058	Connector	Connector,7 pole,ramp connection	front	BNS II, Node 1.4
C	6058A	Connector	Connector,7 pole,ramp connection	front, ramp connection	BNS II, Node 1.4
C	6059	Connector	Connector,6 pole	Customer equipment	Customer equipment
C	6059X	Connector	Connector,6 pole	Customer equipment	Customer equipment
C	6060	Splice	Splice,1 pole	front	BNS II, Node 1.4
C	6061	Connector	Connector,3 pole,WCR middle door	roof right	BNS II, Node 1.1
C	6062	Connector	Connector,9 pole (6-pins changed to 9-pins) 100216	Electric centre	BNS II, Main Node DD
C	6063	Connector	Connector,2 pole	Roof behind driver's place	BNS II, Main Node DD
C	6064	Connector	Connector,3 pole	Electric centre	BNS II, Main Node DD
C	6065	Connector	Connector,6 pole	Electric centre	BNS II, Main Node DD
C	6066	Connector	Connector,12 pole	Electric centre	BNS II, Main Node DD
C	6067	Connector	Connector,6 pole	Electric centre	BNS II, Main Node DD
C	6068	Connector	Connector,6 pole	Electric centre	BNS II, Main Node DD
C	6069	Connector	Connector,6 pole	Electric centre	BNS II, Main Node DD
C	6070	Connector	Connector,6 pole	Electric centre	BNS II, Main Node DD
C	6071	Connector	Connector,6 pole	Electric centre	BNS II, Main Node DD
C	6072	Connector	Connector,3 pole	Electric centre	BNS II, Node 1.2
C	6073	Connector	Connector,3 pole	roof left front	BNS II, Node 1.4
C	6074	Connector	Connector,3 pole	Electric centre	BNS II, Node 1.4
C	6075	Connector	Connector,3 pole	Front	BNS II, Node 1.4
C	6076	Connector	Connector,3 pole	drivers place	BNS II, Node 1.4
C	6077	Connector	Connector,3 pole	drivers place	BNS II, Node 1.4
C	6078	Connector	Connector,3 pole	drivers place	BNS II, Node 1.4
C	6079	Connector	Connector,3 pole	drivers place	BNS II Node 2.1
C	6080	Connector	Connector,3 pole	roof drivers place	BNS II Node 2.2
C	6081	Connector	Connector,6 pole	Front	Front Lighting
C	6082	Connector	Connector,3 pole	Front	Front Lighting
C	6083	Connector	Connector,3 pole	Electric centre	Front Lighting
C	6084	Connector	Connector,3 pole	Electric centre	Front Lighting
C	6085	Connector	Connector,2 pole	roof, in front of artic, left	Front Lighting
C	6086	Connector	Connector,2 pole	roof, in front of artic, right	Front Lighting
C	6087	Connector	Connector,3 pole	roof, after artic, left	Front Lighting ändrad från 2 till 3 poler
C	6088	Connector	Connector,3 pole	roof, after artic, right	Front Lighting ändrad från 2 till 3 poler
C	6089	Splice	Splice,1 pole	front	Front Lighting

C	6090	Splice	Splice,1 pole	front	Front Lighting
C	6091	Connector	Connector,6 pole	Upper salon DD	Rear lighting
C	6092	Connector	Connector,9 pole	roof left front	vent/heating defroster fan
C	6093	Connector	Connector,3 pole	roof right front	BNS II, Node 1.2
C	6094	Connector	Connector,3 pole	roof front right	BNS II, Node 1.2
C	6095	Connector	Connector,9 pole	roof	Wheelchair ramp Compac
C	6096	Connector	Connector,3 pole	roof	Wheelchair ramp Compac
C	6097	Connector	Connector,3 pole	roof	Wheelchair ramp Compac
C	6098	Connector	Connector,3 pole	roof	Wheelchair ramp Compac
C	6099	Connector	Connector,3 pole	roof	Wheelchair ramp Compac
C	6100	Splice	Splice,1 pole	roof	Wheelchair ramp Compac
C	6101	Connector	Connector,3 pole	el centre rear sofa uper deck DD	fire extinguishing system DD
C	6102	Connector	Connector,3 pole	roof right lower deck DD	fire extinguishing system DD
C	6103	Connector	Connector,3 pole	el centre front DD	fire extinguishing system DD
C	6104	Connector	Connector,3 pole	el centre front DD	fire extinguishing system DD
C	6105	Connector	Connector,6 pole	el centre rear sofa uper deck DD	fire extinguishing system DD
C	6106	Connector	Connector,2 pole	el centre rear sofa uper deck DD	fire extinguishing system DD
C	6107	Connector	Connector,2 pole	el centre rear sofa uper deck DD	fire extinguishing system DD
C	6108	Connector	Connector,2 pole	el centre rear sofa uper deck DD	fire extinguishing system DD
C	6109	Connector	Connector,2 pole	el centre rear sofa uper deck DD	fire extinguishing system DD
C	6111	Connector	Connector,2 pole	el centre rear sofa uper deck DD	fire extinguishing system DD
C	6110	Connector	Connector,2 pole	el centre rear sofa uper deck DD	fire extinguishing system DD
C	6112	Splice	Splice,1 pole	roof rear-right	BNS II Node 2.3
C	6113	Splice	Splice,1 pole	roof rear-right	BNS II Node 2.3
C	6114	Connector	Connector,2 pole	roof rear-right	BNS II Node 2.3
C	6115	Connector	Connector,2 pole	roof rear-right	BNS II Node 2.3
C	6116	Connector	Connector,2 pole	roof rear-right	BNS II Node 2.3
C	6117	Connector	Connector,2 pole	roof rear-right	BNS II Node 2.3
C	6118	Connector	Connector,3 pole	roof rear-right	BNS II Node 2.3
C	6119	Connector	Connector,3 pole	roof rear-right	BNS II Node 2.3
C	6120	Connector	Connector,3 pole	roof rear-right	BNS II Node 2.3
C	6121	Connector	Connector,3 pole	roof rear-right	BNS II Node 2.3
C	6122	Connector	Connector,3 pole	roof rear-right	BNS II Node 2.3
C	6123	Connector	Connector,3 pole	roof rear-right	BNS II Node 2.3
C	6124	Connector	Connector,3 pole	roof rear-right	BNS II Node 2.3
C	6125	Connector	Connector,3 pole	roof rear-right	BNS II Node 2.3
C	6126	Connector	Connector,3 pole	roof rear-right	BNS II Node 2.3
C	6127	Connector	Connector,3 pole	roof rear-right	BNS II Node 2.3
C	6128	Connector	Connector,4 pole	roof rear-right	BNS II Node 2.3
C	6129	Connector	Connector,6 pole	roof rear-right	BNS II Node 2.3
C	6130	Connector	Connector,6 pole	roof rear-right	BNS II Node 2.3
C	6131	Connector	Connector,6 pole	roof rear-right	BNS II Node 2.3
C	6132	Splice	Splice,1 pole	roof rear-right	BNS II Node 2.3
C	6133	Splice	Splice,1 pole	roof rear-right	BNS II Node 2.3
C	6134	Splice	Splice,1 pole	roof rear-right	BNS II Node 2.3
C	6135	Splice	Splice,1 pole	roof rear-right	BNS II Node 2.3
C	6136	Splice	Splice,1 pole	roof rear-right	BNS II Node 2.3
C	6137	Connector	Connector,3 pole	roof rear-articulated	BNS II Node 2.4
C	6138	Connector	Connector,2 pole	roof rear-left	BNS II Node 2.2
C	6139	Connector	Connector,2 pole	roof rear-left	BNS II Node 2.2
C	6140	Connector	Connector,2 pole	roof rear-left	BNS II Node 2.2
C	6141	Connector	Connector,2 pole	roof rear-left	BNS II Node 2.2
C	6142	Connector	Connector,3 pole	roof rear-left	BNS II Node 2.2
C	6143	Connector	Connector,3 pole	roof rear-left	BNS II Node 2.2
C	6144	Connector	Connector,3 pole	roof rear-left	BNS II Node 2.2



C	6145	Connector	Connector,3 pole	roof rear-left	BNS II Node 2.2
C	6146	Connector	Connector,6 pole	roof rear-left	BNS II Node 2.2
C	6147	Splice	Splice,1 pole	roof rear-left	BNS II Node 2.2
C	6148	Splice	Splice,1 pole	Main Node	roof
C	6149	Splice	Splice,1 pole	roof rear-left	BNS II Node 2.2
C	6150	Splice	Splice,1 pole	roof rear-left	BNS II Node 2.2
C	6151	Splice	Splice,1 pole	roof rear-left	BNS II Node 2.2
C	6152	Splice	Splice,1 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6153	Splice	Splice,1 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6154	Splice	Splice,1 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6155	Splice	Splice,1 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6156	Splice	Splice,1 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6157	Connector	Connector,2 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6158	Connector	Connector,2 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6159	Connector	Connector,3 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6160	Connector	Connector,3 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6161	Connector	Connector,3 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6162	Connector	Connector,3 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6163	Connector	Connector,3 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6164	Connector	Connector,3 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6165	Connector	Connector,3 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6166	Connector	Connector,3 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6167	Connector	Connector,3 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6168	Connector	Connector,6 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6169	Connector	Connector,6 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6170	Connector	Connector,6 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6171	Connector	Connector,6 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6172	Connector	Connector,9 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6173	Connector	Connector,9 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6174	Splice	Splice,1 pole	electric centre	BNS II, Main Node DD
C	6175	Splice	Splice,1 pole	electric centre	BNS II, Main Node DD
C	6176	Connector	Connector,3 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6177	Connector	Connector,2 pole	roof middle-left	BNS II Node 2.1 +AIP
C	6178	Connector	Connector,3 pole	roof front	Passenger info system
C	6179	Connector	Connector,2 pole	roof front	Passenger info system
C	6180	Connector	Connector,2 pole	roof after artic	Passenger info system
C	6181	Connector	Connector,3 pole	electric centre	Passenger info system
C	6182	Connector	Connector,3 pole	electric centre	Passenger info system
C	6183	Junction box	Junction box, passenger info system	electric centre	Passenger info system
C	6184	Connector	Connector,3 pole	drivers place	Aux.heater Stroco
C	6185	Connector	Connector,6 pole	electric centre	Aux.heater Stroco
C	6186	Connector	Connector,3 pole	electrik panel artic	Aux.heater Stroco
C	6187	Junction box	Connector,2 pole	electrik panel artic	Aux.heater Stroco
C	6188	Splice	Splice,1 pole	engine compartment	Aux.heater Stroco
C	6189	Splice	Splice,1 pole	engine compartment	Aux.heater Stroco
C	6190	Splice	Splice,1 pole	electric centre	Aux.heater Stroco
C	6191	Connector	Connector,2 pole	engine compartment	Pump,Aux.heater Stroco
C	6192	Splice	Splice,1 pole	roof rear-left	BNS II Node 2.2
C	6193	Splice	Splice,1 pole	roof rear-left	BNS II Node 2.2
C	6194	Connector	Connector,2 pole	passenger heating Circ. Pump	convector circuit
C	6195	Connector	Connector,7 pole	front	Cejn P8 connection
C	6196	Connector	Connector,3 pole	electromagnet emergency door	BNS II Node 2.3
C	6197	Splice	Splice,1 pole	electromagnet emergency door	BNS II Node 2.3
C	6198	Splice	Splice,1 pole	electromagnet emergency door	BNS II Node 2.3
C	6199	Connector	Connector,4 pole	lugage rack	

C	6200	Connector	Connector,4 pole	lugage rack	
C	6201	Connector	Connector,9 pole	electric centre	BNS II
C	6202	Connector	Connector,2 pole	front left side	front lighting
C	6203	Connector	Connector,2 pole	front right side	front lighting
C	6204	Connector	Connector,3 pole	electric centre	gas bus
C	6205	Splice	Splice,1 pole	roof	gas bus
C	6206	Splice	Splice,1 pole	roof	gas bus
C	6207	Splice	Splice,1 pole	roof	gas bus
C	6208	Splice	Splice,1 pole	roof	gas bus
C	6209	Connector	Connector,6 pole	electric centre	ICL2
C	6210	Connector	Connector,6 pole	electric centre	ICL3
C	6211	Connector	Connector,3 pole		Side mark light DD
C	6212	Connector	Connector,3 pole	electric centre	Dafo fire exting equipmnt
C	6213	Connector	Connector,3 pole	electric centre artic	Dafo fire exting equipmnt
C	6214	Connector	Connector,3 pole	dasboard	speaking assault alarm
C	6215	Connector	Connector,2 pole	dasboard	speaking assault alarm
C	6216	Connector	Connector,3 pole	electric centre	Dafo fire exting equipmnt
C	6217	Connector	Connector,3 pole	roof front	marker lamp
C	6218	Connector	Connector,2 pole	roof right	marker lamp
C	6219	Connector	Connector,2 pole	roof right	marker lamp
C	6220	Connector	Connector,2 pole	roof right	marker lamp
C	6221	Connector	Connector,2 pole	roof right	marker lamp
C	6222	Connector	Connector,2 pole	roof right	marker lamp
C	6223	Connector	Connector,2 pole	roof right	marker lamp
C	6224	Connector	Connector,2 pole	roof right	marker lamp
C	6225	Connector	Connector,2 pole	roof right	marker lamp
C	6226	Connector	Connector,2 pole	roof left	marker lamp
C	6227	Connector	Connector,2 pole	roof left	marker lamp
C	6228	Connector	Connector,2 pole	roof left	marker lamp
C	6229	Connector	Connector,2 pole	roof left	marker lamp
C	6230	Connector	Connector,2 pole	roof left	marker lamp
C	6231	Connector	Connector,2 pole	roof left	marker lamp
C	6232	Connector	Connector,3 pole	roof rear	marker lamp
C	6233	Connector	Connector,2 pole	roof rear	marker lamp
C	6234	Connector	Connector,2 pole	roof right lower deck DD	marker lamp DD
C	6235	Connector	Connector,2 pole	roof right lower deck DD	marker lamp DD
C	6236	Connector	Connector,2 pole	roof right lower deck DD	marker lamp DD
C	6237	Connector	Connector,2 pole	roof right lower deck DD	marker lamp DD
C	6238	Connector	Connector,2 pole	roof left lower deck DD	marker lamp DD
C	6239	Connector	Connector,2 pole	roof left lower deck DD	marker lamp DD
C	6240	Connector	Connector,2 pole	roof left lower deck DD	marker lamp DD
C	6241	Connector	Connector,2 pole	roof left lower deck DD	marker lamp DD
C	6242	Connector	Connector,3 pole	roof after artic left	Node 2.4
C	6243	Joint connector	Joint connector,fans for nozzles	roof rear left	fans for nuzzles
C	6244	Joint connector	Joint connector,fans for nozzles	roof left	fans for nuzzles
C	6245	Joint connector	Joint connector,fans for nozzles	roof right	fans for nuzzles
C	6246	Connector	Connector,3 pole	roof left	fans for nuzzles
C	6247	Connector	Connector,3 pole	roof right	fans for nuzzles
C	6248	Connector	Connector,3 pole	roof left	fans for nuzzles
C	6249	Connector	Connector,3 pole	roof right	fans for nuzzles
C	6250	Connector	Connector,9 pole	roof left	fans for nuzzles
C	6251	Connector	Connector,3 pole	roof left after artic	fans for nuzzles
C	6252	Joint connector	Joint connector,fans for nozzles	engine room	fans for nuzzles
C	6253	Connector	Connector,3 pole	roof front left	Node 2.1
C	6254	Connector	Connector,3 pole	roof rear left	Node 2.2 /auxiliari heater gas

C	6255	Splice	Splice,1 pole	rear lighting	rear lighting
C	6256	Splice	Splice,1 pole	rear lighting	rear lighting
C	6257	Splice	Splice,1 pole	rear lighting	rear lighting
C	6258	Splice	Splice,1 pole	rear lighting	rear lighting
C	6259	Splice	Splice,1 pole	rear lighting	rear lighting
C	6260	Splice	Splice,1 pole	rear lighting	Dafo fire exting equipmnt
C	6261	Splice	Splice,1 pole	engine room	rear lights
C	6262	Splice	Splice,1 pole	engine room	rear lighting
C	6263	Connector	Connector,9 pole	warning handbrake off	warning handbrake off
C	6264	Connector	Connector,3 pole	behind rear sofa DD	BNS II Node 2.1
C	6265	Connector	Connector,3 pole	El centre artic	Stroco;Webasto
C	6266	Joint connector	Joint connector,auxiliary heater	El centre artic	Stroco;Webasto
C	6267	Connector	Connector,3 pole	electric centre	Monitoring system
C	6268	Connector	Connector,3 pole	electric centre	Monitoring system
C	6269	Connector	Connector,3 pole	electric centre	Monitoring system
C	6270	Connector	Connector,3 pole	electric centre	Monitoring system
C	6271	Connector	Connector,3 pole	roof front left	Monitoring system
C	6271A	Connector	Connector,3 pole	roof front left	Monitoring system
C	6272	Connector	Connector,6 pole	electric centre	Monitoring system
C	6273	Connector	Connector,6 pole	electric centre	Monitoring system
C	6274	Connector	Connector,6 pole	electric centre	Monitoring system
C	6275	Splice	Splice,1 pole	electric centre	Monitoring system
C	694X	Connector	Connector,6 pole	electric centre	horn fa-la
C	6276	Connector	Connector,3 pole	electric centre	horn fa-la
C	6277	Splice	Splice,1 pole	electric centre	horn fa-la
C	6278	Connector	Connector,3 pole	drivers place	rear view mirror
C	6279	Connector	Connector,3 pole	roof front	rear view mirror
C	6280	Connector	Connector,3 pole	drivers place	rear view mirror
C	6281	Charging socket	Charging socket Archived not used	Archived not used	Archived not used
C	6282	Connector	Connector,3 pole	roof chanel,front left	drivers/pasenger heating
C	6283	Connector	Connector,3 pole	drivers place	BNS II Node 1.3
C	6284	Connector	Connector,2 pole	drivers place	drivers gate lock/pow supp nodes
C	6285	Splice	Splice,1 pole	engine room	rear lights
C	6286	Splice	Splice,1 pole	engine room	rear lights
C	6287	Connector	Connector,9 pole	drivers place	BNS II Node 1.5
C	6288	Connector	Connector,3 pole	drivers place	BNS II Node 1.5
C	6289	Connector	Connector,3 pole	drivers place	BNS II Node 1.5
C	6290	Connector	Connector,6 pole	drivers place	BNS II Node 1.5
C	6291	Splice	Splice,1 pole	drivers place	BNS II Node 1.5
C	6292	Connector	Connector,3 pole	electric centre	ISA system
C	6293	Connector	Connector,2 pole	drivers place	drivers gate lock / S order
C	6294	Connector	Connector,3 pole	electric centre	Bus Signals
C	6295	Connector	Connector,4 pole	electric centre	Bus Signals
C	6296	Connector	Connector,4 pole	electric centre	Bus Signals
C	6297	Connector	Connector,12 pole	drivers place	BNS II Node 1.3
C	6298	Connector	Connector,3 pole	electric centre	Bus Signals
C	6299	Connector	Connector,3 pole	electric centre	Bus Signals
C	6300	Connector	Connector,3 pole	electric centre	Bus Signals
C	6301	Connector	Connector,3 pole	electric centre	Bus Signals
C	6302	Connector	Connector,3 pole	electric centre	Bus Signals
C	6303	Connector	Connector,4 pole	electric centre	Bus Signals
C	6304	Connector	Connector,6 pole	electric centre	Bus Signals
C	6304A	Connector	Connector,6 pole	electric centre	Bus Signals
C	6305	Connector	Connector,12 pole	electric centre	Bus Signals
C	6305A	Connector	Connector,12 pole	electric centre	Bus Signals

C	6306	Connector	Connector,12 pole	electric centre	Bus Signals
C	6307	Connector	Connector,6 pole	electric centre	Bus Signals
C	6308	Connector	Connector,9 pole	electric centre	extension cable ACC unit
C	6309	Connector	Connector,9 pole	electric centre	Bus Signals
C	6310	Connector	Connector,9 pole	electric centre	Bus Signals
C	6310A	Connector	Connector,9 pole	electric centre	Bus Signals
C	6311	Connector	Connector,3 pole	drivers place	BNS II, Node 1.3
C	6312	Connector	Connector,2 pole	drivers place	BNS II, Node 1.3
C	6313	Connector	Connector,2 pole	drivers place	BNS II, Node 1.3
C	6314	Connector	Connector,3 pole	roof	fire extinguishing system
C	6315	Connector	Connector,9 pole	drivers place	BNS II, Node 1.3
C	6315X	Connector	Connector,9 pole	drivers place	BNS II, Node 1.3
C	6316	Connector	Connector,4 pole	drivers place	BNS II, Node 1.3
C	6317	Connector	Connector,6 pole	drivers place	BNS II, Node 1.3
C	6318	Connector	Connector,3 pole	drivers place	BNS II, Node 1.3
C	6319	Connector	Connector,3 pole	drivers place	BNS II, Node 1.3
C	6320	Connector	Connector,4 pole	drivers place	BNS II, Node 1.3
C	6321	Splice	Splice,1 pole	drivers place	BNS II, Node 1.3
C	6322	Splice	Splice,1 pole	drivers place	BNS II, Node 1.3
C	6323	Splice	Splice,1 pole	drivers place	BNS II, Node 1.3
C	6324	Splice	Splice,1 pole	drivers place	BNS II, Node 1.3
C	6325	Splice	Splice,1 pole	drivers place	BNS II, Node 1.3
C	6326	Splice	Splice,1 pole	drivers place	BNS II, Node 1.3
C	6327	Splice	Splice,1 pole	drivers place	BNS II, Node 1.3
C	6328	Splice	Splice,1 pole	drivers place	BNS II, Node 1.3
C	6329	Connector	Connector,3 pole	central electric unit	power supp std equip
C	6330	Connector	Connector,6 pole	electric centre	power supp std equip
C	6330A	Connector	Connector,6 pole	electric centre	power supp std equip
C	6330B	Connector	Connector,6 pole	electric centre	power supp std equip
C	6331	Connector	Connector,6 pole	drivers place	BNS II, Node 1.3
C	6332	Connector	Connector,6 pole	roof after artic,left	BNS II, Node 2.4
C	6333	Connector	Connector,6 pole	electric panel artic	power supply Nodes
C	6334	Connector	Connector,6 pole	electric panel artic	power supply Nodes
C	6335	Connector	Connector,6 pole	electric panel artic	power supply Nodes
C	6336	Connector	Connector,3 pole	electric centre	power supply el central
C	6337	Connector	Connector,1 pole	central electric unit	power supply el central
C	6338	Connector	Connector,1 pole	central electric unit	power supply el central
C	6339	Connector	Connector,1 pole	central electric unit	power supply el central
C	6340	Connector	Connector,1 pole	central electric unit	power supply el central
C	6341	Connector	Connector,6 pole	electric centre	power supply el central
C	6342	Connector	Connector,6 pole	Roof hatches	Roof hatches
C	6343	Splice	Splice,1 pole	electric centre	power supply el central
C	6344	Splice	Splice,1 pole	electric centre	power supply el central
C	6345	Splice	Splice,1 pole	electric centre	power supply el central
C	6346	Splice	Splice,1 pole	electric centre	power supply el central
C	6347	Splice	Splice,1 pole	electric centre	power supply el central
C	6348	Connector	Connector,3 pole	drivers place	comunikation system ELKA
C	6349	Connector	Connector,3 pole	drivers place	comunikation system ELKA
C	6350	Splice	Splice,1 pole	electric centre	gas bus
C	6351	Splice	Splice,1 pole	electric centre	gas bus
C	6352	Splice	Splice,1 pole	electric centre	gas bus
C	6353	Splice	Splice,1 pole	electric centre	gas bus
C	6354	Splice	Splice,1 pole	roof rear	power supp STD equip
C	6355	Splice	Splice,1 pole	roof	comm/power
C	6356	Splice	Splice,1 pole	roof	comm/power

C	6357	Connector	Connector,3 pole	CD/Radio;	
C	6358	Connector	Connector,3 pole	roof	power supply STD equipment
C	6359	Connector	Connector,3 pole	roof	power supply STD equipment
C	6360	Connector	Connector,3 pole	roof	power supply STD equipment
C	6361	Connector	Connector,3 pole	roof	power supply STD equipment 6X2
C	6362	Connector	Connector,3 pole	roof	power supply STD equipment
C	6363	Connector	Connector,3 pole	roof	power supply STD equipment
C	6364	Connector	Connector,3 pole	roof	power supply STD equipment 6X2
C	6365	Connector	Connector,2 pole	roof	power supply STD equipment
C	6366	Connector	Connector,2 pole	roof	power supply STD equipment
C	6367	Connector	Connector,2 pole	roof	power supply STD equipment
C	6368	Connector	Connector,2 pole	roof	power supply STD equipment
C	6369	Connector	Connector,2 pole	roof	power supply STD equipment
C	6370	Connector	Connector,2 pole	roof	power supply STD equipment
C	6371	Connector	Connector,3 pole	roof	power supply STD equipment 6X2
C	6372	Connector	Connector,3 pole	electric centre	power supply STD equipment
C	6373	Connector	Undersok	Undersok	Undersok
C	6374	Connector	Connector,3 pole	electric centre	power supply STD equipment
C	6375	Connector	Connector,3 pole	electric centre	power supply STD equipment
C	6376	Connector	Connector,3 pole	electric centre	power supply STD equipment
C	6377	Connector	Connector,9 pole	electric centre	power supply STD equipment
C	6377X	Connector	Connector,9 pole	electric centre	power supply C-order equipment
C	6378	Connector	Connector,9 pole	electric centre	power supply STD equipment
C	6378X	Connector	Connector,9 pole	electric centre	power supply C-order equipment
C	6379	Connector	Connector,9 pole	electric centre	comm/power
C	6380	Connector	Connector,15 pole	electric centre	comm/power
C	6381	Connector	Connector,15 pole	electric centre	comm/power
C	6382	Connector	Connector,9 pole	electric centre	comm/power
C	6383	Connector	Connector,9 pole	electric centre	comm/power
C	6384	Connector	Connector,6 pole	electric centre	comm/power
C	6384A	Connector	Connector,6 pole	electric centre	comm/power
C	6385	Connector	Connector,1 pole	electric centre	comm/power
C	6386	Connector	Connector,1 pole	electric centre	comm/power
C	6387	Connector	Connector,1 pole	electric centre	comm/power
C	6388	Connector	Connector,1 pole	electric centre	comm/power
C	6389	Connector	Connector,15 pole	electric centre	Customer equip vehicle signal
C	6390	Connector	Connector,3 pole	floor	heating film man.wheelchair ramp
C	6391	Connector	Connector,3 pole	floor	heating film man.wheelchair ramp
C	6392	Connector	Connector,4 pole	floor	heating film man.wheelchair ramp
C	6393	Connector	Connector,9 pole	electric centre	front lighting
C	6394	Connector	Connector,9 pole	electric centre	front lighting
C	6395	Splice	Splice,1 pole	electric centre	front lighting
C	6396	Splice	Splice,1 pole	auxiliary heater	auxiliary heater
C	6397	Splice	Splice,1 pole	auxiliary heater	auxiliary heater
C	6398	Splice	Splice,1 pole	auxiliary heater	auxiliary heater
C	6399	Connector	Connector,15 pole	roof	comm/power
C	6400	Connector	Connector,15 pole	roof	comm/power
C	6401	Connector	Connector,6 pole	electric centre	front lighting
C	6402	Splice	Splice,1 pole	electric centre	front lighting
C	6403	Splice	Splice,1 pole	electric centre	front lighting
C	6404	Splice	Splice,1 pole	electric centre	front lighting
C	6405	Splice	Splice,1 pole	electric centre	front lighting
C	6406	Splice	Splice,1 pole	electric centre	front lighting
C	6407	Splice	Splice,1 pole	electric centre	front lighting
C	6408	Splice	Splice,1 pole	electric centre	front lighting

C	6409	Splice	Splice,1 pole	electric centre	front lighting
C	6410	Splice	Splice,1 pole	roof rear left	rear lighting
C	6411	Splice	Splice,1 pole	roof rear left	rear lighting
C	6412	Splice	Splice,1 pole	roof rear left	rear lighting
C	6413	Splice	Splice,1 pole	roof rear left	rear lighting
C	6414	Splice	Splice,1 pole	roof rear left	rear lighting
C	6415	Splice	Splice,1 pole	roof rear left	rear lighting
C	6416	Splice	Splice,1 pole	roof	fans for nuzzles
C	6417	Splice	Splice,1 pole	roof	fans for nuzzles
C	6418	Connector	Connector,3 pole	drivers place	BNS II, Node 1.3
C	6419	Connector	Connector,3 pole	roof rear right	BNS II, Node 2.3
C	6420	Connector	Connector,3 pole	roof rear right	BNS II, Node 2.4
C	6421	Connector	Connector,6 pole	roof hatches	roof hatches
C	6422	Connector	Connector,6 pole	roof hatches	roof hatches
C	6423	Connector	Connector,6 pole	roof hatches	roof hatches
C	6424	Connector	Connector,6 pole	roof hatches	roof hatches
C	6425	Connector	Connector,6 pole	roof hatches	roof hatches
C	6426	Connector	Connector,6 pole	roof hatches	roof hatches
C	6427	Connector	Connector,6 pole	roof hatches	roof hatches
C	6428	Connector	Connector,18 pole	roof hatches	roof hatches
C	6429	Splice	Splice,1 pole	roof	fans for nuzzles
C	6430	Splice	Splice,1 pole	roof	fans for nuzzles
C	6431	Splice	Splice,1 pole	pow supp monitoring	Bus 2010
C	6432	Connector	Connector,9 pole	roof front left	ventilation /heating
C	6433	Connector	Connector,9 pole	roof front left	ventilation /heating
C	6434	Connector	Connector,9 pole	roof front left	ventilation /heating
C	6435	Joint connector	Joint connector, roof fans	roof front left	ventilation /heating
C	6436	Joint connector	Joint connector, roof fans	roof front left	ventilation /heating
C	6437	Joint connector	Joint connector, roof fans	roof front left	ventilation /heating
C	6438	Junction box	Connector,5pole	engine	power supply 30
C	6439	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.4
C	6440	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.4
C	6441	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.4
C	6442	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.4
C	6443	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.4
C	6444	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.4
C	6445	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.4
C	6446	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.4
C	6447	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6448	Connector	Connector,6 pole	roof rear-left	BNS II, Node 2.4
C	6449	Connector	Connector,6 pole	roof rear-left	BNS II, Node 2.4
C	6450	Connector	Connector,6 pole	roof rear-left	BNS II, Node 2.4
C	6451	Connector	Connector,9 pole	roof rear-left	BNS II, Node 2.4
C	6452	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6453	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6454	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6455	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6456	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6457	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6458	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6459	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6460	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6461	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6462	Connector	Connector,6 pole	roof rear-left	BNS II, Node 2.4
C	6463	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4

C	6464	Connector	Connector,2 pole	roof rear-left	BNS II, Node 2.4
C	6465	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6466	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6467	Connector	Connector,6 pole	roof rear-left	BNS II, Node 2.4
C	6468	Connector	Connector,3 pole	roof rear-left	BNS II, Node 2.4
C	6469	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.3
C	6470	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.3
C	6471	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.3
C	6472	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.3
C	6473	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.3
C	6474	Splice	Splice,1 pole	roof rear-left	BNS II, Node 2.3
C	6475	Joint connector	Joint connector,AC passenger	roof rear-left	AC passenger
C	6476	Joint connector	Joint connector,AC passenger	roof left after artic	AC passenger
C	6477	Joint connector	Joint connector,AC driver	roof front left	AC driver
C	6478	Connector	Connector,3 pole	roof front left	AC passenger
C	6479	Connector	Connector,3 pole	roof after artic left	AC passenger
C	6480	Connector	Connector,2 pole	engine	AC passenger
C	6481	Connector	Connector,2 pole	engine	AC passenger
C	6482	Splice	Splice,1 pole	main node	roof
C	6483	Connector	Connector,9 pole	roof after artic left	vent/heating,roof fans
C	6484	Connector	Connector,9 pole	roof after artic left	vent/heating,roof fans
C	6485	Connector	Connector,9 pole	roof after artic right	vent/heating,roof fans
C	6486	Connector	Connector,9 pole	roof after artic right	vent/heating,roof fans
C	6487	Joint connector	Joint connector, roof fans	roof after artic left	vent/heating,roof fans
C	6488	Joint connector	Joint connector, roof fans	roof after artic right	vent/heating,roof fans
C	6489	Splice	Splice,1 pole	roof after artic left	vent/heating,roof fans
C	6490	Splice	Splice,1 pole	roof after artic left	vent/heating,roof fans
C	6491	Joint connector	Joint connector,defroster fan	roof front left	ventilation /heating defroster fan
C	6492	Joint connector	Joint connector,roof fans	roof front left	vent//heating roof fans
C	6493	Connector	Connector,4 pole	roof channel behind front axle	heating film floor
C	6494	Connector	Connector,3 pole	roof channel behind front axle	heating film floor
C	6495	Splice	Splice,1 pole	roof channel behind front axle	heating film floor
C	6496	Splice	Splice,1 pole	roof channel behind front axle	heating film floor
C	6497	Splice	Splice,1 pole	roof	Fire exting. System (shot of valve)
C	6498	Splice	Splice,1 pole	engine compartment	rear lighting
C	6499	Splice	Splice,1 pole	engine compartment	rear lighting
C	6500	Splice	Splice,1 pole	engine compartment	rear lighting
C	6501	Splice	Splice,1 pole	engine compartment	rear lighting
C	6502	Splice	Splice,1 pole	engine compartment	rear lighting
C	6503	Splice	Splice,1 pole	engine compartment	rear lighting
C	6504	Splice	Splice,1 pole	engine compartment	rear lighting
C	6505	Splice	Splice,1 pole	engine compartment	rear lighting
C	6506	Splice	Splice,1 pole	engine compartment	rear lighting
C	6507	Connector	Connector,1 pole	electric centre	CD radio
C	6508	Connector	Connector,3 pole	electric centre	CD radio
C	6509	Connector	Connector,6 pole	electric centre	CD radio
C	6510	Connector	Connector,3 pole	electric centre	CD radio
C	6511	Connector	Connector,4 pole	switches panel	switch emergency stop
C	6512	Connector	Connector,3pole	drivers place	BNS II, Node 1.4
C	6513	Connector	Connector,6 pole	roof	Adapter photocell
C	6514	Connector	Connector,6 pole	roof	Adapter photocell
C	6515	Connector	Connector,3 pole	roof front right	BNS II, Node 1.2
C	6516	Connector	Connector,6 pole	roof front right	BNS II, Node 1.2
C	6517	Connector	Connector,3pole	doors	steplight exit doors
C	6518	Connector	Connector,3pole	doors	steplight exit doors

C	6519	Splice	Splice,1 pole	roof rear left	BNS II, Node 2.2
C	6520	Splice	Splice,1 pole	roof rear left	BNS II, Node 2.2
C	6521	Connector	Connector,2pole	engine compartment	Auxiliary heater Webasto
C	6522	Connector	Connector,2pole	engine compartment	Auxiliary heater Webasto
C	6523	Joint connector	Joint connector,roof fans	roof front left	AC low gas bus (Globalx2)
C	6524	Connector	Connector,3 pole	roof front right	BNS II, Node 2.1( lower gas bus)
C	6525	Joint connector	Joint connector, WCR	roof channel behind front axle	WCR CU6
C	6526	Connector	Connector,3 pole	instrument panel	BNS II, Node 1.3
C	6527	Splice	Splice,1 pole	instrument panel	BNS II, Node 1.3
C	6528	Splice	Splice,1 pole		WCR(Hubner)
C	6529	Splice	Splice,1 pole		WCR(Hubner)
C	6530	Connector	Connector,3 pole		WCR(Hubner)
C	6531	Connector	Connector,6 pole		WCR(Hubner)
C	6532	Connector	Connector,16 pole		WCR(Hubner)
C	6533	Connector	Connector,6 pole		BNS II, Node 1.1
C	6534	Connector	Connector,3 pole		BNS II, Node 2.2
C	6535	Connector	Connector,3 pole		BNS II, Node 1.1
C	6536	Connector	Splice,1 pole		BNS II, Node 1.1
C	6537	Connector	Splice,1 pole		BNS II, Node 1.1
C	6538	Connector	Splice,1 pole		BNS II, Node 2.2
C	6539	Connector	Splice,1 pole		BNS II, Node 2.2
C	6540	Connector	Splice,1 pole		BNS II, Node 2.2
C	6541	Connector	Splice,1 pole		BNS II, Node 2.2
C	6542	Connector	Splice,1 pole		BNS II, Node 2.2
C	6543	Connector	Splice,1 pole		BNS II, Node 2.2
C	6544	Connector	Splice,1 pole		BNS II, Node 2.4
C	6545	Connector	Splice,1 pole		BNS II, Node 2.4
C	6546	Connector	Splice,1 pole		BNS II, Node 2.4
C	6547	Connector	Splice,1 pole		BNS II, Node 2.4
D	6000	Resistor	Resistor,120 Ohm	electric centre	Main Node DD
D	6001	Resistor	Resistor,560 Ohm	roof rear left	Rear lighting
D	6002	Resistor	Resistor,560 Ohm	roof rear right	Rear lighting
D	6003	Resistor	Resistor,560 Ohm	roof	Wheelchair ramp Compac
D	6004	Diode	Diode unit,fire extinguishing system	el centre rear sofa uper deck DD	fire extinguishing system DD
D	6005	Diode	Diode,drivers place fan	drivers place	BNS II, Node 1.4
D	6006	Diode	Diode,drivers place fan	drivers place	BNS II, Node 1.4
D	6007	Diode	Diode,drivers place fan	drivers place	BNS II, Node 1.4
D	6008	Resistor	Resistor,3.3 k ohm	roof rear left	BNS II Node 2.2
D	6009	Diode	Diode,emergency door	electromagnet emergency door	BNS II Node 2.3
D	6010	Diode	Diode unit	electric centre	ICL2
D	6011	Diode	Diode unit	electric centre	Speaking assault alarm
D	6012	Diode	Diode	roof rear left	auxiliary heater gas
D	6013	Diode	Diode	electric centre	power supply el central
D	6014	Resistor	Resistor,3.3 k ohm	electric centre	power supply el central
D	6015	Resistor	Resistor,3.3 k ohm	electric centre	power supply el central
D	6016	Diode	Diode	floor	BNS II, Node 1.3
D	6017	Diode	Diode	electric centre	power supply el central
D	6018	Resistor	Resistor,3.3 k ohm	electric centre	power supply el central
D	6019	Resistor	Resistor,3.3 k ohm	electric centre	power supply el central
D	6020	Diode	Diode	electric centre	Gas valves
D	6021	Resistor	Resistor,120 Ohm	roof	comm/power
D	6022	Resistor	Resistor,120 Ohm	electric centre	Main Node
D	6023	Diode	Diode	electric centre	front lighting
D	6024	Diode	Diode	electric centre	front lighting
D	6025	Resistor	Resistor	electric centre	front lighting



D	6026	Resistor	Resistor	electric centre	front lighting
D	6027	Diode	Diode	AC compressor	AC passenger
D	6028	Diode	Diode	AC compressor	AC passenger
D	6029	Diode	Diode	AC compressor	AC passenger
D	6030	Diode	Diode unit	electric center	gas tank package
D	6031	Resistor	Resistor,10 k ohm		BNS II Node 2.4
D	6032	Resistor	Resistor,10 k ohm		BNS II Node 2.4
D	6033	Resistor	Resistor,10 k ohm		BNS II Node 2.4
E	6000	Control unit	Control unit, Node 1.1	Roof right-middle	BNS II, Node 1.1
E	6001	Control unit	Control unit, Node 1.2	Roof right-front	BNS II, Node 1.2
E	6002	Control unit	Control unit, Node 1.3	drivers place	BNS II, Node 1.3
E	6003	Control unit	Control unit, Node 1.4	drivers place	BNS II, Node 1.4
E	6004	Control unit	Control unit, Node 1.5	drivers place	BNS II, Node 1.5
E	6005	Control unit	Control unit, Node 2.1	roof left-middle	BNS II, Node 2.1
E	6006	Control unit	Control unit, Node 2.2	roof rear-left	BNS II, Node 2.2
E	6007	Control unit	Control unit, Node 2.3	roof rear-right	BNS II, Node 2.3
E	6008	Control unit	Control unit, Node 2.4	roof after artic left	BNS II, Node 2.4
E	6009	Control unit	Control unit, Main Node	electric centre	BNS II, Main Node
E	6010	Control unit	Control unit, wheelchair ramp	roof left side	Wheelchair ramp
E	6011	Control unit	Control unit, fire extinguishing system	el centre rear sofa uper deck DD	fire extinguishing system DD
E	6012	Control unit	Control unit, passenger info system	drivers place	Passenger info system
E	6013	Control unit	Control unit, info display front	roof front	Passenger info system
E	6014	Control unit	Control unit, info display behind artic	roof behind artic	Passenger info system
E	6015	Control unit	Control unit,auxiliary heater	engine compartment	Aux.heater Stroco
E	6015.B	Connector	Connector,7 pole	Roof	fuel shut-off valve
E	6016	Control unit	Control unit,fire extinguishing equipment	engine compartment	Dafo
E	6017	Control unit	Control unit,assault alarm	front	speaking assault alarm
E	6018	Control unit	Control unit,auxiliary heater	engine compartment	Aux.heater Spheros
E	6019	Video monitor	Video monitor	drivers place	monitiring system
E	6020	Video monitor	Video monitor	drivers place	monitiring system
E	6021	Video recorder	Video recorder	electric centre	monitiring system
E	6022	Control unit	Control unit,bitonal horn	electric centre	horn fa-la
E	6023	Control unit	Control unit, ISA	electric centre	ISA system
E	6024	Monitor	Monitor, ISA	drivers place	ISA system
E	6025	Control unit	Control unit, Door Node 1	comm/power	comm/power
E	6026	Control unit	Control unit, Door Node 2	comm/power	comm/power
E	6027	Control unit	Control unit, Door Node 3	comm/power	comm/power
E	6028	Control unit	Control unit, Door Node 4	comm/power	comm/power
E	6029	Control unit	Control unit, Climate Control	comm/power	comm/power
E	6030	Control unit	Control unit, DU Roof hatches	roof hatches	roof hatches
E	6031	Control unit	Control unit, DHC Power supply 1	roof hatches	roof hatches
E	6032	Control unit	Control unit, DHC Power supply 2	roof hatches	roof hatches
E	6033	Control unit	Control unit, DHC Power supply 3	roof hatches	roof hatches
E	6034	Control unit	Control unit, DHC Power supply 4	roof hatches	roof hatches
E	6035	Amplifier	Amplifier,radio passenger	electric centre	CD radio
E	6036	Radio	CD radio	electric centre	CD radio
E	6037	Converter	Voltage converter	electric centre	CD radio
F	6000	Fuse holder	Fuse holder, 2-pole	battery compartment	Cejn P8 connection
F	6001	Fuse holder	Fuse holder, 4-pole	roof rear,left	fans for nuzzles
F	6002	Fuse holder	Fuse holder, 4-pole	roof rear,left	ventilation fans
F	6003	Fuse holder	Fuse holder, 2-pole	battery compartment	auxiliary heater Gas
F	6004	Fuse holder	Fuse holder, 2-pole	battery compartment	power supply el central
F	6005	Fuse holder	Fuse holder, 2-pole	battery compartment	power supply el central
F	6006	Fuse holder	Fuse holder, 2-pole	battery compartment	power supply el central
F	6007	Fuse holder	Fuse holder, 4-pole	electric centre	auxiliary heater

F	6008	Fuse holder	Fuse holder, 2-pole	engine	fans for nozzles 4x2
F	6009	Fuse holder	Fuse holder, 2-pole	engine	fans for nozzles 6x2/2
F	6010	Fuse holder	Fuse holder, 2-pole	engine	roof fans 4x2; 6x2*4;6x2/2
F	6011	Fuse holder	Fuse holder, 2-pole	battery compartment	AC driver
F	6012	Fuse holder	Fuse holder, 2-pole	engine	AC 4x2
F	6013	Fuse holder	Fuse holder, 2-pole	engine	AC 6x2/2 front
F	6014	Fuse holder	Fuse holder, 2-pole	engine	AC 6x2/2rear low gas bus
F	6015	Fuse holder	Fuse holder,4-pole	electric centre	Gas bus
F	6016	Fuse holder	Fuse holder, 2-pole	battery compartment	AC 6x2/2 front, global low gas bus
F	6017	Fuse holder	Fuse holder, 4-pole	floor	Climate DD
G	6000.A	Ground	Ground,1-pole	roof right-middle	BNS II, Node 1.1
G	6000.B	Ground	Ground,1-pole	roof right-middle	BNS II, Node 1.1
G	6000.C	Ground	Ground,1-pole	roof right-middle	BNS II, Node 1.1
G	6001.A	Ground	Ground,1-pole	roof right-front	BNS II, Node 1.2
G	6001.B	Ground	Ground,1-pole	roof right-front	BNS II, Node 1.2
G	6001.C	Ground	Ground,1-pole	roof right-front	BNS II, Node 1.2
G	6001.D	Ground	Ground,1-pole	roof right-front	BNS II, Node 1.3
G	6002.A	Ground	Ground,1-pole	switches panel	BNS II,Node 1.4
G	6002.B	Ground	Ground,1-pole	switches panel	BNS II,Node 1.4
G	6002.C	Ground	Ground,1-pole	switches panel	BNS II,Node 1.4
G	6002.D	Ground	Ground,1-pole	switches panel	BNS II,Node 1.4
G	6003	Ground	Ground,1-pole	roof, in front of artic, right	Front Lighting
G	6004	Ground	Ground,1-pole	roof, after artic, right	Front Lighting
G	6005.A	Ground	Ground,1-pole	front	Front Lighting
G	6005.B	Ground	Ground,1-pole	front	Front Lighting
G	6006	Ground	Ground,1-pole	roof rear left	Rear lighting
G	6007.A	Ground	Ground,1-pole	rear	Rear lighting
G	6007.B	Ground	Ground,1-pole	rear	Rear lighting
G	6007.C	Ground	Ground,1-pole	rear	Rear lighting
G	6008.A	Ground	Ground,1-pole	rear	Rear lighting
G	6008.B	Ground	Ground,1-pole	rear	Rear lighting
G	6008.C	Ground	Ground,1-pole	rear	Rear lighting
G	6009	Ground	Ground,1-pole	el centre rear sofa uper deck DD	
G	6010.A	Ground	Ground,1-pole	roof rear-right	BNS II Node 2.3
G	6010.B	Ground	Ground,1-pole	roof rear-right	BNS II Node 2.3
G	6010.C	Ground	Ground,1-pole	roof rear-right	BNS II Node 2.3
G	6010.D	Ground	Ground,1-pole	roof rear-right	BNS II Node 2.3
G	6010.E	Ground	Ground,1-pole	roof rear-right	BNS II Node 2.3
G	6010.F	Ground	Ground,1-pole	roof rear-right	BNS II Node 2.3
G	6011.A	Ground	Ground,1-pole	roof rear-left	BNS II Node 2.2
G	6011.B	Ground	Ground,1-pole	roof rear-left	BNS II Node 2.2
G	6011.C	Ground	Ground,1-pole	roof rear-left	BNS II Node 2.2
G	6011.D	Ground	Ground,1-pole	roof rear-left	BNS II Node 2.2
G	6011.E	Ground	Ground,1-pole	roof rear-left	BNS II Node 2.2
G	6012.A	Ground	Ground,1-pole	roof middle-left	BNS II Node 2.1 +AIP
G	6012.B	Ground	Ground,1-pole	roof middle-left	BNS II Node 2.1 +AIP
G	6012.C	Ground	Ground,1-pole	roof middle-left	BNS II Node 2.1 +AIP
G	6012.D	Ground	Ground,1-pole	roof middle-left	BNS II Node 2.1 +AIP
G	6012.E	Ground	Ground,1-pole	roof middle-left	BNS II Node 2.1 +AIP
G	6113	Ground	Ground,1-pole	drivers place	Aux.heater Stroco
G	6114	Ground	Ground,1-pole	engine compartment	Aux.heater Stroco
G	6015	Ground	Ground,1-pole	Heating dist.centre	
G	6016.A	Ground	Ground,1-pole	electrical central	Front lighting
G	6016.B	Ground	Ground,1-pole	electrical central	Front lighting
G	6017	Ground	Ground,1-pole	roof front right	Marker lamp

G	6018	Ground	Ground,1-pole	roof front left	Marker lamp
G	6019	Ground	Ground,1-pole	electric centre	all
G	6020	Ground	Ground,1-pole	roof front,left lower salon DD	marker lamp DD
G	6021.A	Ground	Ground,1-pole	roof front,left	heating distribution AIP
G	6021.B	Ground	Ground,1-pole	roof front,left	heating distribution AIP
G	6022	Ground	Ground,1-pole	roof left	fans for nuzzles
G	6023	Ground	Ground,1-pole	roof left	fans for nuzzles
G	6024	Ground	Ground,1-pole	roof left	fans for nuzzles
G	6025	Ground	Ground,1-pole	roof right	fans for nuzzles
G	6026	Ground	Ground,1-pole	roof right	fans for nuzzles
G	6027	Ground	Ground,1-pole	roof right	fans for nuzzles
G	6028	Ground	Ground,1-pole	roof left	fans for nuzzles
G	6029	Ground	Ground,1-pole	roof left	fans for nuzzles
G	6030	Ground	Ground,1-pole	roof front left	ventilation /heating
G	6031	Ground	Ground,1-pole	roof front left	ventilation /heating
G	6032.A	Ground	Ground,1-pole	roof rear-left	BNS II Node 2.4
G	6032.B	Ground	Ground,1-pole	roof rear-left	BNS II Node 2.4
G	6032.C	Ground	Ground,1-pole	roof rear-left	BNS II Node 2.4
G	6032.D	Ground	Ground,1-pole	roof rear-left	BNS II Node 2.4
G	6032.E	Ground	Ground,1-pole	roof rear-left	BNS II Node 2.4
G	6032.F	Ground	Ground,1-pole	roof rear-left	BNS II Node 2.4
G	6032.G	Ground	Ground,1-pole	roof rear-left	BNS II Node 2.4
G	6033	Ground	Ground,1-pole	AC passenger	
G	6034	Ground	Ground,1-pole	AC passenger	
G	6035	Ground	Ground,1-pole	Spare	
G	6036	Ground	Ground,1-pole	Spare	
G	6037	Ground	Ground,1-pole	Spare	
G	6038	Ground	Ground,1-pole	roof front left	vent/heating
G	6039	Ground	Ground,1-pole	roof after artic left	vent/heating,roof fan
G	6040	Ground	Ground,1-pole	roof after artic right	vent/heating,roof fan
G	6041.A	Ground	Ground,1-pole	uper salon DD	Spare
G	6041.B	Ground	Ground,1-pole	uper salon DD	Spare
G	6041.C	Ground	Ground,1-pole	uper salon DD	Spare
G	6041.D	Ground	Ground,1-pole	uper salon DD	Spare
G	6042	Ground	Ground,1-pole	Bowl (Balja) Hybrid bus	Bowl-body
G	6043	Ground	Ground,1-pole	Bowl (Balja) Hybrid bus	body-bowl
G	6044	Ground	Ground,1-pole	Engine	Shut-off fuel valve (Ethanol)
G	6045	Ground	Ground,1-pole	Roof front	Info system (hybrid anten plåt)
G	6046	Ground	Ground,1-pole	Roof front	Info system (hybrid anten plåt)
G	6047	Ground	Ground,1-pole		WCR (Hubner)
G	6048	Ground	Ground,1-pole	Spare	Spare
G	6049	Ground	Ground,1-pole	Spare	Spare
G	6050	Ground	Ground,1-pole	Spare	Spare
G	6051	Ground	Ground,1-pole	Spare	Spare
G	6052	Ground	Ground,1-pole	Spare	Spare
G	6053	Ground	Ground,1-pole	Spare	Spare
G	6054	Ground	Ground,1-pole	Spare	Spare
G	6055	Ground	Ground,1-pole	Spare	Spare
G	6056	Ground	Ground,1-pole	Spare	Spare
G	6057	Ground	Ground,1-pole	Spare	Spare
G	6058	Ground	Ground,1-pole	Spare	Spare
G	6059	Ground	Ground,1-pole	Spare	Spare
G	6060	Ground	Ground,1-pole	Spare	Spare
G	6061	Ground	Ground,1-pole	Spare	Spare
G	6062	Ground	Ground,1-pole	Spare	Spare

G	6063	Ground	Ground,1-pole	Spare	Spare
G	6064	Ground	Ground,1-pole	Spare	Spare
G	6065	Ground	Ground,1-pole	Spare	Spare
G	6066	Ground	Ground,1-pole	Spare	Spare
G	6067	Ground	Ground,1-pole	Spare	Spare
G	6068	Ground	Ground,1-pole	Spare	Spare
G	6069	Ground	Ground,1-pole	Spare	Spare
G	6070	Ground	Ground,1-pole	roof right	fans for nuzzles
G	6071	Ground	Ground,1-pole	roof right	fans for nuzzles
G	6072	Ground	Ground,1-pole	roof	fans for nuzzles
G	6073	Ground	Ground,1-pole	roof	fans for nuzzles
G	6074	Ground	Ground,1-pole	roof	fans for nuzzles
G	6075	Ground	Ground,1-pole	roof	fans for nuzzles
G	6076	Ground	Ground,1-pole	Spare	Spare
G	6077	Ground	Ground,1-pole	Spare	Spare
G	6078.A	Ground	Ground,1-pole	instrument panel	
G	6079.A	Ground	Ground,1-pole	drivers place	BNS II,Node 1.5
G	6079.B	Ground	Ground,1-pole	drivers place	BNS II,Node 1.5
G	6080	Ground	Ground,1-pole	door after front axle	power supp STD equip
G	6081	Ground	Ground,1-pole	door behind artic	power supp STD equip
G	6082.A	Ground	Ground,1-pole	door after rear axle	power supp STD equip
G	6082.B	Ground	Ground,1-pole	door after rear axle	power supp STD equip
G	6083	Ground	Ground,1-pole	door in front of front axle	power supp STD equip
G	6084	Ground	Ground,1-pole	roof behind artic	power supp STD equip
H	6000	Heater	Electrical heated rear view mirror	side,drivers place	rear view mirror
H	6001	Heater	Electrical heated rear view mirror	roof front	rear view mirror
H	6002	Heater	Heating element, drivers seat	floor	BNS II, Node 1.3
H	6003	Heater	Heating element, entrance door	floor	BNS II, Node 1.3
H	6004	Heater	Heating element, entrance door	floor	BNS II, Node 1.3
H	6005	Heater	Heating element, Manual wheelchair ramp	floor	heating film man.wheelchair ramp
H	6006	Heater	Heating element, Manual wheelchair ramp	floor	heating film man.wheelchair ramp
K	6000	Connector	Diagnose for BNS II	electric center	BNS II
L	6000	Lamp	Interior light 2nd circuit	roof in front of artic-right	BNS II, Node 1.
L	6001	Lamp	Interior light 2nd circuit	roof in front of artic-left	BNS II, Node 1.1
L	6002	Lamp	Side walk lamp	door behind front axle	BNS II, Node 1.1
L	6003	Lamp	Interior light 1st circuit	roof in font-right	BNS II, Node 1.2
L	6004	Lamp	Interior light 1st circuit	roof in font-left	BNS II, Node 1.2
L	6005	Lamp	Side marking lamp,left	roof left	Marker lamps
L	6006	Lamp	Stop sign light	roof front	BNS II, Node 1.2
L	6007	Lamp	Stop sign light	roof front	BNS II, Node 1.2
L	6008	Lamp	Lamp,Drivers gate	Drivers place	BNS II, Node 1.4
L	6009	Lamp	Direc ind light, front left	front	Front Lighting
L	6010	Lamp	Direc ind light, front right	front	Front Lighting
L	6011	Lamp	Direc ind light, artic left	after artic-left	Front Lighting
L	6012	Lamp	Direc ind light, artic right	after artic-right	Front Lighting
L	6013	Lamp	Front fog lamp left	front	Front Lighting
L	6014	Lamp	Front fog lamp right	front	Front Lighting
L	6015	Lamp	Front position lamp left	front	Front Lighting
L	6016	Lamp	Front position lamp right	front	Front Lighting
L	6017	Lamp	High/Dipped beam lamp left	front	Front Lighting
L	6018	Lamp	High/Dipped beam lamp right	front	Front Lighting
L	6019	Lamp	High beam lamp left	front	Front Lighting
L	6020	Lamp	High beam lamp right	front	Front Lighting
L	6021	Lamp	Auxil dir/Stop/End-outline lamp, rear left	rear	Rear lighting
L	6022	Lamp	Auxil dir/Stop/End-outline lamp, rear right	rear	Rear lighting

L	6023	Lamp	Direction indication lamp, rear left	rear	Rear lighting
L	6024	Lamp	Direction indication lamp, rear right	rear	Rear lighting
L	6025	Lamp	Stop/Possition lamp, rear left	rear	Rear lighting
L	6026	Lamp	Stop/Possition lamp, rear right	rear	Rear lighting
L	6027	Lamp	Reverse lamp left	rear	Rear lighting
L	6028	Lamp	Reverse lamp right	rear	Rear lighting
L	6029	Lamp	Rear fog lamp left	rear	Rear lighting
L	6030	Lamp	Rear fog lamp right	rear	Rear lighting
L	6031	Lamp	Side marker lamp left	rear	Rear lighting
L	6032	Lamp	Side marker lamp right	rear	Rear lighting
L	6033	Lamp	Registration plate lamps	rear	Rear lighting
L	6034	Lamp	Lamp, Wheelchair ramp	Body side	Wheelchair ramp compac
L	6035	Lamp	Lamp, Wheelchair ramp	Body side	Wheelchair ramp compac
L	6036	Lamp	Lamp,sydewalk lamp	Door behind rear door	BNS II Node 2.3
L	6037	Lamp	Sign,NOT EXIT sign light	Door behind rear door	BNS II Node 2.3
L	6038	Lamp	Lamp,Stairs step light	stair step rear door	BNS II Node 2.3
L	6039	Lamp	Interior light 2nd circuit	roof rear	BNS II Node 2.3
L	6040	Lamp	Interior light 2nd circuit	roof rear	BNS II Node 2.3
L	6041	Lamp	Lamp,School sign light rear	roof rear-left	BNS II Node 2.2
L	6042	Lamp	Lamp,drivers place lamp	roof middle-left	BNS II, Node 2,1
L	6043	Lamp	Lamp,entrance lamp	roof middle-left	BNS II, Node 2,1
L	6044	Lamp	Diped beam lamp left	front	Front Lighting
L	6045	Lamp	Diped beam lamp right	front	Front Lighting
L	6046	Lamp	DRL/position/direction ind lamp left	front	Front Lighting
L	6047	Lamp	DRL/position/direction ind lamp right	front	Front Lighting
L	6048	Lamp	Direction ind lamp front left side	front side	Front Lighting
L	6049	Lamp	Direction ind lamp front right side	front side	Front Lighting
L	6050	Lamp	End-outline marking lamp,right	front	Marker lamp
L	6051	Lamp	End-outline marking lamp,left	front	Marker lamp
L	6052	Lamp	Side marking lamp,right	body side	Marker lamp
L	6053	Lamp	Side marking lamp,right	body side	Marker lamp
L	6054	Lamp	Side marking lamp,right	body side	Marker lamp
L	6055	Lamp	Side marking lamp,right	body side	Marker lamp
L	6056	Lamp	Side marking lamp,right	body side	Marker lamp
L	6057	Lamp	Side marking lamp,right	body side	Marker lamp
L	6058	Lamp	Side marking lamp,right	body side	Marker lamp
L	6059	Lamp	Side marking lamp,right	body side	Marker lamp
L	6060	Lamp	Side marking lamp,left	body side	Marker lamp
L	6061	Lamp	Side marking lamp,left	body side	Marker lamp
L	6062	Lamp	Side marking lamp,left	body side	Marker lamp
L	6063	Lamp	Side marking lamp,left	body side	Marker lamp
L	6064	Lamp	Side marking lamp,left	body side	Marker lamp
L	6065	Lamp	Side marking lamp,left	body side	Marker lamp
L	6066	Lamp	End-outline marking lamp,right	body side	Marker lamp DD
L	6067	Lamp	Side marking lamp,right	body side	Marker lamp DD
L	6068	Lamp	Side marking lamp,right	body side	Marker lamp DD
L	6069	Lamp	Side marking lamp,right	body side	Marker lamp DD
L	6070	Lamp	Side marking lamp,right	body side	Marker lamp DD
L	6071	Lamp	End-outline marking lamp,right	body side	Marker lamp DD
L	6072	Lamp	End-outline marking lamp,left	body side	Marker lamp DD
L	6073	Lamp	Side marking lamp,left	body side	Marker lamp DD
L	6074	Lamp	Side marking lamp,left	body side	Marker lamp DD
L	6075	Lamp	Side marking lamp,left	body side	Marker lamp DD
L	6076	Lamp	Side marking lamp,left	body side	Marker lamp DD
L	6077	Lamp	End-outline marking lamp,left	body side	Marker lamp DD

L	6078	Lamp	DRL/position lamp left	front	front lighting + DD
L	6079	Lamp	DRL/position lamp right	front	front lighting + DD
L	6080	Lamp	Pay table lamp	drivers place	BNS II,Node 1.2
L	6081	Lamp	Route instruction lamp	drivers place	BNS II,Node 1.5
L	6082	Lamp	Extra lamp, stop signal	drivers place	BNS II,Node 1.5
L	6083	Lamp	Diped beam lamp left,LED	front	front light
L	6084	Lamp	Diped beam lamp right,LED	front	front light
L	6085	Lamp	School sign light front	drivers place	BNS II,Node 1.3
L	6086	Lamp	Lamp, Door open in front of front axle	drivers place	doors manoeuvre
L	6087	Lamp	Lamp, Door open after front axle	drivers place	doors manoeuvre
L	6088	Lamp	Lamp, Door open after rear axle	drivers place	doors manoeuvre
L	6089	Lamp	Lamp, Door open behind artic	drivers place	doors manoeuvre
L	6090	Lamp	Lamp,interior light,artic	roof rear-left	BNS II Node 2.4
L	6091	Lamp	Lamp,interior light,artic	roof rear-left	BNS II Node 2.4
L	6092	Lamp	Lamp,interior light 1st cir.behind artic	roof rear-left	BNS II Node 2.4
L	6093	Lamp	Lamp,interior light 1st cir.behind artic	roof rear-left	BNS II Node 2.4
L	6094	Lamp	Lamp,sidewalk lamp,behind artic	roof rear-left	BNS II Node 2.4
L	6095	Lamp	Lamp,stop sign light,behind artic	roof rear-left	BNS II Node 2.4
L	6096	Lamp	Lamp,luggage compartment light	Luggage compartment	BNS II Node 1.1
L	6097	Lamp	Lamp,luggage compartment light	Luggage compartment	BNS II Node 2.3
L	6098	Lamp	Lamp, Front area light	roof front-right	BNS II Node 1.2
L	6099	Lamp	Lamp, Cashier desk light	roof front-right	BNS II Node 1.2
L	6100	Lamp	Lamp, Drivers area light	roof front-right	BNS II Node 1.2
L	6101	Lamp	Lamp,luggage compartment light	Luggage compartment	BNS II Node 2.2
M	6000	Motor	Motor,Convector fan	passenger place,door after f. axle	BNS II,Node 1,1
M	6001	Motor	Motor,Heater fan	passenger place,door after f. axle	BNS II,Node 1,1
M	6002	Motor	Motor,Windscreen washer pump	front	Front lighting
M	6002X	Connector	Connector,2 pole	front	Front lighting
M	6003	Motor	Motor,Windscreen wipers	front	Front lighting
M	6004	Motor	Motor,Convector fan	passenger place,door after r. axle	BNS II,Node 2.3
M	6005	Motor	Motor,Heater fan	passenger place,door after r. axle	BNS II,Node 2.3
M	6006	Motor	Motor,circulation pump	Engine rom	BNS II Node 2.2
M	6007	Motor	Motor,drivers place fan	drivers place	BNS II,Node 1.4
M	6008	Motor	Motor,pump passanger circuit	Heating dist.centre	Passenger heating
M	6009	Motor	Motor,ventilation fan	roof,left	fans for nuzzles
M	6010	Motor	Motor,ventilation fan	roof,left	fans for nuzzles
M	6011	Motor	Motor,ventilation fan	roof,left	fans for nuzzles
M	6012	Motor	Motor,ventilation fan	roof,riht	fans for nuzzles
M	6013	Motor	Motor,ventilation fan	roof,riht	fans for nuzzles
M	6014	Motor	Motor,ventilation fan	roof,riht	fans for nuzzles
M	6015	Motor	Motor,ventilation fan	roof,riht	fans for nuzzles
M	6016	Motor	Motor,ventilation fan	roof,riht	fans for nuzzles
M	6017	Motor	Motor,Convector fan	drivers place	BNS II,Node 1.5
M	6018	Motor	Motor,Convector fan	drivers place,entrance	BNS II,Node 1.5
M	6019	Motor	Motor,adj. interior rear view mirror	drivers place	customer order
M	6020	Motor	Motor,adj. interior rear view mirror	drivers place	customer order
M	6021	Motor	Motor,front edge 1	roof hatches	roof hatches
M	6022	Motor	Motor,rear edge 1	roof hatches	roof hatches
M	6023	Motor	Motor,front edge 2	roof hatches	roof hatches
M	6024	Motor	Motor,rear edge 2	roof hatches	roof hatches
M	6025	Motor	Motor,front edge 3	roof hatches	roof hatches
M	6026	Motor	Motor,rear edge 3	roof hatches	roof hatches
M	6027	Motor	Motor,front edge 4	roof hatches	roof hatches
M	6028	Motor	Motor,rear edge 4	roof hatches	roof hatches
M	6029	Motor	Motor,ventilation flap	front	ventilation/heating

M	6030	Motor	Motor,heater fan door behind artic	roof rear-left	BNS II,Node 2.4
N	6000	Buzzer	Buzzer,Stop signal passenger	Roof middle	BNS II,Node 1,1
N	6001	Buzzer	Buzzer,Warning drivers gate	Driver's place	BNS II,Node 1.4
N	6002	Signal horn	Signal horn	Front	front lighting
N	6003	Buzzer	Buzzer,Reverse warning	engine compartment	BNS II Node 2.2
N	6004	Buzzer	Buzzer,Stop signal passenger	roof rear-left	BNS II Node 2.2
N	6005	Buzzer	Warning not applied P-brake	dashboard	warning handbrake off
N	6006.A	Signal horn	Signal horn,horn FA-LA	front	horn fa-la
N	6006.B	Signal horn	Signal horn,horn FA-LA	front	horn fa-la
N	6007	Loud speaker	Loud speaker,driver	electric centre	CD radio
N	6008	Loud speaker	Loud speaker,driver	electric centre	CD radio
N	6009	Loud speaker	Loud speaker,external	electric centre	CD radio
N	6010	Loud speaker	Loud speaker,passenger-right	electric centre	CD radio
N	6011	Loud speaker	Loud speaker,passenger-right	electric centre	CD radio
N	6012	Loud speaker	Loud speaker,passenger-right	electric centre	CD radio
N	6013	Loud speaker	Loud speaker,passenger-right	electric centre	CD radio
N	6014	Loud speaker	Loud speaker,passenger-right	electric centre	CD radio
N	6015	Loud speaker	Loud speaker,passenger-right	electric centre	CD radio
N	6016	Loud speaker	Loud speaker,passenger-left	electric centre	CD radio
N	6017	Loud speaker	Loud speaker,passenger-left	electric centre	CD radio
N	6018	Loud speaker	Loud speaker,passenger-left	electric centre	CD radio
N	6019	Loud speaker	Loud speaker,passenger-left	electric centre	CD radio
N	6020	Loud speaker	Loud speaker,passenger-left	electric centre	CD radio
N	6021	Loud speaker	Loud speaker,passenger-left	electric centre	CD radio
P	6000	Central el. unit	Central electric unit	Electric centre front	Power supply
P	6001	Central el. unit	Central electric unit,AC passenger	AC passenger	AC passenger
P	6002	Central el. unit	Central electric unit,AC passenger	AC passenger	AC passenger
P	6003	Central el. unit	Central electric unit,AC driver	AC driver	AC driver
R	6000	Relay	Relay,door heater fan	roof right,door after front axle	BNS II,Node 1.1
R	6001	Relay	Relay,door heater fan	roof right,door after front axle	BNS II,Node 2.3
R	6002	Relay	Relay	electric centre	speaking assault alarm
R	6003	Relay	Relay	roof left-right	fans for nuzzles
R	6004	Relay	Relay	roof left-right	fans for nuzzles
R	6005	Relay	Relay	dashboard	warning habdbrake off
R	6006	Relay	Relay	electric center	Horn fa-la
R	6007	Relay	Relay	drivers place	BNS II,Node 1.4 FIP
R	6008	Relay	Relay, Manoeuvre front door	electric centre	comm/power
R	6009	Relay	Relay	electric center	front lighting + DRL + Ej CW11
R	6010	Relay	Relay	PCB	Power supply
R	6011	Relay	Relay	PCB	Power supply
R	6012	Relay	Relay	PCB	Power supply
R	6013	Relay	Relay	PCB	Power supply
R	6014	Relay	Relay	PCB	Power supply
R	6015	Relay	Relay	electric center	front lighting + DRL + Ej CW11
R	6016	Relay	Relay	roof middle-left	Ventilation/heating
R	6017	Relay	Relay	roof middle-left	Ventilation/heating
R	6018	Relay	Relay	roof middle-left	Ventilation/heating
R	6019	Relay	Relay,door heater fan	roof rear-left	BNS II,Node 2.4
R	6020	Relay	Relay,defroster fan	roof front-left	vent/heating defroster fan
R	6021	Relay	Relay,defroster fan	roof front-left	vent/heating defroster fan
R	6022	Relay	Relay,defroster fan	roof front-left	vent/heating defroster fan
R	6023	Relay	Relay	roof after artic left	vent/heating roof fan
R	6024	Relay	Relay	roof after artic left	vent/heating roof fan
R	6025	Relay	Relay	roof after artic left	vent/heating roof fan
R	6026	Relay	Relay	roof after artic right	vent/heating roof fan

R	6027	Relay	Relay	roof after artic right	vent/heating roof fan
R	6028	Relay	Relay	roof after artic right	vent/heating roof fan
R	6029	Relay	Relay, fuel cut off	electric centre	Auxiliari heater (ethanol)
R	6030	Relay	Relay,Solenoid valve gas bus	electric centre	Gas bus
R	6031	Relay	Relay,Solenoid valve gas bus	electric centre	Gas bus
R	6032	Relay	Relay,water pump	roof	auxiliary heater
S	6000	Switch	Switch,drivers gate	drivers place	drivers gate lock
S	6001	Switch	Switch,Alarm	drivers place	comunikation system ELKA
S	6002	Switch	Switch,Speaker	drivers place	comunikation system ELKA
S	6003	Switch	Switch adj. interior rear view mirror	drivers place	customer order
T	533	Sensor	Sensor,roof heating circuit	roof middle-left	BNS II, Node 2,1
T	536	Sensor	Sensor,defroster inlet temperature	roof middle-left	BNS II, Node 2,2
T	550	Sensor	Sensor,defroster inlet temperature	roof middle-left	BNS II, Node 2,3
T	6000	Sensor	Sensor,drivers place temperature	drivers place	BNS II, Node 1.4
T	6001	Sensor	Sensor,ambient lighting	sign box front	BNS II, Node 1.2
T	6002	Sensor	Sensor,roof heating circuit	roof middle-left	BNS II, Node 2,1
T	6003	Sensor	Sensor,defroster inlet temperature	roof middle-left	BNS II, Node 2,1
T	6004	Sensor	Sensor,compartment temperature	roof middle-left	BNS II, Node 2,1
T	6005	Sensor	Sensor,collision sensor	drivers place	Gas bus
T	6006	Sensor	Sensor,compartment temperature	roof rear-left	BNS II,Node 2.4
T	6007	Sensor	Sensor,roof heating circuit	roof rear-left	BNS II,Node 2.4
T	6008	Monitor	Monitor,low compressor pressure	engine	AC
T	6009	Monitor	Monitor,high compressor pressure	engine	AC
U	6000	Arial	Aerial, GPS	roof front	
U	6001	Aerial	Aerial, ISA	roof front	ISA system
U	6002	Clock timer	Clock timer,auxiliary heater	Driver's place	Aux.heater Stroco/Spheros
U	6003	Clock timer	Clock timer,auxiliary heater OBS! Används ej	Spare	Spare
U	6004	Microphone	Microphone,drivers place	electric centre	CD radio
U	6005	Microphone	Microphone,guide	electric centre	CD radio
V	6000	Solenoid valve	Solenoid valve,roof heating circuit	roof middle-left	BNS II, Node 2,1
V	6001	Solenoid valve	Solenoid valve,convector circuit	Heating dist.centre	Passenger heating
V	6002	Solenoid valve	Solenoid valve,drivers place heat.circ.	Heating dist.centre	Drivers heating
V	6003	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6004	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6005	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6006	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6007	Electromagnetic	Electromagnetic,drivers gate	drivers place	drivers gate lock / S order
V	6008	Electromagnetic	Electromagnetic,drivers gate	drivers place	drivers gate lock / S order
V	6009	Solenoid valve	Solenoid valve,park ramp aux. heat. circuit	roof front left	combine auxiliary heater
V	6010	Solenoid valve	Solenoid valve,roof heating circuit	roof rear artic-left	BNS II,Node 2.4
V	6011	Solenoid valve	Solenoid valve,combine pass/drivers AC	roof front left	BNS II,Node 2.1
V	6012	Solenoid valve	Solenoid valve,compressor clutch	engine room	BNS II,Node 2.3
V	6013	Solenoid valve	Solenoid valve,fuel cut off	electric centre	Auxiliari heater (ethanol)
V	6014	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6015	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6016	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6017	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6018	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6019	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6020	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6021	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6022	Solenoid valve	Solenoid valve,shut off gas supply	Roof exterior	gas bus
V	6023	Solenoid valve	Solenoid valve,passenger AC front	roof front right	Artic Lower gas bus
V	6024	Solenoid valve	Solenoid valve, Heating circuit recirculation	roof front l-left	BNS II, Node 2,1



**Component Library****Scania-OMNI-S-order**

No.	Type	Description	Harness	System
C 9000	Connector	Connector,3-pole	Passenger place	Red alarm buttons
C 9001	Connector	Connector,3-pole	Passenger place	Red alarm buttons
C 9002	Connector	Connector,3-pole	Passenger place	Red alarm buttons
C 9003	Connector	Connector,3-pole	Passenger place	Red alarm buttons
C 9004	Connector	Connector,3-pole	Passenger place	Red alarm buttons
C 9005	Connector	Connector,3-pole	Passenger place	Red alarm buttons
C 9006	Splice	Splice, 1pole	Drivers place	Wheelchair place
C 9007	Splice	Splice, 1pole	Drivers place	Wheelchair place
C 9008	Connector	Connector,9-pole	Roof channel	Wheelchair place
C 9009	Connector	Connector,3-pole	Electrical central	Ameli sign box
C 9010	Connector	Connector,1-pole	Electrical central	Ameli sign box
C 9011	Connector	Connector,3-pole	Electrical central	Ameli sign box
C 9012	Connector	Connector,4-pole	Electrical central	Ameli sign box
C 9013	Connector	Connector,6-pole	Electrical central	Ameli power supply
C 9014	Connector	Connector,9-pole	Roof channel	Power supply
C 9015	Junction box	Connector,1-pole	Roof channel	Power supply
C 9016	Connector	Connector,1-pole	Roof channel	Power supply
C 9017	Connector	Connector,1-pole	Roof channel	Power supply
C 9018	Connector	Connector,1-pole	Roof channel	Power supply
C 9019	Connector	Connector,1-pole	Roof channel	Power supply
C 9020	Connector	Connector,1-pole	Roof channel	Power supply
C 9021	Connector	Connector,1-pole	Roof channel	Power supply
C 9022	Connector	Connector,1-pole	Roof channel	Power supply
C 9023	Connector	Connector,1-pole	Roof channel	Power supply
C 9024	Connector	Connector,2-pole	Electrical central	CCTV Skantech
C 9025	Connector	Connector,3-pole	Electrical central	CCTV Skantech
C 9026	Connector	Connector,4-pole	Electrical central	CCTV Skantech
C 9027	Connector	Connector,2-pole	Dashboard	Power supply
C 9028	Connector	Connector,2-pole	Dashboard	Power supply
C 9029	Connector	Connector,2-pole	Dashboard	Power supply
C 9030	Connector	Connector,6-pole	Dashboard	Com.radio alarm
C 9031	Connector	Connector,6-pole	Dashboard	Com.radio alarm
C 9032	Connector	Connector,9-pole	Dashboard	Com.radio alarm
C 9033	Connector	Connector,9-pole	Dashboard	Com.radio alarm
C 9034	Connector	Connector,4-pole	Rear	Marker lamps
C 9035	Connector	Connector,4-pole	Rear	Marker lamps
C 9036	Connector	Connector,2-pole	Rear	Marker lamps
C 9037	Splice	Splice, 1pole	Rear	Marker lamps
C 9038	Connector	Connector,4-pole	Side	Groeneveld
C 9039	Connector	Connector,9-pole	Side	Groeneveld
C 9040	Connector	Connector,3-pole	Side	Groeneveld
C 9041	Connector	Connector,1-pole	Electrical central	Com.radio alarm
C 9042	Connector	Connector,1-pole	Electrical central	Com.radio alarm
C 9043	Connector	Connector,2-pole	Electrical central	Com.radio alarm
C 9044	Connector	Connector,2-pole	Electrical central	Com.radio alarm
C 9045	Connector	Connector,2-pole	Electrical central	Com.radio alarm
C 9046	Connector	Connector,2-pole	Electrical central	LAWO sign box
C 9047	Connector	Connector,2-pole	Electrical central	LAWO sign box
C 9048	Connector	Connector,6-pole	Dashboard	Rosho
C 9049	Connector	Connector,14-pole	Dashboard	Rosho
C 9050	Connector	Connector,4-pole	Dashboard	Rosho
C 9051	Joint connector	Joint connector, power supply	Electrical central	Power supply

C	9052	Joint connector	Joint connector, power supply	Electrical central	Power supply
C	9053	Joint connector	Joint connector, power supply	Electrical central	Power supply
C	9054	Connector	Connector,15-pole	Side	Side walk detector
C	9055	Connector	Connector,9-pole	Side	Aux.heater
C	9056	Connector	Connector,6-pole	Side	Aux.heater
C	9057	Connector	Connector,3-pole	Side	Aux.heater
C	9058	Connector	Connector,3-pole	Side	Aux.heater
C	9059	Connector	Connector,2-pole	Roof channel	Vogel
C	9060	Connector	Connector,9-pole	Roof channel	Vogel
C	9061	Connector	Connector,12-pole	Power supply	Power supply IT
C	9062	Connector	Connector,4-pole	Step light	Step light
C	9063	Connector	Connector,4-pole	Step light	Step light
C	9064	Connector	Connector,3-pole	Electric sun blind	Electric sun blind
C	9065	Connector	Connector,2-pole	Mobitec info system	Mobitec sign boxes
C	9066	Connector	Connector,2-pole	Mobitec info system	Mobitec sign boxes
C	9067	Connector	Connector,2-pole	Mobitec info system	Mobitec sign boxes
C	9068	Connector	Connector,2-pole	Mobitec info system	Mobitec sign boxes
C	9069	Connector	Connector,3-pole	Mobitec info system	Mobitec sign boxes
C	9070	Connector	Connector,3-pole	Mobitec info system	Mobitec sign boxes
C	9071	Connector	Connector,3-pole	Mobitec info system	Mobitec sign boxes
C	9072	Connector	Connector,12-pole	Drager interlock with BSB	Drager interlock
C	9073	Connector	Connector,4-pole	Stop switches	Stop switches
C	9074	Connector	Connector,3-pole	Stop switches	Stop switches
C	9075	Connector	Connector,3-pole	Stop switches	Stop switches
C	9076	Connector	Connector,3-pole	Stop switches	Stop switches
C	9077	Connector	Connector,3-pole	Stop switches	Stop switches
C	9078	Connector	Connector,2-pole	GONG Legrand	GONG Legrand
C	9079	Connector	Connector,4-pole	Exterior wheelchair button	Wheelchair place
C	9080	Connector	Connector,4-pole	Exterior wheelchair button	Wheelchair place
C	9081	Connector	Connector,3-pole	Exterior wheelchair button	Wheelchair place
C	9082	Connector	Connector,3-pole	Exterior wheelchair button	Wheelchair place
C	9083	Connector	Connector,3-pole	Exterior wheelchair button	Wheelchair place
C	9084	Connector	Connector,3-pole	Exterior wheelchair button	Wheelchair place
C	9085	Connector	Connector,5-pole	Belt reminder	Safety belt reminder
C	9086	Connector	Connector,3-pole	CD Radio	CD radio mute
C	9087	Connector	Connector,2-pole	Power supply	Prodata
C	9088	Connector	Connector,2-pole	Power supply	Prodata
C	9089	Connector	Connector,2-pole	Power supply	Prodata
C	9090	Connector	Connector,2-pole	Power supply	Prodata
C	9091	Connector	Connector,2-pole	Power supply	Prodata
C	9092	Connector	Connector,2-pole	Power supply	Prodata
C	9093	Connector	Connector,2-pole	Power supply	Prodata
C	9094	Splice	Splice, 1pole	Power supply	Prodata
C	9095	Splice	Splice, 1pole	Power supply	Prodata
C	9096	Joint connector	Joint connector	Power supply	Prodata
C	9097	Joint connector	Joint connector	Power supply	Prodata
C	9098	Connector	Connector,3-pole	Alarm	Assault alarm
C	9099	Connector	Connector,3-pole	Alarm	Assault alarm
C	9100	Connector	Connector,3-pole	Com.radio.	Prodata
C	9101	Connector	Connector,3-pole	Com.radio.	Prodata
C	9102	Connector	Connector,3-pole	Com.radio.	Prodata
C	9103	Splice	Splice, 1pole	Com.radio.	Prodata
C	9104	Splice	Splice, 1pole	Com.radio.	Prodata
C	9105	Connector	Connector, 1-pole	Com.radio.	Prodata
C	9106	Connector	Connector, 1-pole	Com.radio.	Prodata

C	9107	Splice	Splice, 1pole	Alarm	Assault alarm
C	9108	Splice	Splice, 1pole	Alarm	Assault alarm
C	9109	Connector	Connector, 1-pole	Alarm	Assault alarm
C	9110	Connector	Connector, 6-pole	Loudspeaker	Loudspeaker switch on/off
C	9111	Connector	Connector, 6-pole	Loudspeaker	Loudspeaker switch on/off
C	9112	Connector	Connector, 3-pole	Stop Sign	Stop Sign Rear
C	9113	Connector	Connector, 3-pole	Driver place	Fan
C	9114	Connector	Connector, 11-pole	Above driver	CAN converter
C	9115	Connector	Connector, 3-pole	Above driver	FM radio
C	9116	Connector	Connector, 3-pole	Above driver	FM radio
C	9117	Connector	Connector, 12-pole	Above driver	FM radio
C	9118	Connector	Connector, 2-pole	Above driver	FM radio
C	9119	Connector	Connector, 3-pole	Electrical central	Aesys
C	9120	Connector	Connector, 3-pole	Electrical central	Aesys
C	9121	Connector	Connector, 3-pole	Electrical central	Aesys
C	9122	Connector	Connector, 3-pole	Electrical central	Aesys
C	9123	Splice	Splice, 1pole	Side	Side walk detector
C	9124	Splice	Splice, 1pole	Side	Side walk detector
C	9125	Connector	Connector, 3-pole	Driver place	Stop diode
C	9126	Connector	Connector, 3-pole	Driver place	Stop diode
C	9127	Connector	Connector, 3-pole	IT box signals	IT box signals
C	9128	Connector	Connector, 3-pole	IT box signals	IT box signals
C	9129	Connector	Connector, 3-pole	IT box signals	IT box signals
C	9130	Connector	Connector, 3-pole	IT box signals	IT box signals
C	9131	Connector	Connector, 3-pole	IT box signals	IT box signals
C	9132	Connector	Connector, 1-pole	IT box signals	IT box signals
C	9133	Connector	Connector, 1-pole	IT box signals	IT box signals
C	9134	Connector	Connector, 1-pole	IT box signals	IT box signals
C	9135	Connector	Connector, 1-pole	IT box signals	IT box signals
C	9136	Connector	Connector, 12-pole	IT box signals	IT box signals
C	9137	Connector	Connector, 2-pole	IT box signals	IT box signals
C	9138	Connector	Connector, 2-pole	IT box signals	IT box signals
C	9139	Connector	Connector, 2-pole	IT box signals	IT box signals
C	9140	Connector	Connector, 2-pole	IT box signals	IT box signals
C	9141	Splice	Splice, 1pole	IT box signals	IT box signals
C	9142	Splice	Splice, 1pole	IT box signals	IT box signals
C	9143	Splice	Splice, 1pole	IT box signals	IT box signals
C	9144	Splice	Splice, 1pole	IT box signals	IT box signals
C	9145	Splice	Splice, 1pole	IT box signals	IT box signals
C	9146	Connector	Connector, 3-pole	LED lamp	LED lamp
C	9147	Connector	Connector, 3-pole	LED lamp	LED lamp
C	9148	Connector	Connector, 2-pole	LED lamp	LED lamp
C	9149	Connector	Connector, 2-pole	LED lamp	LED lamp
C	9150	Connector	Connector, 1-pole	LED lamp	LED lamp
C	9151	Connector	Connector, 1-pole	LED lamp	LED lamp
C	9152	Connector	Connector, 1-pole	LED lamp	LED lamp
C	9153	Connector	Connector, 1-pole	LED lamp	LED lamp
C	9154	Connector	Connector, 6-pole	IT box MIIPS system	IT box MIIPS system
C	9155	Connector	Connector, 8-pole	IT box MIIPS system	IT box MIIPS system
C	9156	Connector	Connector, 10-pole	IT box MIIPS system	IT box MIIPS system
C	9157	Connector	Connector, 12-pole	IT box MIIPS system	IT box MIIPS system
C	9058	Connector	Connector,6-pole	Dashboard	Rosho
C	9059	Connector	Connector,6-pole	Roof	Safety belt reminder
C	9060	Connector	Connector,6-pole	Roof	Safety belt reminder
C	9061	Connector	Connector,6-pole	Roof	Safety belt reminder

C	9062	Connector	Connector, 3-pole	Roof	Safety belt reminder
C	9063	Connector	Connector, 3-pole	Roof	Safety belt reminder
C	9064	Connector	Connector, 3-pole	Electrical central	Antitheft system
C	9065	Connector	Connector, 3-pole	Electrical central	Antitheft system
C	9066	Connector	Connector, 3-pole	Electrical central	Antitheft system
C	9067	Connector	Connector, 3-pole	Electrical central	Antitheft system
C	9068	Connector	Connector, 3-pole	Electrical central	Antitheft system
C	9069	Connector	Connector, 12-pole	Electrical central	Antitheft system
C	9070	Splice	Splice, 1pole	Electrical central	Antitheft system
C	9071	Splice	Splice, 1pole	Electrical central	Antitheft system
C	9072	Connector	Connector, 3-pole	Roof	LED Dimming
C	9073	Connector	Connector, 2-pole	Roof	LED Dimming
C	9074	Connector	Connector, 3-pole	Roof	Engine hatch alarm
C	9075	Connector	Connector, 3-pole	Roof	Engine hatch alarm
C	9076	Splice	Splice, 1pole	Roof	Engine hatch alarm
C	9077	Splice	Splice, 1pole	Roof	Engine hatch alarm
C	9078	Splice	Splice, 1pole	Roof	Engine hatch alarm
C	9079	Splice	Splice, 1pole	Roof	Engine hatch alarm
C	9080	Splice	Splice, 1pole	Roof	Engine hatch alarm
C	9081	Splice	Splice, 1pole	Roof	Engine hatch alarm
C	9082	Splice	Splice, 1pole	Roof	Engine hatch alarm
C	9083	Splice	Splice, 1pole	Roof	Engine hatch alarm
C	9084	Splice	Splice, 1pole	Roof	Engine hatch alarm
C	9085	Splice	Splice, 1pole	Roof	Engine hatch alarm
D	9000	Diode	Diode unit	Electrical central	Inhibit engine start
D	9001	Resistor	Resistor	Above driver	FM radio
D	9002	Resistor	Resistor	Driver place	Stop diode
D	9003	Resistor	Resistor	Driver place	Stop diode
D	9004	Diode	Diode unit	Electrical central	Antitheft system
D	9005	Diode	Diode unit	Electrical central	Antitheft system
D	9006	Diode	Diode unit	Roof	Engine hatch alarm
D	9007	Diode	Diode unit	Roof	Engine hatch alarm
D	9008	Diode	Diode unit	Roof	Engine hatch alarm
D	9009	Diode	Diode unit	Roof	Engine hatch alarm
D	9010	Diode	Diode unit	Roof	Engine hatch alarm
D	9011	Diode	Diode unit	Roof	Engine hatch alarm
E	9000	Voltage divider	Voltage divider 24V/12V	Electrical central	CCTV Skantech
E	9001	Voltage divider	Voltage divider 24V/12V	Electrical central	Power supply com radio
E	9002	Control unit	Side walk detector	Side	Side walk detector
E	9003	Control unit	Side walk detector	Side	Side walk detector
E	9004	Electronic unit	Electronic unit Drager	Drager interlock with BSB	Drager interlock
E	9005	Voltage divider	Voltage divider 24V/12V	Belt reminder	Safety belt reminder
E	9006	Radio	Radio	CD Radio	CD radio mute
E	9007	Voltage divider	Voltage divider 24V/12V	CD Radio	CD radio mute
E	9008	Control unit	Side walk detector	Side	Side walk detector
E	9009	Control unit	Antithest system unit	Electrical central	Antitheft system
E	9010	Control unit	Antithest system unit	Electrical central	Antitheft system
E	9011	Control unit	Dimming unit	Roof	LED Dimming
F	9000	Fuseholder	Fuse holder, 8-pole	Electrical central	Power supply
F	9001	Fuseholder	Fuse holder, 8-pole	Roof channel	Power supply
F	9002	Fuseholder	Fuse holder, 6-pole	Electrical central	Power supply
F	9003	Fuseholder	Fuse holder, 6-pole	Roof channel	Power supply
F	9004	Fuseholder	Fuse holder, 1-pole	Roof channel	Power supply
F	9005	Fuseholder	Fuse holder, 6-pole	Roof channel	Power supply
F	9006	Fuseholder	Fuse holder, 8-pole	Electrical central	Power supply

F	9007	Fuseholder	Fuse holder, 8-pole	Roof channel	Power supply
F	9008	Fuseholder	Fuse holder, 1-pole	Battery compartment	Power supply
F	9009	Fuseholder	Fuse holder, 8-pole	Power supply	Prodata
F	9010	Fuseholder	Fuse holder, 1-pole	Power supply	Prodata
F	9011	Fuseholder	Fuse holder, 8-pole	Electrical central	Antitheft system
G	9000	Ground	Ground,1-pole	Roof channel	Power supply
G	9001	Ground	Ground,1-pole	Roof channel	Power supply
G	9002	Ground	Ground,1-pole	Roof channel	Power supply
G	9003	Ground	Ground,1-pole	Above driver	LAWO sign box
G	9004	Ground	Ground,1-pole	Above driver	LAWO sign box
G	9005	Ground	Ground,1-pole	Belt reminder	Safety belt reminder
G	9006	Ground	Ground,Electrical central	CD Radio	CD radio mute
G	9007	Ground	Ground,Roof channel	Side	Side walk detector
G	9008	Ground	Ground,Roof channel	Side	Side walk detector
L	9000	Lamp	Lamp,Wheel chair info red	Drivers place	Wheelchair place
L	9001	Lamp	Lamp,Wheel chair info green	Drivers place	Wheelchair place
L	9002	Lamp	Lamp,Wheel chair info yellow	Drivers place	Wheelchair place
L	9003	Lamp	Lamp,Wheel chair place green	Drivers place	Wheelchair place
L	9004	Lamp	Lamp,Wheel chair place yellow	Drivers place	Wheelchair place
L	9005	Lamp	Side marker lamp left	Rear	Rear lighting
L	9006	Lamp	Side marker lamp right	Rear	Rear lighting
L	9007	Lamp	Lamp, Vogel	Roof channel	Vogel
L	9008	Lamp	Ticket machine lamp	Roof channel	TM light
L	9009	Lamp	Ticket machine lamp	Roof channel	TM light
L	9010	Lamp	Lamp, Bus Stop Brake	Com.radio.	Prodata
L	9011	Lamp	Lamp, Warning lamp	LED lamp	LED lamp
L	9012	Lamp	Lamp, Warning lamp	LED lamp	Engine hatch alarm
M	9000	Motor	Motor,Sunblind	Electric sun blind	Electric sun blind
M	9001	Motor	Motor, ventilation fan	Driver fan for nozzles	Fan
M	9002	Motor	fan	Drivers place	Fan
N	9000	Buzzer	Buzzer, Alarm	Drivers place	Red alarm buttons
N	9001	Loudspeaker	Loudspeaker, driver	CD Radio	CD radio mute
N	9002	Loudspeaker	Loudspeaker, driver	CD Radio	CD radio mute
N	9003	Loudspeaker	Loudspeaker, driver	Com.radio.	Prodata
N	9004	Loudspeaker	Loudspeaker, passenger	Com.radio.	Prodata
N	9005	Loudspeaker	Loudspeaker, passenger	Com.radio.	Prodata
N	9006	Loudspeaker	Loudspeaker, passenger	Com.radio.	Prodata
N	9007	Buzzer	Buzzer, Alarm	Drivers place	Engine hatch alarm
R	9000	Relay	Relay	Drivers place	Red alarm buttons
R	9001	Relay	Relay,Wheel chair pl.lamp red	Electrical central	Wheelchair place
R	9002	Relay	Relay,Wheel chair pl.lamp green	Electrical central	Wheelchair place
R	9003	Relay	Relay,Wheel chair pl.lamp yellow	Electrical central	Wheelchair place
R	9004	Relay	Relay,Reset wheel chair place	Electrical central	Wheelchair place
R	9005	Relay	Relay,starter lock	Instrument panel	Anti thief device
R	9006	Relay	Relay	Electrical central	Ameli sign box
R	9007	Relay	Relay	Electrical central	Ameli sign box
R	9008	Relay	Relay	Electrical central	Ameli sign box
R	9009	Relay	Relay	Electrical central	Inhibit engine start
R	9010	Relay	Relay	Electrical central	CCTV Skantech
R	9011	Relay	Relay	Dashboard	Com.radio alarm
R	9012	Relay	Relay	Dashboard	Com.radio alarm
R	9013	Relay	Relay	Dashboard	Com.radio alarm
R	9014	Relay	Relay	Dashboard	Com.radio alarm
R	9015	Relay	Time relay	Dashboard	Com.radio alarm
R	9016	Relay	Relay	Electrical central	LAWO sign box

R	9017	Relay	Time relay	Side	Side walk detector
R	9018	Relay	Relay	Side	Side walk detector
R	9019	Relay	Relay	Side	Side walk detector
R	9020	Relay	Relay	Step light	Step light
R	9021	Relay	Time relay	Step light	Step light
R	9022	Relay	Relay	Mobitec info system	Mobitec sign boxes
R	9023	Relay	Relay	Mobitec info system	Mobitec sign boxes
R	9024	Relay	Relay	Drager interlock with BSB	Drager interlock
R	9025	Relay	Relay	Stop switches	Stop switches
R	9026	Relay	Relay	Stop switches	Stop switches
R	9027	Relay	Time relay	GONG Legrand	GONG Legrand
R	9028	Relay	Relay	GONG Legrand	GONG Legrand
R	9029	Relay	Relay	Exterior wheelchair button	Wheelchair place
R	9030	Relay	Relay	Exterior wheelchair button	Wheelchair place
R	9031	Relay	Relay	Exterior wheelchair button	Wheelchair place
R	9032	Relay	Time relay	Belt reminder	Safety belt reminder
R	9033	Relay	Relay	Belt reminder	Safety belt reminder
R	9034	Relay	Relay	Roof channel	TM light
R	9035	Relay	Relay	Roof channel	TM light
R	9036	Relay	Relay	Roof channel	TM light
R	9037	Relay	Relay	Power supply	Prodata
R	9038	Relay	Relay	Power supply	Prodata
R	9039	Relay	Relay	Driver fan for nozzles	Fan
R	9040	Relay	Relay	Driver fan for nozzles	Fan
R	9041	Relay	Time relay	Alarm	Assault alarm
R	9042	Relay	Relay	Alarm	Assault alarm
R	9043	Relay	Relay	Electrical central	Aesys
R	9044	Relay	Relay	Electrical central	Aesys
R	9045	Relay	Relay	Electrical central	Aesys
R	9046	Relay	Relay, Warning lamp	LED lamp	LED lamp
R	9047	Relay	Time relay	Roof	Safety belt reminder
R	9048	Relay	Relay	Electrical central	Antitheft system
R	9049	Relay	Relay	Electrical central	Antitheft system
R	9050	Relay	Relay	Electrical central	Antitheft system
R	9051	Relay	Relay	Instrument panel	Engine hatch alarm
S	9000	Switch	Alarm	Passenger place	Red alarm buttons
S	9001	Switch	Alarm	Passenger place	Red alarm buttons
S	9002	Switch	Alarm	Passenger place	Red alarm buttons
S	9003	Switch	Alarm	Passenger place	Red alarm buttons
S	9004	Switch	Alarm	Passenger place	Red alarm buttons
S	9005	Switch	Alarm	Passenger place	Red alarm buttons
S	9006	Switch	Switch,starter lock	Instrument panel	Anti thief device
S	9007	Switch	Aux.heater	Instrument panel	Aux.heater
S	9008	Switch	Monitoring camera	Instrument panel	Monitoring camera
S	9009	Switch	Door manouvring 2	Instrument panel	Door manouvring 2
S	9010	Switch	Announcement	Electrical central	Com.radio alarm
S	9011	Switch	Com.radio	Electrical central	Com.radio alarm
S	9012	Switch	AC shut off	Electrical central	AC shut off
S	9013	Switch	Switch,side walk detector off	Side	Side walk detector
S	9014	Switch	Stairs LED light	Step light	Step light
S	9015	Switch	Reset alcolock	Drager interlock with BSB	Drager interlock
S	9016	Switch	Reset	Stop switches	Stop switches
S	9017	Switch	Supervised stop signal	Stop switches	Stop switches
S	9018	Switch	Supervised stop signal	Stop switches	Stop switches
S	9019	Switch	Supervised stop signal	Stop switches	Stop switches

S	9020	Switch	Switch, GONG Legrand	GONG Legrand	GONG Legrand
S	9021	Switch	Switch, Drivers micro switch - floor	Alarm	Assault alarm
S	9022	Switch	Switch, loudspeaker On/Off	Loudspeaker	Loudspeaker switch on/off
S	9023	Switch	Switch, BDI system	drivers place	Prodata
S	9023X	Connector	Connector, BDI system	drivers place	Prodata
S	9024	Switch	Switch, Manoeuvre front door	Drivers place	Man.front door
S	9024X	Connector	Connector, Manoeuvre front door	Drivers place	Man.front door
S	9025	Switch	Switch, FM radio	Above driver	FM radio
S	9026	Switch	Switch, ramp complete disable	Extension cable	Electrical central
S	9027	Switch	Supervised stop signal	Stop switches	Stop switches
S	9028	Switch	Supervised stop signal	Stop switches	Stop switches
S	9029	Switch	Supervised stop signal	Stop switches	Stop switches
T	9000	Sensor	Sensor	Side	Groeneveld
T	9001	Sensor	Side walk detector	Side	Side walk detector
T	9002	Sensor	Side walk detector	Side	Side walk detector
T	9003	Sensor	Side walk detector	Side	Side walk detector
T	9004	Sensor	Side walk detector	Side	Side walk detector

**Component Library****Engines**

	No.	Type	Description	Harness	System
C	4000	Connector	Connector, 4-pole, Diagnostics	Engine	EMS
C	4001	Connector	Connector, 8-pole, Interface	Engine - Frame	EMS
C	4002	Connector	Connector, 6-pole, Interface	Engine - Frame	EMS
C	4003	Splice	Splice, 1-pole, Interface	Engine	EMS
C	4004	Splice	Splice, 1-pole, Interface	Engine	EMS
C	4005	Splice	Splice, 1-pole, Interface	Engine	EMS
C	4006	Splice	Splice, 1-pole, Interface	Engine	EMS
C	4007	Connector	Connector, 3-pole	Engine	EMS
C	4008	Connector	Connector, 4-pole	Engine	EMS
C	4009	Connector	Connector, 6-pole	Engine	EMS
C	4010	Connector	Connector, 3-pole	Engine	EMS
C	4011	Connector	Connector, 4-pole	Frame	EEC
C	4012	Connector	Connector, 2-pole	Frame	EEC
C	4013	Connector	Connector, 2-pole	Frame	EEC
C	4014	Connector	Connector, 3-pole	Frame	EEC
C	4015	Connector	Splice, 1-pole	Frame	EEC
C	4016	Connector	Connector, 2-pole	Engine	EMS
C	4017	Splice	Splice, 1-pole	Engine	EMS
C	4018	Splice	Splice, 1-pole	Engine	EMS
C	4019	Splice	Splice, 1-pole	Engine	EMS
C	4020	Connector	Connector, 2-pole	Engine	EMS
C	4021	Splice	Splice, 1-pole	Engine	EMS
C	4022	Connector	Connector, 7-pole	Engine	EMS
C	4047	Splice	Splice, 1-pole	Engine	EMS
C	4048	Splice	Splice, 1-pole	Engine	EMS
C	4049	Splice	Splice, 1-pole	Engine	EMS
C	4050	Splice	Splice, 1-pole	Engine	EMS
C	4051	Connector	Connector, 4-pole	Component	EEC
C	4071	Connector	Connector, 4-pole, Interface	Engine - Frame	EMS
C	4072	Cut cable	Cut cable,	Engine - Frame	EMS
C	4073	Cut cable	Cut cable,	Engine - Frame	EMS
C	4074	Connector	Connector, 4-pole	Instrument panel	Instrument panel
C	4075	Splice	Splice, 1-pole	Engine	EMS
C	4076	Splice	Splice, 1-pole	Engine	EMS
C	4077	Connector	Connector, 2-pole	Engine	EMS
C	4080	Connector	Connector, 4-pole	Engine	EMS
C	4081	Connector	Connector, 4-pole	Engine	EMS
C	4082	Connector	Connector, 4-pole	Engine	EMS
C	4083	Splice	Splice, 1-pole	Engine	EMS
D	4000	Resistor	Resistor, EGR	Engine	EMS
D	4001	Potentiometer	Potentiometer, redundant throttle	Instrument panel	Instrument panel
D	4014	Resistor	Resistor, oil pressure	Component	Instrument panel
D	4015	Resistor	Resistor, coolant temperature	Component	Instrument panel
E	4000	Control unit	Control unit coordinator slave	CBC-slave	COO
F	4000	Fuse holder	Fuse holder, 1-pole, SCR	Frame	EEC
F	4017	Fuse	Fuse	Engine	EMS
G	4000	Ground	Ground, engine, SCR	Frame	EEC
G	4001	Ground	Ground, engine,	Engine	EMS
M	4000	Motor	Motor, exhaust brake	Engine	EMS
M	4000.X	Connector	Connector, Motor, exhaust brake	Engine	EMS
R	4007	Relay	Relay, exhaustbrake	Engine	EMS
T	4000	Sensor	Sensor, pressure, atmosphere	Engine	EMS



T	4001	Sensor	Sensor, oil press, oil temp engine	Engine	EMS
T	4002	Sensor unit	Sensor unit, temp/level/quality	Component	EEC
T	4003	Monitor	Monitor, low oil pressure	Component	Instrument panel
T	4004	Monitor	Monitor, high coolant temperature	Component	Instrument panel
T	4005A	Sensor	Sensor, engine speed	Component	Instrument panel
T	4005B	Sensor	Sensor, engine speed	Component	Instrument panel
T	4006	Monitor	Monitor, low coolant pressure	Component	Instrument panel
T	4007	Monitor	Monitor, low fuel pressure	Component	Instrument panel
W	4000	Warning lamp	Warning lamp, SCR tank level	Instrument panel	Instrument panel
W	4001	Warning lamp	Warning lamp, SCR fault code	Instrument panel	Instrument panel
W	4002	Control lamp	Control lamp, throttle out of order	Instrument panel	Instrument panel

FFU			Component Library	PRT-series		
No.	Type	Description	Harness	No. of poles:	System	
C 3000	Socket	Socket, 14 pole	VIS Trailer	14	FFU	
C 3001	Socket	Socket, 7 pole	Taillift	7	FFU	
D 3000	Diode	Diode, Parking brake alarme, COO6	Instrument panel		FFU	
D 3001	Diode	Diode, Parking brake alarme, INL (Interior light)	Instrument panel		FFU	
N 3000	Buzzer	Buzzer, Parking brake alarm	Instrument panel		FFU	
R 3000	Relay	Relay, Parking brake alarm, door information	Instrument panel		FFU	
R 3001	Relay	Relay, Parking brake alarm, p-brake information	Instrument panel		FFU	
R 3002	Relay	Relay, trailer axle lift	Instrument panel		FFU	
S 3000	Switch	Switch, reverse Alarm, Austria	Instrument panel	10	FFU	
S 3001	Switch	Switch, Tag axle lock	Instrument panel	10	FFU	
S 3002	Switch	Switch, Tag axle lift trailer	Instrument panel	8	FFU	
S 3003	Switch	Switch, Sliding fifth wheel	Instrument panel	7	FFU	
S 3004	Switch	Switch, Work light	Instrument panel	-	FFU	
S 3005	Switch	Switch, float front plough	Separate panel	10	FFU	
S 3006	Switch	Switch, float side plough	Separate panel	10	FFU	
S 3007	Switch	Joystick, plough front	Separate panel	8	FFU	
S 3008	Switch	Joystick, plough side	Separate panel	8	FFU	
S 3009	Switch	Load tipping	Instrument panel	10	FFU	
S 3010	Switch	Load tipping	Instrument panel	10	FFU	
S 3011	Switch	Flap release	Instrument panel	10	FFU	
S 3012	Switch	Switch, sprinkler	Instrument panel		FFU	
S 3013	Switch	Switch, vibrator	Instrument panel		FFU	