


YS2R6X400E9183544 / VIS, Visibility system / E 32, CUV control unit / CUV1 / L, Lamps / L139, Parking light and front right-hand direction indicator

C 1, Connector




From front, round sockets.Cable side, round sockets.From front, round pins.Cable side, round pins.





C 1, Connector



C 483, Connector

E 32, CUV control unit

The CUV control unit has three multipin connectors and a 2-pin connector for the voltage supply. It comprises a driver stage which functions as a fuse in the event of overloading. The control unit receives information from the visibility system switch and controls and from other systems via the CAN link. It interprets the information and activates the requested functions or sends messages via the CAN link to other control units.

The control unit has three multipin connectors (15-, 18- and 21-pin) and a 2-pin connector for the voltage supply. Connector CCon-

Pin	Description	Signal type	Source/Destination
A 1-2	Voltage supply for CUV	Input signal, +24 V	C55
B1	Horn	Output signal, +24 V	Horn
B2	Activate the reversing light relay	Output signal, +24 V	Relay R24
B3	Activate the brake light relay	Output signal, +24 V	Relay R8
B4	Main beam LH	Output signal, +24 V	Main beam LH
B5	Ground		G14
B6	Windscreen wipers, low speed	Output signal, +24 V	Wiper motor
B7	Dipped beam RH	Output signal, +24 V	Dipped beam on the right-hand side
B8	Wiper speed interval	Input signal, analogue	Direction indicator and wiper lever
B9	Not used		
B10	Windscreen washer	Output signal, +24 V	Windscreen washer
B11	Starter key is in the drive position	Input signal, +24 V	Starter lock
B12	CANL	CAN	
B13	Windscreen wipers, high speed	Output signal, +24 V	Wiper motor
B14	Not used		
B15	CANH	CAN	

ector D

Pin	Description	Signal type	Source/Destination
C1	Indicator lamp for hazard warning signal	Output signal, +24V	Lighting switch module S139
C2	Activate the horn	Input signal, ground	Signal switch in the steering wheel
C3	Activate the main beam flasher	Input signal, ground	Direction indicator and wiper lever
C4	Dipped beam LH	Output signal, +24V	Dipped beam on the left-hand side
C5	Activate the bumper-mounted spotlight	Input signal, ground	Extra lighting module S140
C6	Activate the sun visor-mounted spotlight	Input signal, ground	Extra lighting module S140
C7	Main beam RH	Output signal, +24V	Main beam on the right-hand side
C8	Ground	Ground	G14
C9	Activate work light	Input signal, ground	Extra lighting module S140
C10	Direction indicator front right	Output signal, +24V	Direction indicator front right
C11	Activate hazard warning signal	Input signal, ground	Lighting switch module S139
C12	Activate the parking lighting	Input signal, ground	Lighting switch module S139
C13	Direction indicator rear left	Output signal, +24V	Direction indicator rear left
C14	Lighting off/parking light	Input signal, ground	Lighting switch module S139
C15	Activate the direction indicator, RH side	Input signal, ground	Direction indicator and wiper lever
C16	Headlamp wipers	Output signal, +24V	Headlamp wiper Headlamp washer
C17	Switch for main/dipped beam	Input signal, ground	Direction indicator and wiper lever
C18	Activate the direction indicator, LH side	Input signal, ground	Direction indicator and wiper lever


Pin	Description	Signal type	Source/Destination
D1	Rear foglight	Output signal, +24V	Rear foglight

D2	Direction indicator, rear right on trailer	Output signal, +24V	Trailer socket
D3	Activate dipped beam/parking lights	Input signal, ground	Lighting switch module S139
D4	Direction indicator, rear left on trailer	Output signal, +24V	Trailer socket
D5	Activate the windscreen washer	Input signal, ground	Direction indicator and wiper lever
D6	High-mounted headlamps indication	Input signal, ground	Switch for e.g. snow plough lighting
D7	Sun visor-mounted spotlight	Output signal, +24V	Sun visor-mounted spotlights
D8	Activate front foglight	Input signal, ground	Front foglight
D9	Extra connection		
D10	Direction indicator rear right	Output signal, +24V	Direction indicator rear right
D11	Activate rear foglight	Input signal, ground	Extra lighting module S140
D12	Washer fluid level indication	Input signal, ground	Washer container
D13	Work light	Output signal, +24V	Work light
D14	Extra connection		
D15	Windscreen wiper end position	Input signal, ground	Wiper motor
D16	Direction indicator, front left	Output signal, +24V	Direction indicator, front left
D17	Activate the windscreen wiper, high or low speed	Input signal, analogue	Direction indicator and wiper lever
D18	Activate electrical equipment with high current consumption	Output signal, +24V	Relay 19
D19	Bumper-mounted spotlight	Output signal, +24V	Bumper-mounted spotlights
D20	Front foglight	Output signal, +24V	Front foglight
D21	Activate the parking light relay	Output signal, +24V	Relay 21

L 139, Parking light and front right-hand direction indicator

The unit comprises lamps for the direction indicators and position and side marker lamps.

- L8 - Position and side marker lamps
- L10 - Direction indicator




L 139, Parking light and front right-hand direction indicator

L 141, Front lamp, right-hand side


The components are built into one single lamp and are directly connected to the CUV control unit.

- L2 - Dipped beam
- L4 - Main beam



L 141, Front lamp, right-hand side

L 141, Front lamp, right-hand side



P 2, Central electric unit

Fuses: Warning! Always switch off the voltage when renewing fuses. Important! Always fit a fuse of the size specified in the list. Important! Always check the fuse and relay positions against the POW electrical diagram concerned. **Fuses for special functions:** Relays and con-

Fuse (No.)	Size (A)	System	Function	Supply	Cable colour	Connec- tion 1	Marking of cable 1	Cable cross- sectional area 1 (mm ²)	Connec- tion 2	Marking of cable 2	Cable cross- sectional area 2 (mm ²)
1	5	COO, BMS	Trailer ECU, ABS/EBS	15AA	Green	A-1	COO125	0.75	A-2	BMS212	0.75
2	30	COO	Trailer valves	15AB	Green	A-3	COO128	4	A-4		
3	5	COO	PT01, PT02	15AC	Green	A-5	COO251	0.75	A-6	COO253	0.75
4	2	MIA, VIS	Mirror adjustment, reverse alarm	15AD	Green	A-7	MIA15	0.75	A-8	VIS167	0.75
5	5	TCO, LDW, FLC	Tachograph, Lane departure warning	15AE	Green	A-9	TCO33	0.75	A-10	LDW12	1.5
6	20	WIW	Window winder, left-hand side	15AF	Green	A-11	WIW12	2.5	A-12	WIW10	2.5

trol units in the central electric unit:

7	10	VIS	Head-lamp wipers	15AG	Green	A-13	VIS16	1.5	A-14	VIS17	1.5
8	10	POW	Cigarette lighter	15AH	Green	A-15	POW45 +POW46	2.5	A-16	POW28	
9	5	FAS, COO	Interactor 200 (FAS)/ Communicator 100, cruise control	15AJ	Green	A-17	FAS14 +FAS15	1.5+1.5	A-18	COO130	0.75
10	5	CCS, INL	ACC/MCC, internal lighting Exclusive	15BA	Green	B-1	CCS3/ CCS2 +CCS4	0.75 +0.75 +0.75	B-2	INL12	0.75
11	10	RDL, AWD/ ABS	Differential locks, ABS 6 channels	15BB	Green	B-3	RDL26	1	B-4	AWD12/ BMS222	1.5
12	5	FHS	Fuel pre-heating, heater for fuel filter	15BC	Green	B-5	FHS9	1	B-6		
13	10	TAL	Tag axle lift	15BD	Green	B-7	TAL17 +TAL4	0.75 +0.75	B-8		1.5
14	5	CSS	Airbag	15BE	Green	B-9	CSS015	0.75	B-10		
15	20	WIW	Window winder, right-hand	15BF	Green	B-11	WIW18 +WIW20	2.5+2.5	B-12	WIW14 +WIW16	2.5+2.5
16	10	CAT	Electric cab tilting	15BG	Green	B-13			B-14	CAT	
17	20	BWS	Body-work	15BH	Green	B-15	BWS111	2.5	B-16	BWS207	1.5
18	5	SCS, POW	Safety belt buckle,	15BJ	Green	B-17	SCS015	0.75	B-18	POW227	01

			safety switch ADR								
19	20	COO	Coor- dinator	30A	Red	C-1	COO58	2.5	C-2		
20	20	EMS	EDC	30B	Red	C-3	COO68	2.5	C-4		
21	10	COO	Starter lock	30C	Red	C-5	COO73	0.75	C-6		
22	20	EMS	EDC	30D	Red	C-7	COO67	2.5	C-8		
23	10	VIS	Brake lamp	30E	Red	C-9	VIS275	1.5	C-10		
24	20	BMS	ABS/EBS	30F	Red	C-11	BMS44	2.5	C-12	BMS45	2.5
25	10	SMS	ELC	30G	Red	C-13	SMS4	1.5	C-14	SMS5	1.5
26	20	CCS	Cab fan	30H	Red	C-15	CCS1	2.5	C-16		
27	5	CCS, AHS	CT/CTR	30J	Red	C-17	CCS5	0.75	C-18	AHS3	0.75
28	20	ROH	Roof hatch	30K	Red	C-19	ROH1	2.5	C-20		
29	10	ICL, TCO	Instru- ment cluster, tachog- raph	30L	Red	C-21	ICL18	1.5	C-22	TCO13	1.5
30	30	BWS	Body- work	30M	Red	C-23	BWS		C-24	BWS	
31	10	AWD, INL	AWD ECU, internal lighting	30N	Red	C-25	AWD5	1.5	C-26	INL5 +INL4 +INL1	1.5+1 +1.5
32	10	COO	SDP3	30R	Red	D-1	COO83	0.75	D-2		
33	10	HVF, VIS	Swiss road toll prepa- ration, rotating beacon	30S	Red	D-3	HVF5	1.5	D-4	VIS172	1.5
34	20	POW	Voltage con- verter 24 V/12 V, 12 V elec-	30T	Red	D-5	POW34	2.5	D-6		

			trical socket								
35	10	TGS, BWS	Trailer	30U	Red	D-7	TGS	1.5	D-8	BWS216	1.5
36	20	GMS	OPC/GA Allison	30V	Red	D-9	GMS1/ GMS136 2 +GMS1 363	2.5/1.5 +1.5			
37	10	LAS	Central locking	30X	Red	D-11	LAS101 +LAS20 1/MCL1	1.5+1.5	D-12	LAS1/ MCL2	1.0/1.5
38	20	AHS	Auxiliary heater (ATA, WTA)	30Y	Red	D-13	AHS1		D-14		1.5
39	10	VIS	Re- versing light	30Z	Red	D-15	VIS276	1.5	D-16		1.5
40	20	POW	24 V elec- trical socket	30AA	Red	D-17	POW24 +POW3 9	2.5+2.5	D-18	POW41	2.5
41	10	APS, FMS	APS ECU, FMS prepa- ration	30AB	Red	D-19	APS9	1.5	D-20	RTG3	1.5
42	30	CAT	Electric cab tilt- ing	30AC	Red	D-21	CAT		D-22		
43	10	REF, FAS	Refri- gerator, Inter- ractor 200/ Commu- nicator 100 (FAS/ RTI)	30AD	Red	D-23	REF	1.5	D-24	FAS	1.5+1.5
44	10	AUS	Am- plifier	30AE	Red	D-25	AUS42	1.5	D-26	AUS44	2.5
45	10	MIH, ACL	Rear view mirror heater, ACL	61A	Blue	E-1	MIH61	1.5	E-2	ACL1	1

46	10	SCS, ALT	Seat heating, Alert	61B	Blue	E-3	SCS61 +SCS26 1	1.5	E-4	ALT30	
47	10	APS, FHS	Air dryer, fuel filter heater	61C	Orange	E-5	APS47	1.5	E-6	FHS13	1.5
48	10	BWS	Body-work	61D		E-7	BWS		E-8	BWS	
49	-	-	-	-	-	-	-	-	-	-	-
50	5	COO	Alert yellow & green bus	X15	white	E-11	COO70	0.75	E-12		
51	-	-	-	-	-	-	-	-	-	-	-
52	2	LAS	Alarm	B	Brown	E-15	LAS40	0.75	E-16	INL	0.75
53	2	INL, ROH	INL Exclusive, warning of open roof hatch	B	Violet, grey	E-17	INL13	0.75	E-18	ROH050	0.75
54	10	VIS	Parking light, left-hand side	58A	Grey	F-1	VIS18 +VIS205	1.5+1.5	F-2	VIS19 +VIS20	1.5+1.5
55	10	VIS	Parking light, right-hand side	58B	Orange	F-3	VIS22 +VIS21	1.5+1.5	F-4	VIS24 +VIS23	1.5+1.5
56	5	INL, VIS	Back-ground lighting, levelling adjustment for head-lamps	58C	Blue	F-5	INL14	0.75	F-6	VIS	0.75
57	20	BWS	Body-work	58D		F-7	BWS		F-8	BWS	
58	10	VIS	Trailer, left-hand	58E	Grey	F-9	VIS203	1.5	F-10		

			side									
59	10	VIS	Trailer, right-hand side	58F	Brown	F-11	VIS204	1.5	F-12			
60	-	-	-	-	-	-	-	-	-	-	-	-
61	2	BWS	Body-work	RA		F-15	BWS		F-16	BWS		
62	2	POW	Voltage converter 24 V/12 V	RA	Violet	F-17	POW31	0.75	F-18			
63	10	DAU, FLC	Driver alert unit, Forward looking camera	30AR		A-19	DAU1	1.5	A-20			
64	5	SMS	Electric power supply	30AS	Red	A-21	SMS200		A-22			
65	20	COO	Variable geometry turbo-charger	30AT	Red	A-23	COO710	2.5	A-24			
66	10	TPM	Electric power supply, TPM control unit	30AU	Red	A-25	TPM1	1.5	A-26			
67	30	KIT, CAT	Kitchen module, cab tilt system	30AF	Red	B-19	KIT530/532 KIT536	4.0	B-20	CAT8	4.0	
68	10	KIT	Electric power supply	30AG	Red	B-21	KIT835	1.5	B-22	KIT830	1.5	
69	20	ATL	Trailer axle lock	30AH	Red	B-23	ATL9	2.5	B-24			
70	10	DIS2	Distance sensor	30AJ	Red	B-25	DIS51	1.0	B-26			


71	20	FHS, FCS	Fuel heater, fuel cooler system	30AK	Red	E-19	FHS15	2.5	E-20	FCS23	
72	10	THR	Electric throttle	30AL	Red	E-21	COO8	2.5	E-22		
73	20	FHS, FCS	Fuel heater, fuel cooler system	30AM	Red	E-23	FHS4	2.5	E-24	FCS24	
74	20	VIS	Head-lamp cleaning	30AN	Green	E-25	VIS16	2.5	E-26		
75			Re-served for future system			F-19			F-20		
76			Re-served for future system			F-21			F-22		
77			Re-served for future system			F-23			F-24		
78			Re-served for future system			F-25			F-26		

Fuse (No.)	Size (A)	System	Function	Supply	Cable colour	Connection	Marking of cable	Cable cross-sectional area
F5	30	KIT	Kitchen equipment	30	Red	F5-6	KIT	4
F5	10	KIT	Kitchen equipment	30	Red	F5-8	KIT	1.5
F9	20	FHS	Heater fuel filter	30	Red	F9-2	FHS4	2.5

F14	20	WIW	Window winder, rear left (crew cab)	30	Green	F14-2	WIW1004 +WIW1005	2.5
F14	20	WIW	Window winder, rear right (crew cab)	30	Green	F14-4	WIW1006 +WIW1007	2.5
F14	10	FST	Footstep (crew cab)	30	White	F14-6	FST1004	1
F14	10	FST, POW	Footstep (crew cab)	30	Yellow, green	F14-8	FST1022, POW1002	1, 1.5

Position	System	Function
1	POW	15 voltage
2	POW	15 voltage
3	POW	controlled by VIS
4	POW	58 supply, controlled by VIS
5	INL	Internal lighting
6	TAL	Tag axle lift
7	VIS	Brake lamp
8	VIS	Reversing light
9	COO	Resistor unit for vehicles with cruise control without buttons for this on steering wheel
10	FMS	ECU for FMS preparation
11	FMS	ECU for FMS preparation
12	CCS	A/C relay (crew cab)
13	POW	Safety switch
18	POW	Extra 15 supply relay for S vehicles
19	CAT	Relay for electronic cab tilting
20	TGL, KIT	Tail lift and kitchen equipment

23	VIS	Auxiliary light
24	VIS	Auxiliary light
25	VIS	Auxiliary light



P 2, Central electric unit