

COLUMN LOAD COMBOS

Vertical loads only – columns

By hand: 423.23 wind EW, 389.34 NS

(+) south to north winds (experiencing compression), (-) west to east winds (experiencing tension) [superposition]

[illegible]