

ROS interface for mobile robots (external)

Based on customer requirements and to facilitate education and research customers to integrate our chassis, our company provides the internal ROS interface and calling method of the chassis.

Note: The ROS interface is designed for internal use by our company. Its interface path, data structure, calling method, behavior, etc. may change with the changes in the chassis internal software. When you plan to upgrade the chassis software, please confirm the changes in the internal interface you are using with our company and modify your program in time according to the changes.

Note: Some ROS interfaces bypass the chassis' safety protection function. Improper use may threaten personal and property safety. Please ensure safety monitoring. If necessary, please consult our company.

You can connect to the chassis' ROS interface through the debug Ethernet interface or WiFi. For stability considerations, we recommend that you use the debug Ethernet interface to call the chassis' ROS interface.

Table of contents

1 ROS version2

Connecting to the chassis through the debugging Ethernet

interface2.1 IP address

configuration2.2 Environment

variable configuration2.2.1

Temporary validity2.2.2

Permanent validity2.3 Common (ROS) interface

description2.4 Subscribe to data

(topic)2.4.1 Get robot status2.4.2 Get robot positioning information2.4.3 Odometer information2.4.4 Power information2.4.5 Get robot positioning information2.4.6 Lower computer information2.4.7 Battery BMS information2.4.8 Lower computer parameter information2.4.9 Speed information2.4.10 Status code2.4.11 Speed control2.4.12 Light strip color control2.4.13 LiDAR data

2.4.14 IMU data acquisition2.4.15 ODOM data acquisition2.4.16 RGB camera data acquisition2.4.17 Camera depth image data acquisition2.4.18 Camera 3D point cloud data acquisition2.4.19 Stereo obstacle avoidance 3D point cloud data acquisition2.4.20 Stereo obstacle avoidance 3D point cloud data acquisition

2.4.21 Modify the local (local_costmap) model (footprint) of the robot 2.4.22 Modify the global (global_costmap) model (footprint) of the robot 2.4.22.1 Calling example 2.5 Service communication interface Services 2.5.1

Task execution 2.5.2 Start/stop positioning module

2.5.3 Start/stop costmap update 2.5.4

Get map data 2.5.5 Change map 2.5.6 Plan global path 2.5.7 Clear obstacles

2.6 Action API

2.6.1 Navigation target point

2.6.2 High-precision speed combination control (applicable to pure motion control high-precision walking) 2.6.3 Navigation mode switching

ROS version

Currently, the ROS version used by the chassis is ROS noetic and the operating system is Ubuntu 20.04. It is recommended that you use the same ROS version and operating system version. In the following text, we assume that you are also using Ubuntu 20.04.

Connect to chassis via debug Ethernet interface

IP address configuration

First, you need to connect your computer's wired Ethernet interface to the chassis' debug Ethernet interface. You can refer to the user manual to complete this operation.

You will then need to configure a static IP address for your computer. The IP address is between 169.254.128.20-169.254.128.49, and the subnet mask is 255.255.255.0.

After the IP address configuration is complete, you can use the ping tool to verify whether the network configuration is effective. Open Terminal on your computer and enter ping 169.254.128.2. If it returns 64 bytes from 169.254.128.2: icmp_seq=1 ttl=64 time=0.203 ms or other similar information, the IP address configuration is successful.

Environment variable configuration

Temporary validity


Specify ROS_MASTER_URI and ROS_IP in Terminal. Here we assume your IP address is 169.254.128.20

Enter in Terminal (valid for the current Terminal)

```
export ROS_MASTER_URI=http://169.254.128.2:11311
```

```
export ROS_IP=169.254.128.20
```

At this point, all ROS programs running in the current terminal will use 169.254.128.2 as the ROS master node. As shown in the following figure:



A terminal window titled 'woosh@R20230114101752: ~' with standard window controls. The terminal shows the following commands and output:

```
woosh@R20230114101752:~$ export ROS_MASTER_URI=http://169.254.128.2:11311
woosh@R20230114101752:~$ export ROS_IP=169.254.128.20
woosh@R20230114101752:~$ rostopic list | head
/IO_input
/IO_module_control
/IO_output
/alley_adjust
/altenative_plan
/amcl_pose
/ar_tag_list
/avoid_3d_trigger
/back_pavo2/parameter_descriptions
/back_pavo2/parameter_updates
woosh@R20230114101752:~$
```

Permanent

Add the following to the end of .bashrc: (assuming your IP address is 169.254.128.20)

```
export ROS_MASTER_URI=http://169.254.128.2:11311
```

```
export ROS_IP=169.254.128.20
```

Common (ROS) interface description

Subscribe to data (topic)

Get robot status

Function description: Get the robot's current task status information, and publish it only when there is a change

Interface name (topic): robot_status

Message type: woosh_msgs/RobotStatus

Specific parameter description:

| Parameter name | type | meaning | whether Required | about bundle |
|----------------|--------|---|------------------|--------------|
| task_id | uint64 | Task ID | yes | |
| task_type | int32 | #Task type, 0: undefined, 1: picking, 2: parking, 3: charging, 4: transporting | yes | |
| task_state | int8 | #Task status, 0: undefined, 3: executing, 4: paused, 5: waiting for action, 7: completed 8: Cancelled, 9: Failed | yes | |
| action_type | int8 | #Action type 0: undefined, 1: navigation, 2: single-step control, 3: secondary positioning entry, 4: secondary Positioning exit, 5: transport action, 6: waiting, 7: charging | yes | |
| action_state | int8 | #Action status 0: Undefined, 1: Executing, 2: Warning, 3: Cancel, 4: Completed, 5: Failed Defeat, 10: Suspension, 11: Control | yes | |
| robot_state | int8 | Robot status 0: Undefined, 1: Uninitialized, 2: Idle, 3: Parking, 4: On a mission, 5: Warning, 6: Abnormal, 8: Charging, 9: Composition | yes | |
| robot_mode | int8 | Robot mode 0: Undefined, 1: Automatic, 2: Manual, 3: Maintenance | yes | |
| work_mode | int8 | #Robot working mode 0: undefined, 1: deployment mode, 2: task mode, 3: scheduling mode | | |
| wait_id | int32 | #Action waiting ID | | |
| dest | string | #target point | | |
| msg | string | #message | | |
| time | int32 | #Last updated time (s) | | |

Robot positioning information acquisition

Function description: Publish plane coordinate information

Interface name (topic): movebase_pose2d

Message type: geometry_msgs/Pose2D

Specific parameter description:

| Parameter | name type | meaning | Is the constraint | required? |
|-----------|-----------|--|-------------------|-----------|
| x | float64 | The x-axis coordinate of the Cartesian coordinate system | yes | |
| y | float64 | The y-axis coordinate of the Cartesian coordinate system | yes | |
| theta | float64 | Cartesian coordinate system z-axis coordinate | yes | |

Odometer information

Function description: Publish machine odometer information

Interface name: odometer

Message type: std_msgs/Float64

Specific parameter description:

| Parameter | name type | meaning | Is the constraint | required? |
|-----------|-----------|------------------------|-------------------|-----------|
| data | float64 | Odometer (unit: meter) | Yes | |

Power Information

Function description: Publish the robot's power information

Interface name: /battery

Message type: woosh_msgs/Battery

Specific parameter description:

| parameter name | type | Meaning | Is it required? | constraint |
|-------------------|------------------------------|---------------|-----------------|--|
| parameter name | type | Meaning | Is it required? | constraint |
| header | Header | | yes | |
| submodule | uint8 submodule | | yes | |
| batteryPercentage | uint8 The battery power | percentage is | | |
| chargeMode | uint8 Charging mode | | yes | 0 (default) - Manual charging 1- Automatic charging |
| chargeStatus | uint8 Charging status | | yes | 0 - Not charging 1-Charging |
| batteryVoltage | float32 battery voltage | | yes | |
| batteryCurrent | float32 battery current | | yes | |
| timeRemain | float32 remaining time | | yes | |
| tempMax | int8 maximum temperature | | yes | |
| tempMin | int8 minimum temperature | | yes | |
| capacityRemain | float32 remaining capacity | | yes | |
| capacityFull | float32 full capacity | | yes | |
| capacityDesign | float32 design capacity | | yes | |
| chargeCycle | uint16 number of loops | | yes | |
| batteryCycle | uint16 Battery life | | yes | |
| bmsStatus | uint32 bms status | | no | |
| cellVoltageMax | float32 maximum cell voltage | | no | |
| cellVoltageMin | float32 minimum cell voltage | | no | |

Robot positioning information acquisition

Function description: Subscribe to robot SLAM positioning coordinate information.

Interface name (topic): /amcl_pose

Message type: geometry_msgs/PoseWithCovarianceStamped

Lower computer information

Function description: Publish the version and parameter information of the lower computer

Interface name: /information

Message type: woosh_msgs/Information

Specific parameter description:

| parameter name | type | Meaning Is the constraint required? | | |
|---------------------------|---|-------------------------------------|-----|--|
| header | std_msgs/Header | Frame Header | yes | |
| hardwareVersion | string | The hardware version number | yes | |
| softwareVersion | string | The software version number | yes | |
| IAPSoftwareVersion string | | The IAP software version number | yes | |
| movebaseType | string | Chassis type | yes | |
| parameter | woosh_msgs/Parameter Chassis parameters are | | yes | |

Battery BMS information

Function description: Release battery BMS information

Interface name: /driver_base/bms

Message type: woosh_msgs/BMS

Specific parameter description:

| parameter name | type | Meaning Is the constraint required? | | |
|-------------------------|-----------------|-------------------------------------|-----|--|
| header | std_msgs/Header | frame header | yes | |
| BMSStatus | uint32 | BMS Status | No | |
| current | float32 | Current | yes | |
| voltageMax | float32 | Maximum cell voltage | No | |
| voltageMin | float32 | Minimum cell voltage | No | |
| voltageTotal | float32 | The total battery voltage | yes | |
| temperatureMax float32 | | The maximum temperature is | yes | |
| temperatureMin float32 | | Minimum temperature | No | |
| chargeCycle | uint16 | The number of cycles | yes | |
| capacityResidue float32 | | The remaining capacity | yes | |
| capacityTotal | float32 | total capacity | yes | |
| switchStatus | uint8 | Switch Status | No | |

Lower computer parameter information

Function description: Publish the lower machine parameter information

Interface name: /driver_base/parameter

Message type: woosh_msgs/Parameter

Specific parameter description:

| parameter name | type | meaning | Is the constraint required? | |
|--------------------|-----------------|---|-----------------------------|--|
| header | std_msgs/Header | frame header | yes | |
| wheelPerimeter | float32 | Wheel circumference | yes | |
| wheelDistant | float32 | Wheel spacing | yes | |
| ratioLeft | float32 | Left motor reduction ratio | yes | |
| ratioRight | float32 | Right motor reduction ratio | yes | |
| pulsePerCircle | float32 | Number of pulses per revolution | yes | |
| maxRPM | float32 | Revolutions per minute | yes | |
| minSpeed | float32 | Minimum speed | yes | |
| maxSpeed | float32 | Maximum speed | yes | |
| maxLinear | float32 | Speed control maximum line speed | yes | |
| maxAngular | float32 | The maximum angular velocity of speed control | yes | |
| joystickMaxLinear | float32 | The maximum linear speed of the joystick | yes | |
| joystickMaxAngular | float32 | The maximum angular velocity of the joystick | yes | |

Speed information

Function description: Publish the robot's speed information

Interface name: odom_twist

Message type: geometry_msgs/Twist

Specific parameter description:

| parameter name | type | Meaning | Is the constraint required? | |
|----------------|-----------------------|-------------------------|-----------------------------|--|
| linear | geometry_msgs/Vector3 | Linear velocity is | yes | |
| angular | geometry_msgs/Vector3 | The angular velocity is | yes | |

status code

Function description: Publish the status code of the robot

Interface name: status_code

Message type: std_msgs/UInt64

Specific parameter description:

| Parameter name | type | meaning | is it required? | constraint |
|----------------|------------|----------------|-----------------|---|
| data | The uint64 | exception code | is | See Robot Status Code and Exception Handling Mechanism for details. |

speed control

Note: Speed control will bypass the chassis' obstacle avoidance, collision detection, speed limit, state limit and other safety functions. Please make sure before calling Make sure that the area around the robot is clear and that someone is watching over it. The caregiver needs to closely monitor the robot while ensuring their own safety. status, and intervene immediately when necessary to stop the robot's movement.

Function description: Subscription speed control instructions (without smoothing)

Interface name: /base_cmd_vel

Message type: geometry_msgs/Twist

Specific parameter description:

| parameter name | type | Meaning | Is the constraint | required? |
|----------------|-----------------------|----------------------|-------------------|-----------|
| linear | geometry_msgs/Vector3 | Linear velocity | is | |
| angular | geometry_msgs/Vector3 | The angular velocity | is | |

Function description: Subscribed speed control instructions (with deceleration smoothing processing)

Interface name: /smooth_cmd_vel

Message type: geometry_msgs/Twist

Specific parameter description:

| parameter name | type | Meaning | Is the constraint | required? |
|----------------|-----------------------|----------------------|-------------------|-----------|
| linear | geometry_msgs/Vector3 | Linear velocity | is yes | |
| angular | geometry_msgs/Vector3 | The angular velocity | is yes | |

Light strip color control

Function description: Subscribed light strip color control instructions

Interface name: rgbled, rgbled_shelf

Message type: woosh_msgs/LED

Specific parameter description:

| Parameter name | type | meaning | is it required? | constraint |
|----------------|--------|--------------------|-----------------|---|
| Parameter name | type | meaning | is it required? | constraint |
| submodule | uint8 | submodule | no | 0-Select All 1~8-Module 1~8 |
| urgency | uint8 | Maintenance status | No | 0x00-Not selected 0xFF-Maintenance |
| abnormal | uint8 | Fault status | No | 0x00-Not selected 0xFF - Failure |
| normal | uint8 | Normal status | no | 0x00-Not selected 0x42 - Low Battery 0x60-Follow 0x80 - Forward 0x81-Turn right 0x82 - Turn Left 0x83 - Boot from Standstill 0x84-Stop waiting 0x85-Traffic control is suspended 0xA0 - Warning 0xA1-Task Execution 0xA2-Task Pause 0xA3 - Idle 0xA4-Initialization 0xA5-Offline 0xF0-Picking task execution (Guanbang) 0xF1-Picking task completed (Guanbang) 0xFF - Normal |
| color | uint32 | 24-bit true color | no | |

Lidar data

Function description: Subscribe to lidar data (data after fusion of multiple lidars) for indoor positioning and information fusion.

Interface name (topic): /scan

Message type: sensor_msgs::LaserScan

IMU data acquisition

Function description: Subscribe to the raw data of IMU for indoor positioning and information fusion.

Interface name (topic): /imu/data_raw

Message type: sensor_msgs/Imu

odom data acquisition

Function description: Subscribe to odom's posture information, raw data (without IMU fusion), for indoor positioning and information fusion.

Interface name (topic): /odom_raw

Message Type: nav_msgs/Odometry

Function description: Subscribe to odom's raw data (fused with IMU) for indoor positioning and information fusion.

Interface name (topic): /odom

Message Type: nav_msgs/Odometry

Specific parameter description:

| parameter name | type | Meaning | Is the constraint required? | |
|-----------------------|-----------------------------------|---------------------|-----------------------------|--|
| header | std_msgs/Header | The frame header is | yes | |
| child_frame_id string | | | yes | |
| pose | geometry_msgs/PoseWithCovariance | coordinates | yes | |
| twist | geometry_msgs/TwistWithCovariance | speed | yes | |

RGB camera data acquisition

Function description: Subscribe to the raw data of the RGB camera

Interface name (topic): /camera_1/color/image_raw

Message type: sensor_msgs/Image

Camera depth image data acquisition

Function description: Subscribe to the raw data of the camera depth image

Interface name (topic): /camera_1/depth/image_raw

Message type: sensor_msgs/Image

Camera 3D point cloud data acquisition

Function description: Subscribe to the raw data of the camera depth image

Interface name (topic): /camera_1/depth/points

Message type: sensor_msgs/PointCloud2

Obstacle avoidance 3D point cloud data acquisition

Function description: Subscribe to camera stereo obstacle point cloud data (remove ground point cloud information)

Interface name (topic): /camera_1/depth/cloud_without_planes

Message type: sensor_msgs/PointCloud2

Obstacle avoidance 3D point cloud data acquisition

Function description: Subscribe to camera stereo obstacle point cloud data (remove ground point cloud information)

Interface name (topic): /camera_1/depth/cloud_without_planes

Message type: sensor_msgs/PointCloud2

Modify the local (local_costmap) model (footprint) of the robot

Function description: Set the size of the local footprint. Support changing the size and shape of the vehicle's footprint under the local costmap during navigation. This change will cause the local_costmap to change (expand or shrink).

This affects the effect of the car's local path planning. It is recommended to modify both the global and local models at the same time.

Interface name: /move_base/local_costmap/set_footprint

Message type: geometry_msgs::Polygon

Specific parameter description:

| parameter name | type | meaning | Is the constraint | required? |
|--------------------------------|----------------------------|--|-------------------|-----------|
| points geometry_msgs/Point32[] | The polygon connected from | the first point to the last point, that is, the footprint is | yes | |

Modify the robot's global (global_costmap) model (footprint)

Function description: Set the size of the global footprint. Support changing the size and shape of the car's footprint under the global costmap during navigation. This change will affect the global_costmap as well (expand or shrink).

This affects the effect of the car's global path planning. It is recommended to modify both the global and local models at the same time.

Interface name: /move_base/global_costmap/set_footprint

Message type: geometry_msgs::Polygon

Specific parameter description:

| parameter name | type | meaning | Is the constraint required? | |
|----------------|-------------------------|---|-----------------------------|--|
| points | geometry_msgs/Point32[] | The polygon connected from the first point to the last point, that is, the footprint is | yes | |

Calling Example

For example, the model size of footprint is as follows:

Footprint: [[-0.400, 0.253], [-0.353, 0.3], [0.353, 0.3], [0.4, 0.253], [0.4, -0.253], [0.353, -0.3], [-0.353, -0.3], [-0.4, -0.253]]

footprint_padding: 0.1 expansion 0.1

```

1  #include <ros/ros.h>
2  #include <geometry_msgs/Polygon.h>
3  #include <geometry_msgs/Point.h>
4
5  int main(int argc, char** argv)
6  {
7      ros::init(argc,argv,"test_set_footprint_node");
8      ros::NodeHandle nh;
9
10     ros::Publisher local_footprint_pub,global_footprint_pub;
11     local_footprint_pub = nh.advertise< geometry_msgs::Polygon > ("/move_base/
local_costmap/set_footprint", 1);
12     global_footprint_pub = nh.advertise< geometry_msgs::Polygon > ("/move_base/
global_costmap/set_footprint", 1);
13
14     //The polygon formed by connecting 8 points is the model of the car
15
16     std::vector< geometry_msgs::Point32 > pts;
17
18     geometry_msgs::Point32 point32;
19
20     point32.x = -0.400;
21
22     point32.y = 0.253;
23
24     point32.z = 0.0;
25     pts.push_back(point32); //Starting point
26
27     point32.x = -0.353;
28
29     point32.y = 0.3;
30
31     point32.z = 0.0;
32     pts.push_back(point32); //The second point
33
34     point32.x = 0.353;
35
36     point32.y = 0.3;
37
38     point32.z = 0.0;
39     pts.push_back(point32); //The third point
40
41     point32.x = 0.400;
42
43     point32.y = 0.253;
44
45     point32.z = 0.0;
46     pts.push_back(point32); //The fourth point
47
48     point32.x = 0.400;
49
50     point32.y = -0.253;
51
52     point32.z = 0.0;

```

```

36     pts.push_back(point32); //The fifth point
37     point32.x = 0.353;
38     point32.y = -0.3;
39     point32.z = 0.0;
40     pts.push_back(point32); //The sixth point
41     point32.x = -0.353;
42     point32.y = -0.3;
43     point32.z = 0.0;
44     pts.push_back(point32); //The seventh point
45     point32.x = -0.4;
46     point32.y = -0.253;
47     point32.z = 0.0;
48     pts.push_back(point32); //The eighth point
49
50     sleep(1);
51     // Connect into polygons, i.e. footprint
52     geometry_msgs::Polygon polygon;
53     for (int i = 0; i < pts.size(); i++)
54     {
55         polygon.points.push_back(pts[i]);
56     }
57     //Modify the local footprint
58     local_footprint_pub.publish(polygon);
59     //Modify the global footprint
60     global_footprint_pub.publish(polygon);
61     while(ros::ok())
62     {
63     }
64     return 0;
}

```

Service Communication Interface

Task Execution

Functional description: Execute task interface

Interface name: exec_task

Request message type: woosh_msgs::ExecTask

Request specific parameter description:

| parameter name | type | meaning | whether Required | about bundle |
|----------------|-----------------------------|---|---------------------|-----------------|
| task_exect | uint8 | #Task execution request, 1: execute, 2: pause, 3: continue, 4: Cancel, 6: Wait for interruption | yes | |
| task_id | int64 | #Task ID | yes | |
| task_type | uint8 | #Task type, 1: Picking 2: Parking 3: Charging 4: Transporting | | |
| direction | uint8 | #Action direction, 0: Undefined 1: Loading 2: Unloading, not loading Fill in 0 for the material cutting task, optional | yes | |
| task_type_no | uint32 | #Type combination, default 0, custom, optional | yes | |
| mark_no | string | #Target point (storage location) number. If you fill in the number, the task route The last item of the task path can be left blank. points, must be consistent with this storage point | | |
| poses | geometry_msgs/PoseStamped[] | #Task path, if it is a point (target point), it means The system plans by itself and reaches this target point eventually. Optional | | |
| custom | byte | # Custom fields, vary by project, optional | | |

Response parameter description:

| Parameter name | type | meaning | Is it necessary fill | constraint |
|----------------|--------|----------------------------------|-------------------------|---|
| success | bool | Responding to a request state | yes | true - indicates the request was successful false - indicates the request failed |
| message | string | Comment Response information | no | |
| statuscode | uint64 | #status is | yes | 1: Uninitialized, 2: Idle, 3: Parking, 4: Tasking, 5: Warning, 6: Abnormal, 8: Charging, 9: Composing |

Start/stop positioning module

Function description: Enable positioning function

Interface name: /start_localization

Request message type: std_srvs::SetBool

Request specific parameter description:

| Parameter name | type | meaning | Required? | constraint |
|----------------|------|-------------------------------|-----------|--|
| data | bool | Start/stop positioning module | yes | true-indicates starting the positioning module false-indicates closing the positioning module |

Response parameter description:

| Parameter name | type | meaning | is it required? | constraint |
|----------------|--------|--------------------------------|-----------------|---|
| success | bool | The response request status is | yes | true - indicates the request was successful false - indicates the request failed |
| message | string | Remarks response information | no | |

Start/stop costmap update

Function description: Enable cost map data update function

Interface name: /move_base/enable_costmaps

Request message type: std_srvs::SetBool

Request specific parameter description:

| parameter name | type | meaning | Required? | constraint |
|----------------|------|--------------------------------|-----------|--|
| data | bool | Start/stop costmap data update | yes | true-indicates starting the costmap update, which can update the obstacle data to the costmap false-indicates turning off costmap updates and not updating obstacle data to the costmap |

Response parameter description:

| Parameter name | type | meaning | is it required? | constraint |
|----------------|--------|--------------------------------|-----------------|---|
| success | bool | The response request status is | yes | true - indicates the request was successful false - indicates the request failed |
| message | string | Remarks response information | no | |

Get map data

Function description: Request current map data information from map_server

Interface name: aic_map_server/get_map

Message Type: nav_msgs::GetMap

Response parameter description:

| parameter name | type | meaning | Is the constraint | required? |
|----------------|------------------------|--|-------------------|-----------|
| map | nav_msgs/OccupancyGrid | The map data information obtained by the client is | | |

Change Map

Function description: Replace the map data information sent

Interface name: set_map

Message type: nav_msgs::SetMap

Request specific parameter description:

| parameter name | type | meaning | Required? | constraint |
|----------------|---|--|-----------|--|
| map | nav_msgs/OccupancyGrid | Map data information sent by the client | yes | |
| initial_pose | geometry_msgs/PoseWithCovarianceStamped | The position information of the robot's initial point (current point) sent by the client | yes | If it is the initialization point, the general robot posture is (0,0,0) If it is a multi-map navigation, the value is the current robot's position information relative to this map |

Response parameter description:

| Parameter name | type | meaning | is it required? | constraint |
|----------------|------|--------------------------------|-----------------|--|
| success | bool | The response request status is | | true - indicates that the request was successful. false - indicates that the request failed |

Planning the global path

Function description: Request global path planning information

Interface name: /move_base/make_plan

Request message type: nav_msgs/GetPlan

Specific parameter description:

| parameter name | type | meaning | whether Required | constraint |
|-------------------|---------------------------|--|------------------|--|
| start | geometry_msgs/PoseStamped | The starting point of the path | yes | |
| goal | geometry_msgs/PoseStamped | The target point of the path | yes | |
| tolerance float32 | | The offset of the target point. When the target point is blocked, It is possible to allow deviation to avoid path planning failure | no | Note: Do not deviate too much More will lead to greater errors |

Response message type: nav_msgs/Path

Specific parameter description:

| parameter name | type | meaning | Is the constraint | required? |
|-----------------------------------|------|--|-------------------|-----------|
| header std_msgs/Header | | Contains timestamp and coordinate system information | | |
| poses geometry_msgs/PoseStamped[] | | The path coordinate information of the navigation to the target point is | | |

Clear obstacles

Function description: Request global path planning information

Interface name: /move_base/clear_costmaps

Request message type: std_srvs::Empty

Request specific parameter description:

| Parameter name | type | meaning | whether it is required | constraint |
|----------------|------|---------|------------------------|------------|
| none | | | | |

Response parameter description:

| Parameter name | type | meaning | whether it is required | constraint |
|----------------|------|---------|------------------------|------------|
| none | | | | |

Action API

Navigation target point

Function description: Send the target point or path to be navigated

Interface name: /move_base/goal

Message type: woosh_msgs/MoveBaseActionGoal

Specific parameter description:

| parameter name | type | meaning | whether Required | constraint |
|---------------------------------------|-----------------------------|---|---------------------|---|
| poses | geometry_msgs/PoseStamped[] | Navigate to the destination <small>Radius coordinate information</small> | no | |
| target_pose geometry_msgs/PoseStamped | | Navigate to the target point <small>Label Information</small> | yes | Regardless of whether the path is sent, this parameter target_pose is required |

High-precision speed combination control (suitable for pure motion control and high-precision walking)

Function description: Subscribed speed control instructions (with deceleration smoothing processing)

Interface name: /cmd_vel_control

Message type: woosh_msgs::StepControlGoal

Specific parameter description:

| parameter name | type | meaning | Is it necessary fill | constraint |
|---|-------|---|-------------------------|---|
| parameter name | type | meaning | Is it necessary fill | constraint |
| mode | uint8 | execution succeed Logo | yes | CANCEL EXCUTE - Execute PAUSE RESUM - Continue Note: In the case of multiple actions combined, you need to resend after pausing. The remaining action combinations |
| useAvoid | bool | Is obstacle avoidance | yes | false - no obstacle avoidance true-obstacle avoidance |
| StepControl[] StepControl step combination is | | | yes | |
| Result | bool | The execution result is | yes | |
| feedback | int8 | The execution status is | yes | |
| percent | float | Completion percentage <small>Compare</small> | No Unit: % | |

StepControl Parameters

| | | | | |
|-------------------------------------|--|--|--|-----------------------------|
| executeMode uint8 Execution mode is | | | | STRAIGHT-Go straight ROTATE |
| data | The float32 execution data is the maximum straight distance of 10m and the maximum rotation radius of 62.8318rad | | | |
| speed | float32 Maximum speed No Default linear speed 0.2m/s, angular speed 0.1rad/s | | | |

Navigation mode switch

Function description: Switching of navigation mode, that is, making corresponding navigation motion strategies according to the sent mode or maximum running speed

Interface name: /navigation_mode/goal

Message type: woosh_msgs::NavigationModeGoal

Specific parameter description:

| parameter name | type | meaning | whether Required | constraint |
|-----------------|---------|---|------------------|--|
| navigation_mode | uint8 | Navigation mode | yes | 0- indicates fuzzy avoidance navigation mode 1- indicates precise avoidance navigation mode 2- Indicates stop and wait navigation mode 3- Waiting for avoidance, wait for a certain period of time before executing avoidance |
| waiting_timeout | float32 | After the waiting time has expired, perform an evasive maneuver. The unit is seconds float32 | no | If the navigation mode is 3, the parameter value must be set to >= 0. It is considered as precise avoidance navigation mode |
| max_speed | maximum | navigation speed | No less than | or equal to 0 - indicates that the default speed of YAML is enabled |