


Computer and 3D printer connected via WiFi BY [CURA](#) , It's necessary to plug the TF card into the board, otherwise, will report an error.

When the PC controls the printer, the TF card needs to be kept in the motherboard at all times, and all the transferred files will be saved in the TF card.

You can also manually control the printing of transferred files in the TF card




WIFI support Ultimaker_Cura-4.2.0-BETA

Download and install CURA sectioning software


<https://github.com/Ultimaker/Cura/releases/tag/4.2-beta>

Copy the (MKS plugin)> file to the CURA installation directory **plugins** directory.




You can find the plugins (MKS Plugin) file in the TF card or send an email to my3d ltd@163.com to request it.

firmware : WiFi username password





Open the **lite_cfg** file with Notepad

2 change into your router's wifi username and password



3 Copy the Has been modified **lite_cfg** file and **mkslite.bin** to the TF card, insert the 3D printer, and then turn on the power switch again. The system will update automatically.



After the update, the files in the TF card are automatically invalidated (can be deleted) and can only be updated once. If you need to update again. Need to re-copy the file into the TF card.

cura.

MY3D

PREPARE

PREVIEW

MONITOR

Preferences

General
Settings
Printers
Materials
Profiles

Printers

Activate Add Remove Rename

Local printers

MY3D

MY3D

Update Firmware Machine Settings MKS WIFI

MKS WIFI

Connect to Networked Printer

To print directly to your printer over the network, please make sure your printer is connected to the network using a network cable or by connecting your printer to your WIFI network. If you don't connect Cura with your printer, you can still use a USB drive to transfer g-code files to your printer.

Select your printer from the list below:

Add

Edit

Remove

Refresh

192.168.31.157
192.168.31.217
192.168.31.75

192.168.31.75

Type

TFT WIFI

Printer Address

Enter the IP address or hostname of your printer on the network.

192.168.31.75

Cancel

OK

Close

If your printer is not listed, read the [network printing troubleshooting guide](#)

Preheat ABS
Control
Wifi
About PrinterMain
Cloud Service
IP:192.168.31.75
wifi:MY3D

