

Following are characters that you have to send from MYOSA mobile app to control the corresponding actions of the actuators on the MYOSA board.

Character - Action

- r - Turns on the relay for 30 seconds
- c - Turns off the relay
- b - Buzzes the buzzer 5 times
- 1 - Turns output pin 1 to high
- 2 - Turns output pin 2 to high
- 3 - Turns output pin 1 to low
- 4 - Turns output pin 2 to low

For controlling actuators through Wi-fi, all you need to do is add the prefix 'w' in the above characters. I.e for buzzing the buzzer through the Wifi, you have to send "wb", without quotes.