

Installation / Environment / Licensing

Documentation

Installation instructions:

www.model.com/support/licensing.asp

Globetrotter FlexLM Doc:

www.globetrotter.com/support/index.html

Web — Download the Latest Release

www.model.com/products/release.asp

Environment Variables (see ModelSim cmd "prntenv")

LM_LICENSE_FILE	Required	Pathname of license.dat file or port@host
DOPATH	Optional	Search path for ".do" files
EDITOR	Optional	Specifies editor for "edit" cmd
MODELSIM	Optional	Pathname of modelsim.ini file
MODELSIM_TCL	Optional	List of modelsim.tcl files
MODEL_TECH_TCL	Optional	Pathname to Tcl/Tk libraries
MODEL_TECH	Don't Set	Used internally by ModelSim
MGC_LOCATION_MAP	Optional	Used as "soft" path to find files
PLIOBJ5	Optional	Used to load PLI object files
TMPDIR	Optional	Used by VSIM for temp space

PATH Environment Variable

Unix:	Add	/<install_dir>/modeltech/bin to \$path
PC:		PATH will be updated automatically during install

Starting the License Server

Unix:	Copy license.dat file to	/<install_dir>/modeltech/<platform>/
	Run	/<install_dir>/modeltech/<platform>/START_SERVER
PC:	Run	/<install_dir>/modeltech/win32/flexlm.cpl
		Use "Setup" and "Control" tabs to configure and start server

Licensing Diagnostics

Unix:	Run	/<install_dir>/modeltech/<platform>/lmstat -a
		or lmdlag
PC:	Run	/<install_dir>/modeltech/win32/lmutil lmstat -a
		or lmutil lmdlag -or-
PC:	Start->Programs->ModelSim->Licensing Wizard	

Invoking ModelSim

Unix:	Run	/<install_dir>/modeltech/bin/vsim
PC:	Start->Programs->ModelSim->ModelSim	-or-
PC:	Double-click on:	<install_dir>/modeltech/win32/modelsim.exe

Key ModelSim Commands

Commands may be used in the following locations: (Shell), (ModelSim> prompt, or (V)SIM> prompt. See Command Reference for complete command list and syntax.

vcom	Sh, M, V	VHDL Compiler (see below)
vdel	Sh, M, V	Deletes a design unit from a specific library
vdhr	Sh, M, V	Lists the contents of a library
vlib	Sh, M, V	Creates a design library
vlog	Sh, M, V	Verilog Compiler (see below)
vmap	Sh, M, V	Defines or displays library mappings
vsim	Sh, M, V	VHDL and/or Verilog Simulator (see below)
add list wave	V	Add signals to the List or Wave windows
add log	V	Log signals to vsim.wlf file for analysis later
alias	M, V	Create a user defined alias (e.g., <i>alias h "history"</i>)
bp, bd	V	Set/Clear a breakpoint (see <i>Managing Breakpoints</i> below)
cd	Sh, M, V	Change directory
change	V	Modify a VHDL variable or Verilog register
checkpoint	V	Save the state of you simulation (see <i>restore</i>)
compare add	M, V	Compare signals
configure	M, V	Configure List or Wave window attributes
delete	V	Remove HDL item from List or Wave window
do	M, V	Execute a file of commands (e.g., <i>do macro.do</i>)
drivers	V	Display current and future value of signal or net drivers
dumplog64	Sh	Dump the contents of the vsim.wlf file in a readable form
echo	M, V	Display message (e.g., <i>echo "Time is \$now ns."</i>)
edit	M, V	Invoke editor specified by the EDITOR env variable
environment	M, V	Display or change current region/signal environment
examine	M, V	Examine one or more HDL items (e.g., <i>exa /top/clock</i>)
find	V	Display pathnames of matching HDL items
force	V	Force signals or nets (e.g., <i>force clk 1 10, 0 20 -r 100</i>)
history	M, V	List previous commands
noforce	V	Release signals or nets from force commands
notepad	M, V	Simple text editor
prntenv	M, V	Display names and values of environment variables
profile on	M, V	Turn on Performance Analyzer
property	V	Change List or Wave signal attributes (color, radix, etc.)
pwd	M, V	Display current path in Main transcript window
radix	M, V	Change the default radix in all windows
report	M, V	returns all control or state variable values
restart	V	Restart the simulator
restore	M, V	Restore the simulation state from a previous <i>checkpoint</i>
resume	M, V	Resume macro execution after a pause command
right left	V	Search in wave window for next transition or -expr
run	V	Advance simulation time (e.g., <i>run 1000</i>)
search next	V	Search specified window for next item matching pattern
seetime	V	Scroll List or Wave window to time (e.g., <i>seetime wave 500</i>)
vcd2wlf	Sh	Translate VCD file into WLF file
vcddumpsports	M, V	Create a VCD file
vgencomp	Sh	Create VHDL component from compiled Verilog module
view	M, V	Open a ModelSim window and pop it to the top
vmake	Sh	Print a makefile for a library
vsources	V	Display HDL source file in Source window
when	M, V	Perform action on condition (e.g., <i>when clk=1 {echo clk}</i>)
where	M, V	Display info about the environment
write	M, V	Records names, window contents, and preferences to a file
↑ ↓	M, V	Toggle thru last commands
!! !n	M, V	Repeat last command, Repeat nth command
!abc	M, V	Repeat cmd starting "abc"
^abc^xyz	M, V	Replace "abc" in previous command with "xyz"

ModelSim Products

www.model.com/products/prodcomp.asp

Quick Guide Notes

Find this document at

www.model.com/support/pdf/qk_guide.pdf

Commands in bold are typed at the ModelSim> or VSIM> prompts

Light blue highlight denotes SE-only features.

Quick Guide

Wave Window

add wave <item> <item>	Wave specific signals/nets
add wave *	Wave signals/nets in scope
add wave -r /*	Wave all signals/nets in design
add wave -label <name> <item>	Wave and rename a signal/net
add wave abus(31:15)	Wave a slice of a bus
view wave	Display wave window
view wave -new	Display additional wave window
write wave	Print wave window to file
<left mouse button>	Select signal / Place cursor
<middle mouse button>	Zoom options
<right mouse button>	Context Menu
<ctrl-f>	Find next item
<tab> (go right)	Search forward for next edge
<shift-tab> (go left)	Search backward for next edge
i or + o or -	Zoom in Zoom out
f l	Zoom full Zoom Last

vlog

Key Arguments (use -help for full list)

[-compat]	Disable event order optimizations
[-f <filename>]	Pass in arguments from file
[-fast]	Optimize design (see <i>Performance</i> below)
[-O5]	Maximum optimization
[-hazards]	Enable run-time hazard checking
[-help]	Display vlog syntax help
[-nodebug]	Hide internal variables & structure
[-quiet]	Disable loading messages
[-R <simargs>]	Invoke VSIM after compile
[-refresh]	Regenerate lib to current version
[-version]	Returns vlog version
[-v <library_file>]	Specify Verilog source library
[-work <libname>]	Specify work library
<filename(s)>	Verilog file(s) to be compiled

Examples

vlog top.v
vlog -work mylib -refresh

vcom

Key Arguments (use -help for full list)

[-93] [-87]	Choose VHDL-1993 or 1987
[-check_synthesis]	Turn on synthesis checker
[-debugVA]	Print VITAL opt status
[-O5]	Maximum optimization
[-explicit]	Resolve ambiguous overloads
[-help]	Display vcom syntax help
[-f <filename>]	Pass in arguments from file
[-norangecheck]	Disable run time range checks
[-nodebug]	Strip internal names
[-novitalcheck]	Disable VITAL95 checking
[-nowarn <#>]	Disable individual warning msg
[-O0]	Disable optimization
[-quiet]	Disable loading messages
[-refresh]	Regenerate library image
[-version]	Returns vcom version
[-work <libname>]	Specify work library
<filename(s)>	VHDL file(s) to be compiled

Examples

vcom MyDesign.vhd
vcom -93 -work /lib/mylib util.vhd
vcom -refresh

vsim

Key Arguments (use -help for full list)

[-c]	Run in cmd line mode
[-coverage]	Invoke Code Coverage
[-do "cmd" <file>]	Run cmd or file at startup
[-elab]	Create elaboration file
[-f <filename>]	Pass in args from file
[-glG<name>=value>]	Set VHDL Generic values
[-hazards]	Enable hazard checking
[-help]	Display vsim syntax help
[-l <logfile>]	Save transcript to log file
[-load_elab]	Simulate an elaboration file
[+notimingchecks]	Disable timing checks
[-quiet]	Disable loading messages
[-restore <filename>]	Restore a simulation
[-sdf[minityp]max]	Apply SDF timing data e.g., sdfmin /top=MySDF.txt
<region>=<sdf>file>]	Disable SDF warnings
[-sdfnowarn]	Disable SDF warnings
[-t [<mult>]<unit>]	Time resolution
[-version]	Returns vsim version
[-view <filename>]	Log file for VSIM to view
[-wif <filename>]	Log file to create
<libname>.<config>	Configuration, Module, or Entity/Arch to simulate
<module>	
<entity>[<arch>]]	

Examples

vsim top
vsim -lib mywork top -do commands.do

Files

modelsim.ini	System Initialization or Project file; stores library locations, simulator resolution, paths, etc.
modelsim.tcl	Window sizes, positions, colors, etc.; user Tcl/Tk code
startup.do	Default name of macro executed after design is loaded; See "startup=" line in modelsim.ini
transcript	Default filename that ModelSim transcript window activity is saved to
vsim.wlf	Default name of simulation log file saved by VSIM

modelsim.ini

To copy modelsim.ini to current directory:

Execute vmap -c

Loading order (stops after finding first file)

1. \$MODELSIM environment variable
2. Current directory if \$MODELSIM is not set
3. In /install_dir/modeltech/<platform> directory
4. In /install_dir/modeltech directory

For Detailed Information see:

ModelSim User's Manual "ModelSim Variables"

modelsim.tcl

Loading order

Always loads: /install_dir/modeltech/tcl/vsim/pref.tcl

Loads the first found from:

1. \$MODELSIM_TCL if it exists ("." separated list)
(all files in list are loaded)
2. Current directory ./modelsim.tcl
3. \$HOME/modelsim.tcl

Managing Breakpoints

bp	Sets a breakpoint; without arg shows all bps
bd	Deletes a breakpoint
disablebp	Turn off all breakpoints
enablebp	Turns all breakpoints on
onbreak	Define what to do when a breakpoint is hit during a macro (e.g., onbreak (resume))
when	Perform actions under certain conditions

Light blue highlight denotes SE-only features.

