

Design changes report

- IrSize signal to indicate to Pc if it will increment by one or by two(immediate value case).
- SP is always updated in the second half of the clock cycle of the execution stage.if it is a pop instruction the out to the EX/MEM old value of sp if push out updated value.
- SP is initialized by 3001.