

Smart Call Center Phone Fix

THIS IS NOT AN OFFICIAL TECHNICAL PUBLICATION. THIS KNOWLEDGEBASE ENTRY IS THE PROPERTY OF CANON U.S.A. AND IS CONFIDENTIAL INFORMATION TO BE RETAINED FOR REFERENCE PURPOSES BY THE AUTHORIZED DEALER WITH WHOM SERVICE AGREEMENTS HAVE BEEN ENTERED INTO. USER AGREES TO INDEMNIFY CANON U.S.A., INC. AND TO HOLD IT HARMLESS AGAINST ANY CLAIM ARISING BY REASON OF THE POSSESSION OR USE THEREOF ITS UNAUTHORIZED USE IS PROHIBITED.

Product:

imageRUNNER ADVANCE 6000/8000 Series

Title:

0C10 Jam Code

Problem:

A jam code of 0C10 is displayed on the user interface. This is an indication there is a piece of paper jammed in the main unit of the machine or the Paper Decks.


Solution:

Fixing Transport Unit

Check the location of the paper jam, and follow the procedure described below, and the procedure that appears on the touch panel display, to remove the jammed paper.


1.

Open the front cover of the main unit.



2.


Turn the dial in the direction of the arrow (counterclockwise) 10 times.



This procedure makes it easier to remove the jammed paper in the following procedures, because the jammed paper moves to the fixing transport unit.

3.

Pull out the fixing transport unit.




1. Move the green lever in the direction of the arrow.

2. Pull out the fixing transport unit.

4.

Remove any jammed paper from the left guide.




1. Open the left guide.

2. Remove any jammed paper.

5.

Remove any jammed paper from the fixing unit.




IMPORTANT

If you cannot pull out the jammed paper, proceed to the next step. Do not pull out jammed paper by force, as this may leave torn pieces inside the machine and cause the machine to malfunction.

6.

Remove any jammed paper from the lower guide.



1. Open the lower guide, holding by the green tab.

2. Remove any jammed paper.


3. Close the lower guide.

CAUTION

When closing the guide, be careful not to get your fingers caught, as this may result in personal injury.

7.

Remove any jammed paper from the fixing unit.



1. Pull the paper gently.

2. Turn the knob to the left to remove any jammed paper.


3. Close the left guide.

CAUTION

When closing the guide, be careful not to get your fingers caught, as this may result in personal injury.

8.

Push the fixing transport unit back into its original position, and close the front cover.



1. Push the fixing transport unit back into its original position.

2. Return the green lever to its original position.

3. Close the front cover.

CAUTION

When returning the unit to its original position or closing the cover, be careful not to get your fingers caught, as this may result in personal injury.

9.

Follow the instructions on the touch panel display.

NOTE

The screen indicating the directions on how to clear the paper jam is displayed repeatedly until the paper jam is cleared.