


Wiring Diagram for PATTONPAK Condensing Unit PEMS100/150-PCCS175/275 Single Phase Compressor



Note:

- For thermostat control remove bridge between "7" & "6". Connect T'stat feed to terminal "6".
- PEMS models (Embraco NJ compressor) not fitted with C/case heater.
- Wired for automatic pump down

UL Tested to AS/NZS 60335.2.98 (Selected clauses)

LEGEND	
Neutral	N
Field Wire	-----●
Internal Wire	-----●

This information is provided for the use of individuals as they see fit. Patton Ltd is not responsible for the use of this information by any party, especially those lacking sufficient skill or knowledge to perform those tasks safely and in accordance with local electrical codes and governance. Any hazard created is the sole responsibility of the user. Patton reserves the right to change information without notice.