

## **Parcel Editing with COGO in ArcGIS**

---

[WWW.ALLEGANCOUNTY.ORG/GIS](http://WWW.ALLEGANCOUNTY.ORG/GIS)

NOVEMBER 23, 2020



# Contents

<b>Contents</b>	<b>i</b>
COGO Tools in ArcGIS . . . . .	1
COGO Workspace Setup . . . . .	1
The COGO Mapping Document(mxld) . . . . .	1
Full Extent Button . . . . .	2
Editor Setup for COGO . . . . .	3
Snapping Setup . . . . .	4
Enable Classic Snapping . . . . .	4
Enable Snap Tips . . . . .	4
Configure Snapping Window . . . . .	5
Find starting point for COGO sketch . . . . .	6
Using the Find Tool . . . . .	6
Begin COGO Sketch . . . . .	10
Start Editing . . . . .	10
Use the Traverse Tool on the COGO Toolbar . . . . .	11
Example Legal Description . . . . .	12
Select Starting Point for the Sketch . . . . .	12
Enter COGO Inputs . . . . .	14
More Examples of Direction Distance Inputs . . . . .	15



# COGO TOOLS IN ARCGIS

## COGO Workspace Setup

### Navigate to the COGO Mapping document (MXD)

J:\Departments\Treasury\gis\COGO




Figure 0.1: COGO Map File

### Copy the file to your personal workspace




Figure 0.2: User Folder

Double click on COGOWorkSpace.mxd to open it




Figure 0.3: First Screen

Zooms out to show all features in the broadest layer

Push **Full Extent Tool**




Figure 0.4: Full Extent Tool Result

## Set up editor options for COGO:

Push **Editor** Toolbar Button to get the dropdown




Figure 0.5: Editor Toolbar Button

Set units for COGO:

**Editor** ⇒ **Options** ⇒ **Units**




Figure 0.6: Editor Options

## Snapping Setup

**Snapping settings** are important for accuracy and precision in editing GIS data

### Enable Classic Snapping

Editor ⇒ Options ⇒ General ⇒ Use Classic Snapping




Figure 0.7: Enable Classic Snapping

### Enable Snap Tips

Snap Tips are text that show what you are snapping to

Editor Dropdown ⇒ Snapping ⇒ Options

- Check the box for Show Snap Tips




Figure 0.8: Enable Snap Tips



## Configure Snapping Window

For each feature layer in the map there are 3 options for snapping:

**Vertex**, **Edge**, and **End** Snapping

Open the Snapping Window

**Editor** ⇒ **Snapping** ⇒ **Snapping Window**

These settings are a good start:




Figure 0.9: Snapping Window

For more information on Snapping:

[Link to Documentation on Classic Snapping](#)

## Find starting point for COGO sketch

### Using the Find Tool

If you have a parcel number near your area of interest, you can use the find tool to get there.




Figure 0.10: Find Tool

## Enter a parcel number into the Find Tool

Input the:

- Parcel Number
- Layer to search
- Field to search

Push **Find**




Figure 0.11: Tool Data

If find tool finds a match:  
right click on it and select zoom to




Figure 0.12: Match

Find a starting point for mapping by:

- Using the mouse wheel to zoom in or out
- Toggle layers on or off in the table of contents




Figure 0.13: Reference Point

## Begin COGO Sketch

### Start Editing

Editor ⇒ Start Editing




Figure 0.14: Editor Toolbar

In the start editing box, under source, select the Shareddata connection




Figure 0.15: Start Editing

## Use the Traverse Tool on the COGO Toolbar

Once you have your starting point:

Push **Traverse** on the COGO toolbar

Push **Template** and select CogoLines




Figure 0.16: Launch COGO Toolbar

## Example Legal Description

Commencing at the South Quarter post of Section 17, Town 1 North, Range 15 West; thence South 88° 28' 49" East on the South section line, 654.51 feet to the West line of the East Half of the Southwest Quarter of the Southeast Quarter and the place of beginning of this description; thence North 00° 44' 38" East on said West line, 295.00 feet; thence South 88° 28' 47" East 295.36 feet; thence South 00° 42' 30" West parallel to the East line of the Southwest Quarter of the Southeast Quarter, 295.00 feet to the South section line; thence North 88° 28' 49" West on same, 295.54 feet to the place of beginning.  
Subject to any and all easements and restrictions of record, or otherwise. Subject to the rights of the public and of any governmental unit in any part thereof taken, used, or deeded for street, road, or highway purposes.

Figure 0.17: Sample Description

For this parcel, you can use the find tool to get to a nearby parcel or navigate to Lee Twp Section 17.

Once there, locate the South Quarter Post for the starting point for sketching.

## Select Starting Point for the Sketch

To the right of the Start box: Push arrow+




Figure 0.18: Start COGO



## Click a starting point in the map




Figure 0.19: Click Starting Point

*Note: The cursor should snap to points specified in the Snapping Window.*

## Enter COGO Inputs

Enter **Direction and Distance**

*i.e.*

From the South Quarter post of Section 17

**One Direction Distance** can be entered or the **entire traverse** can be entered at one time.

The screenshot shows a 'Traverse' dialog box with the following elements:

- Template...** button and **CogoLines** text field.
- Direction-Distance** dropdown menu.
- Direction:**
- Distance:**
- Add** button.
- Table:**

#	Description
1	Straight Direction: S 88-28-49 E Distance: 654.51
2	Straight Direction: N 0-44-38 E Distance: 295
3	Straight Direction: S 88-28-47 E Distance: 295.36
4	Straight Direction: S 0-42-30 W Distance: 295
5	Straight Direction: N 88-28-49 W Distance: 295.54

Navigation buttons on the right:

**Start:**  **Edit...** ☐ **Closed Loop** **Adjust..**

**End:**  **Edit...** **Closure...** **Finish**

Figure 0.20: Sample Traverse

Push **Finish** and the lines are added to the data

## More Examples of Direction Distance Inputs

To go straight North:





Figure 0.21: North Direction Distance

Push **Add** and the line is added to the sketch

*Note: the sketch is only temporary at this point, lines can be reordered added and removed.*

To go straight West:




The screenshot shows the 'Traverse' dialog box with the 'Template...' button and 'CogoLines' selected. The 'Direction-Distance' dropdown is set to 'Direction'. The 'Direction' field contains 'n 90 w' and the 'Distance' field contains '200'. A red arrow points to the 'Add' button. Below the input fields is a table with one row:

#	Description
1	Straight Direction: N 0-0-0 E Distance: 120

At the bottom, there are fields for 'Start' (12710779.211, 405033.853) and 'End', along with buttons for 'Edit...', 'Closed Loop', 'Adjust..', 'Closure...', and 'Finish'.

Figure 0.22: West Direction Distance

To go straight South:



The screenshot shows the 'Traverse' dialog box with the 'Template...' button and 'CogoLines' selected. The 'Direction-Distance' dropdown is set to 'Direction'. The 'Direction' field contains 's 0 w' and the 'Distance' field contains '120'. A red arrow points to the 'Add' button. Below the input fields is a table with two rows:

#	Description
1	Straight Direction: N 0-0-0 E Distance: 120
2	Straight Direction: S 90-0-0 W Distance: 200

At the bottom, there are fields for 'Start' and 'End', along with buttons for 'Edit...', 'Closed Loop', 'Adjust..', 'Closure...', and 'Finish'.

Figure 0.23: South Direction Distance

To go straight East:




Figure 0.24: East Direction Distance

*Note: anytime before you push finish you can add or remove lines and reorder lines.*

Push **Finish** and the lines are added to the data