

Mode Numbers

41 --> Digital mode

73 --> analog mode

F3 --> DS2 native mode

<<QUERY_DS2_ANALOG_MODE>>

CMD=01,41,00,5A,5A (5A,5A,5A,5A)

DAT=--,ID,SS,WW,XX (YY,00,00,ZZ)

ID=mode number

SS=5A --> mode not changed

SS=00 --> mode changed

WW,XX,YY,ZZ=FF,FF,03,5A --> DS2 native mode

WW,XX,YY,ZZ=00,00,00,00 --> not

<<READ_DATA>>

CMD=01,42,00,00,00 (,00,00,00,00)

DAT=--,ID,SS,XX,XX (,XX,XX,XX,XX)

ID=mode number

SS=5A --> mode not changed

SS=00 --> mode changed

XX= button/stick data

<<READ_DATA_AND_VIBRATE>>

CMD=01,42,00,WW,PP (,00,00,00,00)

DAT=--,ID,SS,XX,XX (,XX,XX,XX,XX)

ID=mode number

SS=5A --> mode not changed

SS=00 --> mode changed

WW=00 --> small motor off

WW=01 --> small motor on

PP=00-FF --> large motor speed

XX=button/stick data

<<READ_DATA_AND_VIBRATE_EX>>

CMD=01,42,00,WW,PP (,00,00,00,00,00,00,00,00,00,00,00,00,00,00,00)

DAT=--,ID,SS,XX,XX (,XX,XX,XX,XX,XX,XX,XX,XX,XX,XX,XX,XX,XX,XX)

ID=mode number

SS=5A --> mode not changed

SS=00 --> mode changed

WW=00 --> small motor off

WW=01 --> small motor on

PP=00-FF --> large motor speed

XX= button/stick data

```
*****
*****
<<CONFIG_MODE_ENTER>>
CMD=01,43,00,01,00 (,00,00,00,00)
DAT=--,ID,SS,XX,XX (,XX,XX,XX,XX)
```

ID=mode number

SS=5A --> mode not changed
SS=00 --> mode changed

XX= button/stick data

```
*****
*****
<<CONFIG_MODE_EXIT>>
CMD=01,43,00,00,00 (00,00,00,00)
DAT=--,ID,SS,00,00 (00,00,00,00)
```

ID=mode number

SS=5A --> mode not changed
SS=00 --> mode changed

```
*****
*****
<<CONFIG_MODE_EXIT_DS2_NATIVE>>
CMD=01,43,00,00,5A (5A,5A,5A,5A)
DAT=--,ID,SS,00,00 (00,00,00,00)
```

ID=mode number

SS=5A --> mode not changed
SS=00 --> mode changed

```
*****
*****
<<SET_MODE_AND_LOCK>>
CMD=01,44,00,XX,YY (00,00,00,00)
DAT=--,ID,SS,00,00 (00,00,00,00)
```

XX=01 --> analog mode
XX=00 --> digital mode

YY=03 --> lock mode. Mode button on controller is locked

ID=mode number

SS=5A --> mode not changed
SS=00 --> mode changed

```
*****
*****
<<QUERY_MODEL_AND_MODE>>
CMD=01,45,00,00,00 (00,00,00,00)
DAT=--,ID,SS,01,02 (MM,VV,01,00)
```

ID=mode number

SS=5A --> mode not changed
SS=00 --> mode changed

VV=02 --> dual shock
MM=01 --> analog mode
MM=00 --> digital mode

VV=01 --> DS2 native
MM=01 --> analog mode
MM=00 --> digital mode

<<VIBRATION_ENABLE>>
CMD=01,4D,00,00,01 (FF,FF,FF,FF)
DAT=--,ID,SS,XX,YY (FF,FF,FF,FF)

ID=mode number

SS=5A --> mode not changed
SS=00 --> mode changed

XX,YY=00,01: pad vibration enabled
XX,YY=FF,FF: pad vibration disabled

<<VIBRATION_DISABLE>>
CMD=01,4D,00,FF,FF,FF,FF,FF,FF
DAT=--,ID,SS,XX,YY,FF,FF,FF,FF

ID=mode number

SS=5A --> mode not changed
SS=00 --> mode changed

XX,YY=00,01: pad vibration enabled
XX,YY=FF,FF: pad vibration disabled

<<SET_DS2_NATIVE_MODE>>
CMD=01,4F,00,FF,FF (03,00,00,00)
CMD=--,ID,SS,00,00 (00,00,00,XX)

ID=mode number

SS=5A --> mode not changed
SS=00 --> mode changed

XX=5A --> OK
XX=00 --> NG