



System ID: 722019858400
CID(s): 7225020605

AUTOSCAN, INC
4040 23RD AVE W
SEATTLE, WA 98199
(206) 282-1616

In Service Date: 6/6/1994
Primary Telco: 206 285 0903 M2
Secondary Telco: PANEL IS 5800B
Panel: BO5875, HONEYWELL 5800- MULTI ACCOUNT

Panel Instructions:

TO FORCE ARM: ENTER PASSCODE, PRESS ON/OFF BUTTON (SYSTEM WILL BEEP)
PRESS CLEAR, PRESS ENTER

76 PASSCARDS ALLOWED, PASSCARDS CAN BE 3 TO 6 DIGITS, PASSCARDS CANNOT
BE WITHIN 10 DIGITS OF EACH OTHER ON THE SAME UNIT, DURESS CAN BE USED
BY INCREASING THE LAST DIGIT BY 1 OR 2 DIGITS; I.E. 15624 TO 15625

DESCRIPTION:

25 PASSCARDS, LINES 001-025, PASSCARDS CAN BE 3 TO 6 DIGITS,
PASSCARDS CANNOT BE 10 DIGITS OF EACH OTHER ON THE SAME UNIT.

TO ARM: PRESS NEXT TO ENSURE THAT ALL ZONES ARE NORMAL.
ENTER YOUR PASSCODE.
PRESS THE ALL ON/OFF KEY.

TO DISARM: ENTER YOUR PASSCODE.
PRESS ALL ON/OFF.

TO SILENCE THE ALARM WHILE SYSTEM IS ARMED: DISARM SYSTEM.

TO SILENCE THE ALARM WHILE THE SYSTEM IS DISARMED:
ENTER YOUR PASSCODE AND PRESS THE ENTER KEY.

RESET SENSORS: ENTER YOUR PASSCODE AND ENTER.
PRESS NEXT UNTIL YOU SEE 'RESET SENSORS'.
PRESS THE ENTER KEY.
- THE DISPLAY WILL THEN READ 'SENSORS RESETTING'
ONCE THE SENSORS HAVE BEEN RESET, THE CONTROL
CENTER RETURNS TO THE DATE AND TIME.

CLEAR ALARM MEMORY:
ENTER PASSCODE AND PRESS CLEAR OR
ENTER PASSCODE, PRESS ENTER, THAN PRESS CLEAR TWICE
** If clearing Alarm Memory from hardwired HU buttons
Make sure the button is physically reset before resetting
the keypad.

ADDING, CHANGING, AND DELETING CODES

Changing One's Own Code

- 1) Enter authorized passcode
- 2) Press [Enter] button
- 3) Press 17
- 4) Press [Enter] button
- 5) Enter new code
- 6) Press [Enter] button
- 7) Enter new code again
- 8) Press [Enter] button
- 9) Press [Clear] button to exit

Adding or Deleting Codes (Customer must have User/Line #)

- 1) Enter authorized passcode
- 2) Press [Enter] button



System ID: 722019858400
CID(s): 7225020605

AUTOSCAN, INC
4040 23RD AVE W
SEATTLE, WA 98199
(206) 282-1616

In Service Date: 6/6/1994
Primary Telco: 206 285 0903 M2
Secondary Telco: PANEL IS 5800B
Panel: BO5875, HONEYWELL 5800- MULTI ACCOUNT

Panel Instructions:

3) Press 18 to Add Passcode
or Press 19 to Delete Passcode
To Add Passcode:
4) Enter User Number
5) Press [Enter] button
6) Enter New Code
7) Press [Enter] button
Keypad will ask if Code should be Valid for Area 1?
8) Press [Enter] button
For multiple Areas, Pressing [Enter] = yes
Pressing [Next] = No
9) Press [Next] past Area 8?
Keypad will ask for Auth Level
10) Enter Authority Level 1,2 or 3
11) Press [Enter] button
Valid Area 1? Will appear
12) Press [Enter] button
For multiple Areas, Pressing [Enter] = yes
Pressing [Next] = No
13) Press [Next] past Area 8?
Keypad will display Passcode Added
To Delete Passcode
1) Enter authorized passcode
2) Press [Enter] button
3) Press 19 to Delete Passcode
4) Press [Enter] button
5) Enter User Line #
6) Press [Enter] button, keypad will display 'Delete User #?'
7) Press [Enter] button, again
OR USING THE FUNCTION MENU OPTION:
1) Enter authorized passcode
2) Press [Enter] button
3) Keep pressing the [Next] button until
you see the desired Function Menu Option: below
Hit [Next] button to Change Passcode
Hit [Next] button again to Add Passcode
Hit [Next] button one more time to Delete Passcode