

## Modem-Radionics Codes

EVENT CODE	DESCRIPTION
*	AUDIO IN
[	ERROR
\	CANCEL
A	ALARM
AD	DOOR REQUEST DENIED
AD01	LOG OVERFLOW
AD12	CHECKSUM FAIL
AG	DOOR CYCLED
AL	DOOR LOCKED
AO	DOOR LEFT OPEN
AS	DOOR SECURE
AU	DOOR UNLOCKED
C	CLOSING
D	DURESS
E	FIRE SUPERVISION
F	FIRE ALARM
G	TROUBLE FIRE
GM	MISSING FIRE SUPERVISION
H	FIRE RESTORAL
J	SUPERVISION
L	AUDIO DONE
M	MISSING FIRE
MT	MISSING SUPERVISION
N	BYPASS OR RESET
NB	COMM RESTORE
ND02	PARAMETERS CHANGED
ND03	USER CODE TAMPER
ND04	USER CODE CHANGED
ND05	USER CODE DELETED
ND06	SKED CHANGED
ND07	DATE & TIME CHANGED
ND09	WATCHDOG RESET
ND11	REMOTE RESET

<b>ND14</b>	REBOOT
<b>ND18</b>	RELAY RESET
<b>ND19</b>	RELAY SET
<b>ND20</b>	RELAY RESET
<b>ND21</b>	RELAY SET
<b>ND22</b>	RELAY RESET
<b>ND23</b>	RELAY SET
<b>ND24</b>	RELAY RESET
<b>ND27</b>	SENSOR RESET
<b>ND28</b>	RELAT SET
<b>ND30</b>	CARD ASSIGNED
<b>ND34</b>	FAIL TO EXECUTE
<b>ND35</b>	FAIL TO EXECUTE
<b>ND38</b>	USER CODE ADDED
<b>ND40</b>	USER LEVEL SET
<b>O</b>	OPEN
<b>P</b>	AC FAIL
<b>R</b>	RESTORE
<b>R9</b>	BATTERY RESTORE
<b>RB</b>	PHONELINE 1 RESTORE
<b>RC</b>	PHONELINE 2 RESTORE
<b>RD</b>	BUS RESTORE
<b>RD17</b>	RF RECEIVER RESTORAL
<b>RE</b>	TEST REPORT
<b>RF</b>	FIRE WALK END
<b>RF01</b>	VALID LOCAL ACCESS
<b>S</b>	CREATE STATUS REPORT
<b>SA</b>	STATUS ALARM
<b>SB</b>	LOG THRESHOLD
<b>SC</b>	STATUS CLOSE
<b>SD</b>	SDI FAILURE
<b>SE</b>	STATUS FIRE SUPERVISION
<b>SF</b>	STATUS FIRE ALARM
<b>SG</b>	STATUS FIRE TROUBLE
<b>SI</b>	STATUS DOOR OPEN
<b>SL</b>	LOG OVERFLOW
<b>SM</b>	CHECKSUM FAIL

<b>SO</b>	STATUS OPEN
<b>SP</b>	STATUS POWER FAIL
<b>SR</b>	STATUS RESTORAL/ACCESS
<b>ST</b>	STATUS TROUBLE
<b>SU</b>	USER TAMPER
<b>SV</b>	STATUS MISSING TROUBLE
<b>SY</b>	STATUS MISSING SUPERVISORY
<b>SZ</b>	STATUS MISSING
<b>T</b>	TROUBLE
<b>T9</b>	LOW BATTERY
<b>TB</b>	PHONELINE FAIL 1
<b>TC</b>	PHONELINE FAIL 2
<b>TD</b>	BUS FAIL
<b>TD01</b>	LOG THRESHOLD
<b>TD08</b>	RF INTERFERENCE
<b>TD15</b>	PARAMETER CHECKSUM FAIL
<b>TD16</b>	EXTRA RF POINT
<b>TD17</b>	RF RECEIVER TROUBLE
<b>TD26</b>	EXTEND CLOSE TIME
<b>TD29</b>	EQUIPMENT FAIL
<b>TD49</b>	TEST FAILED UPLINK
<b>TE</b>	FAIL TO OPEN/CLOSE
<b>TF</b>	FIRE WALK START
<b>U</b>	USER ALARM
<b>U7</b>	USER ALARM 7
<b>U9</b>	USER ALARM 9
<b>V</b>	MISSING TROUBLE
<b>W</b>	FORCED ARM
<b>X</b>	RECEIVER MESSAGES
<b>Y</b>	DIAGNOSTIC REPORT