

ADC STEPS

2 Ocak 2025 Perşembe 23:21

STEPS TO USE ADC

1. Set ADC clock prescaler (default: disabled (No conversion))
2. Define VREF (default: Externally supplied ref. Voltage)
3. Select Analog channel (default: PC0)
4. ADC mode (single conversion vs auto-triggered)
5. Interrupt to call when ADC completes (optional)
6. Other options: 8-bit mode, power-safe, etc.