



Manage security with System Manager

ONTAP 9

NetApp
July 21, 2023

This PDF was generated from https://docs.netapp.com/us-en/ontap/concept_security_overview.html on July 21, 2023. Always check docs.netapp.com for the latest.

Table of Contents

- Manage security with System Manager 1
 - Security management overview with System Manager 1
 - Set up multifactor authentication 1
 - Control administrator access 3
 - Diagnose and correct file access issues 3
 - Manage certificates with System Manager 4
 - Manage external key managers 8

Manage security with System Manager

Security management overview with System Manager

Beginning with ONTAP 9.7, you can manage cluster security with System Manager.

With System Manager, you use ONTAP standard methods to secure client and administrator access to storage and to protect against viruses. Advanced technologies are available for encryption of data at rest and for WORM storage.

If you are using the classic System Manager (available only in ONTAP 9.7 and earlier), refer to [System Manager Classic \(ONTAP 9.0 to 9.7\)](#)

Client authentication and authorization

ONTAP authenticates a client machine and user by verifying their identities with a trusted source. ONTAP authorizes a user to access a file or directory by comparing the user's credentials with the permissions configured on the file or directory.

Administrator authentication and RBAC

Administrators use local or remote login accounts to authenticate themselves to the cluster and storage VM. Role-Based Access Control (RBAC) determines the commands to which an administrator has access.

Virus scanning

You can use integrated antivirus functionality on the storage system to protect data from being compromised by viruses or other malicious code. ONTAP virus scanning, called *Vscan*, combines best-in-class third-party antivirus software with ONTAP features that give you the flexibility you need to control which files get scanned and when.

Encryption

ONTAP offers both software- and hardware-based encryption technologies for ensuring that data at rest cannot be read if the storage medium is repurposed, returned, misplaced, or stolen.

WORM storage

SnapLock is a high-performance compliance solution for organizations that use *write once, read many* (WORM) storage to retain critical files in unmodified form for regulatory and governance purposes.

Set up multifactor authentication

Security Assertion Markup Language (SAML) authentication allows users to log in to an application by using a secure identity provider (IdP).

In System Manager, in addition to standard ONTAP authentication, SAML-based authentication is provided as an option for multifactor authentication.

Security Assertion Markup Language (SAML) is an XML-based framework for authentication and authorization between two entities: a service provider and an identity provider.

Enable SAML authentication



To enable SAML authentication, perform the following steps:

Steps

1. Click **Cluster > Settings**.
2. Next to **SAML Authentication**, click .
3. Ensure there is a check in the **Enable SAML Authentication** checkbox.
4. Enter the URL of the IdP URI (including "https://").
5. Modify the host system address, if needed.
6. Ensure the correct certificate is being used:
 - If your system was mapped with only one certificate with type "server", then that certificate is considered the default and it isn't displayed.
 - If your system was mapped with multiple certificates as type "server", then one of the certificates is displayed. To select a different certificate, click **Change**.
7. Click **Save**. A confirmation window displays the metadata information, which has been automatically copied to your clipboard.
8. Go to the IdP system you specified and copy the metadata from your clipboard to update the system metadata.
9. Return to the confirmation window (in System Manager) and check the checkbox **I have configured the IdP with the host URI or metadata**.
10. Click **Logout** to enable SAML-based authentication. The IdP system will display an authentication screen.
11. In the IdP system, enter your SAML-based credentials. After your credentials are verified, you will be directed to the System Manager home page.

Disable SAML authentication

To disable SAML authentication, perform the following steps:

Steps

1. Click **Cluster > Settings**.
2. Under **SAML Authentication**, click the **Enabled** toggle button.
3. *Optional:* You can also click  next to **SAML Authentication**, and then uncheck the **Enable SAML Authentication** checkbox.

Control administrator access

The role assigned to an administrator determines which functions the administrator can perform with System Manager. Predefined roles for cluster administrators and storage VM administrators are provided by System Manager. You assign the role when you create the administrator's account, or you can assign a different role later.

Depending on how you have enabled account access, you might need to perform any of the following:

- Associate a public key with a local account.
- Install a CA-signed server digital certificate.
- Configure AD, LDAP, or NIS access.

You can perform these tasks before or after enabling account access.

Assigning a role to an administrator

Assign a role to an administrator, as follows:

Steps

1. Select **Cluster > Settings**.
2. Select  next to **Users and Roles**.
3. Select  **Add** under **Users**.
4. Specify a user name, and select a role in the drop-down menu for **Role**.
5. Specify a login method and password for the user.

Changing an administrator's role

Change the role for an administrator, as follows:

Steps

1. Click **Cluster > Settings**.
2. Select the name of user whose role you want to change, then click the  that appears next to the user name.
3. Click **Edit**.
4. Select a role in the drop-down menu for **Role**.

Diagnose and correct file access issues

Steps

1. In System Manager, select **Storage > Storage VMs**.
2. Select the storage VM on which you want to perform a trace.
3. Click  **More**.
4. Click **Trace File Access**.
5. Provide the user name and client IP address, then click **Start Tracing**.

The trace results are displayed in a table. The **Reasons** column provides the reason why a file could not be accessed.

6. Click  in the left column of the results table to view the file access permissions.

Manage certificates with System Manager

Beginning with ONTAP 9.10.1, you can use System Manager to manage trusted certificate authorities, client/server certificates, and local (onboard) certificate authorities.

With System Manager, you can manage the certificates received from other applications so you can authenticate communications from those applications. You can also manage your own certificates that identify your system to other applications.

View certificate information

With System Manager, you can view trusted certificate authorities, client/server certificates, and local certificate authorities that are stored on the cluster.

Steps

1. In System Manager, click **Cluster > Settings**.
2. Scroll to the **Security** area.
In the **Certificates** section, the following details are displayed:
 - The number of stored trusted certificate authorities.
 - The number of stored client/server certificates.
 - The number of stored local certificate authorities.
3. Click any number to view details about a category of certificates, or click  to view the **Certificates** page, which contains information about all categories.
The list displays the information for the entire cluster. If you want to display information for only a specific storage VM, perform the following steps:
 - a. Click **Storage > Storage VMs**.
 - b. Select the storage VM.
 - c. View the **Settings** tab.
 - d. Click a number shown in the **Certificate** section.

What to do next

- From the **Certificates** page, you can [Generate a certificate signing request](#).
- The certificate information is separated into three tabs, one for each category. You can perform the following tasks from each tab:

On this tab...	You can perform these procedures...
Trusted certificate authorities	<ul style="list-style-type: none"> • Install (add) a trusted certificate authority • Delete a trusted certificate authority • Renew a trusted certificate authority
Client/server certificates	<ul style="list-style-type: none"> • Install (add) a client/server certificate • Generate (add) a self-signed client/server certificate • Delete a client/server certificate • Renew a client/server certificate
Local certificate authorities	<ul style="list-style-type: none"> • Create a new local certificate authority • Sign a certificate using a local certificate authority • Delete a local certificate authority • Renew a local certificate authority

Generate a certificate signing request

You can generate a certificate signing request (CSR) with System Manager from any tab of the **Certificates** page. A private key and a corresponding CSR are generated, which can be signed using a certificate authority to generate a public certificate.

Steps

1. View the **Certificates** page. See [View certificate information](#).
2. Click **+Generate CSR**.
3. Complete the information for the subject name:
 - a. Enter a **common name**.
 - b. Select a **country**.
 - c. Enter an **organization**.
 - d. Enter an **organization unit**.
4. If you want to override defaults, select **More Options** and provide additional information.

Install (add) a trusted certificate authority

You can install additional trusted certificate authorities in System Manager.

Steps

1. View the **Trusted Certificate Authorities** tab. See [View certificate information](#).
2. Click  **Add**.
3. On the **Add Trusted Certificate Authority** panel, perform the following:
 - Enter a **name**.
 - For the **scope**, select a storage VM.

- Enter a **common name**.
- Select a **type**.
- Enter or import **certificate details**.

Delete a trusted certificate authority

With System Manager, you can delete a trusted certificate authority.



You cannot delete trusted certificate authorities that were preinstalled with ONTAP.

Steps

1. View the **Trusted Certificate Authorities** tab. See [View certificate information](#).
2. Click the name of the trusted certificate authority.
3. Click  next to the name, then click **Delete**.

Renew a trusted certificate authority

With System Manager, you can renew a trusted certificate authority that has expired or is about to expire.

Steps

1. View the **Trusted Certificate Authorities** tab. See [View certificate information](#).
2. Click the name of the trusted certificate authority.
3. Click  next to the name, then click **Renew**.

Install (add) a client/server certificate

With System Manager, you can install additional client/server certificates.

Steps

1. View the **Client/Server Certificates** tab. See [View certificate information](#).
2. Click .
3. On the **Add Client/Server Certificate** panel, perform the following:
 - Enter a **certificate name**.
 - For the **scope**, select a storage VM.
 - Enter a **common name**.
 - Select a **type**.
 - Enter or import **certificate details**.
You can either write in or copy and paste in the certificate details from a text file or you can import the text from a certificate file by clicking **Import**.
 - Enter a the **private key**.
You can either write in or copy and paste in the private key from a text file or you can import the text from a private key file by clicking **Import**.

Generate (add) a self-signed client/server certificate

With System Manager, you can generate additional self-signed client/server certificates.

Steps

1. View the **Client/Server Certificates** tab. See [View certificate information](#).
2. Click **+Generate Self-signed Certificate**.
3. On the **Generate Self-Signed Certificate** panel, perform the following:
 - Enter a **certificate name**.
 - For the **scope**, select a storage VM.
 - Enter a **common name**.
 - Select a **type**.
 - Select a **hash function**.
 - Select a **key size**.
 - Select a **storage VM**.

Delete a client/server certificate

With System Manager, you can delete client/server certificates.

Steps

1. View the **Client/Server Certificates** tab. See [View certificate information](#).
2. Click the name of the client/server certificate.
3. Click  next to the name, then click **Delete**.

Renew a client/server certificate

With System Manager, you can renew a client/server certificate that has expired or is about to expire.

Steps

1. View the **Client/Server Certificates** tab. See [View certificate information](#).
2. Click the name of the client/server certificate.
3. Click  next to the name, then click **Renew**.

Create a new local certificate authority

With System Manager, you can create a new local certificate authority.

Steps


1. View the **Local Certificate Authorities** tab. See [View certificate information](#).
2. Click  .
3. On the **Add Local Certificate Authority** panel, perform the following:
 - Enter a **name**.
 - For the **scope**, select a storage VM.

- Enter a **common name**.
- 4. If you want to override defaults, select **More Options** and provide additional information.

Sign a certificate using a local certificate authority

In System Manager, you can use a local certificate authority to sign a certificate.

Steps

1. View the **Local Certificate Authorities** tab. See [View certificate information](#).
2. Click the name of the local certificate authority.
3. Click  next to the name, then click **Sign a certificate**.
4. Complete the **Sign a Certificate Signing Request** form.
 - You can either paste in the certificate signing content or import a certificate signing request file by clicking **Import**.
 - Specify the number of days for which the certificate will be valid.

Delete a local certificate authority

With System Manager, you can delete a local certificate authority.

Steps

1. View the **Local Certificate Authority** tab. See [View certificate information](#).
2. Click the name of the local certificate authority.
3. Click  next to the name, then click **Delete**.

Renew a local certificate authority

With System Manager, you can renew a local certificate authority that has expired or is about to expire.

Steps

1. View the **Local Certificate Authority** tab. See [View certificate information](#).
2. Click the name of the local certificate authority.
3. Click  next to the name, then click **Renew**.

Manage external key managers

Beginning with ONTAP 9.13.1, you can use System Manager to manage external key managers to store and manage authentication and encryption keys.

Beginning with ONTAP 9.7, you can store and manage authentication and encryption keys with the Onboard Key Manager. Beginning with ONTAP 9.13.1, you can use both the Onboard Key Manager and external key managers to store and manage authentication and encryption keys.

The Onboard Key Manager is used to store and manage keys in a secure database that is internal to the cluster. An external key manager stores and manages keys, but it is external to the cluster. One or more external key managers can be used to store and manage keys.

The scope of the Onboard Key Manager is at the cluster level; however, the scope of external key managers

can be either at the cluster level or at a storage VM level.

If the Onboard Key Manager is enabled, an external key manager cannot be enabled at the cluster level, but it can be enabled at the storage VM level. Conversely, if an external key manager is enabled at the cluster level, the Onboard Key Manager cannot be enabled.

When using external key managers, you can register up to four primary key servers per storage VM and cluster. Each primary key server can be clustered with up to three secondary key servers.

Configure an external key manager



Before you start

To add an external key manager for a storage VM, you should add an optional gateway when you configure the network interface for the storage VM. If the storage VM was created without the network route, you will have to create the route explicitly for the external key manager. See [Create a LIF \(network interface\)](#).

Steps

You can configure an external key manager starting from different locations in System Manager.

1. To configure an external key manager, perform one of the following starting steps.

Workflow	Navigation	Starting step
Configure Key Manager	Cluster > Settings	Scroll to the Security section. Under Encryption , select  . Select External Key Manager .
Add local tier	Storage > Tiers	Click + Add Local Tier . Check the check box labeled "Configure Key Manager". Select External Key Manager .
Prepare storage	Dashboard	In the Capacity section, select Prepare Storage . Then, select "Configure Key Manager". Select External Key Manager .
Configure encryption (key manager at storage VM scope only)	Storage > Storage VMs	Select the storage VM. Click the Settings tab. In the Encryption section under Security , select  .

2. To add a primary key server, click **+ Add**, and complete the **IP Address or Host Name** and **Port** fields.
3. Existing installed certificates are listed in the **KMIP Server CA Certificates** and **KMIP Client Certificate** fields. You can perform any of the following actions:
 - Click  to select installed certificates that you want to map to the key manager. (Multiple service CA certificates can be selected, but only one client certificate can be selected.)
 - Select **Add New Certificate** to add a certificate that has not already been installed and map it to the external key manager.
 - Click  next to the certificate name to delete installed certificates that you do not want to map to the external key manager.
4. To add a secondary key server, click **Add** in the **Secondary Key Servers** column, and provide its details.
5. Click **Save** to complete the configuration.

Edit an existing external key manager

If you have already [configured an external key manager](#), you can modify its settings.

Steps

1. To edit the configuration of an external key manager, perform one of the following starting steps.

Scope	Navigation	Starting step
Cluster scope external key manager	Cluster > Settings	Scroll to the Security section. Under Encryption , select  , then select Edit External Key Manager .
Storage VM scope external key manager	Storage > Storage VMs	Select the storage VM. Click the Settings tab. In the Encryption section under Security , select  , then select Edit External Key Manager .

2. Existing key servers are listed in the **Key Servers** table. You can perform the following operations:
 - Add a new key server by clicking  **Add**.
 - Delete a key server by clicking  at the end of the table cell that contains the name of the key server. The secondary key servers associated with that primary key server are also removed from the configuration.

Delete an external key manager

An external key manager can be deleted if the volumes are unencrypted.

Steps

1. To delete an external key manager, perform one of the following steps.

Scope	Navigation	Starting step
Cluster scope external key manager	Cluster > Settings	Scroll to the Security section. Under Encryption , select  , then select Delete External Key Manager .
Storage VM scope external key manager	Storage > Storage VMs	Select the storage VM. Click the Settings tab. In the Encryption section under Security , select  , then select Delete External Key Manager .

Migrate keys among key managers

When multiple key managers are enabled on a cluster, keys must be migrated from one key manager to another. This process is completed automatically with System Manager.

- If the Onboard Key Manager or an external key manager is enabled at a cluster level, and some volumes are encrypted, then when you configure an external key manager at the storage VM level, the keys must be migrated from the Onboard Key Manager or external key manager at the cluster level to the external key manager at the storage VM level. This process is completed automatically by System Manager.
- If volumes were created without encryption on a storage VM, then keys do not need to be migrated.

Copyright information

Copyright © 2023 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.