

NHRC

REPEATER CONTROLLERS

NHRC-VSQ Installation / User's Guide

1. Set the NHRC-VSQ PCB onto pins 10 - 13 of J904 (IF/Audio & Squelch board connector) in the MASTR-II radio chassis. Pin 1 of the VSQ board will be located at pin 10 of J904 with the potentiometer controls facing toward the receiver chassis.
NOTE: The PCB will not fit properly if it is installed backwards; you should not have to force the connection.
2. Adjust the volume and squelch potentiometers as required.
3. Note: If you do not require a local speaker please add a 10 ohm 10 watt resistor across the speaker connections for a load. This will keep the AF amp from oscillating.
4. For further information please check the NHRC MASTR II info web page at <http://www.nhrc.net>

NHRC Repeater Controllers • 415 4th Range Rd. • Pembroke,
NH 03275
email: info@nhrc.net • phone: 603-485-2248 •
<http://www.nhrc.net>

NHRC

REPEATER CONTROLLERS

NHRC-VSQ Installation / User's Guide

1. Set the NHRC-VSQ PCB onto pins 10 - 13 of J904 (IF/Audio & Squelch board connector) in the MASTR-II radio chassis. Pin 1 of the VSQ board will be located at pin 10 of J904 with the potentiometer controls facing toward the receiver chassis.
NOTE: The PCB will not fit properly if it is installed backwards; you should not have to force the connection.
2. Adjust the volume and squelch potentiometers as required.
3. Note: If you do not require a local speaker please add a 10 ohm 10 watt resistor across the speaker connections for a load. This will keep the AF amp from oscillating.
4. For further information please check the NHRC MASTR II info web page at <http://www.nhrc.net>

NHRC Repeater Controllers • 415 4th Range Rd. • Pembroke,
NH 03275
email: info@nhrc.net • phone: 603-485-2248 •
<http://www.nhrc.net>

NHRC

REPEATER CONTROLLERS

NHRC-VSQ Installation / User's Guide

1. Set the NHRC-VSQ PCB onto pins 10 - 13 of J904 (IF/Audio & Squelch board connector) in the MASTR-II radio chassis. Pin 1 of the VSQ board will be located at pin 10 of J904 with the potentiometer controls facing toward the receiver chassis.
NOTE: The PCB will not fit properly if it is installed backwards; you should not have to force the connection.
2. Adjust the volume and squelch potentiometers as required.
3. Note: If you do not require a local speaker please add a 10 ohm 10 watt resistor across the speaker connections for a load. This will keep the AF amp from oscillating.
4. For further information please check the NHRC MASTR II info web page at <http://www.nhrc.net>

NHRC Repeater Controllers • 415 4th Range Rd. • Pembroke,
NH 03275
email: info@nhrc.net • phone: 603-485-2248 •
<http://www.nhrc.net>

NHRC

REPEATER CONTROLLERS

NHRC-VSQ Installation / User's Guide

1. Set the NHRC-VSQ PCB onto pins 10 - 13 of J904 (IF/Audio & Squelch board connector) in the MASTR-II radio chassis. Pin 1 of the VSQ board will be located at pin 10 of J904 with the potentiometer controls facing toward the receiver chassis.
NOTE: The PCB will not fit properly if it is installed backwards; you should not have to force the connection.
2. Adjust the volume and squelch potentiometers as required.
3. Note: If you do not require a local speaker please add a 10 ohm 10 watt resistor across the speaker connections for a load. This will keep the AF amp from oscillating.
4. For further information please check the NHRC MASTR II info web page at <http://www.nhrc.net>

NHRC Repeater Controllers • 415 4th Range Rd. • Pembroke,
NH 03275
email: info@nhrc.net • phone: 603-485-2248 •
<http://www.nhrc.net>