

[Print](#)[Exit](#)**6AR-FSE ENGINE CONTROL SFI SYSTEM CONTROL FUEL PUMP CONTROL****FUNCTION**

- a. The fuel pump is controlled by the ECM through the fuel pump control ECU assembly. Fuel pump control has a fuel cut control function. Fuel cut control stops the fuel pump when any of the SRS airbags has deployed.

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.