

[Print](#)[Exit](#)**6AR-FSE ENGINE CONTROL SFI SYSTEM CONTROL STARTER CONTROL (CRANKING HOLD FUNCTION)****FUNCTION**

- a. When the engine switch is pressed with the brake pedal depressed and the shift lever in P or N, this function operates the starter assembly until the engine starts. This prevents application of the starter assembly for an inadequate length of time. It also prevents the engine from being cranked after it has started.

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.