

# Wire guide for Modbus - ECL 120

## Industrial USB to RS485 Bidirectional Converter



Modbus device	ECL 120
GND ->	Terminal 36
A+ ->	Terminal 34
B- ->	Terminal 35

WaveShare Industrial Grade Serial Server RS232/485 to WiFi/Ethernet



Modbus device	ECL 120
PE ->	Terminal 36
A ->	Terminal 34
B ->	Terminal 35

# WaveShare RS485 To RJ45 Ethernet PoE Module



Modbus device	ECL 120
(PE / Ground symbol) (NOT GND) ->	Terminal 36
485A ->	Terminal 34
485B ->	Terminal 35