

## Connect Rpi to Computer via VNC:

1. Download & install VNC Viewer  
(<https://www.realvnc.com/en/connect/download/viewer/>);  
follow the instructions to install it
2. Open VNC Viewer and type in your Raspberry PI's IP  
address; login and password is *pi* and *raspberrypi*  
respectively
3. You are now able to access to your Raspberry PI desktop  
via your laptop screen