



Application Note

Atmel Smart Upgrade Tool v1.0

USER MANUAL

Table of Contents

Table of Contents	2
Table of Figures	3
1 Introduction	4
2 Scope 4	
3 Installing Atmel Smart Upgrade Tool	4
3.1 System Requirements	4
4 Working on Smart Upgrade Tool	4
4.1 Opening the Smart Upgrade Tool.....	5
4.2 Starting the Session	5
4.3 Environment	8
4.3.1 Table View.....	9
4.3.2 Output View	10
4.4 Upgrading the Nodes	11
4.5 Stopping the Session	14
4.6 Exiting the Application	14
Reference 15	
Revision History	16

Table of Figures

Figure 1 : Overview	4
Figure 2 Opening Smart Upgrade Tool	5
Figure 3 Connection Settings	5
Figure 4 Configuring the Serial Port	5
Figure 5 Connecting the Server	6
Figure 6 Setting the Channel number	6
Figure 7 Notify Interval Settings for the Client	7
Figure 8 UI Wait Interval for deciding a node's state	7
Figure 9 identifying all the Clients using Identify All button	8
Figure 10 Full picture of Smart Upgrade Tool	8
Figure 11 Table View	9
Figure 12 Upgrade button	9
Figure 13 Table columns explaining Node's detail	9
Figure 14 Idle state indication at Table	10
Figure 15 Output View	10
Figure 16 Getting the Firmware and Board information	11
Figure 17 Doing Upgrade on the respective node	11
Figure 18 Selecting the HEX file	11
Figure 19 Setting the Client Response Interval for Upgrade	12
Figure 20 Setting the UI Wait Interval for Upgrade	12
Figure 21 Switching to new image	13
Figure 22 Upgrade completed status window	13

1 Introduction

Atmel Smart Upgrade tool is a comprehensive application that provides easy upgrading of the firmware for easy and quick OTAU environment to the customer.

This user guide provides how to use this tool effectively to make use of the firmware upgrade of the Atmel devices.

2 Scope

It shows you how to perform firmware upgrading of Smart Connect 6LOWPAN stack.

3 Installing Atmel Smart Upgrade Tool

Start the installation by double-clicking the Atmel Smart Upgrade tool setup (msi) file.

3.1 System Requirements

- Server node for each target system
- Windows 7/8
- 512 MB or better RAM
- 500 MB available disk space
- Dot Net framework 4.5

4 Working on Smart Upgrade Tool

The Tool will first connect to the device called server through any communication medium.

Once the tool establishes the communication with server, it starts communicating with the clients over the air.




Figure 1 : Overview

Above figure gives the whole picture about the upgrade tool architecture.



INFO

In this version, the tool communicates only via serial port to the server node.

4.1 Opening the Smart Upgrade Tool

Once the installation is finished, you can see the shortcut created on your Desktop. Double click and open the Smart Upgrade tool now.




Figure 2 Opening Smart Upgrade Tool

4.2 Starting the Session

This section explains about how to start the session using this tool. Once the application is opened, go to Settings menu and Select Connection.




Figure 3 Connection Settings




Figure 4 Configuring the Serial Port

- Select the desired COM port and click OK to save the settings.




Figure 5 Connecting the Server

- Now Go File-> Connect -> Serial Port.
- Select the desired Channel number from the drop down box available.





Figure 6 Setting the Channel number

- After selecting, Click **Start** to start the session



- Click **Stop** to stop the session at any time (even at the middle of the upgrade session).



Once the session is started, we have to notify the server initially to discover all the clients at the selected channel by clicking the Notify Interval button at the tool bar. By default all clients will notify the server for every 5 seconds. This can be changed at any time after starting the session.




Figure 7 Notify Interval Settings for the Client




Figure 8 UI Wait Interval for deciding a node's state

Also, the user should set the minimum wait time for the tool to decide a node whether it's active or not using **UI Wait Interval** settings from **Preferences** window.



TIP

User should manage to set the timing accordingly at UI Wait Interval based on Notify Interval Settings from Main Window

By default, the timing is configured as.,

Notify Interval for Client	= 5 seconds
UI Wait Interval for Tool	= 15 seconds

So, The tool waits for 15 seconds which is 3 times the client notify interval setting to decide a node as ACTIVE or not. in-




Figure 9 identifying all the Clients using Identify All button

At any time, we can use the **Identify All** button to blink all the Nodes connected to the network. This eventually blinks by toggling its chip LED.

4.3 Environment

The tool environment is composed with two panes horizontal to each other. The top pane is Table View and the bottom one is Output.

- Table View
- Output




Figure 10 Full picture of Smart Upgrade Tool

4.3.1 Table View

The Table view will list down all the nodes that are connected to the network once the session is started. It holds useful information about the node. Each node occupies a row with several columns as described below:

[illegible]

Figure 11 Table View

User can easily upgrade the node using the button provided and it will show the live progress in the progress bar as like below figure.

Upgrade	Upgrade Progress	Extended Address
Upgrade	<div></div>	0x112233445566...
Upgrade	<div></div>	0x42500000001EB
Upgrade	<div></div>	0x42500000001EF

Figure 12 Upgrade button

The remaining columns explains more about the node's detailed information.

Extended Address	Short Address	Device Type	PAN-ID	Parent	Firmware	Firmware version	Board	Board version
------------------	---------------	-------------	--------	--------	----------	------------------	-------	---------------

Figure 13 Table columns explaining Node's detail

When any node goes IDLE or Not-Responding state, the Short-Address column will turn in to Red color to indicate its state.

d Address	Short Address	Device Type
3445566...	0x0	
000001EB	0x1EB	Router
000001EF	0x1EF	Router
000001F1	0x1F1	Router
000001EC	0x1EC	Router
000001EE	0x1EE	Router
000001F3	0x1F3	Router
000001ED	0x1ED	Router

Figure 14 Idle state indication at Table

4.3.2 Output View

This view is used to understand all the activities happening in the tool. It logs all the information that the user requested and provides the status or progress about it. All the success / failure messages can be seen in this view.

Output

```

16:22:33 : Connected to Serial port COM29 38400 successfully
16:22:39 : Started collecting data..
16:22:39 : Getting server information...
16:22:39 : Server : 0x8E87011819250402 has responded.
16:22:39 : Waiting for the client nodes..
16:22:39 : Please wait...
16:22:46 : Node : 0x598C011819250402 has joined the network

```

Figure 15 Output View

4.4 Upgrading the Nodes

To upgrade a node, Follow the below steps.

- First the tool should know what is the firmware version is currently running on the node. So, user should right-click on the node and should first get the information like below.




Figure 16 Getting the Firmware and Board information

- Then the server node will ask the client node about its version details and populates it on the respective columns.
- Now, Click the Upgrade button of the corresponding node.




Figure 17 Doing Upgrade on the respective node

- Select the image file from the dialog box that appears immediately.




Figure 18 Selecting the HEX file



INFO

Please follow the file name format as shown in the above figure. It should be like.

<FirmwareName>_<FirmwareVersion>_<BoardName>_<BoardVersion>

in this case, we have

SC6Lowpan_1.0.5_SAMR21CPro_1.0.0.hex
only hex files are acceptable.

- Click Open now. The upgrade will begin and progress bar will start increasing once the client receives the hex file data.
- The upgrade data will be sent to the client for every 1000 milliseconds by default. If we want to modify this interval, Open **Preferences** from **Settings** menu and change the *Client Response Interval*.

The screenshot shows a window titled "Upgrade" with two settings. The first setting, "Client Response Interval (msecs)", has a value of 1000 and is highlighted with a green border. The second setting, "UI Wait Interval (secs)", has a value of 5.

Figure 19 Setting the Client Response Interval for Upgrade

- If we did not received any response from the client then the tool will stop the upgrade process after the certain period of time. This can configured again from the same Preferences window, *UI Wait Interval* value at the Upgrade section.


The screenshot shows the same "Upgrade" window. In this view, the "UI Wait Interval (secs)" setting, which has a value of 5, is highlighted with a green border. The "Client Response Interval (msecs)" setting remains at 1000.

Figure 20 Setting the UI Wait Interval for Upgrade



TO DO

If we encounter this below message box,



Then it indicates it has record type 4 or 5.

User should modify the hex file so that the file has 0, 1, 2 and 3 record type. The tool only allows above record types only.

For more information about IntelHex file format.

http://en.wikipedia.org/wiki/Intel_HEX

- Once the full image sent to the client, it will be ready to switch the image as per the new image file. The user can switch to the new image whenever wanted.



Figure 21 Switching to new image

- If we click switch, then the client write into its flash memory and restarts as per the new image file selected during this process.
- Once it is successfully switched, then we will get a notification about the status like below figure.




Figure 22 Upgrade completed status window

- Now the upgrade is completed.

4.5 Stopping the Session

A session can be stopped any time even if the upgrade is running at the background. It basically clears all the operation of the tool and clears the table.

4.6 Exiting the Application

Click File-> Disconnect will close the serial port.

Then Click File-> Exit (Alt+F4) to exit the application completely.

Reference

1. Atmel Wireless MCU Software Website
<http://www.atmel.com/products/microcontrollers/wireless/default.aspx?tab=tools>
 2. Atmel Wireless Support avr@atmel.com
 3. IEEE Std 802.15.4™-2006 Part 15.4: Wireless Medium Access Control (MAC) and Physical Layer (PHY) Specifications for Low-Rate Wireless Personal Area Networks (WPANs)
 4. Atmel documents for supported families and boards : asf.atmel.com/docs/latest
 5. Atmel Software Framework <http://www.atmel.com/tools/avrsoftwareframework.aspx>
<http://asf.atmel.com/docs/latest/>
 6. Atmel Studio - <http://www.atmel.com/tools/ATMELSTUDIO.aspx>
-

ATMEL EVALUATION BOARD/KIT IMPORTANT NOTICE AND DISCLAIMER

This evaluation board/kit is intended for user's internal development and evaluation purposes only. It is not a finished product and may not comply with technical or legal requirements that are applicable to finished products, including, without limitation, directives or regulations relating to electromagnetic compatibility, recycling (WEEE), FCC, CE or UL. Atmel is providing this evaluation board/kit "AS IS" without any warranties or indemnities. The user assumes all responsibility and liability for handling and use of the evaluation board/kit including, without limitation, the responsibility to take any and all appropriate precautions with regard to electrostatic discharge and other technical issues. User indemnifies Atmel from any claim arising from user's handling or use of this evaluation board/kit. Except for the limited purpose of internal development and evaluation as specified above, no license, express or implied, by estoppel or otherwise, to any Atmel intellectual property right is granted hereunder. ATMEL SHALL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RELATING TO USE OF THIS EVALUATION BOARD/KIT.

ATMEL CORPORATION
1600 Technology Drive
San Jose, CA 95110
USA

Revision History

Doc Rev.	Date	Comments
0.1	03/2015	Initial document release.

Atmel Confidential: For Release Only Under Non-Disclosure Agreement (NDA)

Atmel®, Atmel logo and combinations thereof, Enabling Unlimited Possibilities®, and others are registered trademarks or trademarks of Atmel Corporation in U.S. and other countries. ARM®, ARM Connected® logo, and others are the registered trademarks or trademarks of ARM Ltd. Other terms and product names may be trademarks of others.

DISCLAIMER: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN THE ATMEL TERMS AND CONDITIONS OF SALES LOCATED ON THE ATMEL WEBSITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS AND PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and products descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.

SAFETY-CRITICAL, MILITARY, AND AUTOMOTIVE APPLICATIONS DISCLAIMER: Atmel products are not designed for and will not be used in connection with any applications where the failure of such products would reasonably be expected to result in significant personal injury or death ("Safety-Critical Applications") without an Atmel officer's specific written consent. Safety-Critical Applications include, without limitation, life support devices and systems, equipment or systems for the operation of nuclear facilities and weapons systems. Atmel products are not designed nor intended for use in military or aerospace applications or environments unless specifically designated by Atmel as military-grade. Atmel products are not designed nor intended for use in automotive applications unless specifically designated by Atmel as automotive-grade.