


ATmega328P Xplained Mini User Guide



Introduction

This user guide describes how to get started with the Atmel® ATmega328P Xplained Mini board.

The ATmega328P Xplained Mini evaluation kit is a hardware platform to evaluate the Atmel ATmega328P microcontroller. The evaluation kit comes with a fully integrated debugger that provides seamless integration with Atmel Studio 6.2 (and later version). The kit provides access to the features of the ATmega328P enabling easy integration of the device in a custom design.

Table of Contents

Introduction	1
1. Getting Started	3
1.1. Features	3
1.2. Design Documentation and Related Links	3
1.3. Board Assembly	3
1.3.1. In Customer Development Assembly	3
1.3.2. Connecting an Arduino Shield	3
1.3.3. Standalone Node	3
1.4. Connecting the Kit	3
1.4.1. Connect the Kit to Atmel Studio	3
1.4.2. Connect the Target UART to the mEBDBG COM Port	3
1.5. Programming and Debugging	4
1.5.1. Programming the Target Using mEBDBG	4
1.5.2. Debugging the Target Using mEBDBG	4
1.5.3. Programming the Target Using an External Programmer	5
1.5.4. Programming the ATmega32U4 Using an External Programmer	5
1.5.5. Programming the ATmega32U4 Using a Bootloader	6
1.5.6. How to Install the "Bootloader PC tool"	6
1.6. Available Example Code	7
2. Hardware User Guide	9
2.1. Board Overview	9
2.2. Clock Distribution	9
2.3. Headers and Connectors	9
2.3.1. JTAG (J100)	9
2.3.2. USB (J101)	10
2.3.3. USART (J104)	10
2.3.4. Target Digital I/O (J200 and J201)	10
2.3.5. Target Analogue I/O (J203)	11
2.3.6. Power (J202, J300, J301)	11
2.3.7. Target SPI (J204)	12
2.3.8. Additional Target Signals	12
2.3.9. Extension Headers	13
2.4. Board GUI	14
2.4.1. LEDs	14
2.4.2. Button	14
2.5. Factory Programmed Data	15
2.6. Errata	15
3. Document Revision History	16

1. Getting Started

1.1 Features

The ATmega328P Xplained Mini evaluation board provides a development platform for the Atmel ATmega328P.

1.2 Design Documentation and Related Links

The most relevant documents and software for the evaluation board is available here:

<http://www.atmel.com/tools/MEGA328P-XMINI.aspx>

1.3 Board Assembly

The Xplained Mini board is very flexible and can be used in a number of ways. E.g. as your own prototype for SW development and HW verification.

1.3.1 In Customer Development Assembly

The ATmega328P Xplained Mini board can be wired into the customer prototype assembly by using the on-board connector grid, where the target signals are available.

1.3.2 Connecting an Arduino Shield

By assembling receptacles in the marked positions (J200, J201, J202, and J203) Arduino® shields can be mounted.

1.3.3 Standalone Node

The ATmega328P Xplained Mini board can be used as a standalone node - use the 4xAAA or 2xAAA battery pack available in Atmel store to provide power.

1.4 Connecting the Kit

How to connect the evaluation board.

1.4.1 Connect the Kit to Atmel Studio


How to connect the ATmega328P Xplained Mini board to Atmel Studio.

1. Download and install [Atmel Studio](#)¹ version 6.2 or later.
2. Launch Atmel Studio.
3. Connect the board to the USB port and it will be visible in Atmel Studio.

1.4.2 Connect the Target UART to the mEBDG COM Port

All Xplained Mini boards have an embedded debugger (mEBDG) with a number of features, among them a CDC/COM port which enables the user to connect the ATmega328P UART to the PC.

1. Connect the mEBDG USB to the PC.
2. Use the Device Manager to find the COM port number.
3. Default COM port settings are 9600baud N81. The COM port settings can be changed using the Device Manager.



¹ <http://www.atmel.com/tools/atmelstudio.aspx>

1.5 Programming and Debugging

How to program and debug the Xplained Mini board.

1.5.1 Programming the Target Using mEDBG

Using the Embedded Debugger on the Xplained Mini board to program the ATmega328 via the SPI bus.

1. Connect the mEDBG USB to the PC.
2. Go to Atmel Studio: click Tools, select Device Programming, and select the connected mEDBG as Tool with Device = ATmega328P and Interface = ISP, click Apply. Note that if ISP programming fails it could be because debugWIRE is enabled. See debugging chapter on how to disable debugWIRE mode: ["Debugging the Target Using mEDBG" on page 4](#).
3. Select "Memories" and locate the source hex or elf file and click Program.
4. If the source contains fuse settings go to "Production file" and upload the elf file and program the fuses.
5. To set fuses manually click Fuses and select the setting.

Recommended fuse setting:

```
BOOTSZ = 1024W_1C00,  
BOOTRST = [ ],  
RSTDISBL = [ ],  
DWEN = [ ],  
SPIEN = [X],  
WDTON = [ ],  
EESAVE = [ ],  
BODLEVEL = DISABLE,  
CKDIV8 = [ ],  
CKOUT = [ ],  
SUT_CKSEL = EXTCLK_6CK_14CK_65MS
```

Note

If any other cpu clk than the external clk supplied by the mEDBG is used the debugWIRE is not guaranteed to work.

The mEDBG will prevent writing certain fuse combinations in order to protect your kit.

Trying to change CKDIV8 and/or SUT_CKSEL will be prevented and an Error message will be displayed ("One or more registers differs").

To be able to set fuses freely the ATmega32U4 EEPROM has to be programmed to 0x00 from address 0x200 to 0x214.

Note

If not exiting debug mode by selecting "Disable debugWIRE and Close" in the Debug menu, the DWEN fuse will be enabled and the target will still be in debug mode, i.e. it will not be possible to program the target using the SPI.

1.5.2 Debugging the Target Using mEDBG

Using the Embedded Debugger on the Xplained Mini board to debug the ATmega328P via debugWIRE.

1. Start Atmel Studio.
2. Connect the mEDBG USB to the PC.
3. Open your project.
4. In the Project menu select the project properties page, select the Tools tab and select mEDBG as debugger and debugWIRE as interface.

5. In the Debug menu click Start Debugging and Break.
6. Atmel Studio will display an error message if the DWEN fuse in the ATmega328P is not enabled, click YES to make Studio set the fuse using the ISP interface.
7. A debug session is started with a break in main, debugging can start.
8. When exiting debug mode select "Disable debugWIRE and Close" in the Debug menu, this will disable the DWEN fuse.

Note

If not exiting debug mode by selecting "Disable debugWIRE and Close" in the Debug menu, the DWEN fuse will be enabled and the target will still be in debug mode, i.e. it will not be possible to program the target using the SPI.

Note

If any other cpu clk than the external clk supplied by the mEDBG is used the debugWIRE is not guaranteed to work.

Note

Applying a signal to J202/RESET (the RESET_SENSE signal) while debugging may result in unexpected behaviour. This signal is NOT available during a debugging session because the RESET line is actively used by the debugWIRE interface.

1.5.3 Programming the Target Using an External Programmer

How to program the target ATmega328P using the AVR[®] JTAGICE mkII, JTAGICE3, or other Atmel Programmers.

1. Connect the External Programmer to the PC.
2. Connect the External Programme to the evaluation board ISP connector (J204) (Need the 6-pin 100mil adapter connected to the JTAGICE).
3. Go to Atmel Studio: Tools/Device Programming, and select the External Programmer connected as Tool, Select Device = ATmega328P, Interface = ISP and click Apply.
4. Select "Memories" and locate the source hex or elf file and click Program.
5. If the source contains fuse settings go to "Production file" and upload the elf file and program the fuses.

Recommended fuse setting:

```

BOOTSZ = 1024W_1C00,
BOOTRST = [ ],
RSTDISBL = [ ],
DWEN = [ ],
SPIEN = [X],
WDTON = [ ],
EESAVE = [ ],
BODLEVEL = DISABLE,
CKDIV8 = [ ],
CKOUT = [ ],
SUT_CKSEL = EXTCLK_6CK_14CK_65MS

```

1.5.4 Programming the ATmega32U4 Using an External Programmer

How to program the ATmega32U4 using the AVR[®] JTAGICE mkII, JTAGICE3, or other Atmel Programmers.

To restore the mEDBG FW use the /tools/mEDBG/mEDBG_fw.zip from the Studio installation.

1. Connect the External Programmer to the PC.
2. Connect the External Programmer to the board connector (J100).
3. Go to Atmel Studio: Tools/Device Programming, and select the External Programmer connected as Tool, select Device = ATmega32U4, Interface = JTAG and click Apply.
4. Select "Memories" and locate the source hex or elf file and click Program.
5. If the source contain fuse settings go to "Production file" and upload the elf file and program the fuses.

Recommended fuse setting:

BODLEVEL = DISABLE

HWBE = [X]

OCDEN = []

JTAGEN = [X]

SPIEN = [X]

WDTON = []

EESAVE = [X]

BOOTSZ = 2048W_3800

BOOTRST = []

CKDIV8 = []

CKOUT = [X]

SUT_CKSEL = EXTOSC_8MHZ_XX_258CK_65MS

Note

CKOUT must be enabled to provide clock to the target.

1.5.5 Programming the ATmega32U4 Using a Bootloader

This section describes how to use the bootloader to program the ATmega32U4.


1. Install the Bootloader interface on the PC as described in "[How to Install the "Bootloader PC tool"](#)" on page 6.
2. Start the Bootloader PC GUI "FLIP".
3. Short strap J102.
4. Connect the board USB connector to the PC.
5. Select Device = ATmega32U4 (Device - Select).
6. Select USB communication (**Ctrl+U**).
7. Select memory area to program (Use the toggle memory button below the Atmel logo).
8. Select Load Hex file (**Ctrl+L**).
9. Select Programming Options.
10. Click "Run", observe status in status field.

1.5.6 How to Install the "Bootloader PC tool"

How to install the Bootloader PC GUI tool.

² <http://www.atmel.com/tools/FLIP.aspx>

1. Download the FLIP "in system programming tool" installer from <http://www.atmel.com/tools/FLIP.aspx>².



2. Run the FLIP Installer.



1.6 Available Example Code

The ATmega328P is preprogrammed with a demo program, ReMorse. Source code is available in [Atmel Spaces](http://spaces.atmel.com/gf/project/avr_xp_mini/)³.

When the CDC COM port is connected to a terminal window, the text you write will be transmitted via the LED in Morse code.


³ http://spaces.atmel.com/gf/project/avr_xp_mini/

Any Morse code transmitted by using the switch will be displayed as text in the terminal window.

2. Hardware User Guide

2.1 Board Overview

Figure 2-1. ATmega328P-XMINI Overview



2.2 Clock Distribution

The ATmega32U4 (mEDBG) has an external 16MHz XTAL.

The ATmega32U4 provides an external 16MHz clock to the ATmega328P (target).

2.3 Headers and Connectors

The board headers and connectors.

2.3.1 JTAG (J100)

J100 is the JTAG programming header typically used by the JTAGICE for programming of the ATmega32U4 (mEDBG).

Table 2-1. J100 JTAG Header

J100 pin	Signal function
1	JTAG_TCK

J100 pin	Signal function
2	GND
3	JTAG_TDO
4	VCC (5V0)
5	JTAG_TMS
6	RESET
7	NC
8	NC
9	JTAG_TDI
10	GND

2.3.2 USB (J101)

J101 is a Micro-B USB connector connected to the embedded debugger (ATmega32U4).

Table 2-2. J101 USB Connector

J101 pin	Function
1	VBUS
2	D-
3	D+
4	NC
5	GND

2.3.3 USART (J104)

The ATmega32U4 USART signals are available on J104 USART header.

The mEDBG CDC COM port is connected to these signals.

Table 2-3. J104 USART Header

J104 pin	ATmega32U4	ATmega328P	Function
1 - UART TXD	PD3	PD1	TxD from ATmega32U4.
2 - UART RXD	PD2	PD0	RxD to ATmega32U4.

2.3.4 Target Digital I/O (J200 and J201)

The J200 and J201 headers provide access to ATmega328P digital I/O pins.

Table 2-4. J200 I/O High Header

J200 pin	ATmega328P pin	Note
J200-1	PB0	
J200-2	PB1	
J200-3	PB2	
J200-4	PB3	
J200-5	PB4	
J200-6	PB5/SCK	Yellow USER LED D200 connected.
J200-7	GND	
J200-8	AREF	
J200-9	PC4/SDA	TWI Serial Data.
J200-10	PC5/SCL	TWI Serial Clock.

Table 2-5. J201 I/O Low Header

J201 pin	ATmega328P pin	Note
J201-1	PD0/RxD	Target USART Receive Pin.
J201-2	PD1/TxD	Target USART Transmit Pin.
J201-3	PD2	
J201-4	PD3	
J201-5	PD4	
J201-6	PD5	
J201-7	PD6	
J201-8	PD7	

2.3.5 Target Analogue I/O (J203)

The ATmega328P analogue I/O pins are available in the J203 header.

Table 2-6. J200 Analogue Header

J203 pin	ATmega328P pin
J203-1	PC0
J203-2	PC1
J203-3	PC2
J203-4	PC3
J203-5	PC4
J203-6	PC5

2.3.6 Power (J202, J300, J301)

The J300 and J301 headers enables selection of power sources and target supply power, the J202 header enables connection to the power system.

Table 2-7. J202 Power Header

J202 pin	Signal	Description
1	NC.	
2	VCC_TARGET	ATmega328P supply voltage.
3	RESET_SENSE	RESET from external source, monitored by the mEDBG, if pulled low the target RESET line will be pulled low. This functionality is NOT available during a debugging session because the RESET line is actively used by the debugWIRE interface. Applying a signal to RESET_SENSE while debugging may result in unexpected behaviour. It is possible to connect RESET_SENSE directly to the target by assembling R212 and removing R110. Note: DebugWIRE will then be disabled.
4	VCC_P3V3	3.3V from on-board DC/DC converter (U300).
5	VCC_P5V0	Voltage from the selected power source, default VBUS.
6	GND	
7	GND	
8	VCC_VIN	The externally connected power source if any.

2.3.6.1 Power Supply Configuration


The J300 and J301 headers enables Power supply configuration.

Table 2-11. Target μ C I/O Signals not connected to any Connector or Header

ATmega328P pin	Grid position
ADC6	H5
ADC7	G5

2.3.9 Extension Headers

The marked area on the grid I7 to R8 can be used for strapping in a Xplained PRO extension header and a few other headers based on the SPI bus.



The general bus connections for a Xplained PRO Extension board is indicated in Table 2-12, detailed wiring can be found in the selected Extension board documentation.

Table 2-12. Xplained Pro Extension Header

Pin	Name	Typical μ C signal	Typical grid pin	Extension signal description
1	ID	NC		Communication line to the ID chip on extension board.
2	GND			Ground.
3	ADC(+)			Analogue to digital converter, positive part of differential ADC.
4	ADC(-)			Analogue to digital converter, negative part of differential ADC.
5	GPIO1			General purpose I/O.
6	GPIO2			General purpose I/O.
7	PWM(+)			Pulse width modulation, alternatively positive part of differential PWM. RESET to RF Extension board.
8	PWM(-)			Pulse width modulation, alternatively positive part of differential PWM.
9	IRQ/GPIO			Interrupt request line from extension board.
10	SPI_SS_B/ GPIO			Slave select for SPI and/or general purpose I/O. Wake up interrupt to RF extension (SLP_TR).

Pin	Name	Typical μ C signal	Typical grid pin	Extension signal description
11	TWI_SDA	PC4/SDA	M6 to Q12	Data line for two-wire interface.
12	TWI_SCL	PC5/SCL	M9 to R12	Clock line for two-wire interface.
13	USART_RX	PD0/RXD	L6 to A12	USART Input Pin from extension board, remove R107 if used.
14	USART_TX	PD1/TXD	L9 to B12	USART Output Pin to extension board, remove R108 if used.
15	SPI_SS_A	PB2/SS	K6 to K5.5	Slave select for Serial peripheral interface.
16	SPI_MOSI	PB3/MOSI	K9 to K10	Master out slave in line of Serial peripheral interface.
17	SPI_MISO	PB4/MISO	J6 to J5.5	Master in slave out line of Serial peripheral interface.
18	SPI_SCK	PB5/SCK	J9 to J10	Clock for Serial peripheral interface.
19	GND		I6 to GND	Ground.
20	VCC		I9 to VCC	Power for extension board.

A number of Xplained PRO Extensions can be found at <http://www.atmel.com/products/microcontrollers/avr/xplainedpro>.

Using Pin 11 to 20 enables connection of the 10-pin connector used on the RZ600 wireless modules and the 10-pin Xplained sensor modules.


2.4 Board GUI

2.4.1 LEDs

There are One LED available for use by the application SW and one for the mEDBG.

Table 2-13. LEDs

LED	Function
D100 - Green	mEDBG, will light during enumeration.
D200 - Yellow	ATmega328P pin 17 - PB5, also connected to mEDBG SCK for ISP programming, in 3-state when not used by the ATmega32U4.



2.4.2 Button

A button is available for general use by application SW.

Table 2-14. Button

Button	Function	ATmega328P pin
SW200	User defined high signal, press to ground (negate).	8 - PB7

2.5 Factory Programmed Data

The ATmega328P Xplained Mini board comes with a demo program preprogrammed in the ATmega328P FLASH using the external clock provided by the ATmega32U4.

The ATmega32U4 is preprogrammed with the mEDBG.

2.6 Errata

The following should be noted on revision 2 of the board (A09-2323/2):

1. VCC on the grid is not connected, VCC can be connected on grid N0 or from the ISP connector pin 2.
2. There is no capacitor on the 3V3 output if the VCC_BOARD is powered from 5V.

3. Document Revision History

Document revision	Date	Comment
42287B	10/2014	Updated version



Atmel Corporation 1600 Technology Drive, San Jose, CA 95110 USA T: (+1)(408) 441.0311 F: (+1)(408) 436.4200 | www.atmel.com

© 2014 Atmel Corporation. / Rev.: 42287B-MCU-10/2014

Atmel®, Atmel logo and combinations thereof, Enabling Unlimited Possibilities®, AVR®, and others are registered trademarks or trademarks of Atmel Corporation in U.S. and other countries. Other terms and product names may be trademarks of others.

DISCLAIMER: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN THE ATMEL TERMS AND CONDITIONS OF SALES LOCATED ON THE ATMEL WEBSITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS AND PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and products descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.

SAFETY-CRITICAL, MILITARY, AND AUTOMOTIVE APPLICATIONS DISCLAIMER: Atmel products are not designed for and will not be used in connection with any applications where the failure of such products would reasonably be expected to result in significant personal injury or death ("Safety-Critical Applications") without an Atmel officer's specific written consent. Safety-Critical Applications include, without limitation, life support devices and systems, equipment or systems for the operation of nuclear facilities and weapons systems. Atmel products are not designed nor intended for use in military or aerospace applications or environments unless specifically designated by Atmel as military- grade. Atmel products are not designed nor intended for use in automotive applications unless specifically designated by Atmel as automotive-grade.