

FANUC

FSSB setup Manual

1. FSSB setting with 16i, 18i, 21i control

After setting of all axis parameter and initialization of servo motor parameter there are 3 ways to set the following FSSB parameter:

- No. 1023
- No. 1905
- No. 1910-1919
- No. 1936, 1937

Automatic setting

By using FSSB screen input amplifier and axis configuration. After switch off/on CNC set parameter 1023, 1905, 1910-1919, 1936, 1937 automatically.

Manual setting 2


Set all FSSB parameter 1023, 1905, 1910-1919, 1936, 1937 by hand.

Manual setting 1

The arrangement of the axis (DSP's) is decided by setting of parameter 1023. Parameter 1905, 1910-1919, 1936, 1937 need not to be set. Because there are some restrictions in configuration the first 2 methods should be preferred.

Slave definition:

In i-series CNC with FSSB , the servo amplifier and pulse modules (M1,M2) are connected via an optical cable. In our description the amplifier and pulse modules we will call "slave". Because each axis represent 1 slave, a 2-axis amplifier is consisting of 2 slaves and a 3-axis amplifier have 3 slaves. The slaves 1,2,3,... are in the range under consideration of the number of connection to the master (CNC).




2.FSSB Setting


2.1. Automatic setting

Set parameter 1902 as follows in order to perform automatic setting by using FSSB setting screen

1902#0 = 0
1902#1 = 0

Please perform the automatic setting using the following procedure:

- Set the servo axis No. in parameter 1023. The total number of axis in parameter 1023 have to be same as number of amplifier axis (except with “-” marked axis in 1023)
- Initialize servo parameter (motor ID, initialization bit)
- Turn off/on CNC power
- Push function key **SYSTEM**
- You can find the FSSB screen pushing  several time



FANUC

Pushing the softkey **FSSB** the amplifier setting screen appears

ACTUAL POSITION

00005 N00099

(ABSOLUTE)

X 90.745

Z -0.251

C 0.000

F **0** MM/M

AMPLIFIER SETTING

NO.	AMP	SERIES	UNIT	CUR.	AXIS	NAME
1	A1-L	α	SUM	40A	1	X
2	A1-M	α	SUM	40A	2	Z

(MODAL)

G00 G25 G18 F M

G97 G22 S

G69 G80 SRPM 0

G99 G67 SSPM 0 T

G21 G54 SMAX 32767

G40 G64 SACT 0

NO. EXTRA TYPE PCB ID

JOG ** * * * * 03:50:20**

ABS REL ALL AMP AXIS MAINT (OPRT)

- Input the axis numbers which should be connected to each amplifier in amplifier setting screen. The information of slaves lines up one by one from top to the bottom. Therefore please set for control axis number to each amplifier neither to 0 nor to duplicate value.

- Press **(OPRT)** to switch to the setting screen

FANUC

ACTUAL POSITION 00005 N00000

(ABSOLUTE)	
X	90.745
Z	-0.251
C	0.000

(MODAL)

G00	G25	G18	F	M
G97	G22		S	
G69	G80		SRPM	0
G99	G67		SSPM	0 T
G21	G54		SMAX	32767
G40	G64		SACT	0

AMPLIFIER SETTING

NO.	AMP	SERIES	UNIT	CUR.	AXIS	NAME
1	A1-L	α	SVM	40A	1	X
2	A1-M	α	SVM	40A	2	Z

NO. EXTRA TYPE PCB ID

MDI ***** 03:52:53 S 0 T0000

ABS REL ALL SETING CANCEL INPUT

- Push the soft key



- To find the axis setting screen push function key

SYSTEM

and



several times.

Push



and after that



The following screen will be displayed.

FANUC

ACTUAL POSITION 00005 N00000

(ABSOLUTE)

X 89.542
Z 3.447
C 0.000

(MODAL)

G00 G25 G18 F M
G97 G22 S
G69 G80 SRPM 0
G99 G67 SSPM 0 T
G21 G54 SMAX 32767
G40 G64 SACT 0

DATA SETTING

AXIS	NAME	AMP	M1	M2	1-DSP	CS	TNDM
1	X	A1-L	0	0	0	0	1
2	Z	A1-M	0	0	0	0	2
3	C	----	0	0	0	1	0


>^

S 0 T0000

MDI ***** 06:23:19

ABS REL ALL AMP AXIS MAINT (OPRT)

- Set the following required information for each axes:
 - External encoder is connected via pulse module M1 or M2 to the axes (full closed loop)
Set connector number of pulse module regarding to axis name (set 1st connector =1 2nd connector =2 and so on)
In case you are connecting basic unit and expansion unit via flat cable, this combination will be considered as one slave (connector No. 1...8)



FANUC

► Define the axis which are occupying 1 DSP (usually 1 DSP controls 2 axis except special functions like 125 μ s current loop up to 9090 servo software and Learning Control)
Set the axis requiring 1 DSP to 1.

► Set Cs contouring axis to 1.

► Determine tandem control master and slave axis. Set 1. master to 1. The controlled slave axes is fixed with the next even number 2 in this case. Define additional axis pairs in the same way : master = odd number, slave = next even number.

ACTUAL POSITION 00005 N00000

(ABSOLUTE)

X	89.542
Z	3.447
C	0.000

(MODAL)

G00	G25	G18	F	M
G97	G22		S	
G69	G80		SRPM	0
G99	G67		SSPM	0 T
G21	G54		SMAX	32767
G40	G64		SACT	0

AXIS SETTING

AXIS	NAME	AMP	M1	M2	1-DSP	CS	TNDM
1	X	A1-L	0	0	0	0	1
2	Z	A1-M	0	0	0	0	2
3	C	----	0	0	0	1	0

S 0 T0000

MDI ***** 06:22:33

ABS

REL

ALL

SETTING

CANCEL


INPUT

- Push  in any case if you input setting data or not.

- Turn off/on CNC power

Following this procedure step by step parameter 1023, 1905, 1910-1919, 1936, 1937 will be set automatically. If Parameter No. 1902#1 is set to 1 by CNC automatically after power on the control indicates FSSB setting is completed.

Example 1: Semi closed loop



Please set parameter No. 1023

X : 1 Z : 3
Y : 2 A : 4

Please set the servo initial setting to each axis.

Turn Off/On CNC power

Input AXIS NO. in Amplifier setting screen

AMPLIFIER SETTING						
NO.	AMP	SERIES	UNIT	CUR	AXIS	NAME
1	A1-L	α	SVM	40A	2	Y
2	A2-L	α	SVM	40A	1	X
3	A3-L	α	SVM	40A	4	A
4	A3-M	α	SVM	80A	3	Z
NO. EXTRA TYPE PCB ID						

Please push soft key



FANUC

Push function key

SYSTEM

FSSB screen appears pushing



several times


Push



Setting is completed after turning Off/On of CNC.

FANUC

Example 2: Full closed loop



Please set parameter No. 1023

X : 1 Z : 3
Y : 2 A : 4

Please set the servo initial setting to each axis.

Turn Off/On CNC power

Input AXIS NO. in Amplifier setting screen

AMPLIFIER SETTING						
NO.	AMP	SERIES	UNIT	CUR	AXIS	NAME
1	A1-L	α	SVM	40A	2	Y
2	A2-L	α	SVM	40A	1	X
3	A3-L	α	SVM	40A	4	A
4	A3-M	α	SVM	80A	3	Z
NO. EXTRA TYPE PCB ID						
5	M1	A	0008	DETECTOR(4 AXES)		

FANUC

Please push soft key



Push function key

SYSTEM

FSSB screen appears pushing



several times

Push



AXIS SETTING

	AXIS	NAME	AMP	M1	M2	1DSP	Cs	TNDM
1	X	A2-L	0	0	0	0	0	0
2	Y	A1-L	1	0	0	0	0	0
3	Z	A3-M	0	0	0	0	0	0
4	A	A3-L	2	0	0	0	0	0

>

Please push soft key




Input parameter 1815#1=1 for Y axis and A axis.

Setting is completed after turning Off/On of CNC.

FANUC

Example 3: In case of Cs axis



Please set parameter No. 1023

X : 1 Z : 3 C : -1
Y : 2 A : 4

Please set the servo initial setting to each axis.

Turn Off/On CNC power

Input AXIS NO. in Amplifier setting screen

AMPLIFIER SETTING						
NO.	AMP	SERIES	UNIT	CUR	AXIS	NAME
1	A1-L	α	SVM	40A	2	Y
2	A2-L	α	SVM	40A	1	X
3	A3-L	α	SVM	40A	4	A
4	A3-M	α	SVM	80A	3	Z
NO. EXTRA TYPE PCB ID						

Please push soft key



FANUC

Push function key

SYSTEM

FSSB screen appears pushing



several times

Push



AXIS SETTING

	AXIS	NAME	AMP	M1	M2	1DSP	Cs	TNDM
1	X	A2-L	0	0	0	0	0	0
2	Y	A1-L	0	0	0	0	0	0
3	Z	A3-M	0	0	0	0	0	0
4	A	A3-L	0	0	0	0	0	0
5	C	-- --	0	0	0	1	0	0

>

Please push soft key


SETTING

Setting is completed after turning Off/On of CNC.

FANUC

Example 4: In case of Tandem axis

1st Tandem axes (X-Master axis, A-Slave axis) 2nd Tandem axes (Y-Master axis, B-Slave axis)



Please set parameter No. 1023

X : 1 Z : 5 B : 4
Y : 3 A : 2

Parameter 9900=5

Parameter 1010=3

Option Parameter: Tandem Operation

Parameter 1817#6=1 (for X axis, A axis, Y axis, B axis)

Please set the servo initial setting to each axis.

Turn Off/On CNC power

Input AXIS NO. in Amplifier setting screen

AMPLIFIER SETTING						
NO.	AMP	SERIES	UNIT	CUR	AXIS	NAME
1	A1-L	α	SVM	40A	3	Y
2	A2-L	α	SVM	40A	1	X
3	A3-L	α	SVM	40A	2	A
4	A3-M	α	SVM	80A	5	Z
5	A4-L	α	SVM	40A	4	B
NO. EXTRA TYPE PCB ID						

FANUC

Please push soft key



Push function key

SYSTEM

FSSB screen appears pushing



several times

Push



AXIS SETTING

	AXIS	NAME	AMP	M1	M2	1DSP	Cs	TNDM
1	X	A2-L	0	0	0	0	0	1
2	Y	A1-L	0	0	0	0	0	3
3	Z	A3-M	0	0	0	0	0	0
4	A	A3-L	0	0	0	0	0	2
5	B	A4-L	0	0	0	0	0	4

>

Please push soft key




Setting is completed after turning Off/On of CNC.

Example 5: In case of Tandem compounded with simple synchronous control

1st Tandem axes (X-Master axis, A-Slave axis) 2nd Tandem axes (Y-Master axis, B-Slave axis)

Simple synchronous Master – X-axis, Simple synchronous Slave – Y-axis



Please set parameter No. 1023

X : 1
Y : 3
Z : 5
A : 2
B : 4

Parameter 9900=5

Parameter 1010=3

Option Parameter: Tandem Operation, Simple Synchronous Control

Parameter 1817#6=1 (for X axis, A axis, Y axis, B axis)

Parameter 1815#1=1 (for X axis, Y axis)

Parameter 8311=1 (for Y axis)

Please set servo initial setting for each axis.

Turn Off/On CNC power

FANUC

Input AXIS NO. in Amplifier setting screen

AMPLIFIER SETTING						
NO.	AMP	SERIES	UNIT	CUR	AXIS	NAME
1	A1-L	α	SVM	40A	1	X
2	A1-M	α	SVM	40A	2	A
3	A2-L	α	SVM	40A	3	Y
4	A2-M	α	SVM	40A	4	B
5	A1-L	α	SVM	80A	5	Z
NO.	EXTRA	TYPE	PCB	ID		
6	M1	A	0008	DETECTOR(4 AXES)		

Please push soft key



Push function key

SYSTEM

FSSB screen appears pushing



several times

Push



AXIS SETTING							
AXIS	NAME	AMP	M1	M2	1DSP	Cs	TNDM
1	X	A1-L	1	0	0	0	1
2	Y	A2-L	2	0	0	0	3
3	Z	A3-L	0	0	0	0	0
4	A	A1-M	0	0	0	0	2
5	B	A2-M	0	0	0	0	4
>							

FANUC


Please push soft key



Setting is completed after turning Off/On of CNC.

Example 6: In case of Electrical Gear Box function

EGB work axis: A axis EGB dummy axis: B axis (parameter No.7771=5)



Please set parameter No. 1023

X : 1 Z : 5 B : 4
Y : 2 A : 3

Option Parameter: Electronic Gear Box

Parameter 7771=5

Parameter 7771,7773

Parameter 2011#0=1 (for A axis, B axis)

Please set the servo initial setting to each axis.

Turn Off/On CNC power

Input AXIS NO. in Amplifier setting screen

AMPLIFIER SETTING						
NO.	AMP	SERIES	UNIT	CUR	AXIS	NAME
1	A1-L	α	SVM	40A	2	Y
2	A2-L	α	SVM	40A	1	X
3	A3-L	α	SVM	40A	3	A
4	A3-M	α	SVM	80A	5	Z
NO.	EXTRA	TYPE	PCB	ID		
5	M1	A	0008	DETECTOR(4 AXES)		

FANUC

Please push soft key



Push function key

SYSTEM

FSSB screen appears pushing



several times

Push



AXIS SETTING							
AXIS	NAME	AMP	M1	M2	1DSP	Cs	TNDM
1	X	A2-L	0	0	0	0	0
2	Y	A1-L	0	0	0	0	0
3	Z	A3-M	0	0	0	0	0
4	A	A3-L	0	0	0	0	0
5	B	-- --	1	0	0	0	0
>							


Please push soft key



Setting is completed after turning Off/On of CNC.

FANUC


Example 7: In case of 1CPU dual path and Cs axis



Automatic setting procedure is not available for CNC with 1 CPU dual path.
It's necessary to use manual setting 2. (see example in chapter 3)

FANUC

Example 8: In case of 2CPU dual path and Cs axis (possible from BEF1-04, BOF1-04)



Path 1:

Please set parameter No. 1023

X1 : 1 C: -1
Z 1: 2


Please set the servo initial setting to each axis.


Turn Off/On CNC power

Input AXIS NO. in Amplifier setting screen

AMPLIFIER SETTING						
NO.	AMP	SERIES	UNIT	CUR	AXIS	NAME
1	A1-L	α	SVM	40A	1	X1
2	A1-M	α	SVM	40A	2	Z1
NO. EXTRA TYPE PCB ID						


FANUC

Please push soft key 

Push function key **SYSTEM** FSSB screen appears pushing  several times

Push   

AXIS SETTING							
AXIS	NAME	AMP	M1	M2	1DSP	Cs	TNDM
1	X1	A1-L	0	0	0	0	0
2	Z1	A1-M	0	0	0	0	0
3	C	-- --	0	0	0	1	0
>							

Please push soft key 

FANUC

Path 2:

Please set parameter No. 1023

X2 : 9 Z2 : 10 C2: -1

Please set the servo initial setting to each axis.

Turn Off/On CNC power

Input AXIS NO. in Amplifier setting screen

AMPLIFIER SETTING						
NO.	AMP	SERIES	UNIT	CUR	AXIS	NAME
1	A2-L	α	SVM	40A	11	X2
2	A2-M	α	SVM	40A	12	Z2
NO. EXTRA TYPE PCB ID						

Please push soft key



Push function key

SYSTEM

FSSB screen appears pushing



several times

Push



FANUC

AXIS SETTING							
AXIS	NAME	AMP	M1	M2	1DSP	Cs	TNDM
1	X2	A2-L	0	0	0	0	0
2	Z2	A2-M	0	0	0	0	0
3	C2	-- --	0	0	0	1	0
>							

Please push soft key



2.2. Manual setting 2

Please set the following parameter by hand in order to carry out manual setting 2:

Parameter 1902#0=1, 1902#1=0

Parameter 1023

Parameter 1905

Parameter 1910 ... 1919

Parameter 1936, 1937

No.	7	6	5	4	3	2	1	0
1902							ASIGN	FSBMD

Data type. Bit

FSBMD setting mode selection

0 : Automatic setting mode

(By using of FSSB setting screen, when the information of axis and amplifier have been entered, parameter No. 1023,1905,1910...1919, 1936, 1937 will be set automatically.

1 : Manual setting 2

(Please input parameter No. 1023,1905,1910...1919, 1936, 1937 by hand)

ASIGN Automatic setting of FSSB

0: is not complete

1: is complete

(After automatic setting have been carry out successfully, this bit becomes 1 automatically)

No.	7	6	5	4	3	2	1	0
1905	FSBM2	FSBM1						FSBSL

Data type: Bit

FSBSL Select the interface between servo amplifier and servo software

0 : Fast type

1 : Slow type

The 2 interface types of servo data transfer are related to the execution order of servo data in the internal process. The data for fast axis will be executed first and as the next the data for slow axis, but booth within one processing cycle time.


There is no difference in point of view of performance between fast and slow type.

The following conditions need to be considered while choosing interface type:

- In case of single axis amplifier Fast or Slow type is available
- In case of 2 axes amplifier, fast type can be used for only one axis
Doe not set Fast type for booth axes
Slow type could be set for booth axes.

FANUC

- In case of 3 axes amplifier, the first and the second axis are restricted in the same way like for 2 axes amplifier. For the third axis you can set either fast or slow type.
- Please select fast type for axes, which are set as odd number in parameter 1023.
(In case of EGB, Learning control or high speed current loop, slow type is also available as an exception)
- Please select Slow type for axis, which are set as even number in parameter 1023.



No.

1910	Address conversation table value for Slave1 (ATR)
1911	Address conversation table value for Slave2 (ATR)
1912	Address conversation table value for Slave3 (ATR)
1913	Address conversation table value for Slave4 (ATR)
1914	Address conversation table value for Slave5 (ATR)
1915	Address conversation table value for Slave6 (ATR)
1916	Address conversation table value for Slave7 (ATR)
1917	Address conversation table value for Slave8 (ATR)
1918	Address conversation table value for Slave9 (ATR)
1919	Address conversation table value for Slave10 (ATR)

Data type: bit

Data range: 0...7, 16, 40, 48

Please set the value of address conversation table for slave 1...10

Each device, amplifier or pulse module connected to CNC by optical cable is called "Slave".

The slave order start with 1 (next module after CNC) up to 10.

Two axes amplifier consists of two slaves and three axes has three slaves.

Please set the parameter as follows:

- In case of amplifier:

Set the related value of parameter No. 1023-1

- In case of pulse module:

Please set 16 for first pulse module (near from CNC) and 48 for the second pulse module (far from CNC)

- No slave connected:



Please set 40

In case of using Electrical Gear Box function, please set these parameter as follows:

EGB dummy axis designated in parameter no. 7771 does not require an amplifier.
Don't set not 40 for such EGB dummy axis but the value in parameter No. 1023-1

FANUC

Example of axis configuration and parameter setting:




Note: M1/M2: 1st / 2nd Pulse Module

FANUC


Example of Electrical Gear Box (EGB) function:

(EGB work axis: A axis, EGB dummy axis: B axis parameter No. 7771=5)



Note: M1/M2: 1st / 2nd Pulse Module


Example of 1 CPU dual path with Cs contour control:



Parameter 1902 and 1910 – 1919 have to be set only for Path 1.

FANUC

Example of 2 CPU's dual path with Cs contour control:



FANUC

No.

1936	Connector number of 1 st Pulse Module
1937	Connector number of 2 nd Pulse Module

Data type: byte

Data range: 0...7

In case of Pulse Module, please set connector No. – 1 for each axis.

That means the number of connector 1...8 corresponds to setting 0...7.

The parameter No. 1905#6,#7 have to be set as well.

Please set 0 for connectors, which are not used.


If not all connectors are required, please start the range of connector from connector 1 and continue with connector 2 and so on. With other words it's not possible to use for instance connector 3 without using connector 2.

Example:

Control Axis	1 st Connector No.	2 nd Connector No.	No.1936	No. 1937	No. 1905 (#7,#6)
X	1	Not used	0	0	0,1
Y	Not used	2	0	1	1,0
Z	Not used	1	0	0	1,0
A	Not used	Not used	0	0	0,0
B	2	Not used	1	0	0,1
C	Not used	3	0	2	1,0

FANUC

Example for complete axis configuration and parameter setting using Manual setting 2



No.	1902#0 FSBMD
	1

No.	1910	1911	1912	1913	1914	1915	1916	1917	1918	1919
	0	1	2	3	4	16	5	48	40	40

No.	1023	1905#0 FSBLS	1905#6 FSBM1	1905#7 FSBM2	1936	1937
X	1	0	1	0	0	0
Y	3	0	0	1	0	1
Z	4	1	0	1	0	0
A	2	1	0	0	0	0
B	5	0	1	0	1	0
C	6	1	0	1	0	2

2.3. Manual setting 1

As default for manual setting 1 please set the following parameter:


No. 1902#0=0

No. 1902#1=0

No. 1910...1919 set all to 0

In manual setting 1, the slave No. has to correspond to the value in No. 1023 for each axis.

The axis, set in parameter No. 1023=1 is connected to the first amplifier (first slave) and the axis, set in parameter No. 1023=2 is connected to the second amplifier (second slave).



Please pay attention to the following restrictions:

- Pulse Module is not available by using this setting. That means external position detector is not usable.
- Please set consecutive value in parameter No. 1023. You can not set 3 without setting 2 in No. 1023.
- The following functions are not available:
 - Learning control
 - High speed current loop control
 - Electrical gear box function

3. Troubleshooting and Recovery

Alarm list: Pulse coder

Number of CNC Alarms	Message	Meaning
360	n AXIS : ABNORMAL CHECKSUM (INT)	A checksum error occurred in the built-in pulse coder.
361	n AXIS : ABNORMAL PHASE DATA (INT)	A phase data error occurred in the built-in pulse coder.
362	n AXIS : ABNORMAL REV.DATA (INT)	A rotation speed count error occurred in the built-in pulse coder.
363	n AXIS : ABNORMAL CLOCK (INT)	A clock error occurred in the built-in pulse coder.
364	n AXIS : SOFT PHASE ALARM (INT)	The digital servo software detected invalid data in the built-in pulse coder.
365	n AXIS : BROKEN LED (INT)	An LED error occurred in the built-in pulse coder.
366	n AXIS : PULSE MISS (INT)	A pulse error occurred in the built-in pulse coder.
367	n AXIS : COUNT MISS (INT)	A count error occurred in the built-in pulse coder.
368	n AXIS : SERIAL DATA ERROR (INT)	Communication data from the built-in pulse coder cannot be received.
369	n AXIS : BROKEN LED (EXT) (INT)	A CRC or stop bit error occurred in the communication data being received from the built-in pulse coder.
380	n AXIS : BROKEN LED (EXT)	The separate detector is erroneous.
381	n AXIS : ABNORMAL PHASE (EXT LIN)	A phase data error occurred in the separate linear scale.
382	n AXIS : COUNT MISS (EXT)	A pulse error occurred in the separate detector.
383	n AXIS : PULSE MISS (EXT)	A count error occurred in the separate detector.
384	n AXIS : SOFT PHASE ALARM (EXT)	The digital servo software detected invalid data in the separate detector.
385	n AXIS : SERIAL DATA ERROR (EXT)	Communication data from the separate detector cannot be received.
386	n AXIS : DATA TRANS. ERROR (EXT)	A CRC or stop bit error occurred in the communication data being received from the separate detector.

FANUC

Alarm list: Servo Amplifier

Number of CNC Alarms	Message	Meaning
430	n AXIS : SV. MOTOR OVERHEAT	A servo motor overheat occurred.
431	n AXIS : CNV. OVERLOAD	1) PSM: Overheat occurred. 2) β series SVU: Overheat occurred.
432	n AXIS : CNV. LOWVOLT CON./POWFAULT	1) PSM: Phase missing occurred in the input voltage. 2) PSMR: The control power supply voltage has dropped. 3) α series SVU: The control power supply voltage has dropped.
433	n AXIS : CNV. LOW VOLT DC LINK	1) PSM: The DC link voltage has dropped. 2) PSMR: The DC link voltage has dropped. 3) α series SVU: The DC link voltage has dropped. 4) β series SVU: The DC link voltage has dropped.
436	n AXIS : SOFTTHERMAL (OVC)	The digital servo software detected the soft thermal state (OVC).
438	n AXIS : INV. ABNORMAL CURRENT	1) SVM: The motor current is too high. 2) α series SVU: The motor current is too high. 3) β series SVU: The motor current is too high.
439	n AXIS : CNV. OVERVOLT POWER	1) PSM: The DC link voltage is too high. 2) PSMR: The DC link voltage is too high. 3) α series SVU: The DC link voltage is too high. 4) β series SVU: The link voltage is too high.
440	n AXIS : CNV. EX DECELERATION POWER	1) PSMR: The regenerative discharge amount is too large. 2) α series SVU: The regenerative discharge amount is too large. Alternatively, the regenerative discharge circuit is abnormal.
441	n AXIS : ABNORMAL CURRENT OFFSET	The digital servo software detected an abnormality in the motor current detection circuit. (current feedback)
443	n AXIS : CNV. COOLING FAN FAILURE	1) PSM: The internal stirring fan failed. 2) PSMR: The internal stirring fan failed. 3) β series SVU: The internal stirring fan failed.

FANUC


Number of CNC alarms	Message	Meaning
445	n AXIS : SOFT DISCONNECT ALARM	The digital servo software detected a broken wire in the pulse coder.
446	n AXIS : HARD DISCONNECT ALARM	A broken wire in the built-in pulse coder was detected by hardware.
447	n AXIS : HARD DISCONNECT (EXT)	A broken wire in the separate detector was detected by hardware.
448	n AXIS : UNMATCHED FEEDBACK ALARM	The sign of feedback data from the built-in pulse coder differs from that of feedback data from the separate detector.
460	n AXIS : FSSB DISCONNECT	FSSB communication was disconnected suddenly. The possible causes are as follows: 1) The FSSB communication cable was disconnected or broken. 2) The power to the amplifier was turned off suddenly. 3) A low-voltage alarm has been detected by the amplifier.
461	n AXIS : ILLEGAL AMP INTERFACE	The axes of the 2-axis amplifier were assigned to the fast type interface.
462	n AXIS : SEND CNC DATA FAILED	Because of an FSSB communication error, a slave could not receive correct data.
463	n AXIS : SEND SLAVE DATA FAILED	Because of an FSSB communication error, the servo system could not receive correct data.
464	n AXIS : WRITE ID DATA FAILED	An attempt was made to write maintenance information on the amplifier maintenance screen, but it failed.
465	n AXIS : READ ID DATA FAILED	At power-up, amplifier initial ID information could not be read.
466	n AXIS : MOTOR/AMP COMBINATION	The maximum current rating for the amplifier does not match that for the motor. (Par.: 2165)
467	n AXIS : ILLEGAL SETTING OF AXIS	The servo function for the following has not been enabled when an axis occupying a single DSP (corresponding to two ordinary axes) is specified on the axis setting screen. 1. Learning control (bit 5 of parameter No. 2008 = 1) 2. High-speed current loop (bit 0 of parameter No. 2004 = 1) 3. High-speed interface axis (bit 4 of parameter No. 2005 = 1)

Alarm list: P/S alarm

Number of CNC Alarms	Message	Meaning
5134	FSSB : OPEN READY TIME OUT	Initialization did not place FSSB in the open ready state.
5135	FSSB : ERROR MODE	FSSB has entered error mode.
5136	FSSB : NUMBER OF AMPS IS SMALL	In comparison with the number of controlled axes, the number of amplifiers recognized by FSSB is not enough.
5137	FSSB : CONFIGURATION ERROR	FSSB detected a configuration error.
5138	FSSB : AXIS SETTING NOT COMPLETE	In automatic setting mode, axis setting has not been made yet. Perform axis setting on the FSSB setting screen.
5197	FSSB : OPEN TIME OUT	The CNC permitted FSSB to open, but FSSB was not opened.
5198	FSSB : ID DATA NOT READ	Temporary assignment failed, so amplifier initial ID information could not be read.


4. FSSB setting with 30i-A control

4.1. Hardware configuration



	Control method and maximum number of axes			Connector name	Remarks
	HRV2	HRV3	HRV4		
First FSSB line	16 axes	10 axes	4 axes	COP10A-1	On the servo card
Second FSSB line	8 axes	8 axes	2 axes	COP10A-2	On the servo card
Third FSSB line	8 axes	8 axes	4 axes	COP10A-3	On the additional axis board

new separate detection unit SDU is required



Order specification: A02B-0303-C205 A02B-0236-C204

Maximum No. of SDU's connectable to 1 FSSB line:

Using HRV2/3	→	2 SDU's +2 expansion	→	16 external pulse coder or scales
Using HRV4	→	1 SDU+1expansion	→	8 external pulse coder or scales

Remark: SDU's connected to first or second FSSB line support only axes of first and second FSSB, not axis of third FSSB.
SDU's connected to third FSSB line support axes of third FSSB and not of first or second FSSB.

4.2. FSSB setting methods

Basically the same setting methods as with 16i, 18i, 21i are valid:

- Automatic setting
- Manual setting 1
- Manual setting 2

FANUC


Differences in 30i conventional and new parameter setting:

			CONVENTIONAL	NEW	
FSSB mode parameter			No.14476#0=1	No.14476#0=0	
ATR value for Slave	Basic axis card	Line1	No.1910～1919	No.14340～14357	
		Line2	No.1970～1979	No.14358～14375	
	Additional axis board	Line1	No.14220～14229	No.14408～14425	
ATR value for Separate detector I/F unit	Basic axis card	1st	—	No.14376～14383	
		2nd	—	No.14384～14391	
		3rd	—	No.14392～14399	
		4th		No.14400～14407	
	Additional axis board	1st	—	No.14444～14451	
		2nd	—	No.14452～14459	
Separate detector I/F unit is used		1st	No.1905#6=1	No.1905#6=1	
		2nd	No.1905#7=1	No.1905#7=1	
		3rd	—	No.1905#1=1	
		4th	—	No.1905#2=1	
Connector number of separate detector I/F unit		1st	No.1936	No.1936	
		2nd	No.1937	No.1937	
		3rd	—	No.1938	
		4th	—	No.1939	

Conventional parameter setting is still possible with 90D0 servo software. If HRV4 is required New setting and 90E0 servo software are necessary.


Note: Booth servo software versions can be loaded into 30i. Parameter 14476#1 defines
 14476#1=0 90D0 servo software
 14476#1=1 90E0 servo software

4.2.1. Automatic setting

- set parameter 1902#0=0
- specify on AMP - amplifier setting screen axis connected to each amplifier
- check on 2nd page No. of connected SDU's
- confirm amplifier setting by pushing 



FANUC

- define on AXIS – axis setting page:
 - M1-4: connector number of separate detector interface
 - 1-DSP: if number of high speed current loop axis is limited on 1 DS
(0 – no limitation, 3 – 3axis per DSP→ HRV3, 1 – 1axis per DSP→ HRV4)
 - CS: CS contour controlled axis – displayed Spindle No. is used for interpolation with a servo axis
 - TNDM: setting of tandem controlled axis pairs – odd No. is Tandem master subsequent even No. is defined as appendant slave
- confirm axes setting by pushing 



- Check setting information on MAINTENANCE – amplifier maintenance screen
 - AXIS : Controlled axis number
 - NAME : Controlled axis name
 - AMP : Type of amplifier connected to each axis
 - SERIES : Servo amplifier series of an amplifier connected to each axis (Alpha, Beta)
 - UNIT : Unit type of a servo amplifier connected to each Axis (SVM, SVPM)
 - AXES : Maximum number of axes controlled by an amplifier connected to each axis
 - CUR. : Maximum rating current for amplifiers connected to each axis
 - EDITION : Unit version number of an amplifier connected to each axis
 - TEST : Date of test performed on an amplifier connected to each axis – Example: 030123 = January 23, 2003
 - MAINT-NO. : Engineering change number for an amplifier connected to each axis Setting

ACTUAL POSITION 00123 N00000

ABSOLUTE	
X ₁	0.000
Y ₁	0.000
Z ₁	0.000
B ₁	0.000
X ₂	0.000

HOBAL	
G00 G08 G15 F 10000.00 H	0
G17 G90 G40.1	0
G90 G20 G25 H	0
G22 G07 G100 D	0
G94 G77 G13.1	0
G21 G54 G50.1 I	0
G40 G64 G54.2 S	0
G49.1009 G80.5	0

AMPLIFIER MAINTENANCE					
AXIS	NAME	AMP	SERIES	UNIT	AXES CUR.
1	X1	AS-L	α1	SVM	2 25A
2	Y1	AS-H	α1	SVM	2 25A
3	Z1	AS-L	α1	SVM	2 25A
4	B1	AS-H	α1	SVM	2 25A
5	X2	AS-L	α1	SVM	2 25A
6	Y2	AS-H	α1	SVM	2 25A
7	Z2	AS-L	α1	SVM	2 25A
8	B2	AS-H	α1	SVM	2 25A

001 STOP *** 12:00:00

AMP AXIS MAINT

ACTUAL POSITION 00123 N00000

ABSOLUTE	
X ₁	0.000
Y ₁	0.000
Z ₁	0.000
B ₁	0.000
X ₂	0.000

HOBAL	
G00 G08 G15 F 10000.00 H	0
G17 G90 G40.1	0
G90 G20 G25 H	0
G22 G07 G100 D	0
G94 G77 G13.1	0
G21 G54 G50.1 I	0
G40 G64 G54.2 S	0
G49.1009 G80.5	0

AXIS	NAME	EDITION	TEST	MAINT-NO.
1	X1	SA	000123	4
2	Y1	SA	000123	4
3	Z1	SA	000123	4
4	B1	SA	000123	4
5	X2	SA	000123	4
6	Y2	SA	000123	4
7	Z2	SA	000123	4
8	B2	SA	000123	4

001 STOP *** 12:00:00

AMP AXIS MAINT

4.2.2. Manual setting 2

Please set the following parameter by hand in order to carry out manual setting 2:

Parameter 1902#0=1, 1902#1=0

Parameter 1023

Parameter 1905

Parameter 14340 ... 14407 (14408-14425, 14444-14459 in case additional axis board is used)

Parameter 1936 - 1939

No.	7	6	5	4	3	2	1	0
1902							ASIGN	FSBMD

Data type. Bit

FSBMD setting mode selection

0 : Automatic setting mode

(By using of FSSB setting screen, when the information of axis and amplifier have been entered, parameter No. 1023,1905,1910...1919, 1936, 1937 will be set automatically.

1 : Manual setting 2

(Please input parameter No. 1023,1905,1910...1919, 1936, 1937 by hand)

ASIGN Automatic setting of FSSB

0: is not complete

1: is complete

(After automatic setting have been carry out successfully, this bit becomes 1 automatically)

No.	7	6	5	4	3	2	1	0
1905	PM2	PM1				PM4	PM3	

Data type: Bit

PM3 3rd separate detector interface

0 : is not used

1 : Used

PM4 4th separate detector interface

0 : is not used

1 : Used

PM1 1st separate detector interface

0 : is not used
1 : Used

PM2 2nd separate detector interface

0 : is not used
1 : Used

1936	Connector number of 1 st Pulse Module
1937	Connector number of 2 nd Pulse Module
1938	Connector number of 3 rd Pulse Module
1939	Connector number of 4 th Pulse Module

Data type: byte

Data range: 0...7

In case of Pulse Module, please set connector No. – 1 for each axis.

That means the number of connector 1...8 corresponds to setting 0...7.

The parameter No. 1905 have to be set as well.

Please set 0 for connectors, which are not used.

If not all connectors are required, please start the range of connector from connector 1 and continue with connector 2 and so on. With other words it's not possible to use for instance connector 3 without using connector 2.

Correspondence between connectors and connector numbers	
Connector	Connector number
JF101	0
JF102	1
JF103	2
JF104	3
JF105	4
JF106	5
JF107	6
JF108	7

FANUC

Example of setting)

Controlled axis	Separate detector connection destination				Parameter setting				
	Connectors for 1st unit	Connectors for 2nd unit	Connectors for 3rd unit	Connectors for 4th unit	No. 1936	No. 1937	No. 1938	No. 1939	No.1905 (#7,#6,#2,#1)
X1	JF101	-	-	-	0	-	-	-	0,1,0,0
Y1	-	JF102	-	-	-	1	-	-	1,0,0,0
Z1	-	-	JF102	-	-	-	1	-	0,0,0,1
X2	-	JF101	-	-	-	0	-	-	1,0,0,0
Y2	-	-	-	JF101	-	-	-	0	0,0,1,0
Z2	-	-	-	-	-	-	-	-	0,0,0,0
A1	-	-	JF101	-	-	-	0	-	0,0,0,1
B1	-	-	-	JF102	-	-	-	1	0,0,1,0
C1	-	JF104	-	-	-	3	-	-	1,0,0,0
A2	JF102	-	-	-	1	-	-	-	0,1,0,0
B2	-	JF103	-	-	-	2	-	-	1,0,0,0
C2	-	-	-	JF103	-	-	-	2	0,0,1,0

No.

14340

ATR value corresponding to slave 01 on FSSB line 1

to

14357

ATR value corresponding to slave 18 on FSSB line 1

Data type: bit

Data range: 0...23, 64, -56, -96

Please set the value of address conversion table for slave 1...18

Each device, amplifier or pulse module connected to CNC by optical cable is called "Slave".

The slave order start with 1 (next module after CNC) up to 18.

Two axes amplifier consists of two slaves and three axes has three slaves.

Please set the parameter as follows:

- In case of amplifier:

Set the related value of parameter No. 1023-1

- In case of pulse module:

Please set 64 for first pulse module (near from CNC) and -56 for the second pulse module (far from CNC)



- No slave connected:

Please set -96

In case of using Electrical Gear Box function, please set these parameter as follows:

EGB dummy axis designated in parameter no. 7771 does not require an amplifier.
Don't set not 40 for such EGB dummy axis but the value in parameter No. 1023-1

Example of axis configuration and parameter setting:



No.

14358

ATR value corresponding to slave 01 on FSSB line 2

to

14375

ATR value corresponding to slave 18 on FSSB line 2

Data type: bit

Data range: 0...23, 80, -40, -96

Please set the value of address conversion table for slave 1...18

Each device, amplifier or pulse module connected to CNC by optical cable is called "Slave".

The slave order start with 1 (next module after CNC) up to 18.

Two axes amplifier consists of two slaves and three axes has three slaves.

Please set the parameter as follows:

- In case of amplifier:

Set the related value of parameter No. 1023-1

- In case of pulse module:

Please set 80 for third pulse module (near from CNC) and -40 for the forth pulse module (far from CNC)

- No slave connected:

Please set -96

No.

14376	ATR value corresponding to connector 1 of 1 st separate detector interface unit
to	
14383	ATR value corresponding to connector 8 of 1 st separate detector interface unit
14384	ATR value corresponding to connector 1 of 2 nd separate detector interface unit
to	
14391	ATR value corresponding to connector 8 of 2 nd separate detector interface unit
14392	ATR value corresponding to connector 1 of 3 rd separate detector interface unit
to	
14399	ATR value corresponding to connector 8 of 3 rd separate detector interface unit
14400	ATR value corresponding to connector 1 of 4 th separate detector interface unit
to	
14407	ATR value corresponding to connector 8 of 4 th separate detector interface unit

Data type: bit

Data range: 0...32

Each of these parameters sets the value (ATR value) of the address translation table corresponding to each connector on a separate detector interface unit.

The first and second separate detector interface units are connected to FSSB line 1, and the third and fourth separate detector interface units are connected to FSSB line 2.

In each of these parameters, set a value of parameter No. 1023 –1 for the axis connected to a connector on a separate detector interface unit.

When for an axis separate detector interface unit is not used, set 32 for those connectors.

No.

14408

ATR value corresponding to slave 01 on additional axis board

to

14425

ATR value corresponding to slave 18 on additional axis board

Data type: bit

Data range: 0...23, 64, -56, -96

Please set the value of address conversion table for slave 1...18

Each device, amplifier or pulse module connected to CNC by optical cable is called "Slave".

The slave order start with 1 (next module after CNC) up to 18.

Two axes amplifier consists of two slaves and three axes has three slaves.

Please set the parameter as follows:

- In case of amplifier:

Set the related value of parameter No. 1023-25

- In case of pulse module:

Please set 64 for first pulse module (near from CNC) and -56 for the second pulse module (far from CNC)

- No slave connected:

Please set -96

No.

14444

ATR value corresponding to connector 1 of 1st separate detector interface unit connected to additional axis board

to

14451

ATR value corresponding to connector 8 of 1st separate detector interface unit connected to additional axis board

14452

ATR value corresponding to connector 1 of 2nd separate detector interface unit connected to additional axis board

to

14459

ATR value corresponding to connector 8 of 2nd separate detector interface unit connected to additional axis board

Data type: bit

Data range: 0...32

Each of these parameters sets the value (ATR value) of the address translation table corresponding to each connector on a separate detector interface unit connected to an additional axis board.

The first and second separate detector interface are connected to an additional axis board.

In each of these parameters, set a value of parameter No. 1023 –25 for the axis connected to a connector on a separate detector interface unit.

When for an axis separate detector interface unit is not used, set 32 for those connectors.

Parameter setting example with following configuration:

The number of controlled axes is 32.

For each axis, a separate detector is used.

Servo axis control card FSSB line 1 (16 axes: X1 to Y5)

Three-axis amplifier, three-axis amplifier, three-axis amplifier,
three-axis amplifier, two-axis amplifier, two-axis amplifier,
first pulse module, and second pulse module are connected
in this order.

Servo axis control card FSSB line 2 (8 axes: Z5 to X8)

Three-axis amplifier, three-axis amplifier, two-axis amplifier,
third pulse module, and fourth pulse module
are connected in this order.

Additional axis board FSSB line (8 axes: Y8 to Z10)

Three-axis amplifier, three-axis amplifier, two-axis amplifier,
first pulse module, and second pulse module
are connected in this order.

No.	14340	14341	14342	14343	14344	14345	14346	14347	14348
	0	1	2	3	4	5	6	7	8
No.	14349	14350	14351	14352	14353	14354	14355	14356	14357
	9	10	11	12	13	14	15	64	-56

No.	14358	14359	14360	14361	14362	14363	14364	14365	14366
	16	17	18	19	20	21	22	23	80
No.	14367	14368	14369	14370	14371	14372	14373	14374	14375
	-40	-96	-96	-96	-96	-96	-96	-96	-96

No.	14408	14409	14410	14411	14412	14413	14414	14415	14416
	0	1	2	3	4	5	6	7	64
No.	14417	14418	14419	14420	14421	14422	14423	14424	14425
	-56	-96	-96	-96	-96	-96	-96	-96	-96

FANUC

No.	14376	14377	14378	14379	14380	14381	14382	14383
	0	1	2	3	8	9	10	11
No.	14384	14385	14386	14387	14388	14389	14390	14391
	4	5	6	7	12	13	14	15
No.	14392	14393	14394	14395	14396	14397	14398	14399
	16	17	18	19	32	32	32	32
No.	14400	14401	14402	14403	14404	14405	14406	14407
	20	21	22	23	32	32	32	32
No.	14444	14445	14446	14447	14448	14449	14450	14451
	(0)	(1)	(2)	(3)	32	32	32	32
No.	14452	14453	14454	14455	14456	14457	14458	14459
	(4)	(5)	(6)	(7)	32	32	32	32

No.	1023	1905#6 PM1	1905#7 PM2	1905#1 PM3	1905#2 PM4	1936	1937	1938	1939
X1	1	1	0	0	0	0	-	-	-
Y1	2	1	0	0	0	1	-	-	-
Z1	3	1	0	0	0	2	-	-	-
A1	4	1	0	0	0	3	-	-	-
X2	5	0	1	0	0	-	0	-	-
Y2	6	0	1	0	0	-	1	-	-
Z2	7	0	1	0	0	-	2	-	-
A2	8	0	1	0	0	-	3	-	-
X3	9	1	0	0	0	4	-	-	-
Y3	10	1	0	0	0	5	-	-	-
Z3	11	1	0	0	0	6	-	-	-
X4	12	1	0	0	0	7	-	-	-
Y4	13	0	1	0	0	-	4	-	-
Z4	14	0	1	0	0	-	5	-	-
X5	15	0	1	0	0	-	6	-	-
Y5	16	0	1	0	0	-	7	-	-
Z5	17	0	0	1	0	-	-	0	-
X6	18	0	0	1	0	-	-	1	-
Y6	19	0	0	1	0	-	-	2	-
Z6	20	0	0	1	0	-	-	3	-
X7	21	0	0	0	1	-	-	-	0
Y7	22	0	0	0	1	-	-	-	1
Z7	23	0	0	0	1	-	-	-	2
X8	24	0	0	0	1	-	-	-	3
Y8	25	1	0	0	0	0	-	-	-
Z8	26	1	0	0	0	1	-	-	-
X9	27	1	0	0	0	2	-	-	-
Y9	28	1	0	0	0	3	-	-	-
Z9	29	0	1	0	0	-	0	-	-
X10	30	0	1	0	0	-	1	-	-
Y10	31	0	1	0	0	-	2	-	-
Z10	32	0	1	0	0	-	3	-	-

4.3. Alarm and Messages


Number of CNC Alarms	Message	Meaning
SV0456	ILLEGAL CURRENT LOOP	An attempt was made to set the current loop that could not be set. The amplifier pulse module in use does not comply with HIGH SPEED HRV. Or, requirements to control are not satisfied in the system.
SV0458	CURRENT LOOP ERROR	The specified current loop differs from the actual current loop.
SV0459	HI HRV SETTING ERROR	For two axes whose servo axis numbers (parameter No. 1023) are consecutively even and odd numbers, HIGH SPEED HRV control is possible for one axis and impossible for the other.
SV0460	FSSB DISCONNECT	The FSSB connection was discontinued. Or, the FSSB connection cable was disconnected or broken. The amplifier was turned off . In the amplifier, the low-voltage alarm occurred.
SV0462	SEND CNC DATA FAILED	The correct data could not be received on a slave side because of the FSSB communication error.
SV0463	SEND SLAVE DATA FAILED	The correct data could not be received in the servo software because of the FSSB communication error.
SV0465	READ ID DATA FAILED	A read of the ID information for the amplifier has failed at power-on.
SV0466	MOTOR/AMP. COMBINATION	The maximum current of an amplifier is different to that of a motor. Or, the connection command for an amplifier is incorrect. The parameter setting is incorrect

FANUC

SV0468	HI HRV SETTING ERROR(AMP)	An attempt was made to set up HIGH SPEED HRV control for use when the controlled axis of an amplifier for which HIGH SPEED HRV control could not be used.
SV5134	FSSB:OPEN READY TIME OUT	In the initialization, the FSSB could not be in an open ready state. The axis card is thought to be defective.
SV5136	FSSB:NUMBER OF AMP. IS INSUFFICIENT	The number of amplifier identified by the FSSB is insufficient than the number of control axes. Or, the setting of the number of axes or the amplifier connection is in error.
SV5137	FSSB:CONFIGURATION ERROR	An FSSB configuration error occurred. The connecting amplifier type is incompatible with the FSSB setting value.
SV5138	FSSB:AXIS SETTING NOT COMPLETE	The axis setting has not completed yet, in an automatic setting mode.
SV5139	FSSB:ERROR	The axis setting has not completed yet, in an automatic setting mode.
SV5197	FSSB:OPEN TIME OUT	Servo initialization has not completed successfully. It is probable that an optical cable failed or a connection between the amplifier and another module failed.
SV5311	FSSB:ILLEGAL CONNECTION	1. This alarm is issued if axes, whose servo axis numbers (parameter No. 1023) are even and odd numbers, are allocated to the amplifiers connected to the FSSB's of different paths. 2. This alarm is issued if an attempt is made to set up for use of the pulse modules connected to the FSSB's of different paths. And the system did not satisfy the requirements for performing HIGH SPEED HRV control.

5. FSSB setting with 30i-B control

5.1. Hardware configuration




New: Spindle amplifier can also be connected to FSSB line

Function		30i-A	30i-B	
			Case of automatic parameter setting mode	Case of manual parameter setting mode
Total of servo and spindle axes per one FSSB line	HRV2	16 Note1)	28+4SDU	32 Note 2)
	HRV3	10 Note1)	13+2SDU	15 Note 2)
	HRV4	5 Note1)	6+1SDU	7 Note 2)
Multiple HRV setting on servo card		Not available	Not available	Available

Note 1) Spindle axis is not included.

Note 2) When SDU is used SDU is counted as one axis.

New separate detection unit SDU is required



Order specification: A02B-0323-C205 A02B-0333-C204


FANUC

Controllable axes per one DSP:

HRV2	6
HRV3	4
HRV4	1

Combination of HRV2+3 or HRV4+3 is possible in the servo card with 2 FSSB output.

Example : Servo card with two FSSB line and 6 DSPs controls 4 basic axes in HRV4 mode



Servo Software: 90G0 series

No. of servo axes needs to be defined in **P1023** as follows:

For 6 axes (HRV2):

Axes	Parameter No.1023 Setting value
(1 st axis)	1
(2 nd axis)	2
(2 rd axis)	3
(4 th axis)	4
(5 th axis)	5
(6 th axis)	6

FANUC

For more than 6 axes in HRV2

Axes	Parameter No.1023 Setting value
(1 st axis)	1
(2 nd axis)	2
(3 rd axis)	3
(4 th axis)	4
(5 th axis)	5
(6 th axis)	6
(7 th axis)	9
(8 th axis)	10
(9 th axis)	11
(10 th axis)	12
(11 th axis)	13
(12 th axis)	14
(13 th axis)	17
(14 th axis)	18

Setting in HRV3

Axes	Parameter No.1023 Setting value
(1 st axis)	1
(2 nd axis)	2
(3 rd axis)	3
(4 th axis)	4
(5 th axes)	9
(6 th axes)	10
(7 th axis)	11
(8 th axis)	12
(9 th axis)	17
(10 th axis)	18

Setting in HRV4

Axes	Parameter No.1023 Setting value
(1 st axis)	1
(2 nd axis)	9
(3 rd axis)	17
(4 th axis)	25
(5 th axes)	33
(6 th axes)	41

5.2. FSSB setting methods

Basically the same setting methods as with 16i, 18i, 21i, 30i-A are valid:

- Automatic setting
- Manual setting 1
- Manual setting 2

Differences in 30i-A and 30i-B parameter setting:

			30i-A	30i-B	
ATR value for Slave	Basic axis card	Line1	No.14340~14357		No. 24000~24031
		Line2	No.14358~14375		No. 24032~24063
	Additional axis board	Line1	No.14408~14425		No. 24064~24095
ATR value for Separate detector I/F unit	Basic axis card	1 st	No.14376~14383	1 st	No. 24104~24111
		2 nd	No.14384~14391	2 nd	No. 24112~24119
		3 rd	No.14392~14399	3 rd	No. 24120~24127
		4 th	No.14400~14407	4 th	No. 24128~24135
	Additional axis board	1 st	No.14444~14451	5 th	No. 24136~24143
		2 nd	No.14452~14459	6 th	No. 24144~24151
				7 th	No. 24152~24159
				8 th	No. 24160~24167
				9 th	No. 24168~24175
				10 th	No. 24176~24183
				11 th	No. 24184~24191
				12 th	No. 24192~24199
Separate detector I/F unit is used		1 st	No.1905#6=1		-
		2 nd	No.1905#7=1		-
		3 rd	No.1905#1=1		-
		4 th	No.1905#2=1		-
Connector number of separate detector I/F unit		1 st	No.1936	1 st /9 th	No. 24096
		2 nd	No.1937	2 nd /10 th	No. 24097
		3 rd	No.1938	3 rd /11 th	No. 24098
		4 th	No.1939	4 th /12 th	No. 24099
				5 th	No. 24100
				6 th	No. 24101
				7 th	No. 24102
				8 th	No. 24103
Separate detector for multiple axes					No. 14476#5=1

5.2.1. Automatic setting

- set parameter 1902#0=0
- specify on Servo and Spindle amplifier setting screen axis connected to each amplifier
- select current control Mode HRV2,3,4
- check on 2nd page No. of connected SDU's, Cs contouring and Master/Slave axes
- confirm all setting by pushing

SETTING

ACTUAL POSITION 00123 N00000

ABSOLUTE

X_{M1} 0.0000
X_{S1} 0.0000
Y 0.0000
Z 0.0000
A 0.0000

MODAL

G00 G80 G15 F500.0000 M
G17 G98 G40.1 H M
G90 G50 G25 D M
G22 G67 G160 T
G94 G97 G13.1 S
G21 G54 G50.1
G40 G64 G54.2
G49 G69 G80.5
S 0/MIN

SERVO AMPLIFIER SETTING

HRV 2

NO.	AMP	SERIES	CUR.	AXIS	NAME
1-01	A1-L	α i SV	20A	01	XM1
1-02	A1-M	α i SV	20A	02	XS1
1-03	A1-N	α i SV	20A	03	Y
1-04	A2-L	α i SV	20A	04	Z
1-05	A2-M	α i SV	20A	05	A
1-06	A2-N	α i SV	20A	06	B
2-01	A3-L	β i SV	40A	07	X2
2-02	A3-M	β i SV	40A	08	Y2
2-03	A3-N	β i SV	40A	09	Z2

A>_

MDI ***** 12:00:00 PATH1

SETTING CANCEL INPUT

ACTUAL POSITION 00123 N00000

ABSOLUTE

X_{M1} 0.0000
X_{S1} 0.0000
Y 0.0000
Z 0.0000
A 0.0000

MODAL

G00 G80 G15 F500.0000 M
G17 G98 G40.1 H M
G90 G50 G25 D M
G22 G67 G160 T
G94 G97 G13.1 S
G21 G54 G50.1
G40 G64 G54.2
G49 G69 G80.5
S 0/MIN

SPINDLE AMPLIFIER SETTING

NO.	AMP	SERIES	PWR.	SP NUM	NAME
1-07	B1-1	α i SP	5.5kW	01	SA1
1-08	B2-1	α i SP	5.5kW	02	S2
1-09	B3-1	α i SP	5.5kW	03	S3

A>_

MDI ***** 12:00:00 PATH1

SETTING CANCEL INPUT

FANUC

ACTUAL POSITION 00123 N00000

ABSOLUTE

X_{M1} 0.0000
X_{S1} 0.0000
Y 0.0000
Z 0.0000
A 0.0000

MODAL

G00 G80 G15 F500.0000 M
G17 G98 G40.1 H M
G90 G50 G25 D M
G22 G67 G160 T
G94 G97 G13.1 S
G21 G54 G50.1
G40 G64 G54.2
G49 G69 G80.5
S 0/MIN

AXIS SETTING

AXIS	NAME	AMP	M	CS	M/S
1	XM1	1-A1-L	0	00	00
2	XS1	1-A1-M	0	00	00
3	Y	1-A1-N	0	00	00
4	Z	1-A2-L	0	00	00
5	A	1-A2-M	0	00	00
6	B	1-A2-N	0	00	00
7	X2	2-A3-L	0	00	00
8	Y2	2-A3-M	0	00	00
9	Z2	2-A3-N	0	00	00
10	A2	2-A4-L	0	00	00

A>_

MDI ***** 12:00:00 PATH1

SETTING CANCEL INPUT

Check of FSSB settings:

Connection status screen displays FSSB lines, HRV type, connected Servo/Spindle amplifier, Pulse modules including connector No.

FSSB CONNECT STATUS 00123 N00000

FSSB1(HRV2)

SV(A1 L/M/N)
1-01 XM1 (L)
1-02 XS1 (M)
1-03 Y (N)

SV(A2 L/M/N)
1-04 Z (L)
1-05 A (M)
1-06 B (N)

SP(B1)
1-07 SA1 (L)

SP(B2)
1-08 S2 (L)

SP(B3)
1-09 S3 (L)

PM(M1)
1-10
1 2 3 4
XM1 XS1 Y Z
5 6 7 8
A B

FSSB2(HRV2)

SV(A1 L/M/N)
2-01 X2 (L)
2-02 Y2 (M)
2-03 Z2 (N)

SV(A2 L/M/N)
2-04 A2 (L)
2-05 B2 (M)
2-06 C2 (N)

PM(M1)
2-07
1 2 3 4
A2 B2

FSSB COMMUNICATION NORMAL

A>_

MDI ***** 12:00:00 PATH1

CONNECT STATUS SERVO AMP SPINDLE AMP PULSE MODULE (OPRT) +

FANUC

Separate detector interface unit screen shows FSSB line, No. type and PCB ID of SDU's

ACTUAL POSITION 00123 N00000

ABSOLUTE

X_{M1} 0.0000
X_{S1} 0.0000
Y 0.0000
Z 0.0000
A 0.0000

MODAL

G00 G80 G15 F500.0000 M
G17 G98 G40.1 H M
G90 G50 G25 D M
G22 G67 G160 T
G94 G97 G13.1 S
G21 G54 G50.1
G40 G64 G54.2
G49 G69 G80.5
S 0/MIN

PULSE MODULE

NO.	EXT TYPE	PCB ID
1-10	M1 A	0 "SDU (8AXES)"
2-07	M5 A	8 "SDU (4AXES)"

MDI ***** 12:00:00 PATH1

CONECT STATUS SERVO AMP SPINDLE AMP PULSE MODULE <OPRT> +

Servo and Spindle Maintenance screens are useful for checking Servo/Spindle axes – amplifier configuration, current/power values, axes per amplifier, amplifier specification, version No. and serial No.

ACTUAL POSITION 00123 N00000

ABSOLUTE

X_{M1} 0.0000
X_{S1} 0.0000
Y 0.0000
Z 0.0000
A 0.0000

MODAL

G00 G80 G15 F500.0000 M
G17 G98 G40.1 H M
G90 G50 G25 D M
G22 G67 G160 T
G94 G97 G13.1 S
G21 G54 G50.1
G40 G64 G54.2
G49 G69 G80.5
S 0/MIN

SERVO AMPLIFIER MAINTENANCE

No	NAME	AMP	SERIES	AXES	CUR.	EDIT
1	XM1 1-A1-L	α i SV	3	20A	1A	
2	XS1 1-A1-M	α i SV	3	20A	1A	
3	Y 1-A1-N	α i SV	3	20A	1A	
4	Z 1-A2-L	α i SV	3	20A	1A	
5	A 1-A2-M	α i SV	3	20A	1A	
6	B 1-A2-N	α i SV	3	20A	1A	
7	X2 2-A3-L	β i SV	3	40A	1A	
8	Y2 2-A3-M	β i SV	3	40A	1A	
9	Z2 2-A3-N	β i SV	3	40A	1A	
10	A2 2-A4-L	β i SV	3	40A	1A	
11	B2 2-A4-M	β i SV	3	40A	1A	
12	C2 2-A4-N	β i SV	3	40A	1A	

MDI ***** 12:00:00 PATH1

AXIS SERVO MAINT SPINDLE MAINT +

FANUC

ACTUAL POSITION 00123 N00000

ABSOLUTE	
X _{M1}	0.0000
X _{S1}	0.0000
Y	0.0000
Z	0.0000
A	0.0000

MODAL	
G00 G80 G15	F500.0000 M
G17 G98 G40.1	H M
G90 G50 G25	D M
G22 G67 G160	T
G94 G97 G13.1	S
G21 G54 G50.1	
G40 G64 G54.2	
G49 G69 G80.5	
S	0/MIN

SERVO AMPLIFIER MAINTENANCE		
No	NAME	SPEC NUMBER SERIAL NUMB
1	XM1 A06B-6117-H106#000001	V0123456789
2	XS1 A06B-6117-H106#000001	V0123456789
3	Y A06B-6117-H106#000001	V0123456789
4	Z A06B-6117-H106#000001	V0123456789
5	A A06B-6117-H106#000001	V0123456789
6	B A06B-6117-H106#000001	V0123456789
7	X2 A06B-6117-H106#000001	V0123456789
8	Y2 A06B-6117-H106#000001	V0123456789
9	Z2 A06B-6117-H106#000001	V0123456789
10	A2 A06B-6117-H106#000001	V0123456789
11	B2 A06B-6117-H106#000001	V0123456789
12	C2 A06B-6117-H106#000001	V0123456789

A>_

MDI **** * 12:00:00 PATH1

< ABSOLUTE RELATIVE ALL AXIS SERVO MAINT SPINDLE MAINT +

ACTUAL POSITION 00123 N00000

ABSOLUTE	
X _{M1}	0.0000
X _{S1}	0.0000
Y	0.0000
Z	0.0000
A	0.0000

MODAL	
G00 G80 G15	F500.0000 M
G17 G98 G40.1	H M
G90 G50 G25	D M
G22 G67 G160	T
G94 G97 G13.1	S
G21 G54 G50.1	
G40 G64 G54.2	
G49 G69 G80.5	
S	0/MIN

SPINDLE AMPLIFIER MAINTENANCE					
No	NAME	AMP	SERIES	AXES	PWR. EDIT
1	SA1 1-B1-1	α i	SP	1	5.5kW 1A
2	S2 1-B2-1	α i	SP	1	5.5kW 1A
3	S3 1-B3-1	α i	SP	1	5.5kW 1A

A>_

MDI **** * 12:00:00 PATH1

< ABSOLUTE RELATIVE ALL AXIS SERVO MAINT SPINDLE MAINT +

FANUC

ACTUAL POSITION				00123 N00000																	
ABSOLUTE X _{M1} 0.0000 X _{S1} 0.0000 Y 0.0000 Z 0.0000 A 0.0000				F 0 MM/MIN PARTS COUNT 14 RUN TIME 0H52M49S CYCLE TIME 0H 0M 0S																	
MODAL G00 G80 G15 F500.0000 M G17 G98 G40.1 H M G90 G50 G25 D M G22 G67 G160 T G94 G97 G13.1 S G21 G54 G50.1 G40 G64 G54.2 G49 G69 G80.5 S 0/MIN				SPINDLE AMPLIFIER MAINTENANCE <table border="1"> <thead> <tr> <th>No</th> <th>NAME</th> <th>SPEC NUMBER</th> <th>SERIAL NUMB</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>SA1</td> <td>A06B-6142-H030#580CE</td> <td>V0912345678</td> </tr> <tr> <td>2</td> <td>S2</td> <td>A06B-6142-H030#580CE</td> <td>V0912345678</td> </tr> <tr> <td>3</td> <td>S3</td> <td>A06B-6142-H030#580CE</td> <td>V0912345678</td> </tr> </tbody> </table>		No	NAME	SPEC NUMBER	SERIAL NUMB	1	SA1	A06B-6142-H030#580CE	V0912345678	2	S2	A06B-6142-H030#580CE	V0912345678	3	S3	A06B-6142-H030#580CE	V0912345678
No	NAME	SPEC NUMBER	SERIAL NUMB																		
1	SA1	A06B-6142-H030#580CE	V0912345678																		
2	S2	A06B-6142-H030#580CE	V0912345678																		
3	S3	A06B-6142-H030#580CE	V0912345678																		
A>_				MDI ***** 12:00:00 PATH1																	
< ABSOLUTE	RELATIVE	ALL		AXIS	SERVO MAINTENANCE																
					SPINDLE MAINTENANCE																
					+																

5.2.2. Manual setting 2

Please set the following parameter by hand in order to carry out manual setting 2:

Parameter 1902#0=1, 1902#1=0

Parameter 1023 - No. of Servos

Parameter 2013#0, 2014#0 - HRV3/HRV4

Parameter 3717 – No. of Spindle amplifier

Parameter 24000.... 24063 (24064...24095 in case additional axis board is used) – ATR value for FSSB slave

Parameter 24096.... 24103 – Connector No. of SDU

Parameter 24104.... 24199 – ATR value corresponding to SDU connector

No.	7	6	5	4	3	2	1	0
1902							ASIGN	FSBMD

Data type. Bit

FSBMD setting mode selection

0 : Automatic setting mode

(By using of FSSB setting screen, when the information of axis and amplifier have been entered, parameter No. 1023, 2013#0, 2014#0, 3717, 11802#4, 24000 to 24103 will be set automatically.)

1 : Manual setting 2

(Parameters Nos. 1023, 2013#0, 2014#0, 3717, 11802#4, 24000 to 24103 are to be manually set.)

ASIGN Automatic setting of FSSB

0: is not complete

1: is complete

(After automatic setting have been carry out successfully, this bit becomes 1 automatically)

No.	7	6	5	4	3	2	1	0
14476			SSC					

Data type. Bit

SSC The number of ATR values for a separate detector interface unit connector is:

0: Only 1.

1: More than 1.

No.	
24000	ATR value corresponding to slave 01 on FSSB line 1
to	
24031	ATR value corresponding to slave 32 on FSSB line 1

Data type: word

Data range: 1001 to 1046, 2001 to 2016, 3001 to 3004, 1000



Each of these parameters sets the value (ATR value) of the address translation table corresponding to each of slave 1 to slave 32 on first FSSB line (first optical connector).

A 2-axis amplifier consists of two slaves, and a 3-axis amplifier consists of three slaves. In each of these parameters, set a value as described below, depending on whether the slave is an amplifier, separate detector interface unit, or nonexistent.

- When the slave is a servo amplifier:
Set the axis number of a servo amplifier to allocate (value set with parameter No. 1023) plus 1000.
- When the slave is a spindle amplifier:
Set the spindle number of a spindle to allocate (value set with parameter No. 3717) plus 2000.
- When the slave is a separate detector interface unit:
Set 3001, 3002, 3003, and 3004, respectively, for the first (one connected nearest to the CNC), second, third, and fourth separate detector interface units.
- When the slave is nonexistent:
Set 1000.

FANUC


Typical setting Example:



SV: Servo amplifier
 SP: Spindle amplifier
 M1/M2: First/second separate detector interface units

FANUC

Setting example with dummy axis: (EGB slave axis: A-axis, EGB dummy axis: B-axis)



No.

24032

ATR value corresponding to slave 01 on FSSB line 2

to

24063

ATR value corresponding to slave 32 on FSSB line 2

Data type: word

Data range: 1001 to 1046, 2001 to 2016, 3005 to 3008, 1000

To specify these parameters, follow the same procedure as for the first FSSB line (parameters Nos. 24000 to 24031). Note, however, that the valid data range varies depending on the separate detector interface unit used.

- When the slave is a separate detector interface unit: Set 3005, 3006, 3007, and 3008, respectively, for the first (one connected nearest to the CNC), second, third, and fourth separate detector interface units.

FANUC

No.

24064	ATR value corresponding to slave 01 on FSSB line 3
to	
24095	ATR value corresponding to slave 32 on FSSB line 3

Data type: word

Data range: 1049 to 1078, 2001 to 2016, 3009 to 3012, 1000

To specify these parameters, follow the same procedure as for the first FSSB line (parameters Nos. 24000 to 24031). Note, however, that the valid data range varies depending on the separate detector interface unit used.

- When the slave is a separate detector interface unit: Set 3009, 3010, 3011, and 3012, respectively, for the first (one connected nearest to the CNC), second, third, and fourth separate detector interface units.

No.

24096	Connector number for the first or ninth separate detector interface unit
to	
24097	Connector number for the second or tenth separate detector interface unit
24098	Connector number for the third or eleventh separate detector interface unit
to	
24099	Connector number for the fourth or twelfth separate detector interface unit
24100	Connector number for the fifth separate detector interface unit
to	
24101	Connector number for the sixth separate detector interface unit
24102	Connector number for the seventh separate detector interface unit
to	
24103	Connector number for the eighth separate detector interface unit

Data type: byte axis

Data range: 0...8

Set a connector number for the connector to which a separate detector interface unit is attached if the separate detector interface unit is to be used. The following table lists the necessary settings. Be sure to specify 0 for connectors not in use.

FANUC

Connectors and corresponding connector numbers:

Connector	Connector number
JF101	1
JF102	2
JF103	3
JF104	4
JF105	5
JF106	6
JF107	7
JF108	8

Setting example:

Controlled axis	Connector to which each separate detector interface unit is attached				Parameter setting			
	1st connector	2nd connector	5th connector	6th connector	No. 24096	No. 24097	No. 24100	No. 24101
X1	JF101	-	-	-	1	0	0	0
Y1	-	JF102	-	-	0	2	0	0
Z1	-	-	JF102	-	0	0	2	0
X2	-	JF101	-	-	0	1	0	0
Y2	-	-	-	JF101	0	0	0	1
Z2	-	-	-	-	0	0	0	0
A1	-	-	JF101	-	0	0	1	0
B1	-	-	-	JF102	0	0	0	2
C1	-	JF104	-	-	0	4	0	0
A2	JF102	-	-	-	2	0	0	0
B2	-	JF103	-	-	0	3	0	0
C2	-	-	-	JF103	0	0	0	3

FANUC

No.

24104	ATR value corresponding to connector 1 on the first separate detector interface unit
to	
24111	ATR value corresponding to connector 8 on the first separate detector interface unit
24112	ATR value corresponding to connector 1 on the second separate detector interface unit
to	
24119	ATR value corresponding to connector 8 on the second separate detector interface unit
24120	ATR value corresponding to connector 1 on the third separate detector interface unit
to	
24127	ATR value corresponding to connector 8 on the third separate detector interface unit
24128	ATR value corresponding to connector 1 on the fourth separate detector interface unit
to	
24135	ATR value corresponding to connector 8 on the fourth separate detector interface unit
24136	ATR value corresponding to connector 1 on the fifth separate detector interface unit
to	
24143	ATR value corresponding to connector 8 on the fifth separate detector interface unit
24144	ATR value corresponding to connector 1 on the sixth separate detector interface unit
to	
24151	ATR value corresponding to connector 8 on the sixth separate detector interface unit
24152	ATR value corresponding to connector 1 on the seventh separate detector interface unit
to	
24159	ATR value corresponding to connector 8 on the seventh separate detector interface unit
24160	ATR value corresponding to connector 1 on the eighth separate detector interface unit
to	
24167	ATR value corresponding to connector 8 on the eighth separate detector interface unit

Data type: word

Data range: 1000 to 1046

Each of these parameters sets the value (ATR value) of the address translation table corresponding to each connector on a separate detector interface unit. The first to fourth separate detector interface units are connected to first FSSB line, and the fifth and eighth separate detector interface units are connected to second FSSB line. Specify each parameter with a value set in parameter No. 1023 (axis connected to a separate detector interface unit connector) plus 1000. If a connector attached to a separate detector interface unit is not in use, set 1000 for the connector.

FANUC

24168	ATR value corresponding to connector 1 on the ninth separate detector interface unit
to	
24175	ATR value corresponding to connector 8 on the ninth separate detector interface unit
24176	ATR value corresponding to connector 1 on the tenth separate detector interface unit
to	
24183	ATR value corresponding to connector 8 on the tenth separate detector interface unit
24184	ATR value corresponding to connector 1 on the eleventh separate detector interface unit
to	
24191	ATR value corresponding to connector 8 on the eleventh separate detector interface unit
24192	ATR value corresponding to connector 1 on the twelfth separate detector interface unit
to	
24199	ATR value corresponding to connector 8 on the twelfth separate detector interface unit

Data type: word

Data range: 1049 to 1078, 1000

Set an address translation table value (ATR value) for each separate detector interface unit connector on the third FSSB line. These parameters must be specified when the separate detector interface units are used with an additional axis board. The ninth to twelfth separate detector interface units are connected to third FSSB line. Specify each parameter with a value set in parameter No. 1023 (axis connected to a separate detector interface unit connector) plus 1000. If a connector attached to a separate detector interface unit is not in use, set 1000 for the connector.

Special setting – one connector of SDU for multiple axes

Example: two EGB pairs and common master axis

(EGB slave axis 1 : A axis, EGB dummy axis 1 : C1 axis)

(EGB slave axis 2 : B axis, EGB dummy axis 2 : C2 axis)

No.	14476#5 SSC
	1

No.	1023	24096
X	1	3
Y	2	4
Z	9	0
A	3	0
B	5	0
C1	4	1
C2	6	1

No.	24104	24105	24106	24107	24108	24109	24110	24111
	1004	1006	1001	1002	1000	1000	1000	1000

5.2.3. Setting for dummy axes

Dummy axes definition: No SVM connected but Feedback connected to SDU

P1023 should have value >0, value could be higher than No. of available CNC axes

Initialize Servo axes – P2001#1=1

Parameter P11802#4=0 (disable servo axis) is required for successful initialization, otherwise it may causes alarm SV1067

Keep P11802#4=0 to ensure receiving of feedback information

P2009#0=1 – No FSSB connection of dummy axes

P2165=0 – No amplifier

P240xx=10yy (xx: last slave of FSSB; yy: value of 1023)

P1815#1=1 for external encoder feedback

P24096/97=x (24096 for 1st SDU, 24097 for 2nd SDU; x=number of connector, i.e. JF103 --> x=3)

5.3. Alarm and Warning messages

5.3.1. Automatic setting messages

Warning message	Cause
Cs and M/S are set with the same axis	On the axis setting screen, a value is specified for Cs and M/S for an axis. Do not specify any value for Cs and M/S simultaneously.
Cs and M1-8 are set with the same axis	On the axis setting screen, a value is specified for Cs and M1-8 for an axis. Do not specify any value for Cs and M1-8 simultaneously.
Same number is set in AXIS	On the servo amplifier setting screen, an axis number is set more than once. Specify each axis number only once.
Same number is set in SP NUM	On the spindle amplifier setting screen, a spindle number is set more than once. Specify each spindle number only once.
Same number is set in CS	On the axis setting screen, a value is set for Cs more than once. Specify each value for Cs only once.
Same number is set in M/S	On the axis setting screen, a value is set for M/S more than once. Specify each value for M/S only once.
AXIS and Cs are set with the same axis	An axis number for which a value is set for Cs on the axis setting screen is set for AXIS on the servo amplifier setting screen. Do not set any axis number for which a value is set for Cs, on the servo amplifier setting screen.
Too many slaves (HRV4)	The maximum number (7) of slaves per FSSB line for servo HRV4 control is exceeded. Reduce the number of slaves connected to an FSSB line to 7 or less.
Too many slaves (HRV3)	The maximum number (15) of slaves per FSSB line for servo HRV3 control is exceeded. Reduce the number of slaves connected to an FSSB line to 15 or less.
Too many slaves (HRV2)	The maximum number (32) of slaves per FSSB line for servo HRV2 control is exceeded. Reduce the number of slaves connected to an FSSB line to 32 or less.
M/S is set with HRV4	For servo HRV4 control, a value is set for M/S. Do not set any value for M/S for servo HRV4 control.
AXIS is set with EGB dummy axis	An axis number set for EGB dummy axis setting is set for AXIS on the servo amplifier setting screen. Do not set any axis number for EGB dummy axis setting, on the servo amplifier screen.
M/S setting is illegal(EGB)	For M/S, the EGB slave axis setting corresponding to an EGB dummy axis setting is not made. Make the EGB slave axis setting.
AXIS is not set with EGB slave axis	An axis number for EGB slave axis setting is not set for AXIS on the servo amplifier setting screen. Set the axis number for EGB slave axis setting, on the servo amplifier setting screen.
AXIS is not set with M/S axis	An axis number set for M/S on the axis setting screen is not set for AXIS on the servo amplifier setting screen. Set the axis number for M/S, on the servo amplifier setting screen.
EGB dummy axis setting is illegal	EGB dummy axis setting is made when 32 slaves are connected to the second FSSB line. Decrease the number of slaves connected to the second FSSB line.
M/S setting is illegal	Invalid M/S setting. Correct the M/S setting.
Setting is illegal(servo)	Invalid servo axis setting (servo amplifier setting, axis setting). Correct the servo axis setting.
Setting is illegal(spindle)	Invalid spindle setting. Correct the spindle setting.

5.3.2. Automatic setting messages

Number	Message	Description
SV0456	ILLEGAL CURRENT LOOP	An attempt was made to set the current loop that could not be set. The amplifier pulse module in use does not comply with HIGH SPEED HRV. Or, requirements to control are not satisfied in the system.
SV0458	CURRENT LOOP ERROR	The specified current loop differs from the actual current loop.
SV0459	HI HRV SETTING ERROR	For two axes whose servo axis numbers (parameter No. 1023) are consecutively even and odd numbers, HIGH SPEED HRV control is possible for one axis and impossible for the other.
SV0462	SEND CNC DATA FAILED	The correct data could not be received on a slave side because of the FSSB communication error.
SV0463	SEND SLAVE DATA FAILED	The correct data could not be received in the servo software because of the FSSB communication error.
SV0465	READ ID DATA FAILED	A read of the ID information for the amplifier has failed at power-on.
SV0466	MOTOR/AMP. COMBINATION	The maximum current of an amplifier is different to that of a motor. Or, the connection command for an amplifier is incorrect. The parameter setting is incorrect
SV0468	HI HRV SETTING ERROR(AMP)	An attempt was made to set up HIGH SPEED HRV control for use when the controlled axis of an amplifier for which HIGH SPEED HRV control could not be used.
SV1067	FSSB:CONFIGURATION ERROR(SOFT)	An FSSB configuration error occurred (detected by software). The connected amplifier type is incompatible with the FSSB setting value.
SV5134	FSSB:OPEN READY TIME OUT	In the initialization, the FSSB could not be in an open ready state. The axis card is thought to be defective.
SV5136	FSSB:NUMBER OF AMP. IS INSUFFICIENT	The number of amplifier identified by the FSSB is insufficient than the number of control axes. Or, the setting of the number of axes or the amplifier connection is in error.
SV5137	FSSB:CONFIGURATION ERROR	An FSSB configuration error occurred. The connecting amplifier type is incompatible with the FSSB setting value.
SV5139	FSSB:ERROR	The axis setting has not completed yet, in an automatic setting mode.
SV5197	FSSB:OPEN TIME OUT	Servo initialization has not completed successfully. It is probable that an optical cable failed or a connection between the amplifier and another module failed.
SV5311	FSSB:ILLEGAL CONNECTION	Different current loops (HRV) are set for FSSB lines. Specify the same current loop for the FSSB lines.

Diagnostic screen

3510

FSSB alarm number

Detail alarm No.	Parameter number	Cause	Action
120 451 452	-	The FSSB internal status did not change to open.	Check the connection between the CNC and each amplifier. Alternatively, the servo card may be faulty.
140 450	24000 to 24095	The ATR value is inconsistent with the connected slave (servo, spindle, or separate detector).	Set the ATR value corresponding to the connected slave.
271	3717 24000 to 24095	The spindle amplifier number corresponding to the ATR value setting is not set.	Make the spindle amplifier number consistent with the ATR value setting.
272	24000 to 24031 24064 to 24095	The fifth to eighth separate detector is set for the first FSSB line (third FSSB line).	Do not set the fifth to eighth separate detectors for the first FSSB line (third FSSB line).
273	24032 to 24063	The first to fourth (ninth to twelfth) separate detector is set for the second FSSB line.	Do not set the first to fourth (ninth to twelfth) separate detectors for the second FSSB line.
276	24000 to 24095	The setting for a separate detector is made more than once.	Make the setting for each separate detector only once in the servo card.
290	24000 to 24095	The maximum number of slaves per FSSB line is exceeded for an FSSB line of servo HRV2 control.	Reduce the number of slaves to 32 (maximum number of slaves per FSSB line of servo HRV2 control) or less.
291	24000 to 24095	The maximum number of slaves per FSSB line is exceeded for an FSSB line of servo HRV3 control.	Reduce the number of slaves to 15 (maximum number of slaves per FSSB line of servo HRV3 control) or less.
293	24000 to 24095	The maximum number of slaves per FSSB line is exceeded for an FSSB line of servo HRV4 control.	Reduce the number of slaves to 7 (maximum number of slaves per FSSB line of servo HRV4 control) or less.
310	1023 24104 to 24199	The servo axis number corresponding to the ATR value setting of a separate detector is not set for parameter No. 1023.	Set the value corresponding to the ATR value setting for parameter No. 1023.
313	1023 14476#5 24104 to 24199	The servo axis number corresponding to the ATR value setting of a separate detector is not set for parameter No. 1023.	Set the value corresponding to the ATR value setting for parameter No. 1023.
314	1023 14476#5 24104 to 24199	The ATR value setting of a separate detector is invalid.	Correct the settings of parameters Nos. 24104 to 24199.
383	-	Manual setting 1 cannot be performed when a separate detector is used.	Disconnect the separate detector. Alternatively, perform manual setting or automatic setting.
453	-	Servo initialization has not completed successfully.	An optical cable may be faulty or the connection between the amplifier and another module may be incorrect.
454	-	Alarm No. 550 to 556 of diagnostic data No. 3511 occurred.	Check diagnostic data No. 3511.
460	24000 to 24095	The ATR value of a spindle or separate detector is set for a slave which is not connected.	Set the ATR value corresponding to the connected slave.
471	24000 to 24095	Although a separate detector is connected, the separate detector setting is not made.	Set the value for the separate detector in the corresponding parameter.
480	24000 to 24095	In ATR value setting, a servo axis number exceeds 80.	Make settings so that any servo axis number does not exceed 80.

Diagnostic screen

3511

FSSB alarm number

Detail alarm No.	Parameter number	Cause	Action
210	24096 to 24103	Although a separate detector is not set, a value is set in parameter No. 24096 to 24103.	Set parameter Nos. 24096 to 24103 to all 0.
220	1023	An unavailable servo axis number is set.	Change the servo axis number.
221	1023	A servo axis number is set more than once.	Change the servo axis number.
250	24096 to 24103	For a specific servo axis, two or more separate detectors are used and the paired separate detectors are two of the first, third, fifth, and seventh units or the second, fourth, sixth, and eighth units.	To use two separate detectors for a specific servo axis, one separate detector must have an odd number and the other must have an even number. Three or more separate detectors cannot be used.
270	1023 24000 to 24095	<ul style="list-style-type: none"> The servo axis number corresponding to the ATR value setting is not set for parameter No. 1023. An unavailable servo axis number is set. A servo axis number is set more than once. 	Check the conditions on the left.
292	1023 2013#0	For an FSSB line of servo HRV3 control, only the following servo axis numbers can be used: (1 + 8n, 2 + 8n, 3 + 8n, 4 + 8n (n = 0, 1, ..., 9))	For the FSSB line of servo HRV3 control, set the servo axis numbers on the left.
294	1023 2014#0	For an FSSB line of servo HRV3 control, only the following servo axis numbers can be used: (1+8n(n=0,1,...,9))	For the FSSB line of servo HRV3 control, set the servo axis numbers on the left.
311	24096 to 24103	A connector number is invalid.	Specify a value between 0 and 8.
314	24096 to 24103	A connector number is set more than once.	Make setting so that each connector number is used only once for one separate detector.
350	2013#0 2014#0	Different current loops (HRV) are used for FSSB lines.	Set the same current loop (HRV) for the FSSB lines.
360	1023 2013#0 2014#0	Different current loops (HRV) are set for the first and second FSSB lines and parameter No. 1023 setting is invalid.	Set servo axis numbers so that each set of (1 to 6), (9 to 14), (17 to 22), (25 to 30), (33 to 38), and (41 to 46) is set for the same FSSB line.
370	1902#0 1902#1 2013#0 2014#0	When servo HRV3 or HRV4 control is set, manual setting 1 cannot be performed.	To set servo HRV3 or HRV4 control, perform manual setting or automatic setting.
380	1023	When a servo axis number is skipped, manual setting 1 cannot be performed.	Set servo axis numbers without skipping any number.

FANUC

Detail alarm No.	Parameter number	Cause	Action
382	1023	An attempt was made to perform manual setting 1 though the maximum number of controlled axes per FSSB line is exceeded.	Reduce the number of connected servo axes to the maximum number of controlled axes or less.
470	24000 to 24095	An ATR value is set more than once.	Set each ATR value only once.
481	1023 24000 to 24095	A servo axis number is inconsistent with the ATR value setting or the servo motor having a servo axis number is not connected.	Check whether the value set in parameter No. 1023 is consistent with ATR value setting and whether the servo motor corresponding to each servo axis number is connected.
520	2165	At power-on, amplifier ID information could not be read.	Check the connection between the CNC and each amplifier. Alternatively, an amplifier may be faulty.
550	1023 24000 to 24095	The ATR value setting is inconsistent with the servo axis number setting.	Make the value set in parameter No. 1023 consistent with the ATR value setting.
551	24000 to 24095	The number of ATR value settings exceeds the number of slaves connected to the CNC.	Make as many settings as the number of slaves connected to the CNC.
552	1023	An unavailable servo axis number is set.	Change the servo axis number.
553	1023	A servo axis number is set more than once.	Change the servo axis number.
554	24096 to 24103	A value is set in parameter No. 24096 to 24103 though no separate detector is connected.	Set parameters Nos. 24096 to 24103 to all 0.
555 557 558	2165	The maximum current of an amplifier (parameter No. 2165) differs from that of a motor.	Set the maximum current of the amplifier (parameter No. 2165) to that of the motor.
1023	1023	An invalid servo axis number is set.	Set a correct servo axis number.

Diagnostic screen

3513	FSSB alarm number (spindle)
------	-----------------------------

Detail alarm No.	Parameter number	Cause	Action
271	3717 24000 to 24095	An ATR value is set more than once.	Make each spindle amplifier consistent with the ATR value setting.
381	3717	When a spindle amplifier number is skipped, manual setting 1 cannot be performed.	Set spindle amplifier numbers without skipping any number.