

460. Used to deliver water at a point higher than the position of the pump itself when the plunger descends, the valve is closed and the water in the cylinder is forced out through the valve and up to the storage.

(a) Pumps

(c) Lift pump

(b) Force pump

(d) Suction pipe



460. Used to deliver water at a point higher than the position of the pump itself when the plunger descends, the valve is closed and the water in the cylinder is forced out through the valve and up to the storage.

(a) Pumps

(b) Force pump

(c) Lift pump

(d) Suction pipe

