

206. Located at the lower end of the pump used to prevent loss of priming the pump?

(a) Foot valve

(c) Angle valve

(b) Gate valve

(d) Globe valve



206. Located at the lower end of the pump used to prevent loss of priming the pump?

(a) Foot valve

(b) Gate valve

(c) Angle valve

(d) Globe valve

