

170. What is the purpose of an air gap in a water distribution system?

- (a) Dampens the shock wave created inside the water distribution piping
- (b) Ensures that water will not rise in the fixture into the water supply outlet
- (c) Prevent domestic water in the building from flowing backward and returning to the pipe main.
- (d) Guards against siphonage



170. What is the purpose of an air gap in a water distribution system?

- (a) Dampens the shock wave created inside the water distribution piping
- (b) Ensures that water will not rise in the fixture into the water supply outlet
- (c) Prevent domestic water in the building from flowing backward and returning to the pipe main.
- (d) Guards against siphonage

