

## DULCOMETER, Compact Controller

Measured variable: conductive conductivity

EN



Please carefully read these operating instructions before use. · Do not discard.  
The operator shall be liable for any damage caused by installation or operating errors.  
The latest version of the operating instructions are available on our homepage.

General non-discriminatory approach

In order to make it easier to read, this document uses the male form in grammatical structures but with an implied neutral sense. It is aimed equally at both men and women. We kindly ask female readers for their understanding in this simplification of the text.

Supplementary information


Please read the supplementary information in its entirety.

Information







*This provides important information relating to the correct operation of the unit or is intended to make your work easier.*

Safety Information

The safety information includes detailed descriptions of the hazardous situation, see  *Chapter 3.1 'Explanation of the safety information' on page 10*

The following symbols are used to highlight instructions, links, lists, results and other elements in this document:

Tab. 1: More symbols

Symbol	Description
1. 	Action, step by step
	Outcome of an action
	Links to elements or sections of these instructions or other applicable documents
	List without set order
[Button]	Display element (e.g. indicators) Operating element (e.g. button, switch)
'Display /GUI'	Screen elements (e.g. buttons, assignment of function keys)
CODE	Presentation of software elements and/or texts

# Table of contents

<b>1</b>	<b>Identity code</b> .....	<b>6</b>
<b>2</b>	<b>Introduction</b> .....	<b>8</b>
	2.1 Measured variables.....	8
<b>3</b>	<b>Safety and Responsibility</b> .....	<b>10</b>
	3.1 Explanation of the safety information.....	10
	3.2 General Safety Information.....	11
	3.3 Intended Use.....	13
	3.4 Users' qualifications.....	14
<b>4</b>	<b>Functional description</b> .....	<b>16</b>
<b>5</b>	<b>Assembly and installation</b> .....	<b>17</b>
	5.1 Scope of delivery.....	18
	5.2 Mounting (mechanical).....	18
	5.2.1 Wall mounting.....	18
	5.2.2 Pipe mounting.....	20
	5.2.3 Control panel mounting.....	21
	5.3 Installation (electrical).....	29
	5.3.1 Cable Cross-Sections and Cable End Sleeves.....	30
	5.3.2 Electrical connection of the conductivity sensor.....	30
	5.3.3 Terminal diagram / wiring.....	31
	5.3.4 Installation (electrical).....	37
	5.4 Switching of inductive loads.....	38
<b>6</b>	<b>Sensor connection</b> .....	<b>40</b>
<b>7</b>	<b>Commissioning</b> .....	<b>43</b>
	7.1 Initial commissioning.....	43
	7.2 Setting the control during commissioning.....	43
	7.3 Selecting the sensor type .....	44
	7.4 Temperature compensation and reference temperature.....	47
<b>8</b>	<b>Operating diagram</b> .....	<b>49</b>
	8.1 Overview of equipment/Operating elements.....	49
	8.2 Entering values.....	50
	8.3 Adjusting display contrast.....	51
	8.4 Continuous display.....	52
	8.5 Information display.....	53

---

## Table of contents

---

8.6	Password.....	54
<b>9</b>	<b>Operating menus .....</b>	<b>55</b>
9.1	Calibrating <i>[CAL]</i> the conductivity sensor .....	55
9.1.1	Calibration of the cell constant.....	57
9.1.2	Calibration of the temperature coefficient.....	60
9.2	Setting limit values <i>[LIMITS]</i> .....	63
9.3	Setting the control <i>[CONTROL]</i> .....	66
9.4	Setting inputs <i>[INPUT]</i> .....	69
9.5	Setting outputs <i>[OUTPUT]</i> .....	73
9.6	Setting the <i>[DEVICE]</i> .....	77
<b>10</b>	<b>Control parameters and functions.....</b>	<b>78</b>
10.1	DULCOMETER® Compact Controller function states .....	78
10.2	<i>[STOP/START]</i> key.....	80
10.3	Priming <i>[PRIME]</i> .....	81
10.4	Hysteresis limit value.....	82
10.5	Temperature correction variable.....	83
10.6	Checkout time for measured variable and correction variable.....	84
10.7	Checkout time control.....	84
10.8	Power relay "P-REL" as limit value relay.....	85
10.9	Setting and functional description of "Relay Used as a Solenoid Valve" ..	86
10.10	Alarm relay.....	88
10.11	"Error logger" operating mode.....	88
<b>11</b>	<b>Maintenance.....</b>	<b>89</b>
11.1	Error messages .....	89
11.2	Changing the fuse, DULCOMETER® Compact Controller.....	93
<b>12</b>	<b>Technical data on DULCOMETER® Compact Controller.....</b>	<b>94</b>
12.1	Permissible ambient conditions.....	94
12.2	Dimensions and weights.....	94
12.3	Material data.....	95
12.4	Chemical Resistance.....	95
12.5	Sound Pressure Level.....	95
<b>13</b>	<b>Electrical data.....</b>	<b>96</b>
<b>14</b>	<b>Spare parts and accessories.....</b>	<b>100</b>

<b>15</b>	<b>Replacing spare part units .....</b>	<b>101</b>
15.1	Replacing the top part of the housing.....	101
15.2	Replacing the lower part of the housing (wall/tube retaining bracket).....	103
15.3	Replacing the lower part of the housing (control panel installation).....	105
<b>16</b>	<b>Standards complied with and Declaration of Conformity.....</b>	<b>109</b>
<b>17</b>	<b>Disposal of Used Parts.....</b>	<b>110</b>
<b>18</b>	<b>Glossary.....</b>	<b>111</b>
<b>19</b>	<b>Index.....</b>	<b>112</b>

## 1 Identity code

DCCa	DULCOMETER® Compact,									
	Mounting type									
	E	Spare part units								
	W	Wall/pipe mounting IP 67								
	S	With fitting kit for control panel mounting IP 54								
		Design								
		00	With ProMinent® logo							
		E1	Spare part unit, controller housing lower part (processor/PCB), fully assembled							
		E2	Spare part unit, controller housing top part (processor/PCB), fully assembled							
			Operating voltage							
			6	90 ... 253 V, 48/63 Hz						
				Measured variable						
				C0	Free chlorine					
				NG	pH/ORP (switchable)					
				L3	Conductive conductivity (designation: COND_C)					
				L6	Inductive conductivity (designation: COND_I)					
					Hardware extension					
					0	None				
					Approvals					
					01	CE (Standard)				
						Certificates				
						0	None			
							Operating instructions language			
							EN	German	KR	Korean

DCCa	DULCOMETER® Compact,									
							EN	English	LT	Lithuanian
							ES	Spanish	LV	Latvian
							IT	Italian	NL	Dutch
							FR	French	PL	Polish
							FI	Finish	PT	Portuguese
							BG	Bulgarian	RO	Romanian
							ZH	Chinese	SV	Swedish
							CZ	Czech	SK	Slovakian
							EL	Greek	SL	Slovenian
							HU	Hungarian	RU	Russian
							YES	Japanese	TH	Thai

## 2 Introduction

### Data and functions


These operating instructions describe the technical data and functions of the DULCOMETER® Compact Controller, measured variable: conductive conductivity.

### 2.1 Measured variables

The controller can process the following measured variables:

- Conductive conductivity [*ConC*]
- Resistance [*RES*]
- TDS value [*TDS*]
- Salinity [*SAL*]

#### Switching between measured variables

Use the  key to switch between the controller's measured variables [*ConC*], [*RES*], [*TDS*] and [*SAL*] in the continuous display.

Depending on the measured variable set, the settings of variables are changed or the variables are hidden completely in the [*INPUT* ➤ *TCOMP*] menu and in the [*LIMIT*] menu.

#### Measured variable: conductive conductivity [*ConC*]

Symbol displayed in the controller's display: [*ConC*]

Units of measurement:  $\mu\text{S/cm}$ ,  $\text{mS/cm}$ ,  $\text{S/cm}$ . The measuring range is automatically detected and switched by the controller.

Physical variable: specific electrical conductivity (K). Only this measured variable is emitted at the mA output, independently of the measured variable set on the controller. The setting of the measured variable on the controller only affects the layout of the display and not the output at the mA output.

#### Measured variable: Resistance [*RES*]

Symbol displayed in the controller's display: [*RES*]

Units of measurement:  $\text{M}\Omega\text{cm}$ ,  $\text{k}\Omega\text{cm}$ ,  $\Omega\text{cm}$ , measuring range is automatically detected and switched by the controller

Physical variable: specific electrical resistance.

Calculating the specific resistance:  $\rho (T_{\text{ref}}) = 1/K (T_{\text{ref}})$



**Measured variable: TDS value**

Symbol displayed in the controller's display: *[TDS]* (total dissolved solids)

Unit of measurement: ppm (mg/l)

Physical variable: Total of all inorganic and organic substances dissolved in a solvent

Display range: 0 .... 2000 ppm

Temperature range: 0 ... 35 °C

*[TLIMIT↑]:* ≤ 40 °C

Setting the TDS value displayed: You can set a multiplicative factor *[TDS]* in the *[INPUT]* menu, with which the TDS value displayed can be changed.

Displayed TDS value *[ppm]* = K (25 °C) *[uS/cm]* \* TDS factor

Setting range of TDS factor: 0.400 ... 1.000 (Default: 0.640)

Temperature compensation is always linear with the TDS display with a reference temperature of 25 °C .

**Measured variable: Salinity (SAL)**

Symbol displayed in the controller's display: *[SAL]* units: ‰ (g/kg)

Physical variable: Mass of salts in a kg of water given in PSU (practical salinity units).

The salinity is derived from the conductivity measured, with a specified non-linear temperature compensation and a reference conductivity (KCL).

Display range: 0 .... 70.0 ‰

Temperature range: 0 ... 35 °C

*[TLIMIT↑]:* ≤ 35 °C

The salinity *[SAL]* is calculated based on the *[Practical Salinity Scale 1978 (PSS-78)]*

### 3 Safety and Responsibility

#### 3.1 Explanation of the safety information

##### Introduction

These operating instructions provide information on the technical data and functions of the product. These operating instructions provide detailed safety information and are provided as clear step-by-step instructions.

The safety information and notes are categorised according to the following scheme. A number of different symbols are used to denote different situations. The symbols shown here serve only as examples.



##### **DANGER!**

###### **Nature and source of the danger**

Consequence: Fatal or very serious injuries.

Measure to be taken to avoid this danger

**Danger!**

- Denotes an immediate threatening danger. If this is disregarded, it will result in fatal or very serious injuries.



##### **WARNING!**

###### **Nature and source of the danger**

Possible consequence: Fatal or very serious injuries.

Measure to be taken to avoid this danger

**Warning!**

- Denotes a possibly hazardous situation. If this is disregarded, it could result in fatal or very serious injuries.



##### **CAUTION!**

###### **Nature and source of the danger**

Possible consequence: Slight or minor injuries, material damage.

Measure to be taken to avoid this danger

**Caution!**

- Denotes a possibly hazardous situation. If this is disregarded, it could result in slight or minor injuries. May also be used as a warning about material damage.

### **! NOTICE!**

#### **Nature and source of the danger**

Damage to the product or its surroundings

Measure to be taken to avoid this danger

Note!

- Denotes a possibly damaging situation. If this is disregarded, the product or an object in its vicinity could be damaged.



#### **Type of information**

*Hints on use and additional information*

*Source of the information, additional measures*

*Information!*

- *Denotes hints on use and other useful information. It does not indicate a hazardous or damaging situation.*

## 3.2 General Safety Information



### **WARNING!**

#### **Live parts!**

Possible consequence: Fatal or very serious injuries

- Measure: Disconnect the mains power supply prior to opening the housing
- De-energise damaged, defective or manipulated units by disconnecting the mains plug



### **WARNING!**

#### **Unauthorised access!**

Possible consequence: Fatal or very serious injuries

- Measure: Ensure that there can be no unauthorised access to the unit



### **WARNING!**

#### **Operating errors!**

Possible consequence: Fatal or very serious injuries

- The unit should only be operated by adequately qualified and technically expert personnel
- Please also observe the operating instructions for controllers and fittings and any other component groups, such as sensors, measuring water pumps ...
- The operator is responsible for ensuring that personnel are qualified



### **CAUTION!**

#### **Electronic malfunctions**

Possible consequence: Material damage to destruction of the unit

- The mains connection cable and data cable should not be laid together with cables that are prone to interference
- Measure: Take appropriate interference suppression measures



### **NOTICE!**

#### **Correct and proper use**

Damage to the product or its surroundings

- The unit is not intended to measure or regulate gaseous or solid media
- The unit may only be used in accordance with the technical details and specifications provided in these operating instructions and in the operating instructions for the individual components



### **NOTICE!**

#### **Correct sensor operation / Run-in time**

Damage to the product or its surroundings

- Correct measuring and dosing is only possible if the sensor is working perfectly
- It is imperative that the run-in times of the sensors are adhered to
- The run-in times should be allowed for when planning initial operation
- It may take a whole working day to run-in the sensor
- Please read the operating instructions for the sensor

**! NOTICE!****Correct sensor operation**

Damage to the product or its surroundings

- Correct measuring and dosing is only possible if the sensor is working perfectly
- Check and calibrate the sensor regularly

**! NOTICE!****Compensation of control deviations**

Damage to the product or its surroundings

- This controller cannot be used in control circuits which require rapid compensation ( $< 30$  s)

### 3.3 Intended Use

**! NOTICE!****Intended Use**

The device is designed to measure and regulate liquid media. The designated measured variable is detailed on the controller and is absolutely binding.

The unit should only be used in accordance with the technical data and specifications provided in these operating instructions and in the operating instructions for the individual components (such as sensors, fittings, calibration devices, metering pumps etc.).

Any other uses or modifications are prohibited.

**! NOTICE!****Compensation for control deviations**

Damage to the product or its surroundings

- The controller can be used in processes, which require compensation of  $> 30$  seconds

### 3.4 Users' qualifications



#### **WARNING!**

**Danger of injury with inadequately qualified personnel!**

**The operator of the plant / device is responsible for ensuring that the qualifications are fulfilled.**

If inadequately qualified personnel work on the unit or loiter in the hazard zone of the unit, this could result in dangers that could cause serious injuries and material damage.

- All work on the unit should therefore only be conducted by qualified personnel.
- Unqualified personnel should be kept away from the hazard zone

Training	Definition
Instructed personnel	An instructed person is deemed to be a person who has been instructed and, if required, trained in the tasks assigned to him/her and possible dangers that could result from improper behaviour, as well as having been instructed in the required protective equipment and protective measures.
Trained user	A trained user is a person who fulfils the requirements made of an instructed person and who has also received additional training specific to the system from ProMinent or another authorised distribution partner.
Trained qualified personnel	A qualified employee is deemed to be a person who is able to assess the tasks assigned to him and recognize possible hazards based on his/her training, knowledge and experience, as well as knowledge of pertinent regulations. The assessment of a person's technical training can also be based on several years of work in the relevant field.

Training	Definition
Electrician	<p>Electricians are deemed to be people, who are able to complete work on electrical systems and recognize and avoid possible hazards independently based on his/her technical training and experience, as well as knowledge of pertinent standards and regulations.</p> <p>Electricians should be specifically trained for the working environment in which they are employed and know the relevant standards and regulations.</p> <p>Electricians must comply with the provisions of the applicable statutory directives on accident prevention.</p>
Customer Service department	<p>Customer Service department refers to service technicians, who have received proven training and have been authorised by ProMinent to work on the system.</p>

***Note for the system operator***

*The pertinent accident prevention regulations, as well as all other generally acknowledged safety regulations, must be adhered to!*

## 4 Functional description

### Brief functional description

The controller for the measured variable conductive conductivity provides the basic functions for water treatment applications. The controller has a fixed configuration with the following features:

- Language-independent operation.  
Use of abbreviations, such as:
  - *[INPUT]*
  - *[OUTPUT]*
  - *[CONTROL]*
  - *[ERROR]*
- Illuminated display
- 3 LEDs indicate the operating statuses:
  - *[f-REL]*, active
  - *[P-REL]*, active
  - Error
- Control characteristics:
  - P, or
  - PID
- Selectable control direction:
  - Raise measured value, or
  - Lower measured value
- Pulse frequency relay *[f-REL]* for control of the metering pump
- Output relay *[P-REL]*, configurable as:
  - Alarm
  - Limit value
  - Pulse width-modulated (PWM) control output for metering pumps
- Analog output 0/4...20 mA, configurable:
  - Measured value (conductivity only), or
  - Correction variable
- Suction function for all actuators



- Digital input to switch off the controller or to process a sample water limit contact by remote control
- Temperature sensor input (Pt100 or Pt 1000) for temperature compensation
- Degree of protection
  - IP67 (wall / pipe mounting)
  - IP54 (control panel mounting)

### Applications:

- Bleeding of for example air scrubbers and chillers
- General water treatment, for instance the monitoring of rinsing baths



## 5 Assembly and installation

- **User qualification, mechanical installation:** trained qualified personnel, see  *Chapter 3.4 'Users' qualifications' on page 14*
- **User qualification, electrical installation:** Electrical technician, see  *Chapter 3.4 'Users' qualifications' on page 14*



### CAUTION!

Possible consequence: Material damage.

The hinge between the front and rear part of the housing cannot absorb high levels of mechanical loading. When working on the controller, hold the top part of the controller housing firmly.



### NOTICE!

#### Mounting position and conditions

- Only carry out the (electrical) installation after the (mechanical) installation
- Ensure that there is unimpeded access for operation
- Ensure safe and low-vibration fixing
- Avoid direct sunlight
- Permissible ambient temperature of the controller at the installation site: - 10 ... 60 °C at max. 95% relative air humidity (non-condensing)
- Take into consideration the permissible ambient temperature of the sensors connected and other components



#### *Read-off and operating position*

- *Install the device in a favourable position for reading and operating (preferably at eye level)*




#### *Mounting position*

- *Leave sufficient clearance for the cables*



#### *Packaging material*

*Dispose of packaging material in an environmentally responsible way. All packaging components carry the corresponding recycling code .*

### 5.1 Scope of delivery

The following parts belong to the standard scope of delivery of a DULCOMETER® Compact Controller.

Description	Quantity
Assembled device	1
Cable connection set DMTa/DXMa (metr.)	1
Operating instructions	1


### 5.2 Mounting (mechanical)

The DULCOMETER® Compact Controller is suitable for mounting on a wall, pipe or control panel.

*Tab. 2: Mounting materials (contained in the scope of supply):*


Description	Quantity
Wall/tube retaining bracket	1
Round head screws 5x45 mm	2
Washer 5.3	2
Rawlplug Ø 8 mm, plastic	2

#### 5.2.1 Wall mounting Mounting (mechanical)



*Fig. 1: Removing the wall/pipe bracket*

1. ➤ Remove the wall/pipe bracket. Pull the two snap-hooks (1) outwards and push upwards
2. ➤ Fold out the wall/pipe bracket (2) and pull out in a downwards direction
3. ➤ Mark two drill holes diagonal to each other by using the wall/pipe bracket as a drilling template
4. ➤ Drill holes:  $\varnothing$  8 mm, d = 50 mm



*Fig. 2: Screwing on the wall/pipe bracket using washers*

5. ➤ Screw on the wall/pipe bracket using the washers
6. ➤ Suspend the DULCOMETER® Compact Controller at the top in the wall/pipe bracket and push using light pressure at the bottom against the wall/pipe bracket. Then press upwards until the DULCOMETER® Compact Controller audibly snaps into position.

### 5.2.2 Pipe mounting

#### Mounting (mechanical)



#### Pipe diameter

Pipe diameter: 25 mm to 60 mm.




Fig. 3: Removing the wall/pipe bracket

1. Remove the wall/pipe bracket. Pull the two snap-hooks (1) outwards and push upwards
2. Fold out the wall/pipe bracket (2) and pull out in a downwards direction
3. Secure the wall/pipe bracket using cable ties (or pipe clips) to the pipe




Fig. 4: Suspend and secure the DULCOMETER® Compact Controller

4. Suspend the DULCOMETER® Compact Controller at the top (1) in the wall/pipe bracket and push using light pressure at the bottom (2) against the wall/pipe bracket. Then press upwards (3) until the DULCOMETER® Compact Controller audibly snaps into position

### 5.2.3 Control panel mounting

*Tab. 3: Mounting kit for control panel installation of the DULCOMETER® Compact Controller: Order number 1037273*

Description	Quantity
Drilling template sheet 3872-4	1
PT screw (3.5 x 22)	3
Profile seals	2
Strain relief strip DF3/DF4	1
PT screw (3.5 x 10)	2
Individual parts packed in transparent cover / Mounting kit is not contained in the standard scope of supply	



#### CAUTION!

##### Material thickness of control panel

Possible consequence: material damage

- The thickness of the material of the control panel should be at least 2 mm to ensure secure fixing



*In the mounted state, the DULCOMETER® Compact Controller extends approx. 30 mm from the control panel.*

## Preparing the control panel




Fig. 5: The drawing is not to scale and is intended for information purposes only.

I. Outline contour of the DULCOMETER® Compact Controller housing

1. ➤ Mark the exact position of the DULCOMETER® Compact Controller on the control panel using the drilling template

2. ➤



### **Core hole**

*Adhere to the 3.5 mm Ø as the core hole diameter for screwing in the fixing bolts.*

Drill four holes for the bolts for the top section of the controller housing using a 3.5 mm Ø drill bit


3. ➤ Drill three holes for the bolts for the bottom section of the controller housing using a 4.5 mm Ø drill bit

4. ➤ Drill four holes using an 8 mm Ø drill bit and use a jigsaw to cut the cut-out

⇒ Deburr all the edges.








A0350


*Fig. 7: Dismantle the hinge*

- 4.** ➔ Remove the screw (2), unclip the hinge (1) on the bottom section of the controller housing (arrows) and remove the hinge



*Fig. 8: Fitting the profile seal on the bottom section of the controller housing*


5. ➤ Position the profile seal evenly around the upper edge of bottom section of the DULCOMETER® Compact Controller housing. Arrange the clips (1) as shown in the figure  
⇒ Ensure that the profile seal evenly surrounds the upper edge of the housing.
6. ➤ Insert the bottom section of the DULCOMETER® Compact Controller housing with the profile seal from behind into the cut-out and use three screws to secure it in place



A0351

*Fig. 9: Fitting the profile seal onto the top section of the controller housing*

- 7.** ➤ Position the profile seal (arrow) evenly into the groove in the top section of the DULCOMETER® Compact Controller housing. Arrange the clips (3) as shown in the figure
- 8.** ➤ Secure the strain relief (2) using two screws (1)



*Fig. 10: Push and lock the ribbon cable in its base*

- 9.** ➤ Push and lock the ribbon cable (1) in its base
- 10.** ➤ Screw the top section of the controller housing onto the bottom section of the DULCOMETER® Compact Controller housing
- 11.** ➤ Once again check that the profile seals are fitted properly
  - ⇒ IP 54 degree of protection can only be provided if the control panel is mounted correctly

### 5.3 Installation (electrical)



#### **WARNING!**

##### **Live parts!**

Possible consequence: Fatal or very serious injuries

- Measure: Disconnect the electrical power supply to the unit before opening the housing and secure to prevent unintentional reconnection
- Disconnect damaged or defective devices or devices that have been tampered with and prevent unintended reconnection
- The plant operator is responsible for providing an appropriate isolating device, such as an emergency-off switch etc.



*Do not route the controller's signal leads alongside interference-prone cabling. This could lead to controller malfunctions.*

### 5.3.1 Cable Cross-Sections and Cable End Sleeves

	Minimum cross-section	Maximum cross-section	Stripped insulation length
Without cable end sleeve	0.25 mm <sup>2</sup>	1.5 mm <sup>2</sup>	
Cable end sleeve without insulation	0.20 mm <sup>2</sup>	1.0 mm <sup>2</sup>	8 - 9 mm
Cable end sleeve with insulation	0.20 mm <sup>2</sup>	1.0 mm <sup>2</sup>	10 - 11 mm

### 5.3.2 Electrical connection of the conductivity sensor



#### **CAUTION!**

#### **Length of the sensor cable**


The sensor is supplied with a fixed cable or a measuring line.

Possible consequence: Slight or minor injuries. Material damage.

Modification of the cable (lengthening, shortening, etc.) is prohibited.

**All conductivity sensors connected to the controller should have a shielded sensor cable.**

5.3.3 Terminal diagram / wiring



A0348

Fig. 11: Threaded connector number

Tab. 4: Recommended cable diameter

Cable designation	Diameter in mm
Mains cable	6.5
Temperature sensor cable	5.0
External control cable	4.5




Fig. 12: Terminal diagram label for the Compact Controller (the cable colours relate to the measuring lines) ➔ Tab. 6 'If you use a sensor without fixed cable or wish to extend the fixed cable, use the pre-assembled sensor cables.' on page 40

Red	Shielding.
Black	Sensor probes, the polarity is arbitrary.
Blue	Sensor probes, the polarity is arbitrary.
Yellow/Green	Temperature sensor probes, the polarity is arbitrary.
Brown	Temperature sensor probes, the polarity is arbitrary.

Tab. 5: Table for the terminal diagram, Fig. 13 and/or the terminal diagram label/ Fig. 12

No.	Terminal Pin	Description	Function	Terminal type (Max. diameter/ current)
1	XE2.1	----	----	Terminal strip, 3-pin  (1.5 mm <sup>2</sup> /10 A)
	XE2.2	[UREF2]	Shield for sensor cable	
	XE2.3	----	----	
2	XE3.1	[LFI]	Sensor, 2 probes, the polarity is arbitrary	Terminal strip, 2-pin  (1.5 mm <sup>2</sup> /10 A)
	XE3.2	[LFGEN]	Sensor, 2 probes, the polarity is arbitrary	



No.	Terminal Pin	Description	Function	Terminal type (Max. diameter/ current)
3	XE4.1	<i>[Pt100x(+)]</i>	Pt100/Pt1000 temperature sensor	
	XE4.2	<i>[Pt100x(-)]</i>	Pt100/Pt1000 temperature sensor	

## Assembly and installation

Drill hole no. Size	Description	Ter- minal	Ter- minal no.	Pin	Function	Recom- mended cable Ø	Remark
1 / M20	Sensor	XE2	2	red	Meas- uring input	5.6 mm	①
		XE3	1	black	Conduc- tivity sensor with/ without tempera- ture sensor	5 mm	
			2	blue			
		XE4	1	yellow/ green			
			2	brown			

① Pass the cable through the M20/2x5 mm multiple seal insert when using an external temperature sensor

2 / M16	Standard signal output	XA1	1	+ 15V	e.g. recorder / actuator	4.5*	②
			2	-			
	Contact input	XK1	1	+	Pause		
			2	-			
	Relay output	XR2	1		f-relay		
			2				

② Pass 1 cable (4-wire) through the M16 / 2x4.5 mm multiple seal insert

3 / M16	Relay output	XR1	1	COM	Raise/lower solenoid valve	5 mm	③
			2	NO			
	Relay output	XR1	1	COM	Limit value relay	5 mm	
			2	NO			

Drill hole no. Size	Description	Terminal	Terminal no.	Pin	Function	Recommended cable Ø	Remark
	Relay output	XR1	1	COM	Alarm relay	5 mm	
			3	NC			
③ Pass cable through M16 single seal insert							
4 / M16	Mains connection	XP1	1	N	85 ... 253 V effective	6.5 mm	④
			2	L			
④ Pass cable through M16 single seal insert							

Wiring diagram





Fig. 13: Wiring diagram

### 5.3.4 Installation (electrical)



*The cable must be routed in a site-provided cable duct to ensure strain relief*

1. ➤ Undo the four housing screws
2. ➤ Slightly lift the controller housing top section forwards and fold it to the left



*Fig. 14: Punch out threaded holes*

3. ➤



*Large threaded connection  
(M 20 x 1.5)*

*Small threaded connection  
(M 16 x 1.5)*

Punch out as many threaded connections on the bottom side of the controller housing bottom section as required

4. ➤ Guide the cable into the respective reducing inserts.
5. ➤ Insert the reducing inserts into the threaded connectors
6. ➤ Guide the cable into the controller.
7. ➤ Connect the cable as indicated in the terminal diagram
8. ➤ Screw the required threaded connections in and tighten
9. ➤ Tighten the clamping nuts of the threaded connections so that they are properly sealed
10. ➤ Click the controller housing top section on to the controller housing bottom section
11. ➤ Manually tighten the housing screws
12. ➤ Once again check the seating of the seal. Only if the mounting is correct, is protection class IP 67 (wall/pipe mounting) or IP 54 (control panel mounting) achieved

### 5.4 Switching of inductive loads



*If you connect an inductive load, i.e. a consumer which uses a coil (e.g. an alpha motorised pump), then you must protect your controller with a protective circuit. If in doubt, consult an electrical technician for advice.*

The RC member protective circuit is a simple, but nevertheless very effective, circuit. This circuit is also referred to as a snubber or Boucherot member. It is primarily used to protect switching contacts.

When switching off, the connection in series of a resistor and capacitor means that the current can be dissipated in a damped oscillation.

Also when switching on, the resistor acts as a current limiter for the capacitor charging process. The RC member protective circuit is highly suitable for AC voltage supplies.

The magnitude of the resistance R of the RC member is determined according to the following equation:

$$R = U / I_L$$

(Where U = Voltage across the load and  $I_L$  = current through the load)

The magnitude of the capacitor is determined using the following equation:

**Units:** R = Ohm; U = Volt;  $I_L$  = Ampere;  
C =  $\mu\text{F}$

$$C = k \cdot I_L$$

$k = 0, 1 \dots 2$  (dependent on the application).

Only use capacitors of class X2.

**Units:** R = Ohm; U = Volt;  $I_L$  = Ampere;  
C =  $\mu\text{F}$



*If consumers are connected which have a high starting current (e.g. plug-in, switched mains power supplies), then a means of limiting the starting current must be provided.*

The switching-off process can be investigated and documented using an oscilloscope. The voltage peak at the switch contact depends on the selected RC combination.




Fig. 15: Switching-off process shown on the oscillogram.




Fig. 16: RC protective circuit for the relay contacts

Typical AC current application with an inductive load:

- 1) Load (e.g. alpha motor-driven pump)
- 2) RC-protective circuit
  - Typical RC protective circuit at 230 V AC:
  - Capacitor [ $0.22\mu F/X2$ ]
  - Resistance [ $100\ \Omega / 1\ W$ ] (metal oxide (pulse resistant))
- 3) Relay contact (XR1, XR2, XR3)

### 6 Sensor connection



#### **Shielded sensor cable**

*All conductivity sensors connected to the controller require a shielded sensor cable.*

Connect the sensor according to the wiring diagram, see 'Wiring diagram' on page 36.

*Tab. 6: If you use a sensor without fixed cable or wish to extend the fixed cable, use the pre-assembled sensor cables.*

Accessories	Part number
Measuring line LF 1 m:	1046024
Measuring line LF 3 m:	1046025
Measuring line LF 5 m:	1046026
Measuring line LF 10 m:	1046027



#### **Selection of the sensor connected**

*All of the sensor-dependent settings are reset to the [DEFAULT] values of the controller when changing the sensor connected.*

Sensor	Connector	Cell constant ZK (1/cm)	T-correction element	Max. temp. (°C)	Measuring range κ <sub>min</sub> (Unit)	Measuring range κ <sub>max</sub> (Unit)
LFTK1FE 3m	Fixed cable 0.25 mm <sup>2</sup> , 3 m, shielded	1.00	Pt1000	80	0.01 mS/cm	20 mS/cm
LFTK1FE 5m	Fixed cable 0.25 mm <sup>2</sup> , 5 m, shielded	1.00	Pt1000	80	0.01 mS/cm	20 mS/cm



Sensor	Connector	Cell constant ZK (1/cm)	T-correction element	Max. temp. (°C)	Measuring range $\kappa$ min (Unit)	Measuring range $\kappa$ max (Unit)
LFTK1-DE	DIN 4-pin	1.00	Pt1000	80	0.01 mS/cm	20 mS/cm
LFTK1-1/2	DIN 4-pin	1.00	Pt1000	80	0.01 mS/cm	20 mS/cm
LF1-DE	DIN 4-pin	1.00	-	80	0.01 mS/cm	20 mS/cm
LFT1-DE	DIN 4-pin	1.00	Pt100	80	0.01 mS/cm	20 mS/cm
LFT1-1/2	DIN 4-pin	1.00	Pt100	80	0.01 mS/cm	20 mS/cm
LMP01	DIN 4-pin	0.10	Pt100	70	0.1 $\mu$ S/cm	500 $\mu$ S/cm
LMP01-HT	DIN 4-pin	0.10	Pt100	120	0.1 $\mu$ S/cm	500 $\mu$ S/cm
LMP01-TA	Fixed cable 0.34mm <sup>2</sup> , 5 m, shielded	0.10	Pt100	70	0.1 $\mu$ S/cm	500 $\mu$ S/cm
LMP001	DIN 4-pin	0.01	Pt100	70	0.01 $\mu$ S/cm	50 $\mu$ S/cm
LMP001-HT	DIN 4-pin	0.01	Pt100	120	0.01 $\mu$ S/cm	50 $\mu$ S/cm
LM1	DIN 4-pin	1.00	-	70	0.1 mS/cm	20 mS/cm
LM1-TA	Fixed cable 0.34 mm <sup>2</sup> , 5 m, shielded	1.00	-	70	0.1 mS/cm	20 mS/cm
LMP1	DIN 4-pin	1.00	Pt100	70	0.1 mS/cm	20 mS/cm
LMP1-HT	DIN 4-pin	1.00	Pt100	120	0.1 mS/cm	20 mS/cm

## Sensor connection

Sensor	Connector	Cell constant ZK (1/cm)	T-correction element	Max. temp. (°C)	Measuring range κ min (Unit)	Measuring range κ max (Unit)
LMP1-TA	Fixed cable 0.34 mm <sup>2</sup> , 5 m, shielded	1.00	Pt100	70	0.1 mS/cm	20 mS/cm
CK1	DIN 4-pin	1.00	-	150	0.01 mS/cm	20 mS/cm
CKPt1	DIN 4-pin	1.00	Pt100	150	0.01 mS/cm	20 mS/cm

### Conductivity sensors from external companies


Sensor = *[MANUAL]*. This setting is selected with conductivity sensors from external companies.

You have to select one of 3 measuring range detection profiles:

- *[mid Cc]* (DEFAULT): is ideal for the majority of sensors
- *[lowCC]*: Profile with a higher measuring frequency in the lowest conductivity ranges (for small cell constants)
- *[highCC]*: Profile with a lower measuring frequency in the medium conductivity ranges (for higher cell constants)

- Or the sensor cable is broken
- Or the sensor is not immersed in the measuring fluid

the error message *[Test?]* appears

If the conductive conductivity sensor has short-circuited, the error *[INPUT↑]* is displayed, see  *Chapter 11.1 'Error messages' on page 89.*

### Monitoring of the sensor / measuring range

- When no sensor is connected
- Or the sensor cable is not connected properly

## 7 Commissioning

- **User qualification:** trained user, see  
 ⓘ *Chapter 3.4 'Users' qualifications'*  
 on page 14



### WARNING!

#### Sensor run-in periods

This can result in hazardous incorrect metering

- Correct measuring and metering is only possible if the sensor is working perfectly
- Observe the sensor's operating instructions
- Calibrate the sensor after commissioning

Following mechanical and electrical installation, integrated the controller into the measuring point.

### 7.1 Initial commissioning

The controller is in STOP state when the controller is first switched on.

#### Setting the auto-ranging profile

1. ➡ Select the conductive conductivity sensor used.
2. ➡ Enter the actual sensor cable length.
  - ⇒ Subsequently the control setting and the setting of the different parameters dependent on the process to be measured.
3. ➡ When connecting external sensors, *[INPUT > SENSOR > MANUAL]*, adjust the auto-ranging profile, see  
 ⓘ *'Using external sensors'*  
 on page 46

### 7.2 Setting the control during commissioning



#### NOTICE!

#### Reset to factory settings

When switching over the metering direction, all actuators in the controller are reset to the factory settings for the selected metering direction.

For safety reasons, all the actuators are deactivated. The basic load is reset to 0 %. All parameters relating to the actuator, are reset to the factory setting.

Reset all the parameters that relate to the actuator.

The controller only controls 'one-way'. Only one position or one negative control variable can be calculated. The direction of the control variable is set in the 'PUMP' menu. There is no dead zone. In this sense, the control cannot be 'deactivated' (except with 'STOP' or 'PAUSE').

The value of the P-proportion of the control ( $X_p$ ) is specified for the controller in the unit of the corresponding measured variable.

With pure P-control and a difference between the set and actual values, which corresponds to the  $X_p$  value, the calculated control variable is +100% (at the 'raise' setting) and -100% (at the 'lower' setting).

### 7.3 Selecting the sensor type




#### ***Input of the cable length and the cross-sectional area***

*The precise entry of the cable length is important with longer cable lengths.*

*With a conductivity value of e.g. 10mS (corresponding to 100 ohms), the displayed value changes by 1% every 10 m of cable length.*

*The Pt100 measurement is corrected by the cable resistance that comes from the cable length entered. The correction for a cable with a cross-sectional area of 0.25 mm<sup>2</sup> is 3.5 °C every 10 m of cable length.*

*ProMinent sensor cable, see  Table on page 100 and the fixed-cable sensors are 0.25 mm<sup>2</sup>.*

*Adjustable parameters in the [INPUT] > [CABLE] menu*

- 0.14 mm<sup>2</sup>*
- 0.25mm<sup>2</sup> (default value)*
- 0.34 mm<sup>2</sup>*
- 0.50 mm<sup>2</sup>*

### Use of fixed-cable ProMinent sensors

1. ➤ Press and move the cursor with the or keys at the **[INPUT]** menu item and confirm the selection with .
2. ➤ Move the cursor with the or keys at the **[SENSOR]** menu item and confirm with .
3. ➤ Select the sensor used using the or keys and confirm with .

Enter the cable length used:



#### ***Adjusting the fixed cable length***

*If you are using a conductivity sensor with a fixed cable and have to shorten the length of the cable, adjust the actual cable length in the menu under [LEN].*

4. ➤ Use the or keys to select the menu item **[LEN]** and confirm with .
5. ➤ Adjust the entry for the cable length using the , or keys and confirm with .
6. ➤ Press twice to return to the continuous display.

### Using ProMinent sensors with 4-pin plug

1. ➤ Press and move the cursor with the or keys at the **[INPUT]** menu item and confirm the selection with .
2. ➤ Move the cursor with the or keys at the **[SENSOR]** menu item and confirm with .
3. ➤ Select the sensor used using the or keys and confirm with .

Enter the cable length used:

4. ➤ Use the or keys to select the menu item **[LEN]** and confirm with .
5. ➤ Adjust the entry for the cable length used using the , or keys and confirm with .
6. ➤ Press twice to return to the continuous display.

### Using external sensors

1. ➤ Press **MENU** and move the cursor with the **▼** or **▲** keys at the **[INPUT]** menu item and confirm the selection with **OK**.
2. ➤ Move the cursor with the **▼** or **▲** keys at the **[SENSOR]** menu item and confirm with **OK**.
3. ➤ Move the cursor with the **▼** or **▲** keys at the **[MANUAL]** menu item and confirm with **OK**.  
⇒ The question **[ARE YOU SURE]** appears
4. ➤ If you wish to set the **[SENSOR]** entry to **[MANUAL]**, select **[YES]** using the **▼** or **▲** keys and confirm with **OK**.

### Enter the cable length used:

5. ➤ Use the **▼** or **▲** keys to select the menu item **[LEN]** and confirm with **OK**.

### Selecting the auto-ranging profile

6. ➤ Use the **▼** or **▲** keys to select the menu item **[PROFILE]** and confirm with **OK**.
7. ➤ Adjust the **[PROFILE]** entry using the **▼** or **▲** keys and confirm with **OK**.
  - If the cell constant is  $< 1$ , then use **[lowCC]**
  - If the cell constant is  $> 1$ , then use **[highCC]**
  - If the cell constant = 1, then use **[midCC]**



*If the selected **[PROFILE]** entry does not deliver the required result, then try another profile.*

8. ➤ Press **ESC** twice to return to the continuous display.

## 7.4 Temperature compensation and reference temperature

Adjust the temperature compensation and reference temperature for correct display of the conductive conductivity [*ConC*] and resistance [*RES*].

Non-adjustable values are specified by the controller for the display of [*TDS*] and [*SAL*].


Tab. 7: Temperature compensation

Variable	Description	Type of temperature compensation	Range	Reference temperature (°C)
Specific conductivity / Electrical resistance	off	none		
	lin	linear, 0 ... 9.99 %/K	- 20 °C...150 °C	15 °C ... 30 °C adjustable
	nLF	non-linear for natural water (DIN EN 27888)	0 °C...35 °C	20 °C or 25 °C selectable
		extended nLF function	35 °C ... 120 °C	20 °C or 25 °C selectable
TDS	---	linear	0°C...40°C	25°C, fixed
SAL	---	non-linear according to PSS-78	0°C...35°C	15°C, fixed according to PSS-78


The conductive conductivity measured at the fluid temperature is converted to the reference temperature  $[TREF]$ .



### ***Changing the reference temperature***

*If the reference temperature  $[TREF]$  is changed, the temperature coefficient  $[TCOEFF]$  has to be recalibrated, see  Chapter 9.1.2 'Calibration of the temperature coefficient' on page 60*


Adjustable process for temperature compensation

- *[off]*
  - Temperature compensation is switched off. It is measured based on the set reference temperature.
- *[lin]*
  - Linear temperature compensation, see  Chapter 10.5 'Temperature correction variable' on page 83, for the temperature range permitted for the sensors. The reference temperature  $[TREF]$  can be set between 15 °C and 30 °C.
- *[nLF]*
  - Non-linear temperature compensation according to DIN EN 27888 for natural water, between 0 °C ... 35 °C. The reference temperature  $[TREF]$  can be switched, 20 °C / 25 °C.



## 8 Operating diagram

### 8.1 Overview of equipment/Operating elements

- **User qualification:** instructed user, see  Chapter 3.4 'Users' qualifications' on page 14




Fig. 17: Overview of equipment/Operating elements

Function	Description
1st respective measured variable	Affix the measured variable label here
2. LCD display	
3. UP key	To increase a displayed numerical value and move up in the operating menu
4. INFO/RIGHT key	Opens the information menu or moves the cursor one place to the right
5. OK key	To apply, confirm or save a displayed value or status or To confirm an alarm

Function	Description
6. DOWN key	To decrease a displayed numerical value and move down in the operating menu
7. MENU key	To access the controller's operating menu
8. STOP/START key	Starts and stops the control and metering function
9. ESC key	Moves one level back in the operating menu, without storing or changing entries or values Switches the measured variables in the continuous display.
10. CAL key	To access the calibration selection menu (cell constant and temperature coefficient) and navigate within the calibration menu.
11. f-REL LED	Shows the activated state of the f-relay
12. P-REL LED	Shows the activated state of the P-relay
13. ERROR LED	Indicates a controller error state. A text message is displayed simultaneously in the LCD display of the continuous display

## 8.2 Entering values

Described by the example of entering set-points in the Control menu.




Fig. 18: Entering values

1. Use to select each position of the value to be entered.



*You can also select and change the unit of the value to be entered.*

2. Enter the values using the and keys
3. : The value entered is transferred to the memory.
4. : Cancelling the input of values without saving the entered value. The original value is retained.

### **8.3 Adjusting display contrast**

If the DULCOMETER® Compact Controller is set to '*continuous display*', you can set the contrast of the LCD-display. By pressing the ▲ key you can adjust the LCD display contrast so it is darker. By pressing the ▼ key you can adjust the LCD display contrast so it is lighter. Here each key press represents a contrast level. I.e. the key must be pressed once for each contrast level.

### 8.4 Continuous display




Fig. 19: Continuous display

- |   |   |   |                                   |
|---|---|---|-----------------------------------|
| 1 | Measured variable (switch using ESC), the following are possible: [ConC], [RES], [TDS] and [SAL]                            | 5 | Temperature (correction variable) |
| 2 | Reference temperature or temperature compensation   | 6 | Measured value (actual value)     |
| 3 | Control variable  | 7 | Operating status                  |
| 4 | Possible error text: for example "Limit ↓" (direction of limit value transgression e.g. value below the limit in this case) |   |                                   |

The bottom line displays the current measuring temperature and a temperature manually entered. The temperature display cannot be switched off.

The temperature (measuring temperature or reference temperature) is needed to calculate all measured variables, which is why the second line of the continuous display therefore displays information about temperature compensation and the reference temperature.

The setpoint is displayed in the Information menu.




#### Switching between measured variables

Use the key to switch between the controller's measured variables [ConC], [RES], [TDS] and [SAL] in the continuous display.

Depending on the measured variable set, the settings of variables are changed or the variables are hidden completely in the [INPUT > TCOMP] menu and in the [LIMIT] menu.

## 8.5 Information display

The most important parameters for each first-level menu item are displayed in the Information display.

Use  to access the Information display from the continuous display. Pressing  again calls up the next Information display. Pressing  calls up the continuous display again.





Fig. 20: Information display

Use  to move from the information display currently shown to the selection menu for this information display.

Use  to move directly back to the information display.

8.6 Password

Access to the setting menu can be limited by a password. The controller is delivered with the password '5000'. The controller is set up with the pre-set password '5000' so that access is possible to all menus.





Fig. 21: Setting the password

Password	Possible values			
Factory setting	Increment	Lower value	Upper value	Remark
5000	1	0000	9999	5000 = [FREE]

## 9 Operating menus

- **User qualification:** instructed user, see  Chapter 3.4 'Users' qualifications' on page 14




Fig. 22: Overview of the first level menus

### 9.1 Calibrating [CAL] the conductivity sensor

The following calibration functions are available depending on the type of sensor:

- Calibration of the cell constant
- Calibration of the temperature coefficient



#### **Correct sensor operation**

- Correct measuring and metering is only possible if the sensor is working perfectly
- Observe the operating instructions for the sensor



### ***Incorrect calibration***

*An error message 'ERR' appears if the result of the calibration lies outside the specified tolerance limits. In this case the current calibration is not applied.*

*Check the prerequisites for calibration and clear the error. Then repeat calibration*

*In the event of repeated calibration failure, observe the notes given in the sensor operating instructions.*

During calibration, the controller sets the control outputs to '0'. Exception: If a basic load or a manual control variable has been set. This remains active. The mA standard signal output is frozen.


When calibration has been completed successfully, all of the error checks relating to the measured value are restarted. The controller saves the data determined for the cell constant and temperature coefficient when the calibration is successful.

The conductivity sensors can be calibrated using 3 different methods. The cell constant is adjusted directly or indirectly in all methods:

- Calibration compared to a reference solution
- Calibration compared to a reference measurement (e.g. manual measuring device)
- Calibration by entering a precisely known or determined cell constant







## 9.1.1 Calibration of the cell constant



A1625


Fig. 23: Calibration of the cell constant






### Calibration compared to a calibration solution

1. ➤ Press  and move the cursor using the  or  key to `[CELLCONST]` and confirm with .
2. ➤ Enter the temperature coefficient of the calibration solution.



*The temperature coefficient of the calibration solution is specified on the storage tank for the calibration solution. ProMinent's calibration solution has a temperature coefficient of 2% /K.*

Confirm with .

3. ➤ Now dip the sensor into the calibration solution and gently move the sensor.
4. ➤ Wait until the conductivity and temperature measured value has stabilised.  
Press   
⇒ The conductivity value measured is displayed.
5. ➤ Now enter the conductivity value measured using the ,  or  keys, in accordance with the conductivity value specified on the calibration solution.  
⇒ If calibration has been completed successfully, the controller stores the determined values for the cell constant and the error checks relating to the measured value are restarted. The numerical setting range of the cell constant is not limited.
6. ➤ Press  twice to return to the continuous display.

## Calibration compared with a reference measurement (e.g. manual measuring device)



### ***Temperature coefficient of the measuring solution***

*The temperature coefficient of the measuring solution has to be known.*

1. ➤ Press **[CAL]**, leaving the sensor in the application in which the sensor is fitted.
2. ➤ Move the cursor using the **[▲]** or **[▼]** key to **[CELLCONST]** and confirm with **[OK]**.
3. ➤ Enter the temperature coefficient of the measuring solution.  
Confirm with **[OK]**.
4. ➤ Press **[CAL]**.  
⇒ The conductivity value measured is displayed.
5. ➤ Now enter the conductivity value displayed using the **[↵]**, **[▲]** or **[▼]** keys, in accordance with the reference value measured.  
⇒ If calibration has been completed successfully, the controller stores the determined values for the cell constant and the error checks relating to the measured value are restarted. The numerical setting range of the cell constant is not limited.
6. ➤ Press **[ESC]** twice to return to the continuous display.

## Calibration by entering a precisely known cell constant

1. ➤ Press **[MENU]** and move the cursor using the **[▲]** or **[▼]** key to **[INPUT]**  
Confirm with **[OK]**.
2. ➤ Move the cursor using the **[▲]** or **[▼]** key to **[CELLC]**.  
Confirm with **[OK]**.
3. ➤ Now adjust the precisely known or previously determined cell constant using the **[↵]**, **[▲]** or **[▼]** keys.  
Confirm with **[OK]**.
4. ➤ Press **[ESC]** twice to return to the continuous display.

Tab. 8: Sensor status

Display	Meaning	Status
[OK]	In order	Cell constant = 0.005 / 15.0
[WRN]	Warning	none
[ERR]	Error	Cell constant < 0.005 or cell constant > 15

### 9.1.2 Calibration of the temperature coefficient



#### ***Conductivity sensors with temperature element***

*You can only calibrate the temperature coefficient with conductivity sensors with a temperature elements, because it is impossible to calculate the temperature coefficient without measuring the temperature.*



#### ***Temperature change***

*It is recommended that the temperature is changed by no more than 0.5 °C per minute, or with a temperature change of e.g. 10°C you will need to wait for a minimum of 20 minutes before calibration.*




Fig. 24: Calibration of the temperature coefficient

- I. If the temperature change is greater than 2°C, the note changes to *[WAIT]*
- II. If the temperature is within the specified range, the note changes to *[STABLE]*
- III. When a stable final temperature has been reached, the note changes to *[ACCEPT?]*  
Calibration can now be terminated manually.

## Operating menus

1. ➤ Calibrate at the first calibration temperature; this calibration temperature should be close to the selected reference temperature.
2. ➤ Press **[CAL]** to accept the first calibration point. At the same time the temperature ranges for the second temperature value are given.
3. ➤ Note: **[CHANGE TEMP]**, now immerse the sensor in the same liquid with the second calibration temperature (minimum temperature difference  $\pm 10^{\circ}\text{C}$ )
4. ➤ If the measured temperature has changed by more than  $2^{\circ}\text{C}$ , **[WAIT]** displayed.
5. ➤ If the temperature has changed by more than  $10^{\circ}\text{C}$ , **[STABLE?]** is displayed, and you can now terminate calibration if the displayed temperature value no longer changes. To do so, press **[CAL]**.
6. ➤ When the Maximum/Minimum temperature has been reached, **[ACCEPT?]** is displayed  
⇒ You can now terminate calibration. To do so, press **[CAL]**.




*This process may take 10 ... 20 minutes depending on the type of sensor.*

7. ➤ Use **[CAL]** to accept the temperature coefficient or **[ESC]** to discard it

### Sensor status

Display	Meaning	Status
<b>[OK]</b>	In order	$\Delta\text{Tkal} > 20^{\circ}\text{C}$
<b>[WRN]</b>	Warning	$\Delta\text{Tkal} = 10^{\circ}\text{C} \dots 20^{\circ}\text{C}$
<b>[ERR]</b>	Error	$\Delta\text{Tkal} < 10^{\circ}\text{C}$
$\Delta\text{Tkal}$ = Temperature difference of the calibration liquids		

## 9.2 Setting limit values [LIMITS]



A1620

Fig. 25: Setting limit values (LIMITS)

Setting		Possible values			
Display	Starting value	Increment	Lower value	Upper value	Remark
[LIMIT ↑]	0.02 S/cm	0.001	0.000 uS/cm	2.000 S/cm	upper limit value
[LIMIT ↓]	0.01 mS/cm	0.001	0.000 uS/cm	2.000 S/cm	lower limit value
[HYST.]	5%	1%	1%	20%	hysteresis of limit values
[TLIMIT ↑] °C	30.0 °C	0.1 °C	0.0 °C	150.0 °C	upper limit correction value °C
[TLIMIT ↓] °C	10.0 °C	0.1 °C	0.0 °C	150.0 °C	lower limit correction value °C
[TLIMIT ↑] °F	86.0 °F	0.1 °F	32.0 °F	302.0 °F	upper limit correction value °F
[TLIMIT ↓] °F	32.0 °F	0.1 °F	32.0 °F	302.0 °F	lower limit correction value °F
[TIMELIM.]	0 min = OFF	1 min	0	999	Checktime after a limit value has been exceeded or undershot

If [TDS] or [SAL] is set in the continuous display, the setting values for [TLIMIT ↑] and [TLIMIT ↓] are hidden in the [LIMIT] menu:

- [TLIMIT ↓] can be changed if the continuous display is showing [Cond\_C] or [RES].
- [TLIMIT ↑] is fixed at 40 °C (with TDS) and 35 °C (with SAL). If the value set at [Cond\_C] for [TLIMIT ↑] is less than this value, this setting is retained.

Hysteresis: the hysteresis is specified as a %, as an absolute indication is impossible due to the breadth of the measuring range. The indication refers to the values given under [LIMIT ↑] and [LIMIT ↓].

### Hysteresis = [HYST.]

If the value has fallen below a limit value, then the limit value criteria are reset when the measured value has reached the value of the limit value plus hysteresis.



If the value has fallen below a limit value, then the limit value criteria are reset when the measured value has reached the value of the limit value minus hysteresis.

If the limit value criteria no longer exist on expiry of *[TIME LIM]*, then the control is automatically reactivated.

9.3 Setting the control [CONTROL]




Fig. 26: Setting the control [CONTROL]


Setting		Possible values			
	Starting value	Increment	Lower value	Upper value	Remark
[PUMP]	dosing ↑	dosing ↓ dosing ↑			Mono-directional control direction <sup>2</sup>
[SET]	1.0 mS/cm	0.001	0.000 uS/cm	2.000 S/cm	
[TYPE]	P	P Manual PID			Controller type
[↵Xp]	0.5 mS/cm	0.001	0.000 uS/cm	2.000 S/cm	P-proportion of control variable
[↵Ti]	0 s	1 s	0 s	9999 s	PID control integral action time (0 seconds = no I-proportion)
[↵Td]	0 s	1 s	0 s	2500 s	PID control derivative action time (0 seconds = no D-proportion)
[BASIC J] <sup>1</sup>	0%	1%	- 100%	100%	Basic load
[↵MANUAL] <sub>1</sub>	0%	1%	- 100%	100%	Manual control value
[CHECK-TIME]	0 min	1 min	0 min	999 min	Control checktime 0 minutes = off

Setting		Possible values			
	Starting value	Increment	Lower value	Upper value	Remark
<i>[↵LIMIT]</i> <sup>1</sup>	0%	1%	- 100%	100%	Checktime limit. No basic load, only PID control value
<i>[BOOT DELAY]</i>	0 s	1 s	0 s	9999 s	Control delay period after the start of the measuring point. After it is switched on, the unit only measures but does not control during this period.

1 = in an upwards direction with mono-directional control: 0 ...+ 100% (setting with PUMP: dosing ↑), in a downwards direction: - 100 ... 0% (setting with PUMP: dosing ↓).

2 = When switching over the metering direction, all actuators in the controller are reset to the factory settings for the selected metering direction.

## 9.4 Setting inputs *[INPUT]*



*Fig. 27: Setting inputs [INPUT]*

## Operating menus

Setting		Possible values			
Display	Starting value	Increment	Lower value	Upper value	Remark
[ <i>SENSOR</i> ]	LFTK1-3m				Sensor type
[↵ <i>TYPE</i> ]	Conductive				Sensor type
[↵ <i>MIN</i> ]	0.0 S/cm	0.001	0.000 uS/cm	2.000 S/cm	Minimum measured value
[↵ <i>MAX</i> ]	0.02 S/cm	0.001	0.000 uS/cm	2.000 S/cm	Maximum measured value
[↵ <i>CELLC</i> ]	1 cm <sup>-1</sup>	0.001	0.006 cm <sup>-1</sup>	15 cm <sup>-1</sup>	Cell constant
[↵ <i>TMAX</i> ]	120 °C	0.01	0.01 °C	150 °C	Maximum temperature that the sensor can withstand
[↵ <i>PRO-FILE</i> ]	midCC	lowCC,			Automatic measuring range detection
		midCC			
		highCC			
[ <i>CABLE</i> ]	0.25mm <sup>2</sup>	0.14mm <sup>2</sup>			Cable diameter
		0.34mm <sup>2</sup>			
		0.25mm <sup>2</sup>			
		0.50mm <sup>2</sup>			
[↵ <i>LEN</i> ]	3 m	0.01	0 m	50 m	Cable length
[↵ <i>R_CABLE</i> ]	0.4 Ω	0.01	0 Ω	100 Ω	Cable resistance
[ <i>TCOMP</i> ]	off				Temperature compensation off
	lin				Linear temperature compensation
	nLF				Non-linear temperature compensation (according to DIN EN 27888)

Setting		Possible values			
Display	Starting value	Increment	Lower value	Upper value	Remark
[ <i>↳ TREF</i> ]	25 °C	1	15 °C	30 °C	Reference temperature
[ <i>TCOEFF</i> ]	1.9 %/°C	0.1	0 %/°C	9.99 %/°C	Temperature coefficient
[ <i>FILTER</i> ]	3 s	1	3 s	30 s	Measured value filtering in seconds <sup>1</sup>
[ <i>TDS</i> ]	0.64	0.001	0.004	1.000	TDS conversion factor
[ <i>TEMP</i> ]	auto	man auto			Correction value source (Pt100 (0), manual)
[ <i>↳ UNIT</i> ]	°C	°C °F			Correction value unit
[ <i>↳ VALU</i> ]	25.0 °C	0.1	0.0 °C	150.0 °C	Manual correction value °C
[ <i>↳ VALUE</i> ]	77.0 °F	0.1	32.0 °F	302.0 °F	Manual correction value °F
[ <i>CONTACT</i> ]	pause	pause hold			Configuration of digital contact input
[ <i>↳ POL</i> ]	norm.open,	norm.open, norm.closed			Polarity of the contact input
[ <i>↳ DELAY OFF</i> ]	0 s	1	0 s	3600 s	Switch-off delay of contact input
[ <i>↳ ALARM</i> ]	off	on off			Alarm at [ <i>Hold</i> ] or [ <i>PAUSE</i> ] event

1) [*FILTER*]: The default value of 3 seconds is suitable in most cases. You should only increase the default value of 3 seconds with fluctuating readings, a factor that also increases the setting time of the display value.

### Sensor



#### ***Selection of the sensor connected***

*If the connected sensor it changed, all the sensor-dependent settings are reset to their [DEFAULT] values.*




#### ***Temperature sensor***

- *[auto]: with conductivity sensors with integral temperature sensor*
- *[Manual], 25°C: with conductivity sensors without integral temperature sensor*



## 9.5 Setting outputs [OUTPUT]



A1623

Fig. 28: Setting outputs (OUTPUT)

## Operating menus

Setting		Possible values			
	Starting value	Increment	Lower value	Upper value	Remark
[P-REL] (Power relay)	alarm	alarm			Alarm relay
		unused			off
		dosing			PWM relay (Pulse Width Modulation)
		limit			Limit value relay
[↵PERIOD]	60 s	1 s	30 s	6000 s	Cycle time of PWM control (P-REL = dosing)
[↵MIN ON] 1	10 s	1 s	5 s	PERIOD/4 or 999	Minimum switch-on period with PWM control (P-REL = dosing)
[↵DELAY ON]	0 s	1 s	0 s	9999 s	Switch-on delay limit value relay (P-REL = limit)
[↵DELAY OFF]	0 s	1 s	0 s	9999 s	Switch-off delay limit value relay (P-REL = limit)
[f-REL]	dosing	dosing			Activation of the low power relay (frequency relay)
		unused			

Setting		Possible values			
	Starting value	Increment	Lower value	Upper value	Remark
[↵PUMPMA X]	180 RPM	1	1 RPM	500 RPM	Maximum stroke rate of the low power relay (frequency relay)
[mA OUT] (Issued variable of the mA standard signal output)	meas val	off			off
		meas val			meas val = measured variable (conductivity)
		corr val			corr val = correction variable
		dosing			dosing = control value
		manual			manual = Manual
[↵RANGE]	4 - 20 mA	0 - 20 mA			Range of the mA standard signal output
		4 - 20 mA			
[↵0/4 mA]	0.01 mS/cm	0.001	0.000 uS/cm	2.000 S/cm	
[↵20 mA]	0.02 S/cm	0.001	0.000 uS/cm	2.000 S/cm	
[↵0/4 mA]	0.0 °C	0.1 °C	0.0 °C	150.0 °C	Temp value assigned 0/4 mA
[↵20 mA]	100.0 °C	0.1 °C	0.0 °C	150.0 °C	Temp. value assigned 20 mA
[↵0/4 mA]	32.0 °F	0.1 °F	32.0 °F	302.0 °F	Temp. value assigned 0/4 mA

## Operating menus

Setting	Possible values				Remark
	Starting value	Increment	Lower value	Upper value	
[↵20 mA]	212.0 °F	0.1 °F	32.0 °F	302.0 °F	Temp. value assigned 20 mA
[↵20 mA] <sup>2</sup>	100 %	1 %	10 % / - 10 %	100 % / - 100 %	Control value assigned 20 mA  (0/4 mA is fixed as 0 %)
[↵VALUE]	4.00 mA	0.01 mA	0.00 mA	25.00 mA	Manual output current value
[↵ERROR]	off	23 mA			Output current value in the event of error, 23 mA
		0/3.6 mA			Output current value in the event of error, 0/3.6 mA
		off			off = no error current is output

1 = The parameter maximum occurs at PERIOD/4 or 999, whichever is smaller

2 = depending on the metering direction, the limits are either -10% and -100% or +10% and +100%

## 9.6 Setting the [DEVICE]




Fig. 29: Setting the [DEVICE]

Setting		Possible values			
	Starting value	Increment	Lower value	Upper value	Remark
[PASS-WORD]	5000	1	0000	9999	5000 = no password protection
[RESTART DEVICE]					Controller is restarted
[FACTORY RESET...]	no	yes no	yes = FAC- TORY RESET!	no = FAC- TORY RESET!	All the controller's parameters are reset to factory settings.

### 10 Control parameters and functions

- **User qualification:** trained user, see  
↳ *Chapter 3.4 'Users' qualifications'*  
on page 14

#### 10.1 DULCOMETER® Compact Controller function states

DULCOMETER® Compact Controller function states have the following priority:

- 1. 'STOP'
- 2. 'PAUSE/HOLD'
- 3. 'CAL' (calibration)
- 4. 'OPERATION' (normal mode)

"CAL" (calibration) peculiarities

- Control goes to basic load, mA measurement outputs are frozen
- New faults are detected, however they have no effect on the alarm relay or the mA output
- Detection of measurement variable relevant faults during 'CAL' (calibration process) are suppressed (e.g. LIMIT↑)

"PAUSE" peculiarities

- Control is switched to 0% control variable. The I-proportion is saved
- New faults are detected, however they have no effect on the alarm relay or the mA output
- Special case alarm relay in 'PAUSE': If activated the output relay switches to 'PAUSE' (error message CONTACTIN)

"HOLD" peculiarities

- Control and all other outputs are frozen
- New faults are detected, however they have no effect on the alarm relay or the mA output. However the effect of already existing faults (e.g. fault current) remains
- Special case alarm relay: Activation of the frozen alarm relay is permitted (= no alarm), if all faults have been acknowledged or have disappeared
- Special case alarm relay in 'HOLD': If activated the output relay switches to 'HOLD' (error message CONTACTIN)

"STOP" peculiarities



- Control OFF
- New faults are detected, however they have no effect on the alarm relay or the mA output
- The alarm relay is switched off in 'STOP'

Peculiarities of the "START" event, i.e. switching from "STOP" to "OPERATION" (normal mode)

- Fault detection starts afresh, all existing faults are deleted

Generally applicable information

- If the cause of a fault disappears, then the fault message in the LCD footer disappears.
- A previously existing 'PAUSE/HOLD' state is not influenced by starting a 'CAL' (calibration) process. If during 'CAL' (calibration) the functional state 'PAUSE/HOLD' is released, then all states will remain frozen until the end of the 'CAL' (calibration) process.

- If 'CAL' (calibration) is started while functional state 'OPERATION' (normal mode) is active, then the functional state 'PAUSE/HOLD' is ignored until 'CAL' (calibration) completes. However STOP/START is possible at any time
- An alarm can be acknowledged or removed as follows: By clearing all faults by pressing the  key and the  key while the continuous display is visible

### 10.2 [STOP/START] key



Control is started / stopped by pressing . You can press regardless of the menu currently displayed. However the [STOP] state is only shown in the continuous display.




Fig. 30: key

When the controller is first switched on, it is in [STOP] state.

In the event of defined error conditions, the controller switched to [STOP] state. The control is then off (= 0 % control variable).

To differentiate the operating status [STOP], caused by an error, from the operating status [STOP], caused by pressing , [ERROR STOP] is displayed instead of [STOP].

Pressing therefore causes the operating status [ERROR STOP] to become [STOP]. Pressing once more causes the controller to start up again.

In [STOP] status, start the controller manually by pressing .

Controller [STOP] means:

- Control is stopped
- The P-relay functioning as a limit value relay and as a PWM relay are switched to a de-energised state
- The P-relay acting as an alarm relay is activated (no alarm)

The controller restarting causes the following:

- If a [STOP] status existed, then you have to manually start the controller after switching on again.
- Error detection starts afresh, all existing errors are deleted



### 10.3 Priming *[PRIME]*




Fig. 31: Priming, e.g. to vent a pump

While the continuous display is visible, in the statuses *[STOP]* and *[OPERATION]*, you can start the priming function *[PRIME]* by simultaneously pressing ▲ and ▼.

Depending on the configuration of the controller, the output relay *[P-REL]* is actuated at 100 %, the frequency relay *[f-REL]* is actuated at 80 % of "PUMPMAX" and 16 mA is output at the mA output. However this is only the case if these outputs are set as actuator *[dosing]*.

The output relay *[P-REL]* starts after priming in an activated state.

You can use this function, for example, to transport the feed chemical up to the pump to vent the metering line.

## 10.4 Hysteresis limit value




Fig. 32: Hysteresis

Upper limit value =  $[LIMIT \uparrow]$

Lower limit value =  $[LIMIT \downarrow]$

The range between  $[LIMIT \uparrow]$  and  $[LIMIT \downarrow]$  is the valid measuring range.

The controller has a  $[hysteresis]$ , which is set as a % to the respective  $[LIMIT]$  value.

An error message is emitted if, for example,  $[HYST] = 5\%$  and  $[LIMIT \uparrow]$  is exceeded. If the level falls below  $0.95 \cdot [LIMIT \uparrow]$ , the error message is retracted. If the level falls below  $[LIMIT \downarrow]$ , the error message is issued, which is retracted again after exceeding  $1.05 \cdot [LIMIT \downarrow]$ .

## 10.5 Temperature correction variable






### ***Available temperature***

*A temperature reading for the conductivity always has to be available, either by a temperature measurement or a manual temperature setpoint.*

The correction variable compensates for the effect of the temperature of the medium on the measured value. The correction variable is the temperature of the medium to be measured.

#### Operating modes

- **[auto]**: The controller analyses the temperature signal from the temperature sensor connected
  - For measurements using a temperature sensor (0 ... 150 °C)
- **[manual]**: The temperature of the medium to be measured has to be measured by the user. The determined value is then entered using the keys:  and  in the **[VALUE]** parameter into the controller and is saved using .
- This setting is needed for measurements where the medium to be measured has a constant temperature. The temperature is taken into consideration in the control.

### 10.6 Checkout time for measured variable and correction variable

Error text	Description
LIMIT ERR	Checkout time of the measured variable
TLIMITERR	Checkout time of the correction variable

If upon the expiry of the checkout time, the valid measuring range is not reached, then the DULCOMETER® Compact Controller exhibits the following behaviour:

- **LIMIT ERR:** The control is switched off. An error current is emitted, provided the output is configured as a measured variable output
- **TLIMITERR:** The control is switched off. An error current is emitted, provided the output is configured as a correction variable output or a measured variable output

Initially the transgression of a limit is only a limit value transgression. This leads to a 'WARNING'. Switching on the control time 'TIMELIM' (> 0 minutes), creates an alarm from the limit value transgression. In the event of a [TLIMITERR] a, the control switches to [STOP].

### 10.7 Checkout time control



#### *Monitoring of the control path*

*The checkout time monitors the control path. The checkout time mechanism permits detection of possible defective sensors.*



#### *Dead time determination*

Each control path has a dead time. The dead time is the time, which the control path requires to detect a change or addition of metered chemicals using its own instrumentation.

You must select the checkout time so that it is greater than the dead time. You can determine the dead time, by operating the metering pump in manual mode and, for example, dosing acid.



#### **NOTICE!**

##### **Dead time determination**

You should only determine the dead time if the current process cannot be negatively influenced by the manual metering.

You must determine the time, which the control path (i.e. the entirety of controllers, sensors, measurement water, flow gauges, etc.) requires to detect a first change in the measured value starting from the beginning of dosing. This time is the 'dead time'. A safety margin, e.g. 25%, must be added to this dead time. You must allocate an appropriate safety margin for your own particular process.

The parameter *'LIMIT'* can be used to set a limit for the control variable. If the control variable exceeds this limit value, the CHECKTIME fault is triggered (checkout time of the control has elapsed). The control is switched to basic load and a fault current output.

### 10.8 Power relay "P-REL" as limit value relay

The power relay *'P-REL'* can be configured as a limit value relay. It always act only on the measurement variable, whereby the limits are set in *'LIMITS'*. The relay is activated upon infringement of either the top or lower limit values.

Constant checking is carried out to determine whether a limit has been infringed and if this is interrupted with the power relay configured *'P-REL=limit'* for at least *'DELAY ON'* seconds, then the relay is activated. If the limit value transgression disappears for at least *'DELAY OFF'* seconds, then the limit value relay is again deactivated.

The limit value relay is deactivated immediately upon: *'STOP'*, user calibration, *'PAUSE'* and *'HOLD'*.

### 10.9 Setting and functional description of "Relay Used as a Solenoid Valve"




Fig. 33: Solenoid valve (= P-REL: dosing)

min. time [MIN ON]  
 Cycle = [PERIOD] (in seconds)



#### Solenoid valve switching times

The switching times of the relay (solenoid valve) depend on the cycle time, the control variable and the 'min. time' (smallest permissible switch-on time for the connected device). The actuating variable determines the ratio  $t_{on}/cycle$  and thus also the switching times.

The 'min. time' affects the switching times in two situations:

### 1. Theoretical switching time < min. time




Fig. 34: Theoretical switching time < min. time

min. time [MIN ON]  
 Cycle = [PERIOD] (in seconds)

The DULCOMETER® Compact Controller does not switch on for a certain number of cycles until the sum of the theoretical switching times exceeds 'min. time'. Then it switches for the duration of this total time.

### 2. Theoretical switching time > (cycle - min. time)





Fig. 35: Theoretical switching time > (cycle - min. time) and calculated switching time < cycle

min. time [MIN ON]  
 Cycle = [PERIOD] (in seconds)

The DULCOMETER® Compact Controller does not switch off for a certain number of cycles until the differences between the cycle and the theoretical switching time exceed 'min. time'.

### 10.10 Alarm relay

The alarm relay triggers in *'OPERATION'* (normal mode) if an error occurs which has been defined as *'ERROR'* and not just as *'WARNING'*.

The error message *'ALARM'* in the continuous display is marked with a \* (star) and can be acknowledged with the  key. The alarm and the \* will then disappear.

### 10.11 "Error logger" operating mode

The last three errors are displayed. Also displayed is how long ago (in minutes) they occurred. When a new fault occurs, the oldest fault is deleted.


Faults are only shown which occur in operating status *'OPERATION'*, i.e. not in operating status *'STOP'*, *'CAL'* (user calibration), *'HOLD'* or *'PAUSE'*.

Only *'ERRORs'* are shown, not *'WARNINGS'*, e.g. a *'LIMIT ERR'* is shown, but not *'LIMIT↑'*.

A fault, whose display has lasted for 999 minutes is automatically deleted from the *'Error Logger'*. The *'Error Logger'* is neither saved nor backed up in the event of power loss.




## 11 Maintenance

- **User qualification:** trained user, see  *Chapter 3.4 'Users' qualifications' on page 14*

The controller is maintenance- free.

### 11.1 Error messages

- **User qualification for diagnosis:** trained user, see  *Chapter 3.4 'Users' qualifications' on page 14*. Further qualifications depend on the type and scope of possible troubleshooting measures to be carried out.



#### **Measuring technology-specific errors: [INPUT ↑]**

*The electrical sensor signal directly on the conductivity sensor input is too high. The conductivity calculated is less than that actual conductivity registered.*

*The error occurs from a value of:*

- 200mS/cm with sensors with cell constant 1.0
- 20mS/cm with sensors with cell constant 0.1
- 2mS/cm with sensors with cell constant 0.01

*The specified limit can also be higher depending on the sensor.*



#### **Measured variable-specific errors: [SAL ↑]**

*>70: If the calculated SAL value is over 70.*



#### **Error detection following device start**

*The majority of errors are only displayed with a 10-second delay following the start-up of the device.*



#### **Measured variable-specific errors: [TDS ↑]**

*>2000: If the calculated TDS value is over 2000.*

Tab. 9: Error messages

Error message	[Error] [Warning]	Brief description of fault
[RANGE↓]	E	The main measured variable falls below the measuring range
[RANGE↑]	E	The main measured variable exceeds the measuring range
[T RANGE↓]	E	Temperature value falls below the measuring range
[T RANGE↑]	E	Temperature value exceeds the measuring range
[CAL ERROR]	E	Calibration error during last calibration performed by the user
[CHECK- TIME]	E	See chapter ↗ <i>Chapter 10.7 'Checkout time control' on page 84</i>
[mA RANGE↑]	E	The current emitted at the mA standard signal outputs is higher than 20 mA. This does not apply with the issue of the 23 mA error current
[mA RANGE↓]	E	The current emitted at the mA standard signal outputs is below 0/4 mA. This does not apply with the issue of the 0/3.6 mA error current
[LIMIT↑]	W	Main measured variable is higher than the limit set
[LIMIT↓]	W	Main measured variable is lower than the limit set
[T LIMIT↑]	W	Correction measured variable higher than the limit set
[T LIMIT↓]	W	Correction measured variable higher than the limit set
[LIMIT ERR]	E	See chapter ↗ <i>Chapter 10.6 'Checkout time for measured variable and correction variable' on page 84</i>
[TLIMI- TERR]	E	See chapter ↗ <i>Chapter 10.6 'Checkout time for measured variable and correction variable' on page 84</i>
[NO CAL]	W	No calibration has been performed by the user
[CON- TACTIN]	E	Alarm triggered by contact input ([INPUT] menu: [ALARM=on] selected)
[TDS↑]	W	The TDS value is too high Continuous display: >2000
[SAL↑]	W	The SAL value is too high Continuous display: >70

Error message	<i>[Error]</i> <i>[Warning]</i>	Brief description of fault
<i>[INPUT↑]</i>	E	Conductivity signal exceeds the input measuring range
<i>[TEST?]</i>	E	Check the sensor's connection Cable breakage? No sample water

Tab. 10: Response of the device due to the error messages

Error message	Control mode	mA measurement output	mA correction output	Limit value relay	Suppressed during user calibration
[RANGE↓]	Basic load	Error current	-	-	yes
[RANGE↑]	Basic load	Error current	-	-	yes
[T RANGE↓]	Basic load	Error current	Error current	-	yes
[T RANGE↑]	Basic load	Error current	Error current	-	yes
[CALERROR]	-	-	-	-	yes
[LOW ZERO]	-	-	-	-	yes
[CHECKTIME]	Basic load	Error current	-	-	no
[mA RANGE↑]	-	-	-	-	no
[mA RANGE↓]	-	-	-	-	no
[LIMIT↑]	-	-	-	activation <sup>1</sup>	yes
[LIMIT↓]	-	-	-	activation <sup>1</sup>	yes
[T LIMIT↑]	-	-	-	-	no
[T LIMIT↓]	-	-	-	-	no
[LIMIT ERR]	Stop	Error current	-	-	yes
[TLIMITERR]	Stop	Error current	Error current	-	no
[NOCAL]	-	-	-	-	yes
[CONTACTIN]	-	-	-	-	no
[TDS↑]	-	-	-	-	no
[SAL↑]	-	-	-	-	no
[INPUT↑]	Basic load	Error current	-	-	no

<sup>1</sup>) If the functionality of the limit value relay is activated and the switch-on delay is overcome.

## 11.2 Changing the fuse, DULCOMETER® Compact Controller



### WARNING!

#### Danger from electrical voltage

Possible consequence: Fatal or very serious injuries.

- The DULCOMETER® Compact Controller does not have a mains switch
- When working inside the control unit, disconnect the control unit from the mains power via an external switch or by removing the external fuse



### NOTICE!

#### Use only 5 x 20 mm micro-fuses

Possible consequence: Damage to the product or its surroundings

- 5x20 T 0.315 A
- Part number 732404

## Fuse change

The mains fuse is located in a sealed fuse holder in the inside of the device.

1. ➤ Disconnect the controller from the mains power
2. ➤ Open the controller and fold the controller housing top section to the left
3. ➤ Remove the PCB cover
4. ➤ Remove the micro-fuse using a suitable tool
5. ➤ Fit the micro-fuse using a suitable tool
6. ➤ Refit the PCB cover
7. ➤ Replace controller housing top section and close the controller

## 12 Technical data on DULCOMETER® Compact Controller

### 12.1 Permissible ambient conditions



#### **Degree of protection (IP)**

*The controller fulfils the IP 67 degree of protection requirements (wall/pipe mounting) or IP 54 (control panel mounting). This degree of protection is only achieved if all seals and threaded connectors are correctly fitted.*

*Tab. 11: Permissible ambient operating conditions*

Temperature	-10 °C ... 60 °C
Air humidity	< 95 % relative air humidity (non-condensing)

*Tab. 12: Permissible ambient storage conditions*

Temperature	-20 °C ... 70 °C
Air humidity	< 95 % relative air humidity (non-condensing)

### 12.2 Dimensions and weights

Complete device:	128 x 137 x 76 mm (W x H x D)
Packaging:	220 x 180 x 100 mm (W x H x D)
Weight of device without packaging:	approx. 0.5 kg
Gross weight of device with packaging:	approx. 0.8 kg

### **12.3 Material data**

<b>Part</b>	<b>Material</b>
Housing lower and upper section	PC-GF10
Bracket rear side housing bottom section	PPE-GF20
Operating film	Polyester PET membrane
Seal	Expanded PUR
Cover screws	Stainless steel A2
Profile seal (control panel mounting)	Silicone

### **12.4 Chemical Resistance**

The device is resistant to normal atmospheres in plant rooms

### **12.5 Sound Pressure Level**

No noise generation measurable

## 13 Electrical data

Mains connection	
Nominal voltage range	100 ... 230 VAC $\pm$ 10 %
Frequency	50 ... 60 Hz
Power consumption	50 ... 100 mA

### Main and auxiliary inputs, display and measuring ranges

*Tab. 13: Main input:*

Variable	Display range
Specific conductive conductivity	0.001 ... 1.999 $\mu$ S/cm
	2.00 ... 19.99 $\mu$ S/cm
	20.0 ... 199.9 $\mu$ S/cm
	200 ... 1999 $\mu$ S/cm
	2.00 ... 19.99 mS/cm
	20.0 ... 199.9 mS/cm
	200 ... 1999 mS/cm
Specific resistance.	0.001 ... 1.999 $\Omega$ cm
	2.00 ... 19.99 $\Omega$ cm
	20.0 ... 199.9 $\Omega$ cm
	0.200 ... 1.999 $\Omega$ cm
	2.00 ... 19.99 $\Omega$ cm
	20.0 ... 199.9 $\Omega$ cm
	0.200 ... 1.999 M $\Omega$ cm
	2.00 ... 19.99 M $\Omega$ cm
	20.0 ... 199.9 M $\Omega$ cm
	200 ... 999 M $\Omega$ cm



Variable	Display range
TDS (total dissolved solids)	0 ... 2000 ppm (mg/l)
SAL (salinity)	0.0 ... 70.0 ‰ (g/kg)

Maximum cable length of the sensor cable ( $K$  = cell constant):

- 10 m: in the range  $1\mu\text{S} \cdot K \dots 200 \text{ mS} \cdot K$
- 50 m: in the range  $10\mu\text{S} \cdot K \dots 20 \text{ mS} \cdot K$

Example for a 10-metre cable:

- $K=1/\text{cm}$ :  $1\mu\text{S}/\text{cm} \dots 200 \text{ mS}/\text{cm}$
- $K=0.1/\text{cm}$ :  $0,1\mu\text{S}/\text{cm} \dots 20 \text{ mS}/\text{cm}$
- $K=0.01/\text{cm}$ :  $0.01\mu\text{S}/\text{cm} \dots 2 \text{ mS}/\text{cm}$

*Tab. 14: Auxiliary input:*

Variable	Display range
Temperature Pt100/Pt1000 (automatic detection)	Cable length 10 m: - 20 °C ... 150 °C
	Cable length 50 m: - 20 °C ... 120 °C

## Electrical data

### Measuring accuracy

Variable	Measuring range	Precision
Specific conductive conductivity	1 $\mu\text{S} \cdot \text{K} \dots 100 \text{ mS} \cdot \text{K}$	1 % of the measured value $\pm 1$ digital increment
	100mS $\cdot \text{K} \dots 200 \text{ mS} \cdot \text{K}$	2 % of the measured value $\pm 1$ digital increment
Specific electrical resistance.	10 $\Omega / \text{K} \dots 1\text{M}\Omega / \text{K}$	1 % of the measured value $\pm 1$ digital increment
	5 $\Omega / \text{K} \dots 10 \Omega / \text{K}$	2 % of the measured value $\pm 1$ digital increment
Temperature Pt100	- 20 °C ... 150 °C	< 0.8 % of the measuring range
Temperature Pt1000	- 20 °C ... 150 °C	< 0.5 °C
K = cell constant		

### Cell constant

- Setting range of the cell constant K(1/cm): 0.005 ... 15.000

The mains connection is isolated from other switching parts by reinforced insulation. The device has no mains switch; a fuse is fitted.

Output relay (P-relay)	
Load capacity of switching contacts	5 A; no inductive loads

Outputs galvanically isolated from other switching parts by reinforced insulation.

Digital input	
Open circuit voltage	22 V DC max.
Short circuit current	6.5 mA
Max.switching frequency	Static. For switching processes like 'PAUSE', 'HOLD', etc.

**! NOTICE!**

Do not supply with voltage

To connect an external semiconductor or mechanical switch.

<b>mA output</b>	<b>0 ... 20 mA</b>	<b>4 ... 20 mA</b>	<b>manual</b>
current range	0 ... 20.5 mA	3.8 ... 20.5 mA	0 ... 25 mA
In the event of a fault	0 or 23 mA	3.6 or 23 mA	
Max. load	480 $\Omega$ at 20.5 mA		
Max. output voltage	19 V DC		
Overvoltage-resistant up to:	$\pm 30$ V		
Output accuracy	0.2 mA		

The mA output is galvanically isolated from all other connections (500 V)

<b>Pump control (f-relay)</b>	
Max. switching voltage:	50 V (protective low voltage)
Max. switching current:	50 mA
Max. residual current (open):	10 $\mu$ A
Max. resistance (closed):	60 $\Omega$
Max. switching frequency (HW) at 50 % filling factor	100 Hz

Digital output galvanically isolated from all other connections via OptoMos relay.

## 14 Spare parts and accessories

Spare parts	Part number
Fine fuse 5x20 T 0.8 A	732408
Wall/tube retaining bracket	1002502
Guard terminal top part (nut)	733389
Measured variable labels	1002503
DMT fixing strap	1002498
Cable connection set DMTa/DXMa (metric)	1022312
Controller housing lower part (processor/PCB), fully assembled	Identity code DCCA_E_E1 ...
Controller housing top part (display/operating part), fully assembled	Identity code DCCA_E_E2 ...

Accessories	Part number
Mounting kit for control panel installation	1037273
Strain relief strap 130	1039762
Measuring line, conductivity, 1m:	1046024
Measuring line, conductivity, 3m:	1046025
Measuring line, conductivity, 5m:	1046026
Measuring line, conductivity, 10m:	1046027

## 15 Replacing spare part units

- **User qualification, mechanical installation:** trained qualified personnel, see *Chapter 3.4 'Users' qualifications' on page 14*
- **User qualification, electrical installation:** Electrical technician, see *Chapter 3.4 'Users' qualifications' on page 14*



### CAUTION!

#### Check strap for strain relief

Possible consequence: Material damage.

The ribbon cable and its base cannot be mechanically stressed. Hence it is essential when mounting the controller in the control panel, that the check strap (part number 1035918) is fitted for strain relief and mechanical fixing. Without the check strap, the ribbon cable or its base could be damaged if they were to fall out of the top part of the controller housing.


## 15.1 Replacing the top part of the housing



### NOTICE!


#### Ribbon cable base

The base of the ribbon cable is firmly soldered onto the PCB. The base cannot be removed. Open the base lock (3) to loosen the ribbon cable, see Fig. 36




*Fig. 36: Loosening the ribbon cable*

1. ➤ Undo four screws and open the DULCOMETER® Compact Controller
2. ➤ Open the right and left lock (3) (arrows) on the base and pull the ribbon cable (1) out of the socket
3. ➤ The catches (2 and 4) are not needed with units for control panel installation.




*Fig. 37: Dismantling the hinge*

4. ➔ Remove the screw (2), unclip the hinge (1) on the lower part of the controller housing (arrows) and remove the hinge
5. ➔ With control panel installation: Remove the two screws and remove the strain relief



*Fig. 38: With control panel installation: Fit the profile seal onto the top part of the controller housing*

6. ➔ With control panel installation: Position the profile seal (arrow) evenly into the groove in the top part of the DULCOMETER® Compact Controller housing. Arrange the flaps (3) as shown in the figure
7. ➔ With control panel installation: Secure the strain relief (2) using two screws (1)



*Fig. 39: Pushing and locking the ribbon cable in its base*


8. ➔ Push and lock the ribbon cable (1) in its base
9. ➔ Fit the hinge
10. ➔ Screw the top part of the controller housing onto the lower part of the DULCOMETER® Compact Controller housing
11. ➔ With control panel installation: Re-check that the profile seals are fitted properly
  - ⇒ Re-check that the seal is seated properly. Only if the mounting is correct, can IP 67 (wall/pipe mounting) or IP 54 (control panel mounting) degree of protection be achieved

## 15.2 Replacing the lower part of the housing (wall/tube retaining bracket)



### **Complete commissioning of the controller**

*Once the lower part of the housing has been replaced, it is necessary to fully commission the measuring and control point, as the new lower part of the housing does not have specific settings, only factory settings.*



*Fig. 40: Removing the wall/tube retaining bracket*


1. ➔ Remove the wall/tube retaining bracket. Pull the two snap-hooks (1) outwards and push upwards



### **NOTICE!**

#### **Ribbon cable base**

The base of the ribbon cable is firmly soldered onto the PCB. The base cannot be removed. Open the base lock (3) to loosen the ribbon cable, see Fig. 36



*Fig. 41: Loosening the ribbon cable*

2. ➔ Undo four screws and open the DULCOMETER® Compact Controller
3. ➔ Open the right and left lock (3) (arrows) on the base and pull the ribbon cable (1) out of the base. The catches (2 and 4) are used to aligned the two halves of the housing.




Fig. 42: Dismantling the hinge

4. ➔ Remove the screw (2), unclip the hinge (1) on the lower part of the controller housing (arrows) and remove the hinge
5. ➔ Label the cable connectors fitted to distinguish them and remove the cables from the lower part of the controller

### Preparing the new lower part of the controller housing




Fig. 43: Punching out the threaded holes

6. ➔



*Large threaded connection  
(M 20 x 1.5)*

*Small threaded connection  
(M 16 x 1.5)*

Punch out as many threaded holes on the bottom of the lower part of the controller housing as required

### Fit the cable and threaded connectors

7. ➔ Guide the cable into the respective reducing inserts
8. ➔ Insert the reducing inserts into the threaded connectors
9. ➔ Guide the cable into the controller
10. ➔ Connect the cable as indicated in the terminal diagram
11. ➔ Screw in the required threaded connectors and tighten
12. ➔ Tighten the threaded connector clamping nuts so that they are properly sealed

### Refit the controller

13. ➔ Fit the hinge




Fig. 44: Fix the ribbon cable



14. ➤ Push and lock the ribbon cable (1) in its base. The catches (2 and 4) are used to align the two halves of the housing.
15. ➤ Screw the top part of the controller housing onto the lower part of the DULCOMETER® Compact Controller housing
16. ➤ Re-check that the seal is seated properly. IP 67 degree of protection (wall/pipe-mounting) can only be provided if the installation is correct




Fig. 45: Suspend and secure the DULCOMETER® Compact Controller

17. ➤ Suspend the DULCOMETER® Compact Controller at the top (1) in the wall/tube retaining bracket and push using light pressure at the bottom (2) against the wall/pipe retaining bracket. Then press upwards (3) until the DULCOMETER® Compact Controller audibly snaps into position

## 15.3 Replacing the lower part of the housing (control panel installation)



### **Complete commissioning of the controller**

*Once the lower part of the housing has been replaced, it is necessary to fully commission the measuring and control point, as the new lower part of the housing does not have specific settings, only factory settings.*



### **NOTICE!**

#### **Ribbon cable base**

The base of the ribbon cable is firmly soldered onto the PCB. The base cannot be removed. Open the base lock (3) to loosen the ribbon cable, see Fig. 36




Fig. 46: Loosen the ribbon cable from the base

1. ➤ Undo four screws and open the DULCOMETER® Compact Controller
2. ➤ Open the right and left lock on the base and pull the ribbon cable (1) out of the base.




Fig. 47: Dismantling the hinge

3. ➤ Remove the screw (2), unclip the hinge (1) on the lower part of the controller housing (arrows) and remove the hinge




Fig. 48: Removing the strain relief

4. ➤ Remove the strain relief (2). Remove the screws (1) to do so.
5. ➤ Check the profile seal (arrow), then position the profile seal evenly into the groove in the top part of the DULCOMETER® Compact Controller housing. Arrange the flaps (3) as shown in the figure
6. ➤ Remove the top part of the controller housing (3 fixing bolts)
7. ➤ Label the cable connectors fitted to distinguish them and remove the cables from the lower part of the controller

### Preparing the new lower part of the controller housing




Fig. 49: Punching out the threaded holes

8. ➤



*Large threaded connection  
(M 20 x 1.5)*


*Small threaded connection  
(M 16 x 1.5)*

Punch out as many threaded holes on the bottom of the lower part of the controller housing as required

### Fit the cable and threaded connectors

9. ▶ Guide the cable into the respective reducing inserts
10. ▶ Insert the reducing inserts into the threaded connectors
11. ▶ Guide the cable into the controller
12. ▶ Connect the cable as indicated in the terminal diagram
13. ▶ Screw in the required threaded connectors and tighten
14. ▶ Tighten the threaded connector clamping nuts so that they are properly sealed

### Refit the controller




*Fig. 50: Fitting the profile seal on the lower part of the controller housing*

15. ▶ Use pliers to break off the catches. They are not needed for control panel installation

Position the profile seal evenly around the top edge of the lower part of the DULCOMETER® Compact Controller housing. Arrange the flaps (1) as shown in the figure


- ⇒ Ensure that the profile seal evenly surrounds the top edge of the housing.

16. ▶ Insert the lower part of the DULCOMETER® Compact Controller housing with the profile seal from behind into the cut-out and use three screws to secure it in place



*Fig. 51: Fit the profile seal onto the top part of the controller housing*

17. ▶ Position the profile seal (arrow) evenly into the groove in the top part of the DULCOMETER® Compact Controller housing. Arrange the flaps (3) as shown in the figure
18. ▶ Secure the strain relief (2) using two screws (1)
19. ▶ Fit the hinge



*Fig. 52: Pushing and locking the ribbon cable in its base*

- 20.** ➤ Push and lock the ribbon cable (1) in its base
- 21.** ➤ Screw the top part of the controller housing onto the lower part of the DULCOMETER® Compact Controller housing
- 22.** ➤ Re-check that the profile seals are fitted properly
  - ⇒ IP 54 degree of protection can only be provided if the control panel is mounted correctly

## **16 Standards complied with and Declaration of Conformity**

The EC Declaration of Conformity for the controller is available to download on our homepage.


EN 60529 Specification for degrees of protection provided by housings (IP code)

EN 61000 Electromagnetic Compatibility (EMC)

EN 61010 Safety requirements for electrical equipment for measurement, control and laboratory use - Part 1: General requirements

EN 61326 Electrical equipment for measuring, control and laboratory use - EMC requirements (for class A and B devices)

### 17 Disposal of Used Parts

- **User qualification:** instructed user, see  Chapter 3.4 'Users' qualifications' on page 14

#### NOTICE!

##### **Regulations governing the disposal of used parts**

- Note the current national regulations and legal standards which apply in your country

The manufacturer will take back decontaminated used units providing they are covered by adequate postage.

Decontaminate the unit before returning it for repair. To do so, remove all traces of hazardous substances. Refer to the Material Safety Data Sheet for your feed chemical.

A current Declaration of Decontamination is available to download on the ProMinent website.

## 18 Glossary

### Cell constant

The cell constant of a conductive conductivity sensor is determined by the geometry (surface of the electrodes and their distance) of the sensor.

The cell constant can deviate by up to 10% from the nominal value specified on the sensor. The geometry can also change through wear and tear or rough attempts at cleaning it.

Calibrating the cell constant generally compensates for both effects. Films on the sensors, caused for example by dirt or lime can also change the cell constant. The cell constants are generally changed gradually over a long period of time. In the event of change, repeated monitoring or cleaning of the sensor is imperative.

### Temperature coefficients

If an aqueous solution is heated, it increases its electrolytic conductivity, although the concentration of, for example, salts has not changed.

The temperature coefficient compensates mathematically for this temperature influence on the conductivity so that when the temperature of the solution is changed, the same display value always appears (Attention: the temperature has to be measured).

The temperature measurement of a conductivity sensor is sluggish, so that it needs a few minutes until the temperature of the liquid is displayed in a stable manner. Wait until the value is stable or slightly begins to change in opposite directions. In the event of rapid temperature changes, we would recommend an external temperature sensor with a fast response time.

The conductivity measurement is based on a reference temperature, which is usually 25°C. However the conductivity measurement can also be adapted to deviating reference temperatures. A comparison of electrolytic conductivity is also possible with temperature changes to automatic temperature compensation. The temperature coefficient  $\alpha$  is given in %/°C or %/K. With potable water, the temperature coefficient is approximately 2% /°C of the temperature change.

## **19 Index**

### **A**

Accessories . . . . .	100
Action, step by step . . . . .	2
Ambient conditions . . . . .	94
Assembled sensor cables . . . . .	40

### **B**

Basic functions . . . . .	16
Bleeding . . . . .	16
Bottom section of the control housing . . . . .	24

### **C**

Cable connection set . . . . .	18
Cable ties . . . . .	20
Check strap for strain relief . . . . .	101
Chemical Resistance . . . . .	95
Configuration . . . . .	16
Contrast setting . . . . .	51
Control panel cut-out . . . . .	22, 24

### **D**

Deburr the edges . . . . .	22
Declaration of Conformity . . . . .	109
Degree of protection IP 54 . . . . .	24, 37
Degree of protection IP 67 . . . . .	37
Dimensions . . . . .	94
Drill . . . . .	22
Drill holes . . . . .	19
Drilling template . . . . .	22

### **E**

Error Logger . . . . .	88
------------------------	----

### **F**

Fine fuse 5x20 T 0.8 A . . . . .	100
----------------------------------	-----

### **G**

General non-discriminatory approach . . . . .	2
General water treatment . . . . .	16

### **H**

Hysteresis . . . . .	64
----------------------	----

### **I**

Identity code . . . . .	6
Incorrect metering . . . . .	43
Intended Use . . . . .	13
Interference-prone cables . . . . .	29

### **L**

Large threaded connection (M 20 x 1.5) . . . . .	37
Legend for "Wiring" table . . . . .	32
Links to elements or sections of these instructions or other applicable documents . . . . .	2

### **M**

Material thickness of control panel . . . . .	21
Max. switching current: . . . . .	99
Max. switching voltage: . . . . .	99
More symbols . . . . .	2
Mounting (mechanical) . . . . .	18
Mounting kit . . . . .	21
Mounting materials . . . . .	18
Mounting position . . . . .	17



**N**

Noise generation . . . . . 95

Non-discriminatory approach . . . . . 2

**O**

Operating elements . . . . . 49

Original Prominent cable . . . . . 32

Overview of equipment . . . . . 49

**P**

Pipe bracket . . . . . 19

Pipe diameter . . . . . 20

plant rooms . . . . . 95

Preparing the control panel . . . . . 22

Profile seal . . . . . 24

Punch out threaded holes . . . . . 37

**Q**

Question: Does the control have to be adjusted during commissioning? . . . . 44

Question: Does the system have temperature compensation? . . . . . 83

Question: How are the device and sensor calibrated? . . . . . 55

Question: How do I vent the pump, for example? . . . . . 81

Question: How is initial commissioning done? . . . . . 43

Question: How should the controller be mounted in terms of its reading, mounting and operating position? . . . . 17

Question: How should the sensor cable be assembled? . . . . . 30

Question: Is there a legend for the "Wiring" table? . . . . . 32

Question: What applications is the controller intended for? . . . . . 16

Question: What can be calibrated? . . . 55

Question: What can the output relays do? . . . . . 16

Question: What control direction is available? . . . . . 16

Question: What do I have to consider in terms of recycling? . . . . . 17

Question: What do the LEDs indicate? 16

Question: What happens in the event of incorrect calibration? . . . . . 56

Question: What information is made available in the continuous display? . . 52

Question: What information is made available in the info display? . . . . . 53

Question: What is the load capacity of the hinge? . . . . . 17

Question: What needs to be considered in terms of accessibility? . . . . . 17

Question: When are the actuators reset to factory settings? . . . . . 44

Question: Where can I find the Declaration of Conformity? . . . . . 109

Question: Which cable is connected to which threaded connector? . . . . . 31

Question: Which measured variables can be processed? . . . . . 16

Question: Which sensors can I connect to the controller? . . . . . 40

Question: Which standards are complied with? . . . . . 109

**R**

Reducing inserts . . . . . 37

Replacing spare part units . . . . . 101

Replacing the lower part of the housing (control panel installation) . .	105
Replacing the lower part of the housing (wall/tube retaining bracket)	103
Replacing the top part of the housing	101

## **S**

Safety information . . . . .	10
Selection of the sensor connected . . .	40
Sensor connection . . . . .	40
Small threaded connection (M 16 x 1.5) . . . . .	37
Snap-hooks . . . . .	19
Sound Pressure Level . . . . .	95
Spare parts . . . . .	100
Standard scope of delivery . . . . .	18
Standards complied with . . . . .	109
Strain relief . . . . .	24, 37

Strain relief strap . . . . .	100
-------------------------------	-----

## **T**

Top section of the control housing . . .	24
--	----

## **U**

Users' qualifications . . . . .	14
---------------------------------	----

## **V**

Venting . . . . .	81
-------------------	----

## **W**

Wall/pipe bracket . . . . .	19
Washer . . . . .	18
Weights . . . . .	94
Wiring . . . . .	32
Wiring diagram . . . . .	36





ProMinent GmbH  
Im Schuhmachergewann 5 - 11  
69123 Heidelberg, Germany  
Telephone: +49 6221 842-0  
Fax: +49 6221 842-419  
Email: [info@prominent.com](mailto:info@prominent.com)  
Internet: [www.prominent.com](http://www.prominent.com)

985092, 3, en\_GB