

Feromatik m/c injection axis zero setting

Feromatik m/c injection axis zero setting

- 1 Emergency stop
- 2 physical zero 202 visible in shaft
- 3 factory menu service login PW (y-d+h+m)
- 4 factory menu
- 5 page 97
- 6 calibration 1
- 7 manual calibration 1
- 8 axis 2
- 9 emergency unlock
- 10 motor on + green button option 6
- 11 service + S1
- 12 all 0 before given 1
- 13 logout