

# Wemo Robot Zero position Procedure

Wemo Robot Zero position Procedure

# Ensure all axis in Zero Physically

# Select Program/Service

# PW 159357

# Select Settings

# Select Required axis ( X, Y, Z )

# Press  Button

# Press axis  Button +  Reset button

# Asking Do you want zero ( Press yes )

# Select Save button ( Wait until configuration save )

# END