

Whatsminer testpower firmware upgrading Guide

1. Power Repair Test Firmware Instructions:

Firmware—whatsminer-testpower-20220420.bin

Scope of use—P21,P21D,P21E,P221C,P222C,P221B,P222B

Control board type—H3,H6OS,H616


2. Tools:

Tool: whatsminer tool 8.1.30

Tool download address: www.whatsminer.com

3. Upgrade:

Scan to control board ip via whatsminer tool 8.1.30, check the ip, click 'upgrade' - 'select file' - 'start upgrade'.



After the upgrade is successful, check the version information and confirm that the 'version info' is changed to 20220420.

4. Connect the PSU to the controller board, plug the network cable.



5. check

Power on the psu and check the voltage.

missions

Remote Ctrl

Export

IP Monitor

Setting

e...	EnvTemp	ChipTemp	Humidity	Volt	SpdIn	SpdOut	PowerSpd	PowerVIn
0.0	27.0			1500	0	0	6040	226.75

6. Power off, change to next PSU which need to be test, then just repeat the item 4-5.