

**FIGURE** <FOR TEACH VACUUM POINT OF PPF>

1. USE M. CENTERING      → NO  
 2. TRAY SIZE X\*Y        = 5      10  
 3. PARTS PITCH X\*Y     = 31.00 20.00  
 4. ACCESS POINT        = 1      1  
 5. DUMP POINT          → TRAY BACK  
 INPUT NUMBER YOU WANT CHANGE  
 IF IT IS OK INPUT 0.

16-10-9

**FIGURE** <FOR TEACH VACUUM POINT OF PPF>

PLEASE TEACH  
 AND PRESS **RUN** KEY

Under the conditions on this screen, the manual movement keys X+, X-, Y+ and Y- are effective.

16-10-10

Teach the pickup position and press the RUN key.

**FIGURE** <FOR TEACH VACUUM POINT OF PPF>

INPUT PART NUMBER → \_

16-10-11

To continue the teaching procedure, input the next part number.  
 To end the procedure, input 0.

## (1) MENU

## USERBOARD MENU

- <1> MOUNT WORK AREA
- <2> PRE DISPENSE WORK AREA
- <3> DOT DISPENSE WORK AREA
- <4> LINE DISPENSE WORK AREA
- <5> MOUNT UTILITY
- <6> DOT DISPENSE UTILITY

PLEASE SELECT MENU(0:END) = \_

f6-11-3

To run the program , Screen shows fig 6-11-3. menu screen. If inputted 5 key in fig 6-11-3. , screen changes to fig 6-11-4. If inputted 6 key in fig 6-11-3. , screen changes to fig 6-11-5. Fig6-11-3,4,5 shows editor menu.

## Utility for user mount board data

- <11> HEAD AND NOZZLE CHANGE
- <12> HEAD AND NOZZLE CONVERT
- <13> PART NUMBER CHANGE
- <14> PART NUMBER CONVERT
- <15> FEEDER REMOVE (F <- R)

PLEASE SELECT I (0:RETURN) = \_

f6-11-4

## Utility for user dot dispense board data

- <21> DISPENSE HEAD CHANGE
- <22> DISPENSE ANGLE CHANGE
- <23> DISPENSE TIMER CHANGE
- <24> DISPENSE TIMER +, -

PLEASE SELECT I (0:RETURN) = \_

f6-11-5

After selected menu (number inputted) , screen shows fig 1-4, and inquire run or cancel.

&lt;\*&gt; \_\_\_\_\_

SELECT I (0:CANCEL , 1:RUN) = \_

f6-11-6

Only selected menu is displayed.  
Run or cancel key-in is inquired.  
Inputted 0 key on the fig 6-11-6. screen , this selected menu is cancelled and screen changes to fig 6-11-3.

## 2-6-10

## USERBOARD

**This program is used to edit user board data.**

Before software version E52, RUN MODE 1: JOB CONDITION could edit the work area. After software version E52, RUN MODE 1: UTILITY (USERBOARD) is created instead of RUN MODE 1: JOB CONDITION. USERBOARD can edit work area and other functions, for example head, feeder parts number, dispensing timer and so on. At f6-2, choose 10 (USERBOARD).

```

RUNNING      100%  PCB NAME: ABCDEFGH
-----11 : RUNNING-----
RUNMODE1      :UTILITY
RUN MODE2      :NORMAL

10. USERBOARD
UTILITY TO MODIFY
USERBOARD DATA
HEAD NO. FEEDER DATA TIME ETC
CAN BE CONVERTED

SELECT EXEC(0) OR ABORT(1) -->

X=0.00      Y=0.00      R=0.00
  
```

To access screen f6-11-1 from the main menu, enter the following: MAIN (MAIN MENU) → 1 (RUN) → f6 (NEXT) → Select Operation Mode 1: Utility → RUN (RUN) → 10 (10.USERBOARD).

f6-11-1

To run the program, select EXEC (0), and press the RETURN key (↵).

```

USERBOARD <DATA CONVERTER>

PLEASE PRESS RUN KEY
  
```

f6-11-2

Press the "RUN" key.

**(2) WORK AREA SETTING**

- <1> MOUNT WORK AREA
- <2> PRE DISPENSE WORK AREA
- <3> DOT DISPENSE WORK AREA
- <4> LINE DISPENSE WORK AREA

This function is used to execute a part of the mount , pre dispense , dot dispense and line dispense data to change to the "SKIP?" function.

|  |  |
|--|--|
| <> WORK AREA<br>START = 0    END = ***<br>PLEASE SET WORK AREA<br>FROM =    TO = -<br>PLEASE SELECT OBJECT<br>(EXEC:1, SKIP:2, CANCEL:0) | Display current PCB data<br>Please input work area!<br>Select function exec/skip of<br>"SKIP?" or cancel of this function. |
|--|--|

f6-11-7

**(caution)**

Only the contents of the "SKIP?" item in the specified data range are changed. No other data is modified.

**(3) MOUNT UTILITY**

- <11> HEAD AND NOZZLE CHANGE

This function is used to change mount head and nozzle data in the specified data range.

|  |  |
|--|--|
| <11> HEAD AND NOZZLE CHANGE<br>START = 0    END = ***<br>PLEASE SET WORK AREA<br>FROM =    TO = -<br>SELECT HEAD, NOZZLE (1-3, 0: CANCEL)<br>HEAD =    SANC NOZZLE = - | Display current PCB data<br>Please input work area!<br>Select function exec/skip of<br>"SKIP?" or cancel of this function. |
|--|--|

f6-11-8

**(caution)**

Only the contents of the "HEAD" and "NOZZLE" item in the specified data range are changed. No other data is modified.

## &lt;24&gt;. DISPENSE TIMER

This function is used to add or subtract dot dispense timer data in the specified data range.

```

<24>. DISPENSE TIMER
      START = 0   END = ""
PLEASE SET WORK AREA
      FROM =     TO = -
SELECT DOT DISPENSE TIMER
      (-125<->125, 0: CANCEL) _
  
```

Display current PCB data  
Please input work area!  
Please input addition(+) or subtraction(-) dot dispense timer data!

**(caution)**

Only the contents of the "TIMER" item in the specified data range are changed. No other data is modified.

### 2-6-11 COMPVERI (option)

The COMPONENT VERIFICATION utility is a tool for the CSM which allows you to test the TWO-LEAD components: resistors, inductors, capacitors in a semi-automatic way.

Different modes are:

- Check after changing a feeder
- Check each component on the first board of a batch
- Continues check of all two-lead components.

For more information of how to use this utility see separate manual of this option.

**(4) DOT DISPENSE UTILITY****<21> DISPENSE HEAD CHANGE**

This function is used to change dot dispense head data in the specified data range.

```

<21> DISPENSE HEAD CHANGE
      START = 0      END = ***
PLEASE SET WORK AREA
      FROM =         TO =
SELECT HEAD (DOT) (1-3, 0: CANCEL)
  
```

Display current PCB data  
Please input work area!  
Please select new dot dispense head number!

16-11-16

**(caution)**

Only the contents of the "HEAD" item in the specified data range are changed. No other data is modified.

**<22> DISPENSE ANGLE CHANGE**

This function is used to change dot dispense angle data in the specified data range.

```

<22> DISPENSE ANGLE CHANGE
      START = 0      END = ***
PLEASE SET WORK AREA
      FROM =         TO =
SELECT DOT DISPENSE ANGLE
(0 DEG=1, 90 DEG=2, CANCEL=0)
  
```

Display current PCB data  
Please input work area!  
Please select new dot dispense angle number!

16-11-17

**(caution)**

Only the contents of the "R" item in the specified data range are changed. No other data is modified.

**<23> DISPENSE TIMER CHANGE**

This function is used to change dot dispense timer data in the specified data range.

```

<23> DISPENSE TIMER CHANGE
      START = 0      END = ***
PLEASE SET WORK AREA
      FROM =         TO =
SELECT DOT DISPENSE TIMER
(1-255, 0: CANCEL)
  
```

Display current PCB data  
Please input work area!  
Please select new dot dispense timer!

16-11-18

**(caution)**

Only the contents of the "TIMER" item in the specified data range are changed. No other data is modified.

## &lt;13&gt; PART NUMBER CHANGE

This function is used to change "PART" data in the specified data range.

```
<13> PART NUMBER CHANGE
      START = 0      END = ...
PLEASE SET WORK AREA
      FROM =        TO =
SELECT PART NO. (1-120, 0: CANCEL)
```

Display current PCB data  
Please input work area  
Please input new feeder parts  
number

#6-11-13

**(caution)**

Only the contents of the "PART" item in the specified data range are changed. No other data is modified.

## &lt;14&gt; PART NUMBER CONVERT

This function is used to convert "PART" data in the specified data range.

```
<14> PART NUMBER CONVERT
      START = 0      END = ...
PLEASE SET WORK AREA
      FROM =        TO =
SELECT PART NO. (1-120, 0: CANCEL)
      OLD  =        NEW =
```

Display current PCB data  
Please input work area  
Please input old feeder parts  
number and new feeder parts  
number

#6-11-14

**(caution)**

Only the contents of the "PART" item in the specified data range are changed. No other data is modified.

## &lt;15&gt; FEEDER REMOVE (F &lt;-&gt; R)

This function is used to correct mount angle (180 deg) data ,  
if feeder removed (front<-> rear) , in the specified data range.

```
<15> FEEDER REMOVE (F <-> R)
PLEASE KEY IN PART NO.
FEEDER SET POSITION
```

Please input removed feeder  
parts number  
Inputted removed feeder set po-  
sition display

```
SELECT I (0: CANCEL, 1: RUN) =
```

#6-11-15

**(caution)**

Only the R of the mount board data in the specified data range are added or substruct 180 deg. . No other data is modified.



## &lt;12&gt; HEAD AND NOZZLE CONVERT

This function is used to convert mount head and nozzle data in the specified data range.

## &lt;12&gt; HEAD AND NOZZLE CONVERT

- (1). HEAD 1 = HEAD 1
- (2). HEAD 2 = HEAD 2
- (3). HEAD 3 NZZL 1 = HEAD 3 NZZL 1
- (3). HEAD 3 NZZL 2 = HEAD 3 NZZL 2
- (3). HEAD 3 NZZL 3 = HEAD 3 NZZL 3

(1-5:MENU, 0:SETTLED) 1

#6-11-9

In the left side, current head and nozzle setting displays (OLD).

In the right side, after conversion head and nozzle setting displays (NEW).

(This screen shows no head and nozzle are converted)

Please input leftside menu number (1-5).

(This screen shows (1).head 1 is selected)

## &lt;12&gt; HEAD AND NOZZLE CONVERT

- (1). HEAD 1 = HEAD 1
- (2). HEAD 2 = HEAD 2
- (3). HEAD 3 NZZL 1 = HEAD 3 NZZL 1
- (3). HEAD 3 NZZL 2 = HEAD 3 NZZL 2
- (3). HEAD 3 NZZL 3 = HEAD 3 NZZL 3

SELECT HEAD NO. (1-3) 3

#6-11-10

Please input new head NO.

(This screen shows (1).head 1 converted to head 3)

## &lt;12&gt; HEAD AND NOZZLE CONVERT

- (1). HEAD 1 = HEAD 1
- (2). HEAD 2 = HEAD 2
- (3). HEAD 3 NZZL 1 = HEAD 3 NZZL 1
- (3). HEAD 3 NZZL 2 = HEAD 3 NZZL 2
- (3). HEAD 3 NZZL 3 = HEAD 3 NZZL 3

SELECT NOZZLE NO. (1-3) 1

#6-11-11

Please input new nozzle NO.(In the case of nozzle change station and nozzle change head exist)

## &lt;12&gt; HEAD AND NOZZLE CONVERT

- (1). HEAD 1 = HEAD 3 NZZL 1
- (2). HEAD 2 = HEAD 2
- (3). HEAD 3 NZZL 1 = HEAD 3 NZZL 1
- (3). HEAD 3 NZZL 2 = HEAD 3 NZZL 2
- (3). HEAD 3 NZZL 3 = HEAD 3 NZZL 3

(1-5:MENU, 0:SETTLED) 0

#6-11-12

In the right side, after conversion head and nozzle setting displays (NEW).

(This screen shows head no.1 are converted to head no.3 and nozzle no.1)

If all setting done, please input 0:SETTLED key in this screen mode.

## &lt;12&gt; HEAD AND NOZZLE CONVERT

- (1). HEAD 1 = HEAD 3 NZZL 1
- (2). HEAD 2 = HEAD 2
- (3). HEAD 3 NZZL 1 = HEAD 3 NZZL 1
- (3). HEAD 3 NZZL 2 = HEAD 3 NZZL 2
- (3). HEAD 3 NZZL 3 = HEAD 3 NZZL 3

SELECT (0:CANCEL, 1:RUN) =

#6-11-13

screen inquires RUN or CANCEL of this mode.

Inputted 0 key on the screen, this selected menu is cancelled and screen changes to fig

6-11-1.

**(caution)**

Only the contents of the "HEAD" and "NOZZLE" item in the specified data range are changed. No other data is modified.



Manual Function Key Table

Part 2

| Page | Function Key | CRT Display | Operation                 | CO No. | Explanation |
|------|--------------|-------------|---------------------------|--------|-------------|
| 4    | F1           | H1 DOWN     | Head 1 descent ON/OFF     | 20     | 4           |
|      | F2           | H1 TURN     | Head 1 rotation ON/OFF    |        | 5           |
|      | F3           | H1 VAC      | Head 1 picking ON/OFF     | 24     | 6           |
|      |              | H1 DISP     | Head 1 dispensing ON/OFF  |        |             |
|      | F4           |             |                           |        |             |
| 5    | F1           | H2 DOWN     | Head 2 descent ON/OFF     | 21     | 4           |
|      | F2           | H2 TURN     | Head 2 rotation ON/OFF    | 23     | 7           |
|      |              | HP VAC      | Spare head picking ON/OFF |        |             |
|      | F3           | H2 VAC      | Head 2 picking ON/OFF     | 25     | 6           |
|      |              | H2 DISP     | Head 2 dispensing ON/OFF  |        |             |
|      | F4           |             |                           |        |             |
| 6    | F1           | H3 DOWN     | Head 3 descent ON/OFF     | 40     | 4           |
|      | F2           | H3 TURN     | Head 3 rotation ON/OFF    | 42     | 7           |
|      |              | HP DOWN     | Spare head descent ON/OFF |        |             |
|      | F3           | H3 VAC      | Head 3 picking ON/OFF     | 44     | 6           |
|      |              | H3 DISP     | Head 3 dispensing ON/OFF  |        |             |
|      | F4           | H3 VCHG     | Head 3 strong vac. ON/OFF | 46     | 12          |

**Note:** CSM 84VZ only.

[Exp 3]

The back light on head 3 is used at the moment of component recognition (above a fixed camera)

**CAUTION:**

**DO NOT LET THE BACKLIGHT LEDs ON FOR TOO LONG.**

*During normal operation the back light is only on for a very short period. Leaving the backlight LEDs on in manual mode for a too long period, may cause damage to the backlight PCB (if the LEDs stay on too long, the heat radiated by the LEDs causes such a concentrated field of heat that it can result in the LEDs starting to de-solder themselves.).*

## 3-2

# Manual Operation of Actuators Using the Function Keys

Manual operation of various kinds of equipment is possible using the function keys of either the hand-held control unit or the CSM itself. At the bottom of the screen, the six keys F1 to F6 and their corresponding instruments and operations are noted in symbol format. The display can be switched to the one shown below by pressing the F5 (BACK) and F6 (FWD) keys. These function keys are effective not only in manual mode, but at any time that they are displayed on the screen.

The operations of the function keys may not always be displayed, depending on the specifications of the equipment (see 4-4-1, "Machine Configuration").

Manual Function Key Table

Part 1

| Page | Function Key | CRT Display | Operation                        | DO No | Explanation |
|------|--------------|-------------|----------------------------------|-------|-------------|
| 0    | F1           | ORIGIN      | Initialize X-Y-R axes            |       |             |
|      | F2           |             |                                  |       |             |
|      | F3           |             |                                  |       |             |
|      | F4           |             |                                  |       |             |
| 1    | F1           | M-CONV      | Conveyor motor ON/OFF            | 06    |             |
|      | F2           | M-STP.      | Main stopper up/down             | 10    |             |
|      | F3           | LOCATE      | Locating pins up/down            | 11    |             |
|      | F4           | CAMERA      | Teaching camera ON/OFF           | 30    | 8           |
| 2    | F1           | REVERSE     | Conveyor reverse function ON/OFF | 31    |             |
|      | F2           | S-STP.      | Sub-stopper up/down              | 00    | 1           |
|      | F3           | PUSHUP      | PCB pushup plate up/down         | 32    |             |
|      | F4           | CLAMP       | Edge positioning clamp ON/OFF    | 33    | 2           |
| 3    | F1           | C-SPD.      | Conveyor low-speed ON/OFF        | 34    |             |
|      | F2           | PUSHIN      | PCB push-in up/down              | 35    | 2           |
|      | F3           | DO(36)      | Head 3 back light ON/OFF         | 36    | 3           |
|      | F4           | COUNT       | PCB counter                      | 37    |             |

CSM84VZ only

## [Exp 1] S-STP

Displayed if the "SUB STOPPER" item in the machine configuration data is "YES".

## [Exp 2] CLAMP, PUSHIN

Displayed if "EDGE CLAMP" is "YES".

## 3-1-2

Setting the  
Manual Speed

There are two ways to set the manual movement speed of the head, described below.


## [Speed setting in 1% increments]

Speed is decreased by 1% of the current value each time the "SPEED" key is pressed, and incremented by 1% each time the SHIFT + "SPEED" keys are pressed.

## [3-stage speed setting]

Using this function, three speed levels can be set in advance, and then accessed simply by pressing the "SPEED" key. To change the movement speeds, press, while you are in the manual screen (see previous page), the "S" key (= [SHIFT][←]). The screen shown below appears. Input up to three speeds. The value is input by pressing the key after the numerals are entered. When inputting of the speeds is finished, press "EDIT" or "EXIT" to exit the setting screen. After this, each time the "SPEED" key is pressed, the movement speed changes in the order of (1) to (3).

To cancel the preset speeds and return to 1% incremental speed setting, input 0 for all three values.



f1-2-1

## Preferred settings:

## a) 3-stage speed setting:

(1) 2%      (2) 20%      (3) 100%

## b) Speed setting in 1% increments


(1) 0%      (2) 0%      (3) 0%

## SECTION 3 Manual

## 3-1

Manual  
Movement  
of  
the Head

Selecting "MANUAL" on the main menu displays the manual screen shown below. In this mode, operations such as head movement, rotation, ascent/descent, and operation of other equipment units can all be controlled manually.



Movement and rotation of the head can only be controlled through the keys of the control keyboard.

## 3-1-1

## Manual speed

The manual speed of the head is displayed at the top of the screen as a percentage figure. The value can be set between 1-100%, with 100% being the maximum possible speed. Pressing the control keyboard movement keys "X+", "X-", "Y+", "Y-", "R+", and "R-" moves and rotates the head. When the key is released, movement stops. Setting this value to 1-5 initiates fix-step movement, so that the head moves only the specified distance each time the key is pressed.

| Set value % | XY direction speed [mm/s] | Movement distance [mm] | Rotation speed (R) [rpm] | Rotation angle [deg] |
|-------------|---------------------------|------------------------|--------------------------|----------------------|
| 100         | 50.0                      | —                      | 24.0                     | 0.15                 |
| 5           | —                         | 0.20                   | —                        | 0.08                 |
| 4           | —                         | 0.10                   | —                        | 0.04                 |
| 3           | —                         | 0.04                   | —                        | 0.02                 |
| 2           | —                         | 0.02                   | —                        | 0.01                 |
| 1           | —                         | 0.01                   | —                        | —                    |

The values as shown above indicate the distance of the fix-step movement.

## 4-1-2

## Data files

Data is stored on the floppy disk in the form of data files. Aside from PCB data and M.I.S. data, all of the file names are fixed, as shown in the table below.

| Data  | Filename (floppy) | Filename (online) | Data contents        |
|---|-------------------|-------------------|----------------------|
| System data                                     | USER.MCH          | MCH               | Entire system        |
| PCB data  | ***.BRD           | BRD               | One PCB              |
| Parts data                                      | USER.FDR          | FDR               | All registered parts |
| Vision data                                     | USER.VIS          | VIS               | Entire vision        |
| M.I.S.<br>(Management<br>Information<br>System) | ***.PRD           | PRD               | All M.I.S. data      |

## NOTE:

The system data file (USER.MCH) contains the data unique to each individual machine, input into the system at production time. This data should be handled with particular care. When CSM is shipped, this file is already stored in the memory of the controller. It is **strongly recommended to make a software back-up on a floppy disk as soon as the machine is powered up at installation. This disk should be kept as a master disk.** Make a second back-up of this USER.MCH file for 'everyday' use.

## 4-2

Data  
Initialization

In case of a malfunction it is possible that all the machine data (described previously) is reset (e.g. lost of battery power or replacement of the CPU board). For this reason, a floppy disk containing the machine USER file must be loaded via a PC after the power is turned on. Under normal conditions this USER file will stay in the memory because the memory is always under power (battery back-up). However, if the USER data is damaged it is not possible and even dangerous to operate the machine (e.g. no software limits etc). In that case it is necessary to load in or create new USER machine data.

## NOTE:

The machine user file (USER.MCH) is particularly important, as it contains the data unique to each individual machine, which is input when adjusting production output. Make sure to load in a correct USER.MCH file via a Personal Computer (PC) using the UFOS-TOOLBOX utility (option) or equivalent.

*If, after initialization of the system, the text on the screen is in the Japanese language then proceed as follows to switch over to English:*

*System with vision: push <main menu>, <3> (data input),  
<4> (system), <3> (initialize) and at last <enter key>  
System without vision: push <main menu>, <3> (data input),  
<3> (system), <3> (initialize) and at last <enter key>*

## CAUTION:

**After this action your PCB, component and vision data files are deleted!!, so make sure that there is a back-up of these files.**



## SECTION 4 DATA INPUT

## 4-1

## Overview

Selecting "DATA INPUT" (3) on the main menu (MAIN) displays the initial data input screen shown below.

The term "data" includes both system configuration data and data input by the user.

DATA IN

1. PCB
2. COMPONENT
3. VISION
4. SYSTEM

F1 F2 F3 F4 F5 F6

UP DOWN [ ] [ ] [ ] NEXT

To access screen f1-1 from the main menu, press MAIN (MAIN MENU) → 3 (3. DATA INPUT).

← Option (displayed only if unit attached)

← Exp. 1

← Function key display

f1-1

[Exp. 1] SYSTEM

This is displayed only in the initial operation status, to move to the next screen.


Data is divided into four types (or up to 5 types if optional equipment is being used). (See Fig. 4-1.)

- |                            |                                    |
|----------------------------|------------------------------------|
| 1. System                  | Standard                           |
| 2. PCB                     | Standard                           |
| 3. Parts (components)      | Standard                           |
| 4. Production control data | Standard                           |
| 5. Vision                  | standard for 84V/VZ, Option for 66 |

All of the data above is input by the user except for part of the system data and the production control data.

## 4-1-1

## Types of data



## Manual Function Key Table

## Part 3

| Page | Function Key | CRT Display | Operation   | DO No. | Explanation |
|------|--------------|-------------|---|--------|-------------|
| 7    | F1           | TRAY-S      | ON/OFF  | 41     | 9           |
|      | F2           | TRAY 0B     | ON/OFF  | 43     |             |
|      | F3           | TRAY1B      | ON/OFF  | 45     |             |
|      | F4           | TRAY2B      |   | 47     |             |
| 8    | F1           | MA.(Y)      | Mechanical alignment<br>Y direction jaw open/close ON/OFF | 50     | 10          |
|      | F2           | MA.(X)      | Mechanical alignment<br>X direction jaw open/close ON/OFF | 51     | 11          |
|      | F3           | NZL(1)      | Nozzle station clamp ON/OFF                               | 52     |             |
|      | F4           | NST. UP     | Nozzle station up/down ON/OFF                             | 53     |             |
| 9    | F1           | MA.U/D      | Mechanical centering ascent,descent<br>ON/OFF             | 54     | 10          |
|      | F2           | NZL 3       |   | 55     | 11          |
|      | F3           | TRAY 3B     |   | 56     | 9           |
|      | F4           | TRAY 4B     |   | 57     |             |

[Exp. 9] TRAY-S, TRAY0B, TRAY1B, TRAY2B, TRAY3B, TRAY4B

This is displayed unless "TRAY HANDLING" is "NO".

[Exp. 10] MA.(Y), MA.(X), MA.U/D

This is displayed if "M.CENTERING \*" is "YES".

[Exp. 11] NZL(1), NST.UP, NZL3

This is displayed if "NOZZLE STATION" is "ANE Type" or "VISION-ANE Type".

[Exp. 12] H3 VCHG

This toggle function is used to get stronger vacuum to the vision head when using the Automatic Nozzle Exchange feature.



[Exp. 4] HEAD 1 DOWN, HEAD 2 DOWN, HEAD 3 DOWN This is displayed unless the "Head \* SPEC." is "NO".

[Exp. 5] H1 TURN

This is displayed if the "HEAD 1 SPEC." is "DOT DISPENSER" or "LINE DISPENSER".

[Exp. 6] H1 VAC, H1 DISP, H2 VAC, H2 DISP, H3 VAC, H3 DISP

Depending on the head specification, the display content appears as shown below.

| HEAD * SPEC.   | CRT Display                 |
|--|-----------------------------|
| NO   | None                        |
| STANDARD<br>IC<br>ANE<br>VISION ANE<br>DOT DISPENSER | H*VAC<br><br><br><br>H*DISP |
| LINE DISPENSER                                       |                             |

\* = 1, 2, 3

[Exp. 7] H2 TURN, HP VAC, H3 TURN, HP DOWN

Depending on the specifications for the spare head unit and the head, the display contents appear as shown below.

| PREP. HEAD |                                 | CRT Display  |
|------------|---------------------------------|--------------|
| YES        |                                 | HPVAC,HPDOWN |
| NO         | HEAD * SPEC.                    |              |
|            | DOT DISPENSER<br>LINE DISPENSER | H*TURN       |
|            | OTHER                           | None         |


[Exp. 8] CAMERA

This is displayed if "TEACHING CAMERA" is "YES".


## 4-3-2

## Data input


On the screen shown below, the numerical items displayed on the right side are currently input items. Use the following procedure to change these items.



I3-2-1

- 1) Use the F1 and F2 keys to move the highlighted display to the items to be changed (on the left side).
- 2) Press the "EDIT" key to display the cursor.
- 3) Enter the new data with the ten-keys. Pressing the  key inputs the entered value. When inputting is finished, the cursor disappears from the screen.

## NOTE

While the cursor is displayed, the effective keys are the \_\_, \_\_ "INS", "DEL", "EDIT", numeric keys, and . Pressing the "EDIT" key before inputting any values cancels all values input up to that point. The cursor also disappears.

## NOTE

For data appearing with decimal points, make sure you include the decimal point when you change the value. If the decimal point is not included in the new value, the error "101: Format Error" will be displayed and input will be inhibited.

## 4-3

Basic Data  
Inputting  
Operations


## 4-3-1

Selection  
type input

First, the various operations which share the data input screen will be explained.


On the screen shown below, the items displayed on the right, as well as highlighted items, are those currently input. Use the following procedure to change these items.

- (1) When there is a function key display:



If the control keyboard is connected, the ↑ ↓ ← and → keys have the same functions as the function keys, and can be used in the same way.

- 1) Using the F1 and F2 keys, move the highlighted display to the item to be changed. Use the F3 and F4 keys to change selected items on the righthand side.
- 2) When there is no function key display:



- 3) Use the ↑ and ↓ keys to move the highlighted display to the items to be changed, and the ← and → keys to change selected items on the righthand side.

**[Exp.3] POINT REGISTER**

When teaching input for mount and dot dispense point data, one point can be taught and the coordinate input, or two points can be taught and their average value input (only placement positions).

**[Exp. 4] HEAD1 SPEC, HEAD2 SPEC, HEAD3 SPEC**

This sets the specifications of the head with which the mounter is equipped. These specifications are set as shown in the table below, so if changing to a different head specification, change the setting on this screen.

| Display Message | Head Specification                       |
|-----------------|--|
| No              | Not provided                             |
| Standard        | Standard head - straight arm chuck       |
| IC              | Standard head - bend arm chuck (for ICs) |
| AANC            | Automatic Nozzle Change precision head   |
| VISION          | Automatic Nozzle Change Vision head      |
| Dot dispenser   | Standard dispenser head                  |
| Line dispenser  | Line-drawing dispenser head              |
| Mech. chuck     |  |
| Gripper         |  |

**[Exp. 5] BEAM SENSOR, PREP. HEAD, EDGE CLAMP, M. CENTERING1, M. CENTERING2.**

This is where the presence or absence of optional equipment is specified. See Chapter 3, "Option Specifications".

**[Exp. 6] TEACHING CAMERA**

This sets whether or not a special teaching camera is provided. This item is not displayed if the mounter is equipped with a vision board.

**[Exp. 7] CONVEYOR SPEC.**

This sets the conveyor carrying method. If the conveyor is equipped with a U-turn function (see "Option Specifications"), specify "Return". This will cause PCBs to be ejected from the same side on which they were loaded. If "Return" is set for a conveyor which does not actually have a U-turn function, erroneous operation will result, so please be careful.

When "manual" is specified, PCBs are loaded and ejected by hand.

**[Exp. 8] : TRAY HANDLING**

This determines the settings for a tray supply device. This device is an optional specification. For setting it, please refer to the table below.

| Display Message | Tray Supply Device Specifications |
|-----------------|-----------------------------------|
| NO              | Manual Tray Feeder                |
| TRAY STACKER    | Auto tray supply device           |
| TRIPLE PALLET   | 3-stage tray supply device        |
| LCS             | External supply device            |
| MANUAL+LCS      | Fixed tray and LCS both used      |

**[Exp. 9] : FIXED CAMERA 2, 3 AND 4**

This sets the specifications for fixed vision camera conditions. When a vision device is not being used, this is not displayed.

| DATA IN SYSTEM    | MACHINE CONFIG.            |
|-------------------|----------------------------|
| CMU MODE          | :ONLINE,OFFLINE            |
| POINT REGISTER    | :1POINT, 2POINT            |
| MOUNT R ATTRIBUTE | :REL,ABS                   |
| HEAD1 SPEC.       | :NO                        |
| HEAD2 SPEC.       | :NO                        |
| HEAD3 SPEC.       | :NO                        |
| BEAM SENSOR       | :NO,YES                    |
| TEACHING CAMERA   | :NO,YES                    |
| PREP. HEAD        | :NO,YES                    |
| CONVEYOR SPEC.    | :LINE,RETURN,MANUAL        |
| EDGE CLAMP        | :NO,YES                    |
| SUB-STOPPER       | :NO,STANDARD,W SEN         |
| M.CENTERING 1     | :NO,YES                    |
| M.CENTERING 2     | :NO,YES                    |
| NOZZLE STATION    | :NO,YES                    |
| TRAY HANDLING     | :NO                        |
| CAMERA2           | :NO,YES                    |
| CAMERA3           | :NO,YES                    |
| CAMERA4           | :NO,YES                    |
| PCS               | :NOT USE, USE              |
| TRAY EMPTY CHECK  | :NO,YES                    |
| FIDUCIAL DATUM    | :MOUNT POINT, BLOCK ORIGIN |
| BAD MARK DATUM    | :PCB-, BLOCK ORIGIN        |
| MSG OUT TO CMU    | :NO,YES                    |

Exp. 2  
Exp. 3  
Exp. 12

Exp. 4

Exp. 5  
Exp. 6  
Exp. 5  
Exp. 7  
Exp. 5  
Exp. 13

Exp. 5  
Exp. 10  
Exp. 8


Exp. 9

Exp. 16  
Exp. 14  
Exp. 15  
Exp. 1  
Exp. 12


To access screen f4-1 from the main menu, press MAIN (MAIN MENU) → 3 (3. DATA INPUT) → 4 (4. SYSTEM) → 1 (1. MECH. CONF.).

#### [EXP 1] : Bad Mark Datum

A PCB can exist of more than 1 block (sometimes called 'circuits'). In order to find out if a block is correct, bad mark locations can be used. Bad marks can have two types of locations: A bad mark can be located in every block, with the same offset towards the block origin. Only one location must be specified since all other bad marks have exactly the same offset. All PCB block origin coordinates must be known. At run mode the system will first check all bad marks, see which block is correct and will then start placing the components on the PCB. In this case the bad mark positions are relative to the block origins. **Bad Mark Datum = Block Origin**



A second way of defining bad marks is that the positions of these bad marks are relative to the PCB Origin. Bad marks can now be located anywhere, but for system speed performance they are kept close together and as close as possible to the PCB origin. Since the bad marks are only relative to one point, all bad mark locations must be taught. In run-mode the head will travel shorter distances in pre-checking the bad marks before mounting the PCB. This process will enhance system performance. **Bad Mark Datum = PCB Origin**



#### [EXP 2] : CMU MODE

This sets the communication mode through the RS232c port to ONLINE or OFFLINE.

## 4-4

System  
Data Input  
Screen

This section describes the actual data items and the input screen. Operations pertaining to system data are organized as shown in the relational diagram below.

As explained previously, these items appear on the screen **only in initial operation status**. They cannot be changed when operation is interrupted.




Fig. 3-2 System Organization Diagram

## 4-4-1

Machine  
Configuration

This data is set at final production prior shipping. Since the head specifications and optional units differ for each mounter being shipped, these data items set the specifications for that particular machine. There is no need to change the data as long as these specifications are not changed.

Please refrain from changing the data needlessly, as this can cause the specifications and settings to be inconsistent. If this happens, correct operation cannot be guaranteed, and incorrect setting screens may be displayed.

If optional equipment is added, change the settings for the items which require updating. In the following section, the item "Machine Configuration" will be explained.

All changes to data are made by selecting the item to be changed (see 3-3-1).



## 4-3-3

Teaching  
input

"Teaching input" means inputting the robot's current XY coordinate data. Because of this, teaching input is only possible as data handling coordinates. On the screen shown below, the data displayed on the righthand side is the currently input coordinate data. Use the following procedure to enter data as teaching input data.

XXXXXX XXXXXX

---

XXXXX : 0.00 0.00  
 XXXXXXX : 0.00  
 XXXXX : y.yy y.yy  
 XXXXX : 0.00 0.00

TEACHING UNIT XXX

X=x.xx Y=y.yy R=r.rr  
 1F F2 F3 F4 F5 F6 ← Current X, Y, R coordinate data.

- 1) Use the F1 and F2 keys to move the highlighted display to the item you want to change. Teaching input can be entered for the item displaying the current position. In addition, the unit being used for teaching at the current point is displayed at the right side after "Teaching Unit".
- 2) When "One Point" is set in the "Teaching Input" item under the machine configuration data, use the key to input the current coordinate data for the robot.
- 3) When "Two Points" is set in the "Teaching Input" item under the machine configuration data, press the key twice in succession to input the value. The average of the first and second coordinate values is input as the coordinate data.

## NOTE

Before inputting this data, always carry out a return to origin.  
The ten-key input explained previously can also be carried out with this item.  
Two-point teaching is possible only for mount or dot dispense point data.



**[Exp. 3] NOZZLE1 XY, NOZZLE2 XY, NOZZLE3 XY**

This sets the nozzle station position coordinates for ANE or VANE (VISION ANE) heads. It is displayed if "Nozzle Station" in the machine configuration data is "YES". For the teaching unit when this coordinate value is input, the head number input for "ANE" or "VANE" in the head specification of the machine coordinate data is displayed. R data is set to 0.00 when the nozzle station attached as standard, parallel in relation to the conveyor.

**[Exp. 4] M. CENTERING1 XYR, M. CENTERING2 XYR**

The mechanical alignment position coordinates are set here.

This is displayed when the "Mechanical Alignment" item of the machine configuration data is set to "YES".

For the teaching unit when this coordinate value is input, the head number input for "ANE" or "VANE" in the head specification of the machine coordinate data is displayed.

The R data is the value that compensates for erroneous attachment of the mechanical alignment. If there is no error, -90.0 is input.

Remark: -1 means UNIT = LOW (big jaws), -2 means UNIT=HIGH (small jaws).

**NOTE**

With this mounter, there is never more than one ANE or VANE head used at a time. If the specifications have been set up this way, the teaching unit cannot be displayed, which also indicates that teaching input is not possible. (See 4-3-3, "Teaching Input".)

**[Exp. 5] CAMERA2,3,4 XY**

This sets the position coordinates for the fixed vision camera, and is displayed if the "Fixed Camera" item of the machine configuration data is set to "YES". For the teaching unit when this coordinate value is input, the head number input for "Vision" in the head specification of the machine coordinate data is displayed.

**Exp. 6] TEMP.STA1 XY**

The No. 1 temporary station is used for the two types of applications described below, and the coordinate position data is specified here. When the "PREP. Head" option of the machine configuration data is set to "YES", or the "Tray Handling" is set to LCS or "Fixed Tray+LCS", this is displayed.

- 1) When a prep. head is being used and components are being supplied to the tray, this is where they are placed temporarily.
- 2) When a LCS is being used and supplied components being received, this is the supply location.

**NOTE**

The Preparatorial head and LCS cannot both be equipped at the same time.

**[Exp. 7] TEMP.STA2 XY**

This is the coordinate position data when components are supplied via a shuttle on the LCS side, to the NO. 2 temporary station. It is displayed when "Tray Handling" of the machine configuration data is "LCS" or "Fixed Tray + LCS". This station is mainly used to bring defect components back to the LCS for discharging.

## 4-4-2

## POSITION

This data is set at the time of production shipping adjustment.  
Coordinates are explained below. Data may be changed by using the control keyboard or input by teaching input.

| DATA IN SYSTEM   | 50%<br>PARAMETER | COORDINATES |
|------------------|------------------|-------------|
| +SOFTLIMIT XY    | 0.00             | 0.00        |
| Z                | 0.00             |             |
| R                | 0.00             |             |
| -SOFTLIMIT XY    | 0.00             | 0.00        |
| Z                | 0.00             |             |
| R                | 0.00             |             |
| LOCATE PIN       | 0.00             | 0.00        |
| PCB CORNER       | 0.00             | 0.00        |
| WAITING PNT      | 0.00             | 0.00        |
| DUMPING PNT      | 0.00             | 0.00        |
| FRONT FDR. DATUM | 10               |             |
| DATUM XY         | 0.00             | 0.00        |
| REAR FDR. DATUM  | 40               |             |
| DATUM XY         | 0.00             | 0.00        |
| NOZZLE 1 XY      | 0.00             | 0.00        |
| NOZZLE 2 XY      | 0.00             | 0.00        |
| NOZZLE 3 XY      | 0.00             | 0.00        |
| M.CENTERING 1 XY | 0.00             | 0.00        |
| R                | 0.00             |             |
| M.CENTERING 2 XY | 0.00             | 0.00        |
| R                | 0.00             |             |
| CAMERA 2 XY      | 0.00             | 0.00        |
| CAMERA 3 XY      | 0.00             | 0.00        |
| CAMERA 4 XY      | 0.00             | 0.00        |
| TEMP.STA1 XY     | 0.00             | 0.00        |
| TEMP.STA2 XY     | 0.00             | 0.00        |
| TEACH UNIT XXX   |                  |             |
| X=0.00           | Y=0.00           | R=0.00      |
| F1               | F2               | F3          |
| F4               | F5               | F6          |

To go to screen (4-2 from the main menu, press "MAIN MENU" key. → 3 key → 4 key → 2 key → 1 key.

Exp. 8

Exp. 10

Exp. 11

Exp. 1

Exp. 2

Exp. 9

Standard

Option

Exp. 3

Remark:

Exp. 4

All coordinates are related to MACHINE ORIGIN!!

Exp. 5

Exp. 6

Exp. 7

F4-2

## [Exp. 1] WAITING PNT

This sets the standby position coordinates for the head. To change the standby position, select coordinates that meet the conditions below.

- 1) The unit will not be affected by the warming-up process of the head (for example, a conveyor).
- 2) The sub-stopper sensor and set position sensor will not be affected by the head (this can cause erroneous operation).

## [Exp. 2] DUMPING PNT

This establishes the position where components are discarded. If there is a picking or mounting error, the head moves to this position and discards the part. Setting of this point is left to the user.

**[Exp. 13] SUB-STOPPER.**

The Sub-stopper can be changed in the following modes:

- 'STANDARD' TYPE
- 'W SENSOR' TYPE This is a new sub-stopper system with 2 sensors.  
(Option)
- 'MOVING' TYPE This is a new sub-stopper system for high speed PCB exchange.  
(Option)

**[Exp. 14] : TRAY EMPTY CHECK**

When set to NO, after the last component is picked, the head will try to pick the next component again at the beginning of the defined tray. The tray must have been refilled by then.

When set to YES; after the last component is picked, the CSM will place the component and then will execute an error. The orange warning light is switched on and an error message 'Tray Empty' will be shown on the screen. This is to indicate that the empty tray must be replaced.

**[Exp. 15]: FIDUCIAL DATUM (=Local Fiducials)**

When set to **Block Origin** the local fiducial coordinates are relative to the block origin. In case of more blocks per PCB, teaching of local fiducials is done for one block only since the coordinates are the same for every block.

When set to **Mount Point**, the local fiducial coordinates are relative to the mount point. All local fiducials, on one or more blocks on a PCB, must be taught separately.

**[Exp. 16]: PCS**

When this option is set to 'NOT USE', the CSM cannot be controlled by the Production Control System software. When set to 'USE', the CSM can be controlled by the Production Control System software.

**Note:**

*This option is only available in firmware version -063 and higher*

**[Exp. 10] : NOZZLE STATION**

The equipment conditions for the nozzle station device are set.

| Display Message  | Tray Supply Device Specification |
|------------------|----------------------------------|
| No               | Not equipped                     |
| AANC type        | ANE head                         |
| VISION HEAD type | For VISION head                  |

**[Exp. 11] : MSG out to CMU**

This parameter must be set to YES, if all the error messages which are displayed on the CSM -error-line are to be send to an external device.

**[Exp. 12] MOUNT R ATTRIBUTE**

The definition of the Rotation (R) in the mount data is selectable.

"REL" shows the mount data R relative see fig. 4-1-1

"ABS" shows the mount data R absolute see fig. 4-1-2

(CAUTION)

Do not change "ABS" or "REL" during RUNNING. The "ABS" data will not be supported by the APG/LOP software rel 2.1 package.

**RELative**



















| Feeder angle      |  |  |  |   |
|-------------------|---|--|---|---|
| Pick up angle     | 0 deg   | 180 deg  | 90 deg  | -90 deg   |
| Mount angle 0 deg |  |  |  |  |
| 180 deg           |  |  |  |  |
| 90 deg            |  |  |  |  |
| -90 deg           |  |  |  |  |

fig. 4-1-1

**ABSolute**



















| Feeder angle      |  |  |  |   |
|-------------------|---|--|---|---|
| Pick up angle     | 0 deg   | 180 deg  | 90 deg  | -90 deg   |
| Mount angle 0 deg |  |  |  |  |
| 180 deg           |  |  |  |  |
| 90 deg            |  |  |  |  |
| -90 deg           |  |  |  |  |

fig. 4-1-2

4-4-3  
Offset

CSM84VZ Only

**CAUTION**

When changing the head 3 offset, **ALWAYS** check the positions of the e.g. ANE station, MA-Unit, LCS shuttle pad, Feeders. When using the ANE Station with incorrect Head 3 Offset may cause damage to the Head 3 Assembly.

CSM84VZ Only

DATA IN  
SYSTEM PARAMETER OFF SET

|             |   |      |      |        |
|-------------|---|------|------|--------|
| CAMERA      | : | 0.00 | 0.00 | Exp. 1 |
| BEAM SENSOR | : | 0.00 | 0.00 | Exp. 2 |
| HEAD.1 XY   | : | 0.00 | 0.00 | Exp. 3 |
| R           | : | 0.00 |      |        |
| HEAD.2 XY   | : | 0.00 | 0.00 | Exp. 3 |
| R           | : | 0.00 |      |        |
| HEAD.3 XY   | : | 0.00 | 0.00 | Exp. 4 |
| Z           | : | 0.00 |      |        |
| R           | : | 0.00 |      | Exp. 5 |
| PREP.HEAD   | : | 0.00 | 0.00 |        |
| TRACK WIDTH | : | 0.00 |      |        |

F4-3

To go to screen 14-3 from the main menu, press "MAIN MENU" key. → 3 key → 4 key → 2 key → 2 key.

## [Exp. 1] CAMERA

This is displayed if a vision board is specified, or if the "Teaching Camera" item in the machine configuration data is set to "YES".

## [Exp. 2] BEAM SENSOR

This is displayed if the "Beam Sensor" item in the machine configuration data is set to "YES".

## [Exp. 3] HEAD1,2,3 XYZR

This is displayed unless the head specification in the machine configuration data is set to "NONE". For a dispenser head, the R offset is not displayed.

The Z offset is the Z coordinate value at the point where the underside of the nozzle and the surface of the PCB first come in contact. The value is normally between -20.00mm and -21.00mm.

## [Exp. 4] PREP. HEAD

This is displayed if the "Spare Head" item in the machine configuration data is set to "YES".

## [Exp. 5] TRACK WIDTH (Option)

Input the initial conveyor width at the origin point of the conveyor (at the back). Input a value which is 0.5mm smaller than the actual value.

## XY Offset

Suppose that components from one supply device (for example, feeder bar No. 10) are being picked up by various different heads (1-3). Because the movement target positions for the XY robot are different, the nozzle of each head moves to the picking position of feeder No. 10. Since there is only one picking coordinate data item for feeder No. 10, the XY coordinate data for the feeder **must be compensated for each head. This compensation of the XY coordinates is called "offset"**. With the CSM the unit whose XY offset amount is 0.00 is the "teaching reference". The offset for each head indicates the amount of shift for this teaching reference unit. (See Fig. 4-5.)

**[Exp: 9] FRONT FDR. DATUM, REAR FDR. DATUM, DATUM XY**

This is the reference data for automatic calculation of the picking position coordinates for the tape feeders (8, 12, 16, 24, 32 embossed and 44 embossed) set on the front and rear plates. In the "Front Feeder Reference", the user specifies which front/rear feeder bar position is to be the reference feeder, and in "Reference XY Position", the picking position coordinates for that reference feeder.

The standard specifications contain the picking position coordinates for the 8mm tape feeder which is 10th from the left end. This serves as a reference in calculating the picking position coordinates for all of the feeders set on the front and rear plates.

Setting is done in the same way for the rear feeders.

**NOTE**

Always use an 8mm tape feeder for teaching the reference position, and use a teaching unit which will be displayed on the screen. If either of these rules is not followed, the head cannot move to the correct picking position.

**NOTE**

Depending on the conditions of the optional equipment, teaching input may not be possible for the 10th feeder from the left end. In this case, change to the "Feeder Reference" and input new coordinates for "Reference XY Position".

**[Exp. 10] LOCATE PIN XY**

The position coordinates of the PCB positioning pins on the fixed side are input.

**[Exp. 11] PCB CORNER XY**

The position coordinates of the PCB corner at the front of the subsequent machine side are input, when the pcb is secured in the work area.



### Setting the + XY soft limit

As shown in Fig. 4-4, an 8mm tape feeder can be attached in the No. 2 position from the right end of the rear feeder bar.

Next, the picking position of this feeder for Head No. 2 is taught. Move along the XY axis in the + direction, approximately 1mm at a time from this position, to set the position through teaching input.




Fig. 4-4. + soft limit

#### NOTE

Never run this setting unless a return to origin has already been carried out. Depending on the condition of the optional equipment, there are times when the limit value cannot be determined using this method.



## [Exp. 8] +SOFTLIMIT XYZR, -SOFTLIMIT XYZR

The XY data contains the movable range for the head. After a return to origin has been completed, if the robot tries to move beyond this movable range in either manual movement or in the automatic operation mode, movement is stopped; in manual mode, a movement stop is applied, and in automatic operation mode, an operation interrupt status is applied. In the same way, the R data sets the allowable rotation for the head.

With standard specifications, this is set to a value less than the relevant soft limit data value.

## CSM84VZ only:

The Z data contains the movable range for the Z-Axis Servo. The values of the Z-axis soft limit in the plus and minus directions should be input as follows:

Z-Soft Limit in the plus direction: Between +1.00 and +3.00 mm

Z-Soft Limit in the minus direction: Between -22.00 and -25.00 mm

## Setting the - XY soft limit

As shown in Fig. 4-3, an 8mm tape feeder can be attached in the No. 2 position from the left end of the front feeder bar.

Next, the picking position of this feeder for Head No. 2 is taught. Move along the XY axis in the + direction, approximately 1mm at a time from this position, to set the position through teaching input.




Fig. 4 - 3 soft limit

## 4-4-7

**AUTOMATIC  
CONVEYOR  
WIDTH  
CONTROL  
SYSTEM  
(Option)**

## &lt;1&gt; Settings

Machine with AUTOMATIC CONVEYOR WIDTH CONTROL shows below message when machine powers on .

**YM\*\*\* ,SERVO Z,\*\*\*\* R**

AUTOMATIC CONVEYOR WIDTH CONTROL uses the Z axis for conveyor width , and Z origin existed conveyor maximum width . So system uses W axis for display a real conveyor width .

**W = (Z origin(maximum) width) - Z**

Please set TRACK WIDTH in OFFSET (DATA IN SYSTEM PARAMETER OFFSET) .The width of 0.5 (mm) is needed so the PCB can go smoothly through the conveyor without jamming.

**TRACK WIDTH = (Z origin(maximum) width) - 0.5 (mm)**

Please set SOFT LIMIT Z+ and SOFT LIMIT Z- in POSITION (DATA IN SYSTEM PARAMETER POSITION).

**SOFT LIMIT Z+ = TRACK WIDTH - 30mm(minimum size)+0.50mm**  
**SOFT LIMIT Z- = -0.50mm**

Please set PCB WIDTH in PCB SHAPE (DATA IN PCB PCB SHAPE).

**PCB WIDTH = measured PCB width**

## &lt;2&gt; EXECUTION in RUNNING Mode

Machines with AUTOMATIC CONVEYOR WIDTH CONTROL stops and shows below message when automatic operation is executed by RUN key in RUNNING mode . In the case of within 1.0 (mm) conveyor width motion , operation continues .

**JOB : INITIALIZE  
CONVEYOR WIDTH WILL  
BE CHANGED TO 128  
ASSURE THE SAFE  
AND PUSH RUN KEY**

Please remove PCB on conveyor and push-up pins , and push RUN key , then conveyor width operation starts . After this , conveyor keep position .

## NOTE

- 1) While the display shows "OPERATION INTERRUPTED" , don't change conveyor width in manual mode .
- 2) Remove the PCB from the conveyor and let the 'push-up' pins down, before starting the conveyor width operation.

4-4-5  
CountersDATA IN  
SYSTEM PARAMETER COUNTER

|               |   |   |
|---------------|---|---|
| RETRY TIME    | : | 0 |
| PCB COUNT MAX | : | 0 |

To go to screen f4-5 from the main menu, press "MAIN MENU" key. → 3 key → 4 key → 2 key → 4 key.

Exp. 1  
Exp. 2

F4-5

## [Exp. 1] RETRY TIME

This sets the number of retries carried out after erroneous picking or mounting in the mounting operation. It is normally set to 3, but a value from 0-7 can be input. If 0 is set, no retry is carried out.

## [Exp. 2] PCB MOUNT MAX

This is used when the mounter is connected to a loader. It is normally set to 0. A value between 1-255 can be input, and when that number of PCBs has been produced, operation stops to prevent loader overflow.

Remark: 0 means continuous production.

4-4-6  
Communi-  
cations pa-  
rameters

These are the parameters which set the conditions for communication between the CSM and an external host computer when an RS-232C interface is used. For details on communications conditions, please refer to Section 5, "RS-232C Interface". Data setting is done through selection-type input (see 3-3-1). Starting UFOS version E64 settings for the HOST as well as for the EXT port can be defined separately.

**Note:** Separate HOST and EXT settings only possible with UFOS versions E64 and Higher.

DATA IN  
SYSTEM PARAMETER CMU PARAMETER

1. HOST  
2. EXT

DATA IN  
SYSTEM PARAMETER CMU PARAMETER EXT (or HOST)

|          |   |                      |
|----------|---|----------------------|
| DATA BIT | : | 8                    |
| BIT RATE | : | 2400,4800,9600,19200 |
| STOP BIT | : | 1,2                  |
| PARITY   | : | NONE,ODD,EVEN        |
| CR/CRLF  | : | CR,CRLF              |
| XON/XOFF | : | NO,YES               |

**NOTE:**

The high lighted parameters are the standard settings.

#### 4-4-4 Timers

| DATA IN<br>SYSTEM          | PARAMETER | TIMER |
|----------------------------|-----------|-------|
| SET-PIN UP                 | :         | 0.00  |
| SET-PLATE UP               | :         | 0.00  |
| MOUNT CHECK<br>AFTER MOUNT | :         | 0.00  |

To go to screen F4-4 from the main menu, press "MAIN MENU" key. → 3 key → 4 key → 2 key → 3 key.

Exp. 1  
Exp. 2  
Exp. 3  
Exp. 4

F4-4

##### [Exp. 1] SET-PIN UP

This sets the time from the point where the set position sensor detects a PCB to where the locating pin ascent command is transmitted. Normally, this setting does not have to be changed.

With a variable-speed conveyor, the timer has to be adjusted so that the setting of the low-speed knob, the position of the PCB set position sensor, and the time from the set position sensor detection to the pin ascent are all coordinated with each other.

##### [Exp. 2] SET-PLATE UP

This sets the time from the point where the set position sensor detects a PCB to where the pushup plate ascent command is transmitted. Normally, this setting does not have to be changed.

With a variable-speed conveyor, the timer has to be adjusted so that the setting of the low-speed knob, the position of the PCB set position sensor, and the time from the set position sensor detection to pushup are all coordinated with each other.

##### [Exp. 3] MOUNT CHECK

This is displayed, and can be set, when "ANE", or "VANE" is set for the "Head \* Specification" in the machine configuration data.

With these heads, a mounting check is carried out right after picking and mounting are finished. This is the mounting check timer for the time starting right after mounting is finished to the point where the sensor is checked. If this time interval is not set large enough, the checking procedure cannot be conducted properly.

##### [Exp. 4] AFTER MOUNT

This is displayed, and can be set, when "ANE", or "VANE" is set for the "Head \* Specification" in the system machine configuration data. With these heads, a mounting check is carried out right after mounting is finished. This is the post-mounting check timer for the time starting right after mounting is finished to the point where the negative-pressure generating switch is turned on. Be careful that sufficient time is provided for checking, especially if the parts being mounted are taller than ordinary parts.




Fig. 4-5. Offset

The center of a unit which has been offset can be thought of as the coordinate axis which serves as the origin. The + direction of the coordinate axis is the same as the robot XY axis. At this point, the center coordinate of the teaching reference unit becomes the offset of the other unit. In actuality, the same point is taught with each of the various units, and then, from the XY data obtained by teaching the unit to be offset, the XY data obtained by teaching with the teaching reference unit is subtracted. In this way, the offset can be obtained for each unit. (See Section 4, Chapter 2, "Using Utilities".)

The teaching references for the CSM are determined in the priority order shown below.


|        |               |             |       |              |
|--------|---------------|-------------|-------|--------------|
| Camera | -----         | Beam sensor | ----- | Head 1       |
| ←      | High priority |             |       | Low priority |


**NOTE**

On the offset setting screen, the unit shown in the uppermost position is the teaching reference. The XY offset values for the teaching reference unit (the uppermost unit in the display) will always be 0.00 for both the X and Y values.

R Offset

This is used for the angle compensation of a chuck-type mounting head. When the R rotation axis is 0.00 [deg], the chuck angle will never be 0.00. The R offset is used to correct this, and is determined by the actual component to be mounted.


- 3) To delete a point that has been input, use the "DEL" key. When the screen shown below is displayed, input the point number to be deleted, or the range of point numbers. When the  key is pressed, a confirmation message is displayed. Follow the directions in the message. To cancel, press the "EXIT" key.




f5-3-2

## NOTE

Bad mark points cannot be deleted.

- 4) When copying an input point to another number, use the "COPY" key. The screen shown below is displayed. Input the original point number range and the first point number of the destination point. When the  key is pressed, a confirmation message is displayed. Follow the directions in the message. The original point becomes the point shown in the display. To cancel, press the "EXIT" key.



f5-3-3

## NOTE

When copying from mount point data to dot dispense point data, insert a "D" at the beginning of the destination, as shown here. ####-####. D#### When copying from dot dispense point data to mount point data, insert an "M" at the beginning of the destination, as shown here. ####-####. M#### When copying between mount point and dot dispense point data, or copying fiducial point data, only XY coordinate data is copied. Deleting and copying point data can only be done on the leftmost page.



**[Point Data Input]**

This is based on the data input operation (par. 4-3), but there are some operations which are unique to the point input screen.

- 1) Ten-key (keys 0-9) input is done one item at a time. When input is completed by pressing the  $\diamond$  key, the cursor moves to the next item. The item to which the cursor moves next is determined by the results of data input up to that point and the settings of the system machine configuration data (par. 4-4-1). Always make sure that coordinate data contains a decimal point.  
For some items, when the cursor moves it changes to a highlighted display. For these items, use the  $\leftarrow$  and  $\rightarrow$  keys to select the content, and the  $\diamond$  key to terminate the input. The "EDIT" key can also be used to conclude input for these items, but if this is done, the cursor disappears and will not move to the following items.
- 2) Teaching input is only possible on the leftmost page. Use the  $\uparrow$  and  $\downarrow$  keys to move the highlighted display to the point number where teaching input is to be entered. As explained previously, for teaching input of mount and dot dispense points, either one-point or two-point input is possible. One-point data is input by pressing the  $\diamond$  key once. For two-point data, two points are taught, and their average value is input. Two-point teaching is used when teaching the center of a pad on the PCB. By teaching two points on a diagonal line on the pad, the center position can be input. When teaching of the first point is concluded (by pressing the  $\diamond$  key), a message is displayed indicating that the next point can be taught. Continue teaching input. If teaching is not continued, the first point input is cancelled, and the message described previously disappears from the screen. If this happens, it is necessary to start over again, teaching from the first point. Teaching of block origins beyond the No. 1 origin point is only possible when the PCB origin and No. 1 block origin has been input. Subsequent points can only be taught if the PCB origin and No. 1 block origin have been input. At the right side of the teaching unit display screen, the current coordinate origin is displayed. Values entered through teaching input are automatically related to values of that origin.

**NOTE**

Teaching input of fiducial point data is not possible. Fiducial point data is supposed to be provided by the CAD department.

It is not possible to teach the ROTATION.



#### 4-5-3 Point input screen


In this section, the displays and operations common to all of the point input screens are explained.


##### [Basic Configuration of Point Data]

All point data is composed of the two types of data listed below.

- (1) X, Y, (R) coordinate data
- (2) Other necessary information

##### [Displays and Operations on Point Data Screens]

- 1) Up to a total of 2560 points of point data can be input for all of the PCB's. So with 10 PCB files each file can contain 256 points of point data. Ten points are displayed on the screen at one time. Use the "ROLL UP", "ROLL DOWN", ↑ and ↓ keys to change the point data display.
- 2) Because one point contains a great deal of information, this cannot all be displayed on the screen at one time. Use the → key to see the right page and the ← key to see the left page. When moving from the point table screen (par. 4-5-2) to the various point screens, the leftmost page is displayed. The number of pages varies depending on the point. Coordinate data is displayed on the leftmost page.
- 3) To change the displayed point, the desired point number can be input directly. When the numeric keys are pressed, a screen like that shown below is displayed. The first number pressed is displayed; continue inputting. When the  key is pressed, the point data for the number input at that point is displayed, starting at the top. If the input number exceeds the maximum point number (for fiducial points, this is 7), the error message "120: NO POINT" is displayed, and the system returns to the original screen.



DATA IN 100% PCB NAME : MOUNTER  
PCB XXXXX

| NO. | X [MM] | Y [MM] | R [DEG] |
|-----|--------|--------|---------|
| 0   |        |        |         |
| 1   |        |        |         |
| 2   |        |        |         |
| 3   |        |        |         |
| 4   |        |        |         |
| 5   |        |        |         |
| 6   |        |        |         |
| 7   |        |        |         |
| 8   |        |        |         |
| 9   |        |        |         |

CHANGE POINT No. : ###  
X

IS-3-1

#### NOTE

This direct point display function does not work for bad mark points.

#### 4-5 PCB Data Input Screen




Fig. 4-6. Relational Diagram of PCB

#### 4-5-2 Point table

This function displays a table of PCB points read from the host PC. This screen is used to access the input screens for the various points.

PCB NAME : MOUNTER  
 REMAINED POINT : 2560

|                      |  |  |  |  |  |
|----------------------|--|--|--|--|--|
| 1. ORIGIN            |  |  |  |  |  |
| 2. FIDUCIAL          |  |  |  |  |  |
| 3. BAD MARK          |  |  |  |  |  |
| 4. MOUNT             |  |  |  |  |  |
| 5. PRE-DISPENSE      |  |  |  |  |  |
| 6. DOT-DISPENSE      |  |  |  |  |  |
| 7. LINE-DISPENSE     |  |  |  |  |  |
| 8. LINE-DISPENSE SUB |  |  |  |  |  |

F1 F2 F3 F4 F5 F6  
 UP DOWN [ ] [ ] [ ] [ ] [ ] [ ]

Name of currently selected PCB  
 No. of remaining points which can be input  
 Exp. 1  
 Exp. 2  
 Exp. 3  
 To access the f5-2 screen from the main menu, press MAIN (MAIN MENU) → 3 (DATA INPUT) → 1 (1. BOARD) → 16 (NEXT).

f5-2-1

#### [Exp. 1] Fiducial/Bad Mark

The fiducial and bad mark items are displayed only when a vision board has been installed, or when the "Beam Sensor" item in the machine configuration data is set to "YES".

#### [Exp. 2] Pre-dispense/Dot Dispense

The pre-dispense and dot dispense items are displayed only when a head exists for which "Dot Dispenser" or "Line Dispenser" is set in the head specification item of the machine configuration data.

#### [Exp. 3] Line Dispense/Line Dispense Sub

The line dispense and line dispense sub items are displayed only when a head exists for which "Line Dispenser" is set in the head specification item of the machine configuration data.




Fig. 4-7. Fiducial Point Input Screen Flow

[Exp. 3]

Because two marks form one group, the coordinates are set separately for each mark. First, the coordinates for the scanning mark are set on the left side, and then the coordinates for the other mark are set on the right. Input the XY coordinates for these marks related to the origin values as shown below.

| How the mark is used:   | Data origin:       | Fiducial type:          |
|---|--------------------|-------------------------|
| No. 0 group is used for compensation of entire PCB, as in method 1).            | PCB origin         | PCB fiducial            |
| No. 0 group is used for compensation of individual blocks, as in method 2).     | Block No. 1 origin | Block fiducial          |
| Groups No. 1 to No. 7 is used for compensation of the point or local fiducials. | Mount point origin | Point or Local fiducial |

In addition to the position coordinates for the marks described above, it is necessary to specify various information items relating to fiducial points. All of this information is specified on the righthand screen following the screen shown above. The items determined necessary by the system machine configuration settings and the optional equipment conditions are displayed, so input data for the displayed items as requested. Fig. 4 -7 shows the flow of these specification screens.

**NOTE**

The distance between two marks must be set to less than 570.00 [mm].

## 4-5-5

## Fiducial



NOTE

This is where information relating to fiducial marks is stored. Two fiducial marks form one pair. With the CSM, up to 16 pairs of data can be set.

Fiducial Datum can only be input when in the RUNNING menu it is defined whether the datum of the fiducial is relative to the PCB or BLOCK origin. If this setting is not set, then the following error is displayed on the screen:

"66: SELECT DATUM POINT"

DATA IN 100% PCB NAME : MOUNTER  
PCB FIDUCIAL

| NO. | X [MM] | Y [MM] | X [MM] | Y [MM] |
|-----|--------|--------|--------|--------|
| 0   | 0.00   | 0.00   | 0.00   | 0.00   |
| 1   |        |        |        |        |
| 2   |        |        |        |        |
| 3   |        |        |        |        |
| 4   |        |        |        |        |
| 5   |        |        |        |        |
| 6   |        |        |        |        |
| 7   |        |        |        |        |

X=0.00 Y=0.00 R=0.00  
F1 F2 F3 F4 F5 F6

LOCATE MSTP LOCATE FWD

To go to screen f5-5-1 from the main menu, press "MAIN MENU" key. → 3 key → 1 key → F6 key → 2 key.

f5-5-1

[Exp. 1]

The No. 0 fiducial mark group is used as compensation in the two cases described below.

- 1) Entire PCB fiducial correction
- 2) Block fiducial correction

The type of No. 0 group is determined on the operation conditions screen (par. 2-2).

[Exp. 2]

Groups No. 1 to No. 7 are used for storing the XY data [X(f1-1), X(f1-2), Y(f1-1) and Y(f1-2)] of the point (or local) fiducials (f1-1 and f1-2) related to the centre of the PCB mount point (M1) see fig f5-5-1a.




fig. f5-5-1a

4-5-4  
Origin

This is where the origin point coordinate data is stored.

**Note:** This screen should be called "ORIGIN" instead of "PCB ORIGIN" because it gives not only PCB but also BLOCK origins.

DATA IN 100% PCB NAME : MOUNTER

PCB ORIGIN\*\*

| NO. | X [MM] | Y [MM] | R [DEG] | SKIP?  |
|-----|--------|--------|---------|--------|
| 0   | 125.00 | 45.00  |         |        |
| 1   | 0.00   | 0.00   | 0.00    | NO     |
| 2   |        |        | ↑       | ↑      |
| 3   |        |        | Exp. 3  | Exp. 4 |
| 4   |        |        |         |        |
| 5   |        |        |         |        |
| 6   |        |        |         |        |
| 7   |        |        |         |        |
| 8   |        |        |         |        |
| 9   |        |        |         |        |

TEACH UNIT XXX DATA FROM MCH ORG

X=0.00 Y=0.00 R=0.00

F1 F2 F3 F4 F5 F6

MODET IM-STP LOCATE FWD

15-4-1

Item display

PCB origin coordinates Exp. 1

Block origin coordinates Exp. 2

To go to screen 15-4-1 from the main menu, press "MAIN MENU" key. → 3 key → 1 key → F6 key → 1 key.

## [Exp. 1] PCB origin coordinates

The No. 0 point is called the PCB origin. Only XY data can be input for this item. The coordinate origin at this point is related to the XY machine origin ( machine origin = the head position when a return to origin is carried out after power is turned on).

## [Exp. 2] Block origin coordinates

Points No. 1 and further are called "block origins". The origin for these is the PCB origin noted above.

## [Exp. 3] R

This can only be input for block origin point data.

## [Exp. 4] SKIP ?

"SKIP?" is set as shown below.

| Display message | Relevant block operation         |
|-----------------|----------------------------------|
| NO              | Run (Don't mount chips on block) |
| YES             | Not run (mount chips on block)   |



## SCREEN 1

The screen will only contain one line (line 0). In this screen the coordinates of the bad mark must be defined (the x and y coordinates as shown in figure 5-6-1). The coordinates can be taught and are shown relative to the block origin.

**MARK POS. XY [mm]** : Teach or define the X and Y coordinates of the Bad Mark

## SCREEN 2

When, in the RUNNING menu, the BAD MARK CHECK is set to MASTER MARK, then coordinates of the **Master Bad Mark** must be entered here. Especially in the case that a PCB exists of more than one block a master mark is useful. The system, before a dispense or mount job is started, will check first all blocks to see if a bad mark exists on a block. After this cycle, the system will mount/dispense all blocks that were not marked. If, in most cases, all blocks are good, then it is useful to only check for the bad marks when it is sure a PCB contains a bad block. This can be done with the Master Bad Mark. When the Master Bad Mark is 'true', then all blocks will be checked for the existence of a bad mark. Checking bad marks in this way saves machine cycle time and enhances the overall system performance.

1. The Master Bad Mark coordinates are relative to the PCB origin
2. The Master Bad Mark and Bad Mark(s) are read by the same reading equipment and must be of the same logic (see screen 3 and 4)

## SCREEN 3 and 4

Screen 3 and 4  
when Read  
Method is  
CAMERA

Screen 3 and 4  
when Read  
Method is  
BEAM  
SENSOR




Figure 5-6-3

## 4-5-6

## Bad marks

Bad mark lines are defined in the **DATA IN - PCB - [PCB NAME] - BAD MARK** menu. Layout of this screen is dependent on the setting of the parameter **BAD MARK DATUM** in the **DATA IN - SYSTEM - MACHINE CONFIG** menu. The two choices in this menu are:

**Bad Mark Datum = BLOCK ORIGIN**

**Bad Mark Datum = PCB ORIGIN**

Dependent on this choice, the **DATA IN - PCB - BAD MARK** menu have the following layout as is described in the next two sections.

## 4-5-6-1. Bad Mark Datum = BLOCK ORIGIN

Whether one or more blocks exist on a PCB, only one input line exists for defining the bad mark position. This is because the bad mark position is relative to the **BLOCK ORIGIN**. No matter how many blocks exist, if it is defined that the coordinates of a Bad Mark are located a distance **X** and **Y** from the block origin, then these coordinates **X** and **Y** are the same for all blocks. See figure below.

## EXAMPLE ONLY




Figure 5-6-1

For every block the coordinates **X** and **Y** for the bad mark position are the same. This coordinate is entered in the following four screens.

## SCREEN 1 and 2

**Screen 1**

100% PCB NAME : MOUNTER

PCB BAD MARK

| NO. | MARK | POS. XY [MM] |
|-----|------|--------------|
| 0   |      | 0.00         |

XXX : DATA FROM BLK ORG

X=0.00  
F1

Y=0.00  
F2

R=0.00  
F3

F4

F5

F6

PWD

**Screen 2**

| NO. | MASTER MARK | POS. XY [MM] |
|-----|-------------|--------------|
| 0   | 0.00        | 0.00         |

Only 1 line (line 0) available

X and Y coordinates of the Bad Mark

Coordinates are relative to the block origin

Figure 5-6-2

**[Exp. 4] READ METHOD**


This is displayed and can be selected only when the system is equipped with a vision board and the "BEAM SENSOR" selector of the machine configuration data is set to "YES".

**[Exp. 5] MARK DIA**

Input the size of the fiducial marks. For round marks: diameter in [mm] units. For square marks : length of one side in [mm]. Diamond shaped mark length of diagonal line in [mm].

**[Exp. 6] AREA**

Input the range to be scanned with the beam sensor when looking for marks. The XY coordinate value of the mark explained before is the center, while scanning is carried out in the  $\pm$  directions of the input value over the specified range. The mark must always be contained within this range.

**[Exp. 7] LOGIC**

This specifies the dark/light relation between the fiducial mark and the PCB (background). If the mark is a reflective object and the PCB is a non-reflective object, the logic is set to "ON".

If the mark is doughnut-shaped, while the center of the mark being non-reflective and the edge reflective, the logic is set to "OFF".

| Display message | Mark type      | Back-ground    |
|-----------------|----------------|----------------|
| ON              | Reflective     | Non-reflective |
| OFF             | Non-reflective | Reflective     |

**[Exp. 8] SCAN TYPE**

This sets the method by which fiducial marks are read with the beam sensor.

| Display message | Reading Sequence                  | Mark                 |
|-----------------|-----------------------------------|----------------------|
| XY              | X $\rightarrow$ Y                 | Round, Diamond-shape |
| XYX             | X $\rightarrow$ Y $\rightarrow$ X | Square               |

**[Exp. 9] VISION FILE NO.**

This is set when a vision camera is used to read fiducial marks. Input the vision file number set in the vision data relating to marks. (See the section on vision files.)

## A) Reading with a camera

| NO. | READ METHOD | ← Exp. 4 |
|-----|-------------|----------|
| 0   | CAMERA      |          |
| 1   |             |          |
| 2   |             |          |
| 3   |             |          |
| 4   |             |          |
| 5   |             |          |
| 6   |             |          |
| 7   |             |          |

Use the → key to go from screen f5-5-1 to screen f5-5-2.

f5-5-2

| NO. | VISION FILE NO. | ← Exp. 9 |
|-----|-----------------|----------|
| 0   | 0               |          |
| 1   |                 |          |
| 2   |                 |          |
| 3   |                 |          |
| 4   |                 |          |
| 5   |                 |          |
| 6   |                 |          |
| 7   |                 |          |

Use the → key to go from screen f5-5-2 to screen f5-5-3.

f5-5-2

## B) Reading with a beam sensor

| NO. | READ METHOD | ← Exp. 4 |
|-----|-------------|----------|
| 0   | BEAM SENSOR |          |
| 1   |             |          |
| 2   |             |          |
| 3   |             |          |
| 4   |             |          |
| 5   |             |          |
| 6   |             |          |
| 7   |             |          |

Use the → key to go from screen f5-5-1 to screen f5-5-4.

f5-5-4

| NO. | MARK.DIA | AREA   | LOGIC  | SCAN TYPE |
|-----|----------|--------|--------|-----------|
| 0   | 1.60     | 5.00   | OFF    | XY        |
| 1   | ↑        | ↑      | ↑      | ↑         |
| 2   | Exp. 5   | Exp. 6 | Exp. 7 | Exp. 8    |
| 3   |          |        |        |           |
| 4   |          |        |        |           |
| 5   |          |        |        |           |
| 6   |          |        |        |           |
| 7   |          |        |        |           |

Use the → key to go from screen f5-5-4 to screen f5-5-5.

f5-5-5

## [Exp. 5] SKIP ?

"Skip?" is set as shown below.

| Display message | Mounting of relevant no. |
|-----------------|--------------------------|
| NO              | Mount                    |
| YES             | Do not mount             |

## [Exp. 6] FIDU.

There are times when a special fiducial mark is set for a mounting point. This mark, as explained previously, is specified for fiducial point nos. 1 to 7. The "FIDU" item is used to specify whether or not these marks will be used and compensation carried out. If the marks are not to be used, set "Not used", while if they are to be used, specify the fiducial point number to be used.

|                                   |        |        |                   |        |          |
|-----------------------------------|--------|--------|-------------------|--------|----------|
| DATA IN                           |        | 100%   | PCB NAME: MOUNTER |        |          |
| PCB MOUNT                         |        |        | 2                 |        |          |
| ←                                 |        |        |                   |        |          |
| NO.                               | PART   | HEAD   | NZZL              | SKIP?  | FIDU     |
| 0                                 | 1      | 1      |                   | NO     | NOT USED |
| 1                                 | 2      | 1      |                   | NO     | NOT USED |
| 2                                 | 6      | 2      |                   | YES    | NOT USED |
| 3                                 | 55     | 3      | 1                 | NO     | USED     |
| 4                                 | ^      | ^      | ^                 | ^      | ^        |
| 5                                 | Exp.2  | Exp.3  | Exp.4             | Exp.5  | Exp.6    |
| 6                                 |        |        |                   |        |          |
| 7                                 |        |        |                   |        |          |
| 8                                 |        |        |                   |        |          |
| TEACH UNIT XXX: DATA FROM BLK ORG |        |        |                   |        |          |
| X:0.00                            |        | Y:0.00 |                   | R:0.00 |          |
| F1                                | F2     | F3     | F4                | F5     | F6       |
| m-conv.                           | m-stp. | locate |                   |        | fwd      |

f5-7-2

Use the → key to go from screen f5-7-1 to screen f5-7-2.

4-5-7  
Mount

The information for the items indicated below, for each mounting point on the PCB, is stored here.

Indicates previous pages

Indicates page number

Indicates more pages to follow.

To go to screen f5-7-1 from the main menu, press "MAIN MENU" key. → 3 key → 1 key → F6 key → 4 key.

**Remark:**  
No empty lines between mount lines are allowed in the program.

f5-7-1

```

DATA IN 100% PCB NAME : MOUNTER
PCB MOUNT 2
NO. X [MM] Y [MM] R [DEG]
0
1
2
3
4
5
6
7
8
9
          ↑
          Exp. 1

TEACH UNIT XXX :DATA FROM BLK ORG
X=0.00 Y=0.00 R=0.00
F1 F2 F3 F4 F5 F6
M-CONV M-RTP LOCATE FWD
  
```

## [Exp. 1] R

This item sets how many times parts will be rotated when being mounted on the PCB, depending on the orientation of the part as it is supplied from the feeder. Seen from above, **counter-clockwise rotation is the + direction.**

Other necessary items may be displayed, depending on the system machine configuration settings and optional equipment conditions. Fill in these items as required. Fig. 4-9 shows the flow of the specifications screens.

For Exp. 2 until 6 see f5-7-2.

## [Exp. 2] PART

Input the registration number used for parts registration (par. 4-6-1). A value between 1-120 can be specified.

## [Exp. 3] HEAD

Input the head number used when mounting parts. The value may be between 1 and 3.

## [Exp. 4] NOZZLE

This item is displayed if the "Nozzle Station" item of the system machine configuration data is set to "YES". Also, it is not displayed and cannot be input unless the head number is set to "AANC" or "SANC". Input the nozzle number to be used when mounting parts.



Entering Bad Mark data relative to the PCB Origin is done via two screens. These screens are the following:-

SCREEN 1

| DATA IN                                |         |         | 100%    | PCB NAME : ERIC |     |
|--|---------|---------|---------|-----------------|-----|
| PCB BAD MARK                           |         |         |         |                 |     |
| NO.                                    | X [mm]  | Y [mm]  |         |                 |     |
| 0                                      | -200.00 | 10.00   |         |                 |     |
| 1                                      | -195.00 | 10.00   |         |                 |     |
| 2                                      | -190.00 | 10.00   |         |                 |     |
| 3                                      | -185.00 | 10.00   |         |                 |     |
| 4                                      | -180.00 | 10.00   |         |                 |     |
| 5                                      |         |         |         |                 |     |
| 6                                      |         |         |         |                 |     |
| 7                                      |         |         |         |                 |     |
| 8                                      |         |         |         |                 |     |
| 9                                      |         |         |         |                 |     |
| TEACH UNIT : CAMERA: DATA FROM PCB ORG |         |         |         |                 |     |
| X= 0.00                                |         | Y= 0.00 | Z= 0.00 | R= 0.00         |     |
| F1                                     | F2      | F3      | F4      | F5              | F6  |
| MOONV                                  | STOP    | LOCATE  |         | BACK            | FWD |

SCREEN 2

| DATA IN                                |             |         | 100%            | PCB NAME : ERIC |     |
|--|-------------|---------|-----------------|-----------------|-----|
| PCB BAD MARK                           |             |         |                 |                 |     |
| NO.                                    | READING     | LOGIC   | VISION FILE NO. |                 |     |
| 0                                      | CAMERA      |         | 10              |                 |     |
| 1                                      | BEAM SENSOR |         |                 |                 |     |
| 2                                      | BEAM SENSOR |         |                 |                 |     |
| 3                                      | BEAM SENSOR |         |                 |                 |     |
| 4                                      | BEAM SENSOR |         |                 |                 |     |
| 5                                      |             |         |                 |                 |     |
| 6                                      |             |         |                 |                 |     |
| 7                                      |             |         |                 |                 |     |
| 8                                      |             |         |                 |                 |     |
| 9                                      |             |         |                 |                 |     |
| TEACH UNIT : CAMERA: DATA FROM PCB ORG |             |         |                 |                 |     |
| X= 0.00                                |             | Y= 0.00 | Z= 0.00         | R= 0.00         |     |
| F1                                     | F2          | F3      | F4              | F5              | F6  |
| MOONV                                  | STOP        | LOCATE  |                 | BACK            | FWD |

SCREEN 1

Since all bad marks are related to one point (the PCB origin), all positions must be taught. The lines contain the following information:

- Line 0 : This line is **ALWAYS** reserved, whether it is used or not, for the **Master Bad Mark**. This line is being processed when, in the RUNNING menu, the option BAD MARK CHECK is set to MASTER MARK. This line, even if Master Bad Marks are not used, must **always** contain valid values.
- Line 1 to 'n' : These lines contain the X and Y position data of the Bad Marks of Block 1 to Block 'n'. All values can be taught and the coordinates shown are relative to the PCB origin.

SCREEN 2

For each line (see screen 1) this screen determines the reading equipment, the logic in case the beam sensor is used and the vision file number in case the camera is used.

| READING   | LOGIC    | VISION FILE No.               | REMARKS  |
|-----------|----------|-------------------------------|--|
| CAMERA    | not used | Any valid vision file number. | Valid is, generally, any value between 1 and 29.   |
| BEAM SENS | ON       | not used                      | Area is more reflective than surrounding area. On the screen BEAM SENS ON is shown as BEAM SENSOR.                     |
| BEAM SENS | OFF      | not used                      | Area is less reflective than surrounding area or not reflective. On the screen BEAM SENS OFF is shown as BEAM SENSOFF. |

**SCREEN 3**

During run mode this screen determines, when used, by what equipment the master bad mark and bad marks are read. Choices are:

|             |   |   |
|-------------|---|---|
| Camera      | : | The moving camera. A vision file must be present          |
| Beam Sensor | : | Logic must be determined to be, or not to be, reflective. |

**SCREEN 4**

Screen 4 determines the type of bad mark. If, in screen, 3 the reading equipment is CAMERA, then screen 4 contains a number of a vision file which contains the description of the master bad mark and bad marks (for both cases: Only when used).  
If, in screen 3, the reading equipment is set to BEAM SENSOR, then screen 4 describes the bad mark logic (the 'true' condition of the bad mark(s))

|       |   |     |   |  |
|-------|---|-----|---|--|
| LOGIC | = | ON  | : | Bad mark(s) are more reflective than surrounding area.                                   |
| LOGIC | = | OFF | : | Bad mark(s) are less reflective than surrounding area or bad mark(s) are not reflective. |

**4-5-6-2. BAD MARK DATUM = PCB ORIGIN**

If use is made of bad marks and Bad Mark Datum was set to Block Origin, the head must travel to each block (see section 4-5-6-1) to find out if a bad mark is present or not. This travel distance can be made much shorter by creating bad marks that are relative to the PCB origin. Of course the bad marks can now be placed anywhere on the PCB, but to keep the travel distance of the head as short as possible it is recommended to set the locations of the bad marks as close as possible together. When use is made of a Master Bad Mark, then it is recommended to have this Mark near the group of Bad Marks. See figure below:

EXAMPLE ONLY

Figure 5-6-4

