

← USB A-B cable
to USB port
on host computer

Acroname
USB-to-serial
connector

serial
extension
cable

PXA-AVR UART
jumper
(not provided &
not needed)

5V power adapter to
power outlet

Micro-SD card

verdex-pro + robostix

Bluetooth antenna

